

Changes for the Better



MITSUBISHI CNC

700/70 Series

HANDBOOK



Contents

I Alarms

1. Operation Alarms (M)	I - 1
2. Stop Codes (T)	I - 8
3. Servo/Spindle Alarms	I - 12
3.1 Servo alarm (S01/S03/S04)	I - 12
3.2 Initial parameter error (S02)	I - 27
3.3 Parameter error (S51)	I - 27
3.4 Servo warning (S52)	I - 28
4. MCP Alarm (Y)	I - 30
5. System Alarms (Z)	I - 37
6. Absolute Position Detection System Alarms (Z7*)	I - 40
7. Distance-coded Reference Scale Errors (Z8*)	I - 42
8. Messages during Emergency Stop (EMG)	I - 43
9. Auxiliary Axis Alarms	I - 45
9.1 Aux ax servo alarm/warning (S)	I - 45
9.2 Aux ax abs position error (Z)	I - 48
9.3 Aux ax operation error (M)	I - 49
9.4 Auxiliary axis MCP alarms (Y)	I - 50
10. Computer Link Errors (L)	I - 51
11. User PLC Alarms (U)	I - 52
12. Network Service Errors (N)	I - 54
13. Program Errors (P)	I - 55

II Parameters

1. User Parameters	II - 1
2. Base Specifications Parameters	II - 39
3. Axis Specifications Parameters	II - 82
4. Servo Parameters	II - 99
5. Spindle Parameters	II - 114
6. Rotary Axis Configuration Parameters	II - 148
7. Machine Error Compensation	II - 153
8. PLC Constants	II - 154
9. Macro List	II - 155
10. Position Switch	II - 162
11. Auxiliary Axis Parameter	II - 172
12. Open Parameter	II - 185
13. CC-Link Parameter	II - 186
14. Anshin-net Parameter 2 / MTB-net Parameter 2	II - 194
15. PLC Axis Parameters	II - 202

III PLC Devices

1. Bit Type Input Signals (CNC->PLC).....	III - 1
2. Data Type Input Signals (CNC->PLC)	III - 20
3. Bit Type Output Signals (PLC->CNC).....	III - 38
4. Data Type Output Signals (PLC->CNC)	III - 63
5. Each Application : Pallet Program Registration	III - 72
6. Each Application : PLC Axis Indexing.....	III - 73
7. Each Application : Tool Life Management Interface.....	III - 74
8. Special Relays	III - 77

I Alarms

1. Operation Alarms (M)

M01 Dog overrun 0001

Details When returning to the reference position, the near-point detection limit switch did not stop over the dog, but overran the dog.

Remedy

- Increase the length of the near-point dog.
- Reduce the reference position return speed.

M01 Some ax does not pass Z phase 0002

Details One of the axes did not pass the Z-phase during the initial reference position return after the power was turned ON.

Remedy

- Move the detector one rotation or more in the opposite direction of the reference position, and repeat reference position return.

M01 R-pnt direction illegal 0003

Details When manually returning to the reference position, the return direction differs from the axis movement direction selected with the AXIS SELECTION key.

Remedy

- The selection of the AXIS SELECTION key's +/- direction is incorrect. The error is canceled by feeding the axis in the correct direction.

M01 External interlock axis exists 0004

Details The external interlock function has activated (the input signal is "OFF") and one of the axes has entered the interlock state.

Remedy

- As the interlock function has activated, release it before resuming operation.
- Correct the sequence on the machine side.
- Check for any broken wires in the "interlock" signal line.

M01 Internal interlock axis exists 0005

Details The internal interlock state has been entered.
The absolute position detector axis has been removed.
A command for the manual/automatic simultaneous valid axis was issued from the automatic mode.
The manual speed command was issued while the "tool length measurement 1" signal is ON.

Remedy

- The servo OFF function is valid, so release it first.
- An axis that can be removed has been issued, so perform the correct operations.
- The command is issued in the same direction as the direction where manual skip turned ON, so perform the correct operations.
- During the manual/automatic simultaneous mode, the axis commanded in the automatic mode became the manual operation axis. Turn OFF the "manual/automatic valid" signal for the commanded axis.
- Turn ON the power again, and perform absolute position initialization.
- Turn OFF the "tool length measurement 1" signal to start the program by the manual speed command.

M01 H/W stroke end axis exists 0006

Details The stroke end function has activated (the input signal is "OFF") and one of the axes is in the stroke end status.

Remedy

- Move the machine manually.
- Check for any broken wires in the "stroke end" signal line.
- Check for any limit switch failure.

M01 S/W stroke end axis exists 0007

Details The stored stroke limit I, II, IIB or IB function has activated.

Remedy

- Move the machine manually.
- Correct any setting error of the parameters for the stored stroke limit.

M01 Chuck/tailstock stroke end ax 0008

Details The chuck/tail-stock barrier function turned ON, and an axis entered the stroke end state.

Remedy

- Reset the alarm with reset, and move the machine in the reverse direction.

M01 Ref point return No. invalid 0009

Details 2nd reference position return was performed before 1st reference position return has been completed.

Remedy

- Execute 1st reference position return.

M01 Sensor signal illegal ON 0019

Details The sensor signal was already ON when the "tool length measurement 1" signal was validated.
The sensor signal turned ON when there was no axis movement after the "tool length measurement 1" signal was validated.
The sensor signal turned ON at a position within 100?m from the final entry start position.

Remedy

- Disable the "tool length measurement 1" signal and move the axis in a safe direction.
- Disabling the sensor signal also clears the operation alarm.

(Note) When the "tool length measurement 1" signal is disabled, the axis can be moved in either direction. Pay attention to the movement direction.

M01 Ref point retract invalid 0020

Details Reference position retract was performed while the coordinates had not been established.

Remedy

- Execute reference position return.

I Alarms

1. Operation Alarms (M)

M01 Tool ofs invld after R-pnt 0021

Details Reference position return had been performed during the tool escape and return, which invalidated the tool compensation amount after the reference position return.

Remedy

- The error is cleared if the operation mode is changed to other than reference position return before the axis performs reference position return.
- The error is cleared when the tool return is completed.
- The error is cleared if reset 1 is input or the emergency stop button is pushed.

M01 R-pnt ret invld at abs pos alm 0024

Details A reference position return signal was enabled during an absolute position detection alarm.

Remedy

- Reset the absolute position detection alarm, and then perform the reference position return.

M01 R-pnt ret invld at zero pt ini 0025

Details A reference position return signal was input during zero point initialization of the absolute position detection system.

Remedy

- Complete the zero point initialization, and then perform reference position return.

M01 Now skip on 0030

Details The "skip input" signal remains enabled when the operation has shifted from skip retract to measurement.

Remedy

- Increase the skip retract amount.

M01 No skip 0031

Details Even though the 1st skip was to the correct position, the 2nd skip could not be found.

Remedy

- Check whether the measurement target has moved.

M01 Operation error 0035

Details Movement prohibited during tool retract
An axis movement was attempted from the tool retract position.
The movement was attempted by a manual command in the tool return.

Remedy It is not allowed to move an axis arbitrarily from the tool retract position. Take the following steps to move the axis.

- Cancel the program execution by reset.
- Use the tool escape and retract function and let the axis escape from the tool retract position.

The interruption by a manual command is not allowed in a tool return. Take the following step to move the axis.

- Cancel the program execution by reset.

M01 Chopping axis R-pnt incomplete 0050

Details Chopping mode has been entered while the chopping axis has not completed reference position return.
All axes interlock has been applied.

Remedy

- Reset the NC or disable the "chopping" signal, and then carry out the reference position return.

M01 Synchronous error excessive 0051

Details The synchronization error of the master and slave axes exceeded the allowable value under synchronous control.
A deviation exceeding the synchronization error limit value was found with the synchronization deviation detection.

Remedy

- Select the correction mode and move one of the axes in the direction in which the errors are reduced.
- Set a larger value or "0" for "#2024 synerr (Allowable error)" to disable the error check.
- When using simple C-axis synchronous control, set "0" for "synchronous control operation method".

M01 No spindle select signal 0053

Details Synchronous tapping command was issued when the "spindle selection" signals for all spindles were OFF in the multiple-spindle control II.

Remedy

- Turn ON the "spindle selection" signal for the tapping spindle before performing the synchronous tapping command.

M01 No spindle serial connection 0054

Details Synchronous tapping command was issued in the multiple-spindle control II, while the spindle with the "spindle selection" signal ON was not serially connected.

Remedy

- Make sure the "spindle selection" signal for the spindle is ON.
- Consider the machine construction when issuing the command.

M01 Spindle fwd/rvs run para err 0055

Details Asynchronous tapping command was issued when M code of the spindle forward/reverse run command, set by "#3028 sprcmm", was one of the followings in the multiple-spindle control II.

- M0, M1, M2, M30, M98, M99, or M198
- M code No. that commands to enable/disable the "macro interrupt" signal

Remedy

- Correct the "#3028 sprcmm (Tap cycle spindle forward run/reverse run M command)" setting.

I Alarms

1. Operation Alarms (M)

M01 Tap pitch/thread number error 0056

Details The command for the pitch or the number of threads is not correct in the synchronous tapping command of the multiple-spindle control II.
The pitch is too small for the spindle rotation speed.
Thread number is too large for the spindle rotation speed.

Remedy - Correct the pitch, number of threads or rotation speed of the tapping spindle.

M01 Handle ratio too large 0060

Details Handle ratio is too large for the rapid traverse rate (or external deceleration speed when external deceleration is valid).

Remedy - Set a smaller ratio.

M01 R-pos offset value illegal 0065

Details At the start of reference position initial setting, "#2034 rfpofs (Distance-coded reference position detection offset) is not set to "0".

Remedy - Set "#2034 rfpofs" to "0", then turn the power ON again to perform the reference position initial setting.

M01 R-pos scan distance exceeded 0066

Details Reference position could not be established within the maximum scan distance.

Remedy - Check the scale to see if it has dirt or damage.
- Check if the servo drive unit supports this function.

M01 No operation mode 0101

Details

Remedy - Check for any broken wires in the input mode signal line.
- Check for any failure of the MODE SELECT switch.
- Correct the sequence program.

M01 Cutting override zero 0102

Details The "cutting feed override" switch on the machine operation panel is set to "0".
The override was set to "0" during a single block stop.

Remedy - Set the "cutting feed override" switch to a value other than "0" to clear the error.
- If the "cutting feed override" switch has been set to a value other than "0", check for any short circuit in the signal line.
- Correct the sequence program.

M01 External feed rate zero 0103

Details MANUAL FEEDRATE switch on the machine operation panel is set to "0" when the machine is in the JOG or automatic dry run mode.
"Manual feedrate B" is set to "0" during the JOG mode when manual feedrate B is valid.
"Each axis manual feedrate B" is set to "0" during the JOG mode when each axis manual feedrate B is valid.

Remedy - Set the MANUAL FEEDRATE switch to a value other than "0" to release the error.
- If the MANUAL FEEDRATE switch has been set to a value other than "0" check for any short circuit in the signal line.
- Correct the sequence program.

M01 F 1-digit feed rate zero 0104

Details The F1-digit feedrate has been set to "0" when the F1-digit feed command was executed.

Remedy - Set the F1-digit feedrate (from "#1185 spd_F1 (F1 digit feedrate F1)" to "#1189 spd_F5 (F1 digit feedrate F5)").

M01 Spindle stop 0105

Details Spindle is being stopped when the synchronous feed command is issued.

Remedy - Rotate the spindle.
- If the workpiece is not being cut, start dry run.
- Check for any broken spindle encoder cable.
- Check the connections for the spindle encoder connectors.
- Check the spindle encoder pulse.
- Correct the program (commands and addresses).

M01 Handle feed ax No. illegal 0106

Details The axis, designated at handle feed, is out of specifications.
No axis has been selected for handle feed.

Remedy - Check for any broken wires in the handle feed axis selection signal line.
- Correct the sequence program.
- Check the number of axes in the specifications.

M01 Spindle rotation speed over 0107

Details Spindle rotation speed exceeded the axis clamp speed during the thread cutting command.

Remedy - Lower the commanded rotation speed.

M01 Fixed pnt mode feed ax illegal 0108

Details The axis, designated in the manual arbitrary feed, is out of specifications.
The feedrate in manual arbitrary feed mode is illegal.

Remedy - Check for any broken wires in the axis selection signal line or the feedrate line for the manual arbitrary feed mode.
- Check the specifications for the manual arbitrary feed mode.

I Alarms

1. Operation Alarms (M)

M01 Block start interlock 0109

Details An interlock signal has been input to lock the block start.

Remedy - Correct the sequence program.

M01 Cutting block start interlock 0110

Details An interlock signal has been input to lock the cutting block start.

Remedy - Correct the sequence program.

M01 Restart switch ON 0111

Details Restart switch has been turned ON and manual mode has been selected before the restart search is completed.

Remedy - Search the block to restart.
- Turn the restart switch OFF.

M01 Program check mode 0112

Details The automatic start button was pressed during program check or in program check mode.

Remedy - Press the reset button to cancel the program check mode.

M01 Auto start in buffer correct 0113

Details The automatic start button was pressed during buffer correction.

Remedy - Press the automatic start button after the buffer correction is completed.

M01 In reset process 0115

Details The automatic start button was pressed during resetting or tape rewinding.

Remedy - When rewinding the tape, wait for the winding to end, or press the reset button to stop the winding, and then press the automatic start button.
- During resetting, wait for the resetting to end, and then press the automatic start button.

M01 Playback not possible 0117

Details The playback switch was turned ON during editing.

Remedy - Cancel the editing by pressing the input or previous screen key before turning ON the playback switch.

M01 Turn stop in normal line cntrl 0118

Details The turning angle at the block joint exceeded the limit during normal line control.

In normal line control type I:

"#1523 C_feed (Normal line control axis turning speed)" has not been set.

In normal line control type II:

When turning in the inside of the arc, the set value for "#8041 C-rot. R" is larger than the arc radius.

Remedy - Correct the program.
- Correct the "#1523 C_feed (Normal line control axis turning speed)" setting.
- Correct the "#8041 C rot. R" setting.

M01 Reverse run impossible 0119

Details Either of the following conditions occurred:

- there is no block to run backward.
- eight blocks has been continued without any travel command.

Remedy - Execute forward run to clear the alarm.
- Reset to clear the alarm.

M01 In synchronous correction mode 0120

Details The synchronous correction mode switch was pressed in non-handle mode.

Remedy - Select the handle or manual arbitrary feed mode.
- Turn OFF the correction mode switch.

M01 No synchronous control option 0121

Details The synchronous control operation method was set (with R2589) while no synchronous control option was provided.

Remedy - Set "0" for "synchronous control operation method".

M01 Computer link B not possible 0123

Details Cycle start was attempted before resetting was completed.
Computer link B operation was attempted at the 2nd or further part system in a multi-part system.

Remedy - Perform the cycle start after resetting has been completed.
- Set "#8109 HOST LINK" to "0" and then set to "1" before performing the cycle start.
- Computer link B operation cannot be performed at the 2nd or further part system in a multi-part system.

M01 X/Z axes simultaneous prohibit 0124

Details The basic axis corresponding to the inclined axis was started simultaneously in the manual mode while the inclined axis control was valid.

Remedy - Turn the inclined axis and basic axis start OFF for both axes. (This is also applied for manual/automatic simultaneous start.)
- Disable the basic axis compensation, or command it to axes one by one.

I Alarms

1. Operation Alarms (M)

M01 Rapid override zero 0125

Details The RAPID TRAVERSE OVERRIDE switch on the machine operation panel is set to "0".

Remedy

- Set the RAPID TRAVERSE OVERRIDE switch to a value other than "0" to clear the error.
- If the RAPID TRAVERSE OVERRIDE switch has been set to a value other than "0", check for any short circuit in the signal line.
- Correct the sequence program.

M01 Program restart machine lock 0126

Details Machine lock was applied on the return axis being manually returned to the restart position.

Remedy - Cancel the machine lock and resume the operation.

M01 Rot axis parameter error 0127

Details Orthogonal coordinate axis name does not exist.

Rotary axis name does not exist.

A duplicate name is used for the designated orthogonal coordinate axis.

The number of axes that were selected to change tool length compensation along the tool axis amount exceeds the maximum number of axes.

The designated orthogonal coordinate axis name is the same as the rotary axis name.

Remedy - Correct the rotary axis configuration parameters.

M01 Restart pos return incomplete 0128

Details Automatic return was performed with an axis whose return to the restart position was not complete.

Remedy

- Perform restart position return manually.
- Enable "#1302 AutoRP (Automatic return by program restart)" before executing the automatic start.

M01 Chopping override zero 0150

Details The override became "0" in the chopping operation.

Remedy

- Correct the setting of "chopping override" (R2503).
- Correct the setting of "rapid traverse override" (R2502).

M01 Command axis chopping axis 0151

Details A chopping axis movement command was issued from the program during the chopping mode. (This alarm will not occur for the command with the movement amount "0".)
(All axes interlock state will be applied.)

Remedy - Press the reset button or turn OFF the "chopping" signal. When the "chopping" signal is turned OFF, the axis returns to the reference position and performs the movement command in the program.

M01 Bottom dead center pos. zero 0153

Details The bottom dead center position is set to the same position as the upper dead center position.

Remedy - Correct the bottom dead center position.

M01 Chopping disable for handle ax 0154

Details Chopping has been attempted while the chopping axis is selected as the handle axis.

Remedy - Select an axis other than the chopping axis as the handle axis, or start chopping after changing the mode to the other mode.

M01 No speed set out of soft limit 0160

Details The axis, without any maximum speed outside of the soft limit range set, was returned from the outside of the soft limit range.

Remedy

- Correct the "#2021 out_f (Maximum speed outside soft limit range)" setting.
- Correct the soft limit range (with "#2013 OT- (Soft limit I-)" and "#2014 OT+ (Soft limit I+)").

M01 Aux axis changeover error 0166

Details One of the following attempts was made on an axis that can be switched to NC/auxiliary axis.

- A command was issued to an auxiliary axis from machining program.

- When there were more than one NC axis having a same name, a command was issued to those axes from machining program.

- "NC axis control selection" signal was turned OFF while the NC axis was in motion.

- "NC axis control selection" signal was turned ON while the auxiliary axis was in motion.

Remedy

- Turn ON the "NC axis control selection" signal to set the auxiliary axis to NC axis when issuing a command to the axis from machining program.
- When more than one axis have a same name, let only one of the axes work as an NC axis.
- Do not change the "NC axis control selection" signal while the axis is in motion.

M01 Ill. op during T tip control 0170

Details Illegal operation was attempted during tool tip center control.

Remedy - Change the operation mode to the previous one and restart.

M01 G114.n command illegal 1005

Details G114.n has been commanded during the execution of G114.n.
G51.2 has been commanded when G51.2 spindle-spindle polygon machining mode has been already entered at another part system.

Remedy

- Command G113 to cancel the operation.
- Turn ON the "spindle synchronization cancel" signal to cancel the operation.
- Command G50.2 to cancel the operation.
- Turn ON the "spindle-spindle polygon cancel" signal to cancel the operation.

I Alarms

1. Operation Alarms (M)

M01 Spindle in-use by synchro tap 1007

Details The spindle is being used in synchronized tapping.

Remedy - Cancel the synchronized tapping.

M01 SP-C ax ctrl runs independntly 1026

Details C axis mode command has been issued for polygon machining spindle.
C axis mode command has been issued for synchronized tapping spindle.
Polygon command has been issued for synchronized tapping spindle.
Spindle is being used as spindle/C axis.

Remedy - Cancel the C axis command.
- Cancel the polygon machining command.
- Cancel the C axis with servo OFF.

M01 Synchronization mismatch 1030

Details Different M codes were each commanded as synchronization M code in each of the two part systems.
Synchronization with the "I" code was commanded in another part system during M code synchronization.
Synchronization with the M code was commanded in another part system during synchronization with the "I" code.

Remedy - Correct the program so that the M codes match.
- Correct the program so that the same synchronization codes are commanded.

M01 Multiple C axes select invalid 1031

Details The "C axis selection" signal has been changed when the multiple C axes selection is not available.
The selected axis by the "C axis selection" signal cannot be controlled for the multiple C axes selection.

Remedy - Correct the parameter settings and program.

M01 Tap retract Sp select illegal 1032

Details Tap retract has been executed with a different spindle selected. Cutting feed is in wait state until synchronization is completed.

Remedy - Select the spindle for which tap cycle was halted before turning ON the "tap retract" signal.

M01 Sp-Sp polygon cut interlock 1033

Details Cutting feed is in wait state until synchronization is completed.

Remedy - Wait for the synchronization to end.

M01 Mixed sync ctrl prmtr illegal 1034

Details Mixed synchronization control with exceeding number of control axes was attempted.
Mixed synchronization control with duplicate axis address was attempted.

Remedy - Correct the parameter settings for mixed synchronization control.

M01 Mixed sync ctrl disable modal 1035

Details Mixed synchronization control was commanded for a part system in which the mixed synchronization control is disabled as shown below.

- During nose R compensation mode
- During pole coordinate interpolation mode
- During cylindrical interpolation mode
- During balance cut mode
- During fixed cycle machining mode
- During facing turret mirror image

Remedy - Correct the program.

M01 Synchro ctrl setting disable 1036

Details "Synchronous control operation method" was set (with R2589) when the mode was not the C axis mode.

"Synchronous control operation method" was set (with R2589) in the zero point not set state.
Mirror image is disabled.
External mirror image or parameter mirror image was commanded during facing turret mirror image.

Remedy - Set the contents of the R2589 register to "0".
- Correct the program and parameters.

M01 Synchro start/cancel disable 1037

Details Synchronous control start/cancel command was issued when the start/cancel is disabled.

Remedy - Correct the program and parameters.

M01 Move cmnd invld to synchro ax 1038

Details A travel command was issued to a synchronous axis in synchronous control.

Remedy - Correct the program.

M01 Sp synchro phase calc illegal 1106

Details Spindle synchronization phase alignment command was issued while the "phase shift calculation request" signal was ON.

Remedy - Correct the program.
- Correct the sequence program.

I Alarms

1. Operation Alarms (M)

M80 POSITION ERROR

Details An axis position is illegal. An alarm is displayed (AL4 is output) and a block stop is applied on the machining program. When the block stop is not allowed in the thread cutting cycle and the like, the stop is applied at the next position where allowed.

Remedy Carry out reset. Then confirm that the system starts the operation. If the alarm is displayed again, turn ON the emergency stop switch and turn the NC power OFF and ON.

M90 Parameter set mode

Details The lock for setup parameters has been released. Setting the setup parameters is enabled while automatic start is disabled.

Remedy Refer to the manual issued by the machine tool builder.

M91 INVALID MEASUR. 0002

Details Data is over the range
The measurement result exceeds the tool data setting range.

Remedy Correct the settings of "#2015 tml- (Negative direction sensor of tool setter)" and "#2016 tml+ (Positive direction sensor of tool setter or TLM standard length)".

M91 INVALID MEASUR. 0003

Details No corresponding No.
No measurement tool No. has been set.
The registered No. is out of the specifications.

Remedy Correct the measurement tool No.

M91 INVALID MEASUR. 0045

Details Measurement axis illegal
Sensor has been turned ON while two or more axes are moving.

Remedy Move a single axis when the sensor is contacted.

M91 INVALID MEASUR. 0046

Details Measurement axis has not returned to reference position
Reference position return has not been executed on a measurement axis in an incremental system.

Remedy Carry out the reference position return on the measurement axis before measuring the tool.

M91 INVALID MEASUR. 0089

Details Sensor signal illegal ON
Sensor has already been ON when TLM mode is turned ON. The travel amount was so small that the tool contacted the sensor.

Remedy All axes are interlocked when this alarm has occurred. Turn the TLM mode OFF or use the interlock cancel signal to move the tool off the sensor. Ensure at least 0.1mm for the movement to the sensor.

M91 INVALID MEASUR. 9000

Details Speed at contact is below minimum
The tool has contacted the sensor at the lower speed than set in "#1508 TLM_Fmin (Minimum speed toward tool setter)".

Remedy Correct the feed rate to move the tool to the sensor.

M91 INVALID MEASUR. 9001

Details Speed at contact is over maximum
The tool has contacted the sensor at the higher speed than set in "#1509 TLM_Fmax (Maximum speed toward tool setter)".

Remedy Correct the feed rate to move the tool to the sensor.

M91 INVALID MEASUR. 9002

Details Change of compensation No. or sub-side selection during measurement
A compensation No. or sub-side valid signal state has been changed while a sensor signal is ON or a compensation amount is being written.

Remedy Carry out the measurement again.

M91 INVALID MEASUR. 9003

Details Error on response timing of sensor signal
A compensation No. has been changed at the same time as a sensor's response.

Remedy Carry out the measurement again.

M92 IGNORE INT.LOCK

Details Manual tool length measurement Interlock temporarily canceled
"M01 Operation error 0005" and "M01 Operation error 0019", which occur at manual tool length measurement, are temporarily canceled. When a tool has contacted a sensor and "M01 Operation error 0019" has occurred, tool escape is enabled by temporarily turning ON the interlock cancel request. This alarm notifies that the interlock is disabled in the meantime.

Remedy After carrying out the tool escape from the sensor, turn OFF the interlock temporary cancel signal for manual tool length measurement.

2. Stop Codes (T)

T01 Axis in motion 0101

Details Automatic start is not possible as one of the axes is moving.

Remedy - Try automatic start again after all axes have stopped.

T01 NC not ready 0102

Details Automatic start is not possible as the NC is not ready.

Remedy - Another alarm has occurred. Check the details and remedy.

T01 Reset signal ON 0103

Details Automatic start is not possible as the "reset" signal has been input.

Remedy

- Turn OFF the "reset" signal.
- Check for any failure of the reset switch which has caused the switch's continuous ON.
- Correct the sequence program.

T01 Auto operation pause signal ON 0104

Details The feed hold switch on the machine operation panel is ON (valid).

Remedy

- Correct the feed hold switch setting.
- The feed hold switch is B contact switch.
- Fix any broken wires in the feed hold signal line.
- Correct the sequence program.

T01 H/W stroke end axis exists 0105

Details Automatic start is not possible as one of the axes is at the stroke end.

Remedy

- Manually move any axis whose end is at the stroke end.
- Check for any broken wires in the stroke end signal line.
- Check for any failure in the stroke end limit switch.

T01 S/W stroke end axis exists 0106

Details Automatic start is not possible as one of the axes is at the stored stroke limit.

Remedy

- Move the axis manually.
- If the axis's end is not at the stroke end, check the parameters.

T01 No operation mode 0107

Details The operation mode has not been selected.

Remedy

- Select automatic operation mode.
- Check for any broken wires in the signal line for automatic operation mode (memory, tape, MDI).

T01 Operation mode duplicated 0108

Details Two or more automatic operation modes have been selected.

Remedy

- Check for any short circuit in the mode (memory, tape, MDI) selection signal line.
- Check for any failure in the switch.
- Correct the sequence program.

T01 Operation mode changed 0109

Details The automatic operation mode has changed to another automatic operation mode.

Remedy - Return to the original automatic operation mode, and execute automatic start.

T01 Tape search execution 0110

Details Automatic start is not possible as tape search is being executed.

Remedy - Wait for the tape search to be completed and then execute the automatic start.

T01 Restart pos. return incomplete 0112

Details Automatic start is not possible as the axis has not been returned to the restart position.

Remedy

- Manually return the axis to the restart position.
- Turn ON the automatic restart valid parameter, and then execute the automatic start.

T01 CNC overheat 0113

Details Automatic start is not possible because a thermal alarm (Z53 CNC overheat) has occurred.

Remedy

- Temperature of the control unit has exceeded the specified temperature.
- Take appropriate measures to cool the unit.

T01 Cycle st. prohibit(Host comm.) 0115

Details Automatic start cannot is not possible because the NC is communicating with the host computer.

Remedy - Wait for the communication with host computer to be ended and then execute the automatic start.

T01 Cycle st prohibit(Battery alm) 0116

Details Automatic start is not possible because the voltage of the battery in the NC control unit has dropped.

Remedy

- Replace the battery of the NC control unit.
- Contact the service center.

I Alarms

2. Stop Codes (T)

T01 R-pnt offset value not set 0117

Details Automatic operation is not possible because no reference position offset value has been set.

Remedy - Perform the reference position initialization setting, then set "#2034 rfpofs(Distance-coded reference position detection offset)".

T01 Cycle start prohibit 0118

Details Tool retract position signal OFF
The axis was moved from the tool retract position. Tool retract position reached signal is OFF.

Remedy Once the axis has been moved off the tool retract position, resuming the program is not possible. Cancel the program by reset and then execute it from the start.

T01 In absolute position alarm 0138

Details A start signal was input during an absolute position detection alarm.

Remedy - Clear the absolute position detection alarm, and then input the start signal.

T01 In abs posn initial setting 0139

Details A start signal was input during zero point initialization in the absolute position detection system.

Remedy - Complete the zero point initialization before inputting the start signal.

T01 Start during MDI operation at other part system disable 0141

Details In multi-part system, a start signal was input for MDI mode while the MDI operation was being carried out in another part system.

Remedy - End the other part system's operation before starting.

T01 Cycle start prohibit 0142

Details In manual coordinate system setting
Automatic start is not allowed during the manual coordinate system setting.

Remedy The system restarts after either of the manual coordinate system setting completion signal or the error end signal has been turned ON.

T01 Cycle start prohibit 0180

Details Automatic start became disabled while servo auto turning is enabled.

Remedy - Set "#1164 ATS" to "0" when the servo auto turning is not executed.

T01 Cycle start prohibit 0190

Details Automatic start is not possible because the setting of setup parameters is enabled.

Remedy - Refer to the manual issued by the machine tool builder.

T01 Cycle start prohibit 0191

Details Automatic start was attempted while a file was being deleted/written.

Remedy - Wait for the file to be deleted/written and then execute the automatic start.

T01 Cycle st. prohibit (Term exp'd) 0193

Details Automatic start is not possible because the valid term has been expired.

Remedy - Enter the decryption code and turn the power ON again.

T02 H/W stroke end axis exists 0201

Details An axis is at the stroke end.

Remedy - Manually move the axis away from the stroke end limit switch.
- Correct the machining program.

T02 S/W stroke end axis exists 0202

Details An axis is at the stored stroke limit.

Remedy - Manually move the axis.
- Correct the machining program.

T02 Reset signal ON 0203

Details The reset has been entered.

Remedy - The program execution position has returned to the start of the program. Execute automatic operation from the start of the machining program.

T02 Auto operation pause signal ON 0204

Details The "feed hold" switch is ON.

Remedy - Press the CYCLE START switch to resume the automatic operation.

T02 Operation mode changed 0205

Details The operation mode has changed to another mode during automatic operation.

Remedy - Return to the original automatic operation mode, and press the CYCLE START switch to resume the automatic operation.

I Alarms

2. Stop Codes (T)

T02 Acc/dec time cnst too large 0206

Details The acceleration and deceleration time constants are too large. (This alarm occurs with the system alarm Z59.)

Remedy

- Set a larger value for "#1206 G1bF(Maximum speed)".
- Set a smaller value for "#1207 G1btL(Time constant)".
- Set a lower cutting speed.

T02 Abs posn detect alarm occurred 0215

Details An absolute position detection alarm occurred.

Remedy - Clear the absolute position detection alarm.

T02 Aux axis changeover error 0220

Details A travel command was issued to an auxiliary axis.

Remedy - Turn ON the "NC axis control selection" signal and press the CYCLE START switch to restart the automatic operation with.

T03 Single block stop signal ON 0301

Details The SINGLE BLOCK switch on the machine operation panel is ON. The SINGLE BLOCK or MACHINE LOCK switch changed.

Remedy - Press the CYCLE START switch to resume the automatic operation.

T03 Block stop cmdnd in user macro 0302

Details A block stop command was issued in the user macro program.

Remedy - Press the CYCLE START switch to resume the automatic operation.

T03 Operation mode changed 0303

Details Automatic mode changed to another automatic mode.

Remedy - Return to the original automatic operation mode, and press the CYCLE START switch to resume the automatic operation.

T03 MDI completed 0304

Details MDI operation has ended the last block.

Remedy - Set the MDI operation again, and press the CYCLE START switch to start the MDI operation.

T03 Block start interlock 0305

Details The interlock signal, which locks the block start, is ON.

Remedy - Correct the sequence program.

T03 Cutting blk start interlock 0306

Details The interlock signal, which locks the block cutting start, is ON.

Remedy - Correct the sequence program.

T03 Inclined Z offset change 0310

Details The "inclined axis control: No Z axis compensation" signal has turned ON or OFF during the program operation.

Remedy - Press the CYCLE START switch to resume the automatic operation.

T03 Aux axis changeover error 0330

Details The "NC axis control selection" signal was turned OFF while a NC axis was traveling.

Remedy - Turn the "NC axis control selection" signal ON and press the CYCLE START switch to resume the automatic operation.

T04 Collation stop 0401

Details Collation stop occurred.

Remedy - Execute the automatic start to resume the automatic operation.

T10 Fin wait 0ooo

Details The following Nos. are shown during the operation of the corresponding completion wait factor. The numbers will disappear when the operation is completed.

The completion wait factor is indicated with four digits (in hexadecimal).
Display format of completion wait factor

0____

(a)(b)(c)

Each of the hexadecimal numbers (a), (b) and (c) indicates the following details.

(a)

bit0: In dwell execution
bit3: Unclamp signal wait (Note 1)

(b)

bit0: Waiting for spindle position to be looped
bit3: Door open (Note 2)

(c)

bit0: Waiting for MSTB completion
bit1: Waiting for rapid traverse deceleration
bit2: Waiting for cutting speed deceleration
bit3: Waiting for spindle orientation to com
(Note 1) This shows the wait state for the unclamp signal's ON/OFF for the index table indexing.

(Note 2) This shows the door open state caused by the door interlock function.

I Alarms

2. Stop Codes (T)

T10 Fin wait 0200

Details Waiting for completion of G11
G11 was issued while an axis was moving.

Remedy Resume the operation after G11 has been completed.

3. Servo/Spindle Alarms

3.1 Servo alarm (S01/S03/S04)

Servo drive unit alarm

S01 Insufficient voltage : PR 0010 (Axis name)

Details A drop of bus voltage was detected in main circuit.
- Stop method: Dynamic stop

S01 Software processing error 1 : PR 0013 (Axis name)

Details An error was detected for the software execution state.
- Stop method: Dynamic stop

S01 Init mag pole pos detect err : PR 0016 (Axis name)

Details The initial magnetic pole position, detected in the initial magnetic pole position detection control, is not reliable.
In the DC excitation function, this error will be detected when the servo ON has been set before the magnetic pole shift amount is set while the absolute position detector is used.
- Stop method: Dynamic stop

S01 A/D converter error : PR 0017 (Axis name)

Details A current feedback error was detected.
- Stop method: Dynamic stop

S01 Motor side dtc: Init commu err : PR 0018 (Axis name)

Details An error was detected in the initial communication with the motor side detector.
- Stop method: Initial error

S01 Machine side dtc: Init comu er : PR 001A (Axis name)

Details An error was detected in the initial communication with the machine side detector.
- Stop method: Initial error

S01 Machine side dtc: Error 1 : PR 001B (Axis name)

Details An error was detected by the detector connected to the machine side.
The error details are different according to the connected detector.
- OSA17, OSE104, OSE105, OSA104, OSA105, OSA405, OSA166 (MITSUBISHI) Memory alarm
- OSA18 (MITSUBISHI) CPU alarm
- MDS-B-HR (MITSUBISHI) Memory error
- AT343, AT543 (Mitutoyo) Initialization error
- LC191M, LC491M, RCN723, RCN223, APE391M (HEIDENHAIN) Initialization error
- MP scale, MPI scale (Mitsubishi Heavy Industries) Installation accuracy fault
- Resetting methods : PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method : Dynamic stop

S01 Machine side dtc: Error 2 : PR 001C (Axis name)

Details An error was detected by the detector connected to the machine side.
The error details are different according to the connected detector.
- OSA17, OSE104, OSE105, OSA104, OSA105, OSA405, OSA166 (MITSUBISHI) LED alarm
- AT343, AT543 (Mitutoyo) EEPROM error
- LC191M, LC491M, RCN723, RCN223, APE391M (HEIDENHAIN) EEPROM error
- Resetting methods : PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method : Dynamic stop

I Alarms

3. Servo/Spindle Alarms

S01 Machine side dtc: Error 3 : PR 001D (Axis name)

- Details** An error was detected by the detector connected to the machine side.
The error details are different according to the connected detector.
- OSA17, OSE104, OSE105, OSA104, OSA105, OSA405, OSA166(MITSUBISHI)
Data alarm
 - OSA18(MITSUBISHI)
Data alarm
 - MDS-B-HR(MITSUBISHI)
Data error
 - AT343, AT543(Mitutoyo)
Photoelectric type, static capacity type data mismatch
 - LC191M, LC491M, RCN723, RCN223, APE391M(HEIDENHAIN)
Relative/absolute position data mismatch
 - MP scale, MPI scale(Mitsubishi Heavy Industries)
Detection position deviance
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

S01 Machine side dtc: Error 4 : PR 001E (Axis name)

- Details** An error was detected by the detector connected to the machine side.
The error details are different according to the connected detector.
- AT343, AT543(Mitutoyo)
ROM/RAM error
 - LC191M, LC491M, RCN723, RCN223, APE391M(HEIDENHAIN)
ROM/RAM error
 - MP scale, MPI scale(Mitsubishi Heavy Industries)
Scale breaking
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

S01 Machine side dtc: Commu error : PR 001F (Axis name)

- Details** An error was detected in the communication with the machine side detector.
- Stop method :Dynamic stop

S01 Machine side dtc: No signal : PR 0021 (Axis name)

- Details** An error was detected in the ABZ-phase in the full closed loop control system.
- Stop method :Dynamic stop

S01 Grounding : PR 0024 (Axis name)

- Details** The motor power cable is in contact with FG (Frame Ground).
- Stop method :Dynamic stop

S01 Unused axis error : PR 0026 (Axis name)

- Details** A power module error was detected on the axis set to Free.
- Stop method :Dynamic stop

S01 Machine side dtc: Error 5 : PR 0027 (Axis name)

- Details** An error was detected by the detector connected to the motor side.
The error details are different according to the connected detector.
- MDS-B-HR(MITSUBISHI)
Scale not connected
 - AT343, AT543(Mitutoyo)
CPU error
 - LC191M, LC491M, RCN723, RCN223, APE391M(HEIDENHAIN)
CPU error
 - MP scale, MPI scale (Mitsubishi Heavy Industries)
Absolute value detection fault
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

S01 Machine side dtc: Error 6 : PR 0028 (Axis name)

- Details** An error was detected by the detector connected to the motor side.
The error details are different according to the connected detector.
- AT343, AT543(Mitutoyo)
Photoelectric type overspeed
 - LC191M, LC491M, RCN723, RCN223, APE391M(HEIDENHAIN)
Overspeed
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

I Alarms

3. Servo/Spindle Alarms

S01 Machine side dtc: Error 7 : PR 0029 (Axis name)

Details

- An error was detected by the detector connected to the motor side.
The error details are different according to the connected detector. R
- AT343, AT543(Mitutoyo)
Static capacity type error
 - LC191M,LC491M,RCN723,RCN223, APE391M(HEIDENHAIN)
Absolute position data error
 - Futaba absolute position scale (Futaba)
Waveform error
 - MP scale, MPI scale (Mitsubishi Heavy Industries)
Gain fault
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

S01 Machine side dtc: Error 8 : PR 002A (Axis name)

Details

- An error was detected by the detector connected to the motor side.
The error details are different according to the connected detector.
- AT343, AT543(Mitutoyo)
Photoelectric type error
 - LC191M,LC491M,RCN723,RCN223, APE391M(HEIDENHAIN)
Relative position data error
 - Futaba absolute position scale (Futaba)
Overspeed Absolute position is lost
 - MP scale, MPI scale (Mitsubishi Heavy Industries)
Phase fault
 - MJ831(SONY)
Detector alarm
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

S01 Motor side dtc: Error 1 : PR 002B (Axis name)

Details

- An error was detected by the detector connected to the motor side.
The error details are different according to the connected detector.
- OSA17,OSE104,OSE105,OSA104,OSA105,OSA405,OSA166(MITSUBISHI)
Memoryalarm
 - OSA18(MITSUBISHI)
CPU alarm
 - MDS-B-HR(MITSUBISHI)
Memory error
 - AT343, AT543(Mitutoyo)
Initialization error
 - LC191M,LC491M,RCN723,RCN223, APE391M(HEIDENHAIN)
Initialization error
 - MP scale, MPI scale (Mitsubishi Heavy Industries)
Installation accuracy fault
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

S01 Motor side dtc: Error 2 : PR 002C (Axis name)

Details

- An error was detected by the detector connected to the motor side.
The error details are different according to the connected detector.
- OSA17,OSE104,OSE105,OSA104,OSA105,OSA405,OSA166(MITSUBISHI)
LED alarm
 - AT343, AT543(Mitutoyo)
EEPROM error
 - LC191M,LC491M,RCN723,RCN223, APE391M(HEIDENHAIN)
EEPROM error
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

S01 Motor side dtc: Error 3 : PR 002D (Axis name)

Details

- An error was detected by the detector connected to the motor side.
The error details are different according to the connected detector.
- OSA17,OSE104,OSE105,OSA104,OSA105,OSA405,OSA166(MITSUBISHI)
Data alarm
 - OSA18(MITSUBISHI)
Data alarm
 - MDS-B-HR(MITSUBISHI)
Data error
 - AT343, AT543(Mitutoyo)
Photoelectric type, static capacity type data mismatch
 - LC191M,LC491M,RCN723,RCN223, APE391M(HEIDENHAIN)
Relative/absolute position data mismatch
 - MP scale, MPI scale(Mitsubishi Heavy Industries)
Detection position deviance
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

I Alarms

3. Servo/Spindle Alarms

S01 Motor side dtc: Error 4 : PR 002E (Axis name)

- Details** An error was detected by the detector connected to the motor side. The error details are different according to the connected detector.
- AT343, AT543(Mitutoyo)
ROM/RAM error
 - LC191M,LC491M,RCN723,RCN223, APE391M(HEIDENHAIN)
ROM/RAM error
 - MP scale, MPI scale(Mitsubishi Heavy Industries)
Scale breaking
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

S01 Motor side dtc: Commu error : PR 002F (Axis name)

- Details** An error was detected in the communication with the motor side detector.
- Stop method:Dynamic stop

S01 Over regeneration : PR 0030 (Axis name)

- Details** Over-regeneration level exceeded 100%. The regenerative resistor is overloaded.
- Stop method:Dynamic stop

S01 Overspeed : PR 0031 (Axis name)

- Details** The motor speed exceeded the allowable speed.
- Stop method:Deceleration stop enabled

S01 Power module overcurrent : PR 0032 (Axis name)

- Details** The power module detected the overcurrent.
- Stop method:Dynamic stop

S01 Overvoltage : PR 0033 (Axis name)

- Details** The bus voltage in main circuit exceeded the allowable value.
- Stop method:Dynamic stop

S01 NC-DRV commu: CRC error : PR 0034 (Axis name)

- Details** An error was detected in the data received from the NC.
- Stop method:Deceleration stop enabled

S01 NC command error : PR 0035 (Axis name)

- Details** The travel command data received from the NC was excessive.
- Stop method:Deceleration stop enabled

S01 NC-DRV commu: Commu error : PR 0036 (Axis name)

- Details** The communication with the NC was interrupted.
- Stop method:Deceleration stop enabled

S01 Initial parameter error : PR 0037 (Axis name)

- Details** An incorrect set value was detected among the parameters send from the NC at the power ON.
- Stop method:Initial error

S01 NC-DRV commu: Protocol error 1 : PR 0038 (Axis name)

- Details** An error was detected in the communication frames received from the NC.
- Stop method:Deceleration stop enabled

S01 NC-DRV commu: Protocol error 2 : PR 0039 (Axis name)

- Details** An error was detected in the axis data received from the NC.
- Stop method:Deceleration stop enabled

S01 Overcurrent : PR 003A (Axis name)

- Details** Excessive motor drive current was detected.
- Stop method:Dynamic stop

S01 Power module overheat : PR 003B (Axis name)

- Details** The power module detected an overheat.
- Stop method:Dynamic stop

S01 Regeneration circuit error : PR 003C (Axis name)

- Details** An error was detected in the regenerative transistor or in the regenerative resistor.
- Stop method:Dynamic stop

S01 Pw sply volt err acc/dec : PR 003D (Axis name)

- Details** A motor control error, due to an input voltage failure, was detected.
- Stop method:Dynamic stop

S01 Feedback error 3 : PR 0041 (Axis name)

- Details** Either a missed feedback pulse in the motor side detector or an error in the Z-phase was detected in the full closed loop system.
- Stop method:Dynamic stop

I Alarms

3. Servo/Spindle Alarms

S01 Feedback error 1 : PR 0042 (Axis name)

- Details** Either a missed feedback pulse in the detector used for the position detection or an error in the Z-phase was detected.
- Stop method:Dynamic stop

S01 Feedback error 2 : PR 0043 (Axis name)

- Details** An excessive difference in feedback was detected between the machine side detector and the motor side detector.
- Stop method:Dynamic stop

S01 Fan stop : PR 0045 (Axis name)

- Details** An overheat of the power module was detected during the cooling fan stopping.
- Stop method:Dynamic stop

S01 Motor side dtc: Error 5 : PR 0048 (Axis name)

- Details** An error was detected by the detector connected to the motor side. The error details are different according to the connected detector.
- MDS-B-HR(MITSUBISHI)
Scale not connected
- AT343, AT543(Mitutoyo)
CPU error
- LC191M,LC491M,RCN723,RCN223, APE391M(HEIDENHAIN)
CPU error
- MP scale, MPI scale (Mitsubishi Heavy Industries)
Absolute value detection fault
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

S01 Motor side dtc: Error 6 : PR 0049 (Axis name)

- Details** An error was detected by the detector connected to the motor side. The error details are different according to the connected detector.
- AT343, AT543(Mitutoyo)
Photoelectric type overspeed
- LC191M,LC491M,RCN723,RCN223, APE391M(HEIDENHAIN)
Overspeed
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

S01 Motor side dtc: Error 7 : PR 004A (Axis name)

- Details** An error was detected by the detector connected to the motor side. The error details are different according to the connected detector.
- AT343, AT543(Mitutoyo)
Static capacity type error
- LC191M,LC491M,RCN723,RCN223, APE391M(HEIDENHAIN)
Absolute position data error
- Futaba absolute position scale (Futaba)
Waveform error
- MP scale, MPI scale (Mitsubishi Heavy Industries)
Gain fault
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

S01 Motor side dtc: Error 8 : PR 004B (Axis name)

- Details** An error was detected by the detector connected to the motor side. The error details are different according to the connected detector.
- AT343, AT543(Mitutoyo)
Photoelectric type error
- LC191M,LC491M,RCN723,RCN223, APE391M(HEIDENHAIN)
Relative position data error
- Futaba absolute position scale (Futaba)
Overspeed Absolute position is lost
- MP scale, MPI scale (Mitsubishi Heavy Industries)
Phase fault
- MJ831(SONY)
Detector alarm
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Dynamic stop

S01 Sfty obsrvation: Cmd spd err : PR 005B (Axis name)

- Details** A commanded speed exceeding the safe speed was detected in speed monitoring mode.
- Stop method:Deceleration stop enabled

S01 Sfty obsrvation: Door stat err : PR 005D (Axis name)

- Details** The door state signal input in the NC does not coincide with the door state signal input in the drive unit. Otherwise, door open state was detected in normal mode.
- Stop method:Deceleration stop enabled

I Alarms

3. Servo/Spindle Alarms

S01 Sfty obsrvation: FB speed err : PR 005E (Axis name)

Details A motor speed exceeding the safe speed was detected in the speed monitoring mode.
- Stop method: Deceleration stop enabled

S01 Drive unit communication error : PR 0087 (Axis name)

Details The communication frame between drivers was aborted.
- Stop method: Dynamic stop

S01 Drivers commu data error 1 : PR 008A (Axis name)

Details The communication data 1 between drivers exceeded the tolerable value in the communication between drivers.
- Stop method: Dynamic stop

S01 Drivers commu data error 2 : PR 008B (Axis name)

Details The communication data 2 between drivers exceeded the tolerable value in the communication between drivers.
- Stop method: Dynamic stop

S03 Motor overheat : NR 0046 (Axis name)

Details Either the motor or the motor side detector detected an overheat.
- Stop method: Deceleration stop enabled

S03 Instantaneous power interrupt : NR 004F (Axis name)

Details The control power supply has been shut down for 50ms or more.
- Stop method: Deceleration stop enabled

S03 Overload 1 : NR 0050 (Axis name)

Details Excessive load current was detected.
- Stop method: Deceleration stop enabled

S03 Overload 2 : NR 0051 (Axis name)

Details Excessive load current was detected.
- Stop method: Deceleration stop enabled

S03 Excessive error 1 : NR 0052 (Axis name)

Details A position tracking error was detected. (during servo ON)
- Stop method: Deceleration stop enabled

S03 Excessive error 2 : NR 0053 (Axis name)

Details A position tracking error was detected. (during servo OFF)
- Stop method: Dynamic stop

S03 Excessive error 3 : NR 0054 (Axis name)

Details The anomalous motor current was detected at the detection of Excessive error 1.
- Stop method: Dynamic stop

S03 Command speed monitoring error : NR 0056 (Axis name)

Details The command speed by the NC command exceeded the rapid speed or the motor maximum speed.
- Stop method: Deceleration control

S03 Collision detection 1: G0 : NR 0058 (Axis name)

Details A disturbance torque exceeded the tolerable disturbance torque in rapid traverse modal (G0). The tolerable disturbance torque is decided by SV060:TLMT.
- Stop method: Maximum capacity deceleration stop

S03 Collision detection 1: G1 : NR 0059 (Axis name)

Details A disturbance torque exceeded the tolerable disturbance torque in the cutting feed modal (G1). The tolerable disturbance torque is decided by SV060:TLMT and SV035:SSF4/dG1(bitC, bitD and bitE).
- Stop method: Maximum capacity deceleration stop

S03 Collision detection 2 : NR 005A (Axis name)

Details A current command with the maximum capacity current value was detected.
- Stop method: Maximum capacity deceleration stop

S03 External contactor error : NR 005F (Axis name)

Details A contact of the external contactor is welding.
- Stop method: Deceleration stop enabled

S04 Axis selection error : AR 0011 (Axis name)

Details The axis selection rotary switch has been incorrectly set.
- Stop method: Initial error

S04 Memory error 1 : AR 0012 (Axis name)

Details A hardware error was detected during the power ON self-check.
- Stop method: Initial error

I Alarms

3. Servo/Spindle Alarms

S04 Absolute position data lost : AR 0025 (Axis name)

Details The absolute position was lost in the detector.
- Stop methodÄFInitial error

S04 Magnet pole pos detect err : AR 003E (Axis name)

Details The magnetic pole position, detected in the magnetic pole position detection control, is not reliable.
- Stop methodÄFDynamic stop

S04 Motor side dtc: cable err : AR 0080 (Axis name)

Details A difference of type was detected between the motor side detector and the cable connected to the detector. Otherwise, the cable type for the motor side detector was not successfully achieved.
- Stop methodÄFInitial error

S04 Machine side dtc: cable err : AR 0081 (Axis name)

Details A difference of type was detected between the machine side detector and the cable connected to the detector. Otherwise, the cable type for the machine side detector was not successfully achieved.
- Stop methodÄFInitial error

S04 Watchdog : AR 0088 (Axis name)

Details The drive unit does not operate correctly.
- Stop methodÄFDynamic stop

I Alarms

3. Servo/Spindle Alarms

Spindle drive unit alarm

S01 Insufficient voltage : PR 0010 (Axis name)

Details A drop of bus voltage was detected in main circuit.
- Stop method:Coast to a stop

S01 Software processing error 1 : PR 0013 (Axis name)

Details An error was detected for the software execution state.
- Stop method:Coast to a stop

S01 Init mag pole pos detect err : PR 0016 (Axis name)

Details The magnetic pole position, detected in the initial magnetic pole position detection control, is not reliable.
- Stop method:Coast to a stop

S01 A/D converter error : PR 0017 (Axis name)

Details A current feedback error was detected.
- Stop method:Coast to a stop

S01 Motor side dtc: Init commu err : PR 0018 (Axis name)

Details An error was detected in the initial communication with the motor side detector.
- Stop method:Initial error

S01 Detector commu err in syn cont : PR 0019 (Axis name)

Details An error was detected in the communication with the extended connection detector.
- Stop method:Coast to a stop

S01 Machine side dtc: Init comu er : PR 001A (Axis name)

Details An error was detected in the initial communication with the machine side detector.
- Stop method:Initial error

S01 Machine side dtc: Error 1 : PR 001B (Axis name)

Details An error was detected by the detector connected to the machine side.
The error details are different according to the connected detector.
- TS5690, TS5691(MITSUBISHI)
Memory error
- MDS-B-HR(MITSUBISHI)
Initialization error
- OSA18(MITSUBISHI)
CPU error
- ERM280+APE391M(HEIDENHAIN)
Initialization error
- MPCl scale (Mitsubishi Heavy Industries)
Installation accuracy fault
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop metho :Coast to a stop

S01 Machine side dtc: Error 2 : PR 001C (Axis name)

Details An error was detected by the detector connected to the machine side.
The error details are different according to the connected detector.
- TS5690, TS5691(MITSUBISHI)
Waveform error
- ERM280+APE391M(HEIDENHAIN)
EEPROM error
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop metho :Coast to a stop

S01 Machine side dtc: Error 3 : PR 001D (Axis name)

Details An error was detected by the detector connected to the machine side.
The error details are different according to the connected detector.
- MDS-B-HR(MITSUBISHI)
Data error
- OSA18(MITSUBISHI)
Data error
- MPCl scale (Mitsubishi Heavy Industries)
Detection position deviance
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop metho :Coast to a stop

S01 Machine side dtc: Error 4 : PR 001E (Axis name)

Details An error was detected by the detector connected to the machine side.
The error details are different according to the connected detector.
- MPCl scale (Mitsubishi Heavy Industries)
Scale breaking
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop metho :Coast to a stop

I Alarms

3. Servo/Spindle Alarms

S01 Machine side dtc: Commu error : PR 001F (Axis name)

- Details** An error was detected in the communication with the machine side detector.
- Stop method:Coast to a stop

S01 Motor side dtc: No signal : PR 0020 (Axis name)

- Details** The cable type of the motor side detector does not coincide with the detector type set with the parameter.
- Stop method:Initial error

S01 Machine side dtc: No signalExcessive speed error : PR 0021 (Axis name)

- Details** The cable type of the machine side detector does not coincide with the detector type set with the parameter.
- Resetting methods:After removing the cause of the alarm, reset the alarm by turning the NC power ON again.
- Stop method:Initial error

- Details** An error was detected in the ABZ-phase in the full closed loop control system.
- Stop method:Coast to a stop

S01 Unused axis error : PR 0026 (Axis name)

- Details** A power module error was detected on the axis set to Free.
- Stop method:Coast to a stop

S01 Machine side dtc: Error 5 : PR 0027 (Axis name)

- Details** An error was detected by the detector connected to the machine side.
The error details are different according to the connected detector.
- MDS-B-HR(MITSUBISHI)
Connection error
- ERM280+APE391M(HEIDENHAIN)
CPU error
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop metho :Coast to a stop

S01 Machine side dtc: Error 6 : PR 0028 (Axis name)

- Details** An error was detected by the detector connected to the machine side.
The error details are different according to the connected detector.
- TS5690, TS5691(MITSUBISHI)
Overspeed
- ERM280+APE391M(HEIDENHAIN)
Overspeed
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop metho :Coast to a stop

S01 Machine side dtc: Error 7 : PR 0029 (Axis name)

- Details** An error was detected by the detector connected to the machine side.
The error details are different according to the connected detector.
- MPCI scale (Mitsubishi Heavy Industries)
Gain fault
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop metho :Coast to a stop

S01 Machine side dtc: Error 8 : PR 002A (Axis name)

- Details** An error was detected by the detector connected to the machine side.
The error details are different according to the connected detector.
- TS5690, TS5691(MITSUBISHI)
Relative position data error
- ERM280+APE391M(HEIDENHAIN)
Relative position data error
- MPCI scale (Mitsubishi Heavy Industries)
Phase fault
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop metho :Coast to a stop

I Alarms

3. Servo/Spindle Alarms

S01 Motor side dtc: Error 1 : PR 002B (Axis name)

- Details** An error was detected by the detector connected to the motor side.
The error details are different according to the connected detector.
- TS5690, TS5691(MITSUBISHI)
Memory error
 - MDS-B-HR(MITSUBISHI)
Initialization error
 - OSA18(MITSUBISHI)
CPU error
 - ERM280+APE391M(HEIDENHAIN)
Initialization error
 - MPCl scale (Mitsubishi Heavy Industries)
Installation accuracy fault
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop metho :Coast to a stop

S01 Motor side dtc: Error 2 : PR 002C (Axis name)

- Details** An error was detected by the detector connected to the motor side.
The error details are different according to the connected detector.
- TS5690, TS5691(MITSUBISHI)
Waveform error
 - ERM280+APE391M(HEIDENHAIN)
EEPROM error
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop metho :Coast to a stop

S01 Motor side dtc: Error 3 : PR 002D (Axis name)

- Details** An error was detected by the detector connected to the motor side.
The error details are different according to the connected detector.
- MDS-B-HR(MITSUBISHI)
Data error
 - OSA18(MITSUBISHI)
Data error
 - MPCl scale (Mitsubishi Heavy Industries)
Detection position deviance
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop metho :Coast to a stop

S01 Motor side dtc: Error 4 : PR 002E (Axis name)

- Details** An error was detected by the detector connected to the motor side.
The error details are different according to the connected detector.
- MPCl scale (Mitsubishi Heavy Industries)
Scale breaking
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop metho :Coast to a stop

S01 Motor side dtc: Commu error : PR 002F (Axis name)

- Details** An error was detected in the communication with the motor side detector.
- Stop methodAFCoast to a stop

S01 Over regeneration : PR 0030 (Axis name)

- Details** Over-regeneration level exceeded 100%.
The regenerative resistor is overloaded.
- Stop methodAFCoast to a stop

S01 Overspeed : PR 0031 (Axis name)

- Details** The motor speed exceeded the allowable speed.
- Stop methodAFDeceleration stop enabled

S01 Power module overcurrent : PR 0032 (Axis name)

- Details** The power module detected the overcurrent.
- Stop methodAFCoast to a stop

S01 Overvoltage : PR 0033 (Axis name)

- Details** The bus voltage in main circuit exceeded the allowable value.
- Stop methodAFCoast to a stop

S01 NC-DRV commu: CRC error : PR 0034 (Axis name)

- Details** An error was detected in the data received from the NC.
- Stop methodAFDeceleration stop enabled

S01 NC command error : PR 0035 (Axis name)

- Details** An error was detected in the travel command data received from the NC.
- Stop methodAFDeceleration stop enabled

I Alarms

3. Servo/Spindle Alarms

S01 NC-DRV commu: Commu error : PR 0036 (Axis name)

Details The communication with the NC was interrupted.
- Stop method:Deceleration stop enabled

S01 Initial parameter error : PR 0037 (Axis name)

Details An incorrect set value was detected among the parameters send from the NC at the power ON.
- Stop method:Initial error

S01 NC-DRV commu: Protocol error 1 : PR 0038 (Axis name)

Details An error was detected in the communication frames received from the NC.
- Stop method:Deceleration stop enabled

S01 NC-DRV commu: Protocol error 2 : PR 0039 (Axis name)

Details An error was detected in the axis data received from the NC.
- Stop method:Deceleration stop enabled

S01 Overcurrent : PR 003A (Axis name)

Details Excessive motor drive current was detected.
- Stop method:Coast to a stop

S01 Power module overheat : PR 003B (Axis name)

Details The power module detected an overheat.
- Stop method:Coast to a stop

S01 Regeneration circuit error : PR 003C (Axis name)

Details An error was detected in the regenerative transistor or in the regenerative resistor.
- Stop method:Coast to a stop

S01 Feedback error 3 : PR 0041 (Axis name)

Details An error was detected in the feedback of the motor side detector.
- Stop method:Coast to a stop

S01 Feedback error 1 : PR 0042 (Axis name)

Details An error was detected in the feedback of the machine side detector.
- Stop method:Coast to a stop

S01 Feedback error 2 : PR 0043 (Axis name)

Details An excessive difference in feedback was detected between the motor side detector and the machine side detector.
- Stop method:Coast to a stop

S01 Fan stop : PR 0045 (Axis name)

Details A cooling fan in the drive unit stopped.
- Stop method:Coast to a stop

S01 Motor side dtc: Error 5 : PR 0048 (Axis name)

Details An error was detected by the detector connected to the motor side. The error details are different according to the connected detector.
- MDS-B-HR(MITSUBISHI)
Connection error
- ERM280+APE391M(HEIDENHAIN)
CPU error
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Coast to a stop

S01 Motor side dtc: Error 6 : PR 0049 (Axis name)

Details An error was detected by the detector connected to the motor side. The error details are different according to the connected detector.
- TS5690, TS5691(MITSUBISHI)
Overspeed
- ERM280+APE391M(HEIDENHAIN)
Overspeed
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Coast to a stop

S01 Motor side dtc: Error 7 : PR 004A (Axis name)

Details An error was detected by the detector connected to the motor side. The error details are different according to the connected detector.
- MPC1 scale (Mitsubishi Heavy Industries)
Gain fault
- Resetting methods :PR
(Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Coast to a stop

I Alarms

3. Servo/Spindle Alarms

S01 Motor side dtc: Error 8 : PR 004B (Axis name)

- Details** An error was detected by the detector connected to the motor side.
The error details are different according to the connected detector.
- TS5690, TS5691(MITSUBISHI)
Relative position data error
 - ERM280+APE391M(HEIDENHAIN)
Relative position data error
 - MPCI scale (Mitsubishi Heavy Industries)
Phase fault
 - Resetting methods :PR
- (Note) A driver processes all reset types of alarms as 'PR'. However, 'AR' will be applied according to the detector.
- Stop method :Coast to a stop

S01 Sfty obsrvation: Cmd spd err : PR 005B (Axis name)

- Details** A commanded speed exceeding the safe speed was detected in speed monitoring mode.
- Stop method:Deceleration stop enabled

S01 Sfty obsrvation: Door stat err : PR 005D (Axis name)

- Details** The door state signal input in the NC does not coincide with the door state signal input in the drive unit. Otherwise, door open state was detected in normal mode.
- Stop method:Deceleration stop enabled

S01 Sfty obsrvation: FB speed err : PR 005E (Axis name)

- Details** A motor speed exceeding the safe speed was detected in the speed monitoring mode.
- Stop method:Deceleration stop enabled

S01 Motor side dtc: cable err : PR 0080 (Axis name)

- Details** The connected cable type does not coincide with the motor side detector type.
- Stop method:Initial error

S01 Machine side dtc: cable err : PR 0081 (Axis name)

- Details** The connected cable type does not coincide with the machine side detector type.
- Stop method:Initial error

S01 Drive unit communication error : PR 0087 (Axis name)

- Details** The communication frame between drivers was aborted.
- Stop method:Coast to a stop

S01 Drivers commu data error 1 : PR 008A (Axis name)

- Details** The communication data 1 between drivers exceeded the tolerable value in the communication between drivers.
- Stop method:Coast to a stop

S01 Drivers commu data error 2 : PR 008B (Axis name)

- Details** The communication data 2 between drivers exceeded the tolerable value in the communication between drivers.
- Stop method:Coast to a stop

S03 Grounding : NR 0023 (Axis name)

- Details** An excessive speed tracking error was detected (during servo ON).
- Stop method:Coast to a stop

S03 Motor overheat : NR 0046 (Axis name)

- Details** Either the motor or the motor side detector detected an overheat.
- Stop method:Deceleration stop enabled

S03 Current err mag pole estim : NR 004C (Axis name)

- Details** Current detection failed at the pulse-applied magnetic pole estimation by IPM spindle motor.
- Stop method:Coast to a stop

S03 NC command mode error : NR 004E (Axis name)

- Details** An error was detected in the spindle control mode send from the NC.
- Stop method:Deceleration stop enabled

S03 Instantaneous power interrupt : NR 004F (Axis name)

- Details** The control power supply has been shut down for 50ms or more.
- Stop method:Deceleration stop enabled

S03 Overload 1 : NR 0050 (Axis name)

- Details** Excessive load current was detected.
- Stop method:Deceleration stop enabled

S03 Overload 2 : NR 0051 (Axis name)

- Details** Excessive load current was detected.
- Stop method:Deceleration stop enabled

I Alarms

3. Servo/Spindle Alarms

S03 Excessive error 1 : NR 0052 (Axis name)

Details A position tracking error was detected. (during servo ON)
- Stop methodÄFDeceleration stop enabled

S03 Excessive error 3 : NR 0054 (Axis name)

Details The anomalous motor current was detected at the detection of Excessive error 1.
- Stop methodÄFCoast to a stop

S03 External contactor error : NR 005F (Axis name)

Details A contact of the external contactor is welding.
- Stop methodÄFDeceleration stop enabled

S04 Axis selection error : AR 0011 (Axis name)

Details The axis selection rotary switch has been incorrectly set.
- Stop methodÄFInitial error

S04 Memory error 1 : AR 0012 (Axis name)

Details A hardware error was detected during the power ON self-check.
- Stop methodÄFInitial error

S04 Machine side dtc: No signal : AR 0024 (Axis name)

Details A grounding of the motor power cable or motor was detected.
- Stop methodÄFCoast to a stop

S04 Magnet pole pos detect err : AR 003E (Axis name)

Details The magnetic pole position, detected in the magnetic pole position detection control, is not reliable.
- Stop methodÄFCoast to a stop

S04 Watchdog : AR 0088 (Axis name)

Details The drive unit does not operate correctly.
- Stop methodÄFCoast to a stop

I Alarms

3. Servo/Spindle Alarms

Power supply alarm

S01 Pw sply: Pwr module overcurrnt : 0061 (Axis name)

Details Overcurrent protection function in the power module has started its operation.
- LED displayAF1

S01 Pw sply: Frequency error : 0062 (Axis name)

Details The input power supply frequency increased above the specification range.
- LED displayAF2

S01 Process error : PR 0066 (Axis name)

Details An error occurred in the process cycle.

S01 Pw sply: Phase interruption : 0067 (Axis name)

Details An open-phase condition was detected in input power supply circuit.
- LED displayAF7

S01 Pw sply: Grounding : 0069 (Axis name)

Details The motor power cable is in contact with FG (Frame Ground).
- LED displayAF9

S01 Pw sply: Ext contactor weld : 006A (Axis name)

Details A contact of the external contactor is welding.
- LED displayAFA

S01 Pw sply: Rush relay welding : 006B (Axis name)

Details A resistor relay for rush short circuit fails to be OFF.
- LED displayAFB

S01 Pw sply: Main circuit error : 006C (Axis name)

Details An error was detected in charging operation of the main circuit capacitor.
- LED displayAFC

S01 Parameter setting error : PR 006D (Axis name)

Details An error was detected in the parameter sent from the drive unit.

S01 Pw sply: Ext emergency stp err : 0070 (Axis name)

Details A mismatch of the external emergency stop input and NC emergency stop input continued for 30 seconds.
- LED displayAFG

S01 Pw sply: Fan stop : 0072 (Axis name)

Details A cooling fan built in the power supply unit stopped, and overheat occurred in the power module.
- LED displayAFI

S01 Pw sply: Power module overheat : 0077 (Axis name)

Details Thermal protection function in the power module has started its operation.
- LED displayAFN

S03 Pw sply: Instant pwr interrupt : 0071 (Axis name)

Details The power was momentarily interrupted.
- LED displayAFH

S03 Pw sply: Over regeneration : 0073 (Axis name)

Details Over-regeneration detection level became over 100%. The regenerative resistor is overloaded. This alarm cannot be reset for 15 min from the occurrence to protect the regeneration resistor. Leave the drive system energized for more than 15 min, then turn the power ON to reset the alarm.
- LED displayAFJ

S03 Pw sply: Overvoltage : 0075 (Axis name)

Details L+ and L- bus voltage in main circuit exceeded the allowable value. As the voltage between L+ and L- is high immediately after this alarm, another alarm may occur if this alarm is reset in a short time. Wait more than 5 min before resetting so that the voltage drops.
- LED displayAFL

S04 Pw sply: Watchdog : 0068 (Axis name)

Details The system does not operate correctly.
- LED displayAF8

S04 Pw sply: Memory error/AD error : 006E (Axis name)

Details An error was detected in the internal memory or A/D converter.
- LED displayAFE

S04 Power supply error : 006F (Axis name)

Details No power supply is connected to the drive unit, or a communication error was detected.
- LED displayAFF

I Alarms

3. Servo/Spindle Alarms

S04 Pw sply: Ext EMG stop set err : 0076 (Axis name)

Details

The rotary switch setting of external emergency stop is not correct, or a wrong external emergency stop signal is input.
- LED displayAFM

3.2 Initial parameter error (S02)

S02 Initial parameter error 2201-2264 (Axis name)

Details The servo parameter setting data is illegal.
The alarm No. is the No. of the servo parameter where the error occurred.

Remedy Check the descriptions for the appropriate servo parameters and correct them.

S02 Initial parameter error 2301 (Axis name)

Details The number of constants to be used in the following functions is too large:
- Electronic gears
- Position loop gain
- Speed feedback conversion

Remedy Check that all the related parameters are specified correctly. sv001:PC1, sv002:PC2, sv003:PGN1 sv018:PIT, sv019:RNG1, sv020:RNG2

S02 Initial parameter error 2302 (Axis name)

Details When high-speed serial incremental detector (OSE104, OSE105) is connected, parameters for absolute position are set to ON.
Set the parameters for absolute position detection to OFF.
To detect an absolute position, replace the incremental specification detector with an absolute position detector.

Remedy Check that all the related parameters are specified correctly. sv017:SPEC, sv025:MTYP

S02 Initial parameter error 2303 (Axis name)

Details No servo option is found.
The closed loop (including the ball screw-end detector) or dual feedback control is an optional function.

Remedy Check that all the related parameters are specified correctly. sv025:MTYP/pen sv017:SPEC/dfbx

S02 Initial parameter error 2304 (Axis name)

Details No servo option is found.
The SHG control is an optional function.

Remedy Check that all the related parameters are specified correctly. sv057:SHGC sv058:SHGCsp

S02 Initial parameter error 2305 (Axis name)

Details No servo option is found.
The adaptive filtering is an optional function.

Remedy Check that all the related parameters are specified correctly. sv027:SSF1/aft

S02 Initial parameter error 13001-13256 (Axis name)

Details Parameter error
The spindle parameter setting data is illegal.
The alarm No. is the No. of the spindle parameter where the error occurred.

Remedy Check the descriptions for the appropriate spindle parameters and correct them. Refer to Alarm No.37 in Spindle Drive Maintenance Manual.

3.3 Parameter error (S51)

S51 Parameter error 2201-2264 (Axis name)

Details Servo parameter setting data is illegal.
The alarm No. is the No. of the servo parameter where the warning occurred.

Remedy Check the descriptions for the appropriate servo parameters and correct them.

S51 Parameter error 13001-13256 (Axis name)

Details Spindle parameter setting data is illegal.
The alarm No. is the No. of the spindle parameter where the warning occurred.

Remedy Check the descriptions for the appropriate spindle parameters and correct them. Refer to Spindle Drive Maintenance Manual.

3.4 Servo warning (S52)

Servo drive unit warning

S52 Scale feedback error 0096 (Axis name)

Details An excessive difference in feedback amount was detected between the motor side detector and the MPI scale in MPI scale absolute position detection system.
- Resetting methods: Automatically reset once the cause of the warning is removed.

S52 Scale offset error 0097 (Axis name)

Details An error was detected in the offset data that is read at the NC power-ON in MPI scale absolute position detection system.

S52 Absolute position detector: Revolution counter error 009E (Axis name)

Details An error was detected in the revolution counter data of the absolute position detector. The accuracy of absolute position is not guaranteed.
- Resetting methods: Automatically reset once the cause of the warning is removed.

S52 Battery voltage drop 009F (Axis name)

Details The battery voltage to be supplied to the absolute position detector is dropping.
- Resetting methods: Automatically reset once the cause of the warning is removed.

S52 Fan stop warning 00A6 (Axis name)

Details A cooling fan in the drive unit stopped.
- Resetting methods: Automatically reset once the cause of the warning is removed.

S52 Overregeneration warning 00E0 (Axis name)

Details Over-regeneration detection level exceeded 80%.
- Resetting methods: Automatically reset once the cause of the warning is removed.

S52 Overload warning 00E1 (Axis name)

Details A level of 80% of the Overload 1 alarm state was detected.
- Resetting methods: Automatically reset once the cause of the warning is removed.

S52 Set parameter warning 00E4 (Axis name)

Details An incorrect set value was detected among the parameters send from the NC in the normal operation.
- Resetting methods: Automatically reset once the cause of the warning is removed.

S52 Control axis detachment warning 00E6 (Axis name)

Details A control axis is being detached. (State display)
- Resetting methods: Automatically reset once the cause of the warning is removed.

S52 In NC emergency stop state 00E7 (Axis name)

Details In NC emergency stop. (State display)
- Resetting methods: Automatically reset once the cause of the warning is removed.
- Stop method: Deceleration stop enabled

S52 Power supply warning 00E8-00EF

Details The power supply unit detected a warning.
The error details are different according to the connected power supply unit.
Refer to "Power supply warning".
- Resetting methods: Automatically reset once the cause of the warning is removed.
- Stop method: EA: Deceleration stop enabled

Spindle drive unit warning

S52 Fan stop warning 00A6 (Axis name)

Details A cooling fan in the drive unit stopped.
- Resetting methodsAFAutomatically reset once the cause of the warning is removed.

S52 Overregeneration warning 00E0 (Axis name)

Details Over-regeneration detection level exceeded 80%.
- Resetting methodsAFAutomatically reset once the cause of the warning is removed.

S52 Overload warning 00E1 (Axis name)

Details A level of 80% of the Overload 1 alarm state was detected.
- Resetting methodsAFAutomatically reset once the cause of the warning is removed.

S52 Set parameter warning 00E4 (Axis name)

Details A parameter was set to the value over the setting range.
- Resetting methodsAFAutomatically reset once the cause of the warning is removed.

S52 Control axis detachment warning 00E6 (Axis name)

Details A control axis is being detached. (State display)
- Resetting methodsAFAutomatically reset once the cause of the warning is removed.

S52 In NC emergency stop state 00E7 (Axis name)

Details In NC emergency stop. (State display)
- Resetting methodsAFAutomatically reset once the cause of the warning is removed.
- Stop methodAFDeceleration stop enabled

S52 Power supply warning 00E8-00EF

Details The power supply unit detected a warning.
The error details are different according to the connected power supply unit.
Refer to "Power supply warning".
- Resetting methodsAFAutomatically reset once the cause of the warning is removed.

Power supply warning

S52 Instantaneous power interruption warning : 00E9 (Axis name)

Details The power was momentarily interrupted.
- LED displayAFP

S52 In external emergency stop state : 00EA (Axis name)

Details External emergency stop signal was input.
- Reset methodAF*
- LED displayAFQ

S52 Power supply: Over regeneration warning : 00EB (Axis name)

Details Over-regeneration detection level exceeded 80%.
- Reset methodAF*
- LED displayAFR

S52 Pw sply: Fan stop warning : 00EE (Axis name)

Details A cooling fan built in the power supply unit stopped.
- Reset methodAF*
- LED displayAFU

4. MCP Alarm (Y)

Y02 System alm: Process time over 0050

Details System alarm: Process time is over.

Remedy The software or hardware may be damaged. Contact the service center.
(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

Y02 SV commu er: CRC error 1 0051 0000

Details A communication error has occurred between controller and drive unit.

Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

Y02 SV commu er: CRC error 2 0051 0001

Details A communication error has occurred between controller and drive unit.

Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

Y02 SV commu er: Recv timing err 0051 0002

Details A communication error has occurred between controller and drive unit.

Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

Y02 SV commu er: Data ID error 0051 xy03

Details A communication error has occurred between controller and drive unit.

x: Channel No. (0 to)
y: Drive unit rotary switch No. (0 to)

Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

Y02 SV commu er: Recv frame No. 0051 xy04

Details A communication error has occurred between controller and drive unit.

x: Channel No. (from 0)
y: Drive unit rotary switch No. (from 0)

Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

I Alarms

4. MCP Alarm (Y)

Y02 SV commu er: Commu error 0051 x005

Details A communication error has occurred between controller and drive unit.
x: Channel No. (from 0)

Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

Y02 SV commu er: Connect error 0051 x006

Details A communication error has occurred between controller and drive unit.
x: Channel No. (from 0)

Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

Y02 SV commu er : Init commu error 0051 xy20

Details A communication error has occurred between controller and drive unit.
The drive unit could not shift to the initial communication run time and stopped.
x: Channel No. (from 0)
y: Drive unit rotary switch No. (from 0)

Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

Y02 SV commu er: Node detect error 0051 xy30

Details A communication error has occurred between controller and drive unit.
No response from drive unit to the request from NC when setting network configuration.
x: Channel No. (from 0)
y: Station No. (from 0)

Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

Y02 SV commu er: Commu not support 0051 xy31

Details A communication error has occurred between controller and drive unit.
Drive unit's software version doesn't support the communication mode that the controller requires.
x: Channel No. (from 0)
y: Station No. (from 0)

Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

Y02 Servo communication error : Transfer to buffer is not properly done. 0052 0001

Details Transfer to buffer is not properly done.

Remedy This suggests a software/hardware fault. Contact the service center.
(Note 1) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.
(Note 2) Station No. always shows "0" in the alarm details, because C70 has only one communication channel.

Y03 Drive unit unequipped axis name

Details The drive unit is not correctly connected.
Alphabet (axis name): Servo axis drive unit not mounted
1 to 4: PLC axis drive unit not mounted
S: No.1 spindle drive unit not mounted
T: No.2 spindle drive unit not mounted
M: No.3 spindle drive unit not mounted
N: No.4 spindle drive unit not mounted

Remedy Check the drive unit mounting state.
- Check the end of the cable wiring.
- Check for any broken wires.
- Check the connector insertion.
- The drive unit input power has not been ON.
- The drive unit axis No. switch is illegal.

Y05 Initial parameter error

Details There is a problem in the value set for the number of axes or the number of part systems.

Remedy Correct the value set for the following corresponding parameters: "#1001 SYS_ON (System validation setup)", "#1002 axisno (Number of axes)", "#1039 spinno (Number of spindles)", etc.

Y06 mcp_no setting error 0001

Details There is a skipped number in the channels.

Remedy Check the values set for the following parameters. "#1021 mcp_no (Drive unit I/F channel No. (servo))" "#3031 smcp_no (Drive unit I/F channel No. (spindle))"

Y06 mcp_no setting error 0002

Details There is a duplicate setting for random layout.

Remedy Check the values set for the following parameters. "#1021 mcp_no (Drive unit I/F channel No. (servo))" "#3031 smcp_no (Drive unit I/F channel No. (spindle))"

Y06 mcp_no setting error 0003

Details The drive unit fixed setting "0000" and random layout setting "*****" are both set.

Remedy Check the values set for the following parameters. "#1021 mcp_no (Drive unit I/F channel No. (servo))" "#3031 smcp_no (Drive unit I/F channel No. (spindle))"

Y06 mcp_no setting error 0004

Details The spindle/C axis "#1021 mcp_no (Drive unit I/F channel No. (servo))" and "#3031 smcp_no (Drive unit I/F channel No. (spindle))" are not set to the same values.

Remedy Check the values set for the following parameters. "#1021 mcp_no (Drive unit I/F channel No. (servo))" "#3031 smcp_no (Drive unit I/F channel No. (spindle))"

Y06 mcp_no setting error 0005

Details A random layout has been set while "#1154 pdoor" has been set to "1" in two-part system.

Remedy Check the values set for the following parameters. "#1021 mcp_no (Drive unit I/F channel No. (servo))" "#3031 smcp_no (Drive unit I/F channel No. (spindle))"

Y06 mcp_no setting error 0006

Details The channel No. parameter is not within the setting range.

Remedy Check the values set for the following parameters. "#1021 mcp_no (Drive unit I/F channel No. (servo))" "#3031 smcp_no (Drive unit I/F channel No. (spindle))"

Y07 Too many axes connected 0000 - Exceeded number of axes

Details The number of axes connected to each channel exceeds the maximum number of connectable axes.
The exceeded number of axes per channel is displayed as alarm No.
This alarm also occurs when the drive unit is connected only with the 2nd channel without connecting with the 1st channel.

Remedy Remove connected axes from the channel whose alarm No. is other than '0' for the number displayed as the alarm No. Keep the number of connected axes to or less than the maximum that can be connected.

(Note 1) The number of axes is limited per each drive unit interface channel.

(Note 2) Maximum number of axes that can be connected differs depending on whether or not an expansion unit is available or the setting of '#11012 16 axes for 1ch (Connecting 16 axes for 1ch)'.

With the expansion unit, up to eight axes can be connected to a channel. Without the expansion unit, up to eight axes are allowed when '#11012 16 axes for 1ch (Connecting 16 axes for 1ch)' is set to '0', sixteen axes when set to '1'.

(Note 3) If this alarm occurs, the alarm 'Y03 Message: Drive unit unequipped' will not occur.

(Note 4) This alarm is displayed taking precedence over the alarm 'Y08 Too many drive units connected' and 'Y09 Too many axisno connected'.

Y08 Too many drive units connected 0000 - 00FF

Details The number of drive units connected to each channel exceeds 8.
The exceeded number of drive units per channel is displayed as alarm No.

Remedy Remove drive units from the channel whose alarm No. is other than "0" for the number displayed as the alarm No. Keep the number of connected drive units to 8 or less.

(Note 1) The drive unit is not counted when all the axes connected to it are invalid.

(Note 2) If this alarm occurs, the alarm "Y03 Message: Drive unit unequipped" will not occur.

(Note 3) The alarm "Y07 Too many axes connected" and "Y09 Too many axisno connected" are displayed taking precedence over this alarm.

I Alarms

4. MCP Alarm (Y)

Y09 Too many axisno connected Exceeded number of axes

- Details** The No. of the axis (drive unit's rotary switch No.) connected to each channel is bigger than the No. allowed.
- Remedy** For the channel whose alarm No. is "1", keep the axis No. (drive unit's rotary switch No.) not bigger than the No. allowed.
(Note 1) The axis No. is limited per each drive unit interface channel.
(Note 2) The biggest allowed connected axis No. differs depending on whether or not an expansion unit is available or the setting of "#11012 16 axes for 1ch (Connecting 16 axes for 1ch)". The biggest connectable axis No. is as shown below.
With the expansion unit, axes No. '0' to '7' can be connected.
Without the expansion unit, axes No. '0' to '7' are allowed when '#11012 16 axes for 1ch (Connecting 16 axes for 1ch)' is set to '0', axes No. '0' to 'F' when set to '1'.
(Note 3) If this alarm occurs, the alarm "Y03 Message: Drive unit unequipped" will not occur.
(Note 4) This alarm is displayed taking precedence over the alarm "Y08 Too many drive units connected".
(Note 5) The alarm "Y07 Too many axes connected" is displayed taking precedence over this alarm.

Y11 Node Detect Err 8002 , 8300 xy00

- Details** Drive unit does not respond to the request from NC when the NC is turned ON.
Error No. shows the No. of communication phase at which the response stopped.
X: Channel No. (from 0)
Y: Station No. with the error (from 0)
- Remedy** The communication error may be caused by the drive unit software version that does not correspond to the NC software version. Check the drive unit software version. This alarm is canceled after the NC restarts. When the alarm is not canceled, write down the alarm No. and contact to the Service Center.

Y12 No commu. with axis drv unit

- Details** Although the high-speed synchronous tapping option is valid, the connected drive unit doesn't support the option.
- Remedy** Replace the drive unit with that supports the option.

Y13 No commu. with sp drv unit

- Details** Although the high-speed synchronous tapping option is valid, the connected drive unit doesn't support the option.
- Remedy** Replace the drive unit with that supports the option.

Y14 Comm btwn drives not ready

- Details** Communication between drive units failed to be ready within a specified time.
- Remedy** - Connection of drive units may be wrong.
- Check if any of drive units is broken.

Y20 Parameter compare error 0001 Axis name

- Details** The speed monitoring parameter in the NC does not correspond to the parameter transmitted to the drive unit.
The name of the axis with an error is displayed.
- Remedy** The NC or the servo drive unit may be damaged. Contact the service center.

Y20 Sfty obsrvation: Cmd spd err 0002 Axis name

- Details** The speed exceeding the speed set with the parameter was commanded during the speed monitoring mode.
The name of the axis with an error is displayed.
- Remedy** Check the speed monitoring parameter and the sequence program. Restart the NC.

Y20 Sfty obsrvation: FB pos err 0003 Axis name

- Details** The commanded position, transmitted to the servo drive unit from NC, is totally different from the feedback position received from the servo drive unit during the speed monitoring mode.
The name of the axis with an error is displayed.
- Remedy** The NC or the servo drive unit may be damaged. Contact the service center.

Y20 Sfty obsrvation: FB speed err 0004 Axis name

- Details** Actual rotation speed of the motor is exceeding the speed that has been set with speed monitoring parameter during the speed monitoring mode.
The name of the axis with an error is displayed.
- Remedy** Correct the speed observation parameter and the sequence program. Restart the NC.

Y20 Door signal: Input mismatch 0005 Door No.

- Details** Door state signals on the NC side and the drive side do not match. It may be caused by the followings:
- Cable disconnection
- Damaged door switch
- Damaged NC or servo drive unit
- Remedy** Check the cable. Check the door switch. Restart the NC.

Y20 No speed observation mode in door open 0006 Door No.

- Details** The door open state was detected when the speed monitoring mode was invalid.
The causes may be same as the ones for 0005 (Door signal: Input mismatch). Also the sequence program may not be correct.
- Remedy** Correct the sequence program. Restart the NC.

I Alarms

4. MCP Alarm (Y)

Y20 Speed obsv: Para incompatible 0007 Axis name

Details Two speed monitoring parameters are not matched at the rising edge of the "speed monitor mode" signal.
The name of the axis with an error is displayed.

Remedy Correct the relevant parameters so that the two speed monitoring parameters match. Restart the NC.

Y20 Contactor welding detected 0008 Contactor No.

Details Contactor welding was detected.

Remedy Make sure that contactor's auxiliary b contact signal is output correctly to the device set on "#1330 MC_dp1(Contactor weld detection device 1)" and "#1331 MC_dp2(Contactor weld detection device 2)". If welding, replace the contactor. Restart the NC.

Y20 No spec: Safety observation 0009

Details "#2313 SV113 SSF8/bitF (Servo function selection 8)" and "#13229 SP229 SFNC9/bitF (Spindle function 9)" are set for a system with no safety observation option.

Remedy Disable "#2313 SV113 SSF8/bitF (Servo function selection 8)" and "#13229 SP229 SFNC9/bitF (Spindle function 9)". Then, restart the NC.

Y20 SDIO connector input volt err 0010

Details 24VDC power is not supplied to SDIO connector correctly. (SDIO 4A pin supply voltage was dropped to 16V or less, or 1ms or more instant power interrupt was detected.)
In this case, "Pw sply:Inst pw interpt(DC24V)" alarm occurs because the contactor control output signal cannot be controlled.
This state remains until restarting the NC even if the cause of the alarm has been removed.

Remedy Check the wiring. Supply 24VDC power to the SDIO connector. Restart the NC.

Y20 Safety signal: compare error 0020 (Device No.)

Details The safety signals are not matched between PLC CPU and CNC CPU.

The following factors may cause the error.

- Cable is disconnected.
- Sensor is broken.

Alarm No. shows the device No. which has the error. ("0024" indicates the device No. X24.)

When two or more signals are detected for errors, the No. shows the first detected signal.

Remedy Check the wiring.

Y20 Safety signal: comparison ladder transfer error 0021 (Data transfer error code)

Details The request to transfer data from CNC CPU to PLC CPU was not successfully processed.
<Data transfer error code>

4029: The user ladder area does not have enough capacity for safety signal comparison ladder to be written in.

4031: Incorrect device size has been set in PC parameter.

Remedy <Data transfer error code> 4029: Check whether the user ladder area has enough capacity. If the area does not have enough capacity, decrease the number of steps in the user ladder and then restart the NC. 4031: Make sure that no change has been made to the device allocation settings of PC parameter. Correct the PC parameter and then restart the NC. Other than above: Contact the service center.

Y20 Safety signal: comparison ladder transfer timeout 0022 (Data request code)

Details A timeout error occurred at the data transfer request from CNC CPU to PLC CPU.
This error may occur when a file is being accessed by other devices such as GX Developer and GOT.

Remedy Disconnect the access by other devices and restart the NC.

Y20 Safety signal: comparison ladder compare error 0023

Details The safety signal comparison ladder written in PLC CPU is not matched with that in CNC CPU.

A fault of PLC CPU or CNC CPU may cause the error.

Remedy Contact the service center.

Y20 Safety signal: comparison stop (on PLC) 0024

Details Safety signal comparison stopped on PLC CPU.

The following factor may cause the error.

"SSU_CMP" is not entered in the [PLC parameter] - [Program] settings.

Remedy Correct the settings of PC parameter.

Y20 Safety signal: comparison stop (on NC) 0025

Details Safety signal comparison stopped on CNC CPU.

Remedy Contact the service center.

Y20 Safety signal: output/FB compare error 0026

Details The output signal from safety signal module is not matched with the feedback signal.

The following factor may cause the error.

- The safety signal module is not supplied with 24VDC.

Remedy Supply 24VDC to the safety signal module. Make sure that the safety signal output is successfully done, and then restart the NC. If the error is not cleared by these measures, the safety signal module may have a fault. Replace the module.

I Alarms

4. MCP Alarm (Y)

Y20 Safety signal: parameter setting error 0027

- Details** The parameter settings are incorrect.
Parameters to check:
"#21125 SSU_num (Number of safety signal units)"
"#21143 SSU_Dev1 (Safety signal unit device1)" to "#21145 SSU_dev3 (Safety signal unit device3)"
- Remedy** Correct the parameter settings.

Y20 Safety signal: parameter compare error 0028

- Details** Parameters have not been successfully transferred from CNC CPU to PLC CPU.
Parameters to check:
"#21125 SSU_num (Number of safety signal units)"
"#21142 SSU_delay (Safety signal compare tolerance time)"
"#21143 SSU_Dev1 (Safety signal unit device1)" to "#21145 SSU_dev3 (Safety signal unit device3)"
- Remedy** Contact the service center.

Y20 Safety signal: comparison ladder read error 0029

- Details** The controller, when turned ON, cannot read the safety signal comparison ladder correctly from the FROM of CNC CPU.
- Remedy** Contact the service center.

Y20 Safety signal: comparison ladder read error 0030 (Unconfirmed module to be mounted)

- Details** Some of the safety signal modules in the parameter "#21125 SSU_num (Number of safety signal units)" are not confirmed to be mounted.
Alarm No. shows the unconfirmed module to be mounted at the bit-level.
("0006" indicates the module No.2 and 3.)
- Remedy** Make sure that the safety signal modules entered in the parameter are all mounted. Make sure that the remote I/O cable is connected. Check for any overlapped station No. set with rotary switch of safety signal module.

Y20 Safety observation: parameter memory error 0031 (Parameter No.)

- Details** Parameter "#21125 SSU_num (Number of safety signal units)" and "#21142 SSU_delay (Safety signal compare tolerance time)" are not consistent with the check data.
- Remedy** Correct the parameter settings.

Y21 Speed obsv signal: Speed over 0001 (Axis name)

- Details** The speed exceeds the safety speed limit when the "speed monitor mode" signal is ON. The name of the axis with an error is displayed.
- Remedy** Decelerate the speed to reset the warning and start the speed monitor.

Y21 Safety signal: State after error unconfirmed 0020 (Device No.)

- Details** A safety signal comparison error was detected.
Some of the signal inputs from PLC CPU and NC CPU have not been confirmed since the power was turned ON again.
- Remedy** Remove the fault of the signal that caused the signal comparison error. Then restart the controller and turn ON/OFF the signals in the observation signal comparison state. If you do not use the safety signal with the error, reset the NC to clear the alarm.

Y51 Parameter G0tL illegal 0001

- Details** The time constant has not been set or exceeded the setting range.
- Remedy** Correct "#2004 G0tL (G0 time constant (linear))".

Y51 Parameter G1tL illegal 0002

- Details** The time constant has not been set or exceeded the setting range.
- Remedy** Correct "#2007 G1tL (G1 time constant (linear))".

Y51 Parameter G0t1 illegal 0003

- Details** The time constant has not been set or exceeded the setting range.
- Remedy** Correct "#2005 G0t1 (G0 time constant(primary delay) / Second-step time constant for soft acceleration/deceleration)".

Y51 Parameter G1t1 illegal 0004

- Details** The time constant has not been set or exceeded the setting range.
- Remedy** Correct "#2008 G1t1 (G1 time constant (primary delay)/Second-step time constant for soft acceleration/deceleration)".

Y51 Parameter grid space illegal 0009

- Details** The grid space is illegal.
- Remedy** Correct "#2029 grspc(Grid interval)".

Y51 Parameter stapt1-4 illegal 0012

- Details** The time constant has not been set or exceeded the setting range.
- Remedy** Correct the parameters from "#3017 stapt1(Tap time constant (Gear: 00))" to "#3020 stapt4(Tap time constant (Gear: 11))".

I Alarms

4. MCP Alarm (Y)

Y51 Slave axis No. illegal 0014

Details In the axis synchronization, parameter settings for slave axis have been attempted in different part system from that of master axis.

Remedy - Correct the "#1068 slavno (Slave axis number)" setting.

Y51 Parameter skip_tL illegal 0015

Details The time constant has not been set or exceeded the setting range.

Remedy Correct "#2102 skip_tL (Skip time constant linear)".

Y51 Parameter skip_t1 illegal 0016

Details The time constant has not been set or exceeded the setting range.

Remedy Correct "#2103 skip_t1 (Skip time constant primary delay / Second-step time constant for soft acceleration/deceleration)".

Y51 Parameter G0bdcc illegal 0017

Details "#1205 G0bdcc (Acceleration and deceleration before G0 interpolation)" for the 2nd part system is set to acceleration/deceleration before G0 interpolation.

Remedy Correct "#1205 G0bdcc (Acceleration and deceleration before G0 interpolation)".

Y51 OMR-II parameter error 0018

Details An illegal setting was found in the OMR-II-related parameters. OMR-II has been disabled.

Remedy Correct the related parameter settings.

Y51 PLC indexing stroke length err 0019

Details "#12804 aux_tleng (Linear axis stroke length)" has not been set or exceeded the setting range while the linear axis equal indexing is enabled for the PLC indexing axis.

Remedy Correct "#12804 aux_tleng (Linear axis stroke length)".

Y51 No hi-accu acc/dec t-const ext 0020

Details There is no expansion option for the high-accuracy acceleration/deceleration time constant.

Remedy Set "#1207 G1btL (Time constant)" to a value within the setting range with no expansion specification for the extended high-accuracy time constant.

Y51 Values of PC1/PC2 too large 0101

Details The PC1 and PC2 settings for the rotary axis are too large.

Remedy Correct "#2201 SV001 PC1 (Motor side gear ratio)" and "#2202 SV002 PC2 (Machine side gear ratio)".

Y90 No spindle signal 0001-0007

Details There is an error in the spindle encoder signal.
The data transmission to the drive unit is stopped when this error occurs.

Remedy Check the spindle encoder's feedback cable and the encoder.

5. System Alarms (Z)

Z31 Socket open error(socket) 0001

Details Socket open error (socket)

Remedy Set the parameter then turn the power OFF and ON again.

Z31 Socket bind error(bind) 0002

Details Socket bind error (bind)

Remedy Set the parameter then turn the power OFF and ON again.

Z31 Connection wait queue error(listen) 0003

Details Connection wait queue error (listen)

Remedy Set the parameter then turn the power OFF and ON again.

Z31 Connection request error(accept) 0004

Details Connection request error (accept)

Z31 Data recv error(socket error) 0005

Details Data receive error (socket error)

Z31 Data recv error(data error) 0006

Details Data receive error (data error)

Z31 Data send error(socket error) 0007

Details Data send error (socket error)

Z31 Data send error(data error) 0008

Details Data send error (data error)

Z31 Socket close error(close) 000A

Details Socket close error (close)

Remedy Set the parameter then turn the power OFF and ON again.

Z40 Format mismatch

Details "#1052 MemVal (No. of common variables shared in part system designation)", formatted at "0", was set to "1".

Remedy - Reset "#1052 MemVal (No. of common variables shared in part system designation)" to "0" or format and restart.

Z51 EEPROM ERROR

Details The data read from EEPROM does not coincide with the data that has been written into it.

Remedy - If the same alarm occurs with the same operation, a hardware fault may be the cause. Contact the service center.

Z52 Battery fault 000x

Details The voltage of the battery in the NC control unit has dropped. (The battery used to save the internal data.)

0001: Battery warning

0002: Battery detecting circuit error

0003: Battery alarm

(Note)The display of "Z52 battery fault 0001" can be removed by resetting. However, the warning state will not be cleared until the battery is replaced.

Remedy - Replace the battery of the NC control unit.
- Check for any disconnection of the battery cable.
- After fixing the battery's fault, check the machining program.

Z53 CNC overheat

Details The controller or operation board temperature has risen above the designated value. (Note) Temperature warning

When an overheat alarm is detected, the alarm is displayed and the overheat signal is output simultaneously. Automatic operation will be continued, while restarting after resetting or stopping with M02/M30 is not possible. (Restarting after block stop or feed hold is possible.) The alarm will be cleared and the overheat signal will turn OFF when the temperature drops below the specified temperature.

Z53 CNC overheat 000x

[000x]

0001: The temperature in the control unit is high.

0002: The temperature around the communication terminal (setting and display unit) is high.

0003: The temperature in the control unit and around the communication terminal (setting and display unit) is high.

The ambient temperature must be lowered immediately when a "Z53 CNC overheat" alarm occurs. However, if the machining needs to be continued, set "0" for "#6449/bit6(Communication terminal overheat detected)" and "#6449/bit7(Control unit overheat detected)". Then the alarm will be invalidated.

Remedy - Cooling measures are required.
- Turn OFF the controller power, or lower the temperature with a cooler, etc.

Z55 RIO communication stop

Details

An error occurs in the communication between the control unit and remote I/O unit.
Disconnection of a cable
Fault in remote I/O unit fault
Fault of power supply to remote I/O unit
The alarm and the I/O unit No. is displayed when an error occurs in the communication between the control unit and remote I/O unit.
The remote I/O unit No. is displayed in eight digits. Two digits are used for each board and part system.
[Display format of remote I/O unit No.]
Z55 RIO communication stop

(a) (b) (c) (d)(e) (f) (g) (h)

(a)(b): Remote I/O 2nd part system communication interrupted station
(c)(d): Remote I/O 1st part system communication interrupted station
(e)(f): Remote I/O 3rd part system communication interrupted station
(g)(h): Board connection remote I/O communication interrupted station
(a)(b) indicates the following station in hexadecimal.
bit0: RIO (0th station)
bit1: RIO (first station)
bit2: RIO (second station)
bit3: RIO (third station)
bit4: RIO (fourth station)
bit5: RIO (fifth station)
bit6: RIO (sixth station)
bit7: RIO (seventh station)

This also applies for the remote I/O 1st part system communication interrupted station, remote I/O 3rd part system communication interrupted station and board connection remote I/O communication interrupted station.

Remedy

- Check and replace the cables.
- Replace the remote I/O unit.
- Check the power supply (existence of supply and voltage).

Z57 System warning

Details

Program memory capacity has been set over the value that can be formatted.
An expansion cassette (HR437) has not mounted after formatting.
The mounted expansion cassette is different from the one (HR437) that was mounted at formatting.

Remedy

- Check the followings.
- Program memory capacity
 - Mounting of an expansion cassette (HR437)
 - APLC release option

Z58 ROM write not completed

Details

A machine tool builder macro program has not been written to FROM after being registered/ edited/ copied/ condensed/ merged/ the number changed/ deleted.

Remedy

- Write the machine tool builder macro program to FROM.
- The program does not need to be written to FROM unless the editing operations and so on need to be valid after the NC power OFF.

Z59 Acc/dec time cnst too large

Details

Acceleration and deceleration time constants are too large.
(This alarm is output at the same time as "T02 0206".)

Remedy

- Set the larger value for "#1206 G1bF(Maximum speed)".
- Set the smaller value for "#1207 G1btL(Time constant)".
- Set the lower feedrate.

Z60 Fieldbus communication error n1 n2 n3 n4

Details

A communication error has occurred on the Fieldbus communication with HN571/HN573/HN575.

[n1 :Shows state of the master channel (shown in hexadecimal number)]
00 :Offline In initializin
40 :Stop Cutting I/O communication
80 :Clear Resetting output data of each slave by sending 0 data.
C0 :In operation I/O In I/O communication
[n2 :Shows error state (shown in hexadecimal number)]
bit0 :Control error Parameter error
bit1 :Auto clear error Communication with all the slave channels was cut because a communication with one slave channel had an error.
bit2 :Non exchange error Slave channel with communication error is found.
bit3 :Fatal error The communication cannot be continued because sever network failure exists.
bit4 :Event error Short-circuit was found on the network.
bit5 :Not ready CNC communication is not ready.
bit6 :Time out error Time out was detected in communication with each channel.
bit7 :Not used
[n3 :Shows error No. (shown in hexadecimal number)]
- Error in master channel (when remote address with an error is FF (hexadecimal number))
0 :No error Operating normally
32 :No USR_INT Damage in HN571. Replace HN571.
33 :No global data field
34 :No FDL-task
35 :No PLC-task
37 :Master parameter incorrect
39 :Slave parameter incorrect
3C :Data offset exceeding allowable set value received Check the configuration setting.
3D :Slave data send range overlap
3E :Slave data receive range overlap
3F :Not set data hand shake Damage in HN571. Replace HN571.
40 :RAM range exceeded
41 :Slave parameter data set illegal
CA :No segment
D4 :Data base read illegal Download the configuration data again.
D5 :Operating system illegal Damage in HN571. Replace HN571.
DC :Watch dog error
DD :Hand shake mode No data communication by 0
DE :Master auto clear mode When setting auto clear mode, the auto clear mode was performed because one slave was not able to connect in run time.
- Error in slave channel (when remote address with an error is other than FF (hexadecimal number))
Check the configuration of slave channel in which error has occurred. Check if there is any short-circuit in wire to bus.
2 :Station overflow reported
3 :Station stopped responding to master command
9 :No slave required responding data
11 :No station respond
12 :No master to logical token ring
15 :Illegal parameter requested
[n4 : Shows slave No. where communication error has occurred. (shown in hexadecimal number)]
'FF' means an error in master channel.

Z64 Valid term soon to be expired xx

Details

The valid term will be expired in less than a week. Remaining valid term is xx days.

Remedy

- Obtain a decryption code by making a payment. Enter the decryption code.

Z65 Valid term has been expired

Details

The valid term has been expired with no decryption code input.

Remedy

- Obtain a decryption code by making a payment. Enter the decryption code.

Z67 CC-Link communication error

Details

A communication error occurred during CC-Link communication using CC-Link unit.

Remedy

- Refer to "List of Messages" in CC-Link (Master/Slave) Specification manual (BNP-C3039-214).

Z68 CC-Link unconnected

Details

A cable between CC-Link unit and a device is disconnected or broken.

Remedy

- Connect the cable.
- Check for any broken cables.

6. Absolute Position Detection System Alarms (Z7*)

Z70 Abs posn base set incomplete 0001 (Axis name)

Details Zero point initialization is incomplete. Otherwise, the spindle was removed.

Remedy Complete zero point initialization.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Required

Z70 Absolute position lost 0002 (Axis name)

Details The absolute position basic point data saved in the NC has been damaged.

Remedy Set the parameters. If the basic point data is not restored by setting the parameters, perform zero point initialization.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: (Required)

Z70 Abs posn param changed 0003 (Axis name)

Details Any of the parameters for absolute position detection has been changed.

#1003 iunit
#1016 iout
#1017 rot
#1018 ccw
#1040 M_inch
#2049 type
#2201 PC1
#2202 PC2
#2218 PIT
#2219 RNG1
#2220 RNG2
#2225 MTPP

Remedy Correct the parameter settings. Then turn the power ON again and perform zero point initialization.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Required

Z70 Abs posn initial set illegal 0004 (Axis name)

Details The zero point initialization point is not at the grid position.

Remedy Perform the zero point initialization again.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Required

Z70 Abs posn param restored 0005 (Axis name)

Details The data has been restored by inputting the parameters during the alarm No.0002.

Remedy Turn the power ON again to start the operation.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Not required

Z70 Abs data error 0006

Details Deviation of the servo axis with scale when the power is OFF exceeds the set value in "#2051 check (Check)".

Remedy Search for the factor which led the deviation of the servo axis at the power OFF.

- Zero point initialization: Not required
- Alarm reset when power is turned OFF: -
- Servo alarm No.: -

Z70 Abs posn data lost 0080 (Axis name)

Details The absolute position data has been lost. An error of the multi-rotation counter data in the detector and so on may be the cause.

Remedy Replace the detector and complete zero point initialization.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Required
- Servo alarm No.: (9E)etc.

Z70 Abs posn error(servo alm 25) 0101 (Axis name)

Details The servo alarm No. 25 was displayed and the power was turned ON again.

Remedy Perform zero point initialization again.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Required
- Servo alarm No.: -25

Z70 Abs posn error(servo alm E3) 0106 (Axis name)

Details The servo alarm No. E3 was displayed and the power was turned ON again.

Remedy Perform zero point initialization again.
 (Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Required
- Servo alarm No.: (E3)

Z71 AbsEncoder:Backup voltage drop 0001 (Axis name)

Details Backup voltage in the absolute position detector dropped.

Remedy Replace the battery, check the cable connections, and check the detector. Turn the power ON again and perform zero point initialization.

- Zero point initialization: Required
- Alarm reset when power is turned OFF: -(Z70-0101 is displayed after the power is turned ON again.)
- Servo alarm No.: 25

Z71 AbsEncoder: Commu error 0003 (Axis name)

Details Communication with the absolute position detector has been disabled.

Remedy Check and replace the cables, card or detector. Turn the power ON again and perform zero point initialization.

- Zero point initialization: (Required) only when the detector has been replaced.
- Alarm reset when power is turned OFF: Reset
- Servo alarm No.: 91

Z71 AbsEncoder: Abs data changed 0004 (Axis name)

Details Absolute position data has been changed at the absolute position establishment.

Remedy Check and replace the cables, card or detector. Turn the power ON again and perform zero point initialization.

- Zero point initialization: (Required) only when the detector has been replaced.
- Alarm reset when power is turned OFF: Reset
- Servo alarm No.: 93

Z71 AbsEncoder: Serial data error 0005 (Axis name)

Details An error of the serial data was found in the absolute position detector.

Remedy Check and replace the cables, card or detector. Turn the power ON again and perform zero point initialization.

- Zero point initialization: (Required) only when the detector has been replaced.
- Alarm reset when power is turned OFF: Reset
- Servo alarm No.: 92

Z71 AbsEncoder: Abs/inc posn diffr 0006 (Axis name)

Details Servo alarm E3
 Absolute position counter warning

Remedy Operation is possible until the power is turned OFF.

- Zero point initialization: (Required) after the power is turned ON again.
- Alarm reset when power is turned OFF: Reset (Z70-0106 is displayed after the power is turned ON again.)
- Servo alarm No.: E3

Z71 AbsEncoder: Initial commu er 0007 (Axis name)

Details Initial communication with the absolute position detector is not possible.

Remedy Check and replace the cables, card or detector. Turn the power ON again and perform zero point initialization.

- Zero point initialization: (Required) only when the detector has been replaced.
- Alarm reset when power is turned OFF: Reset
- Servo alarm No.: 18

Z72 Message: Position check error (Axis name)

Details An error is detected at the comparison of detector's absolute position and controller coordinate values in the absolute position detection system.

Remedy

Z73 Battery for abs data fault 0001 (Axis name)

Details Servo alarm 9F
 Low battery voltage

Remedy This is displayed when the battery voltage is 0 low or the cable has been damaged. The absolute position initialization is not required.
 (Note) When this alarm has occurred, do not turn OFF the drive unit power in order to protect the absolute position data. Replace the battery with the drive unit power ON.

7. Distance-coded Reference Scale Errors (Z8*)

Z80 Basic position lost 0001

Details The basic point data saved in the NC has been damaged.

Remedy - Set the parameters. If the basic point data is not restored by setting the parameters, perform zero point initialization.

Z80 Basic position restore 0002

Details The basic point data has been restored by setting the parameters.

Remedy - Turn the power ON again to start the operation.

Z80 No spec: Distance-coded scale 0003

Details The distance-coded reference scale has been set available although this function is out of the specifications.

Remedy - Check the specifications.
- If you do not use this function, correct the detector type with the servo parameter.

Z81 R-pos adjustment data lost 0001

Details Reference position adjustment value data saved in the NC has been damaged.

Remedy - Set the parameter. If the data is not restored by setting the parameter, establish the reference position again.

Z81 R-pos adjustment data restored 0002

Details After the 'Z81 R-pos adjustment data lost 0001', the data has been recovered by setting the parameter.

Remedy - Establish the reference position to start the operation.

8. Messages during Emergency Stop (EMG)

EMG Emergency stop PLC

- Details** The user PLC has entered the emergency stop state during the sequence process.
Remedy - Investigate and remove the cause of the user PLC emergency stop.

EMG Emergency stop EXIN

- Details** The "emergency stop" signal is significant (open).
Remedy - Cancel the "emergency stop" signal.
- Check for any broken wires.

EMG Emergency stop SRV

- Details** An alarm occurred in the servo system causing an emergency stop.
Remedy - Investigate and remove the cause of the servo alarm.

EMG Emergency stop STOP

- Details** The user PLC (ladder sequence) is not running.
Remedy - Check the setting of the control unit rotary switch CS2. Correct it if set to "1".
- Check the [RUN/SP] (run/stop) switch on the PLC edit file save screen (onboard function). Turn it OFF if ON.

EMG Emergency stop SPIN

- Details** Spindle drive unit is not mounted.
Remedy - Cancel the causes of the other emergency stop.
- Check the "emergency stop" signal input in the spindle drive unit.

EMG Emergency stop PC_H

- Details** Failure in the high-speed PC processing abnormal
Remedy - Correct the sequence program. (To stop monitoring the high-speed PC processing temporarily, set "1" in "#1219 aux03/bit1 (Stop high-speed PC monitoring function)". Disable the monitoring function only as a temporary measure.)

EMG Emergency stop PARA

- Details** Setting of the door open II fixed device is illegal.
Setting of the parameters for dog signal random assignment is illegal.
Remedy - Correct the "#1155 DOOR_m" and "#1156 DOOR_s" settings. (When the door open II fixed device is not used, set "#1155 DOOR_m" and "#1156 DOOR_s" to "100".)
- Correct the "#2073 zrn_dog (Origin dog Random assignment device)", "#2074 H/W_OT+ (H/W OT+ Random assignment device)", "#2075 H/W_OT- (H/W OT- Random assignment device)" and "#1226 aux10/bit5 (Arbitrary allocation of dog signal)" settings.

EMG Emergency stop LINK

- Details** An emergency stop occurs when the FROM/TO instruction is not executed within 500 ms.
Remedy - Execute the FROM/TO instruction one or more times every 500 ms.
* The time in which no interrupt request is issued from MELSEC is measured and stored in the following R registers. R10190: Current timeout counter R10191: Maximum timeout counter after power ON R10192: Maximum timeout counter after system is started up (this is backed up)
Details MELSEC is in error and reset states.
Remedy - Check the MELSEC states.
Details The contents of MELSEC-specific code area in buffer memory have been damaged.
Remedy - Check the MELSEC states.
Details PLC serial link communication has stopped.
(Note) When "WAIT" is entered in the PLC serial link, only the preparation sequence has been established before the communication stops. It is supposed that the settings of the serial link parameters "#1902 Din size" and "#1903 Dout size" are incorrect or the "#1909 Tout (ini)" set-time is too short in basic specification parameters.
Remedy - Check the HR571 card wiring and the external sequencer transmission.
- Clear the link communication errors shown on the diagnostic screen.
- Correct the settings of the serial link parameters in basic specification parameters.

EMG Emergency stop WAIT

- Details** The preparation sequence is not sent from the master station. Otherwise, the contents of the received preparation sequence are inconsistent with those of the parameters, so that the usual sequence cannot be started.
(Note) When "LINK" is also entered for the PLC serial link, refer to "Note" in the section, "LINK".
Remedy - Check that the HR571 card rotary switch and wiring and the external sequencer transmission are normal.
- Check the diagnostic screen for link communication errors.

EMG Emergency stop XTEN

- Details** The HR571 card operates abnormally or the rotary switch is set incorrectly.
Remedy - Check the HR571 card rotary switch, and replace the HR571 card if required.

EMG Emergency stop LAD

- Details** The sequence program has an illegal code.
Remedy - Correct any illegal device Nos. or constants in the sequence program.

EMG Emergency stop CVIN

Details The "emergency stop" signal for power supply is significant (open) because the external emergency stop function for power supply is enabled.

Remedy

- Cancel the "emergency stop" signal.
- Check for any broken wires.

EMG Emergency stop MCT

Details The contactor shutoff test is being executed.

Remedy

- The emergency stop is reset automatically after the contactor shutoff is confirmed.
- If the contactor shutoff is not confirmed within 5 seconds after the "contactor shutoff test" signal (Y742) has been input, The alarm "Y20 Contactor welding detected" occurs and the emergency stop status remains.
- Make sure that the contactor's auxiliary b contact signal is correctly output to the device that is set in "#1330 MC_dp1 (Contactor weld detection device 1)" and "#1331 MC_dp2 (Contactor weld detection device 2)", and then turn the power ON again.

EMG Emergency stop IPWD

Details The data backup for power failure might not have been executed successfully at the previous power failure.

Remedy

- If this message appears frequently, the power supply may be deteriorated. Contact the service center.

EMG Emergency stop SUIN

Details The emergency stop input signal (M0) is OFF in the NC/PLC safety circuit.

Remedy

- Check the conditions for turning ON the emergency stop input signal.
- Check for any broken wires.

EMG Emergency stop STP2

Details Sequence programs stopped in CNC.

Remedy

- Correct the rotary switch 1 (on the right) of the control unit if set to "1".

EMG Emergency stop MULT

Details An error related to Q bus or Qr bus occurred.

Remedy

- Refer to the error No. that follows the message "A01 Multi CPU error" to take a remedy.

9. Auxiliary Axis Alarms

9.1 Aux ax servo alarm/warning (S)

S01 Aux ax PCB err (Drive circuit) 0011 (Axis No. 1 to 4)

Details An error occurred in the drive unit's internal PCB.

Remedy - Replace servo drive unit.

S01 Aux ax S/W processing error 0013 (Axis No. 1 to 4)

Details An error occurred in the drive unit's internal reference clock.

Remedy - Replace servo drive unit.

S01 Aux ax motor/detector type err 0016 (Axis No. 1 to 4)

Details Motor type error.

Remedy - Use a correct drive unit and motor combination.

Details Detector initial communication error.

Remedy - Connect correctly.
- Replace the motor.
- Replace or repair cable.

Details Detector CPU error.

Remedy - Replace the motor (detector).

S01 Aux ax PCB error(A/D err) 0017 (Axis No. 1 to 4)

Details An error occurred in the drive unit's internal A/D converter.

Remedy - Replace servo drive unit.

S01 Aux ax absolute posn lost 0025 (Axis No. 1 to 4)

Details An error occurred in the detector's internal absolute position data.

Remedy - Turn the power ON for 2 to 3 minutes while the alarm is occurring, and then turn the power ON again.
- Replace the battery, and initialize the absolute position again.

S01 Aux ax CRC error 0034 (Axis No. 1 to 4)

Details An error occurred in the communication with the NC.

Remedy - Take countermeasures against noise.

S01 Aux ax communication timeout 0036 (Axis No. 1 to 4)

Details Communication with the NC was cut off.

Remedy - Connect correctly.
- Turn the NC power ON.
- Replace the drive unit or NC.

S01 Aux ax parameter error 0037 (Axis No. 1 to 4)

Details The parameter setting value is incorrect.

Remedy - Set the parameter correctly.

S01 Aux ax frame error 0038 (Axis No. 1 to 4)

Details An error occurred in the communication with the NC.

Remedy - Take countermeasures against noise.

S01 Aux ax commu INFO error 0039 (Axis No. 1 to 4)

Details Undefined data was transferred from the NC.

Remedy - Change the NC software version to a compatible version.

S02 Aux ax PCB err (Drive circuit) 0011 (Axis No. 1 to 4)

Details An error occurred in the drive unit's internal PCB.

Remedy - Replace servo drive unit.

S02 Aux ax S/W processing error 0013 (Axis No. 1 to 4)

Details An error occurred in the drive unit's internal reference clock.

Remedy - Replace servo drive unit.

S02 Aux ax EEROM error 0015 (Axis No. 1 to 4)

Details A write error occurred to the EEROM in the drive unit.

Remedy - Replace servo drive unit.

S02 Aux ax PCB error(A/D err) 0017 (Axis No. 1 to 4)

Details An error occurred in the drive unit's internal A/D converter.

Remedy - Replace servo drive unit.

S02 Aux ax PCB error(LSI err) 0018 (Axis No. 1 to 4)

Details An error occurred in the drive unit's internal LSI.

Remedy - Replace servo drive unit.

I Alarms

9. Auxiliary Axis Alarms

S02 Aux ax detector error 0020 (Axis No. 1 to 4)

Details An error occurred in the communication between the servo drive unit and detector.

Remedy

- Connect correctly.
- Replace or repair cable.

S02 Aux ax ground fault detection 0024 (Axis No. 1 to 4)

Details A ground fault of the output was detected when the power was turned ON.

Remedy

- Repair the ground fault section.
- Replace the cable or motor.

S03 Aux ax under voltage 0010 (Axis No. 1 to 4)

Details The power voltage is 160V or less.

Remedy

- Review the power supply.
- Replace the servo drive unit.

S03 Aux ax regeneration error 0030 (Axis No. 1 to 4)

Details The tolerable regeneration power of the internal regenerative resistor or external regenerative option was exceeded.

Remedy

- Set the parameter #50002 correctly.
- Connect correctly.
- Lower the positioning frequency.
- Change the regenerative option to a larger capacity.
- Lower the load.
- Review the power supply.

Details Regenerative transistor error

Remedy

- Replace the servo drive unit.

S03 Aux ax overspeed 0031 (Axis No. 1 to 4)

Details The motor's rotation speed exceeded the tolerable momentary speed.

Remedy

- Increase the acceleration/ deceleration time constant.
- Review the gear ratio.
- Replace the detector.

S03 Aux ax overcurrent 0032 (Axis No. 1 to 4)

Details A current exceeding the servo drive unit's tolerable current flowed.

Remedy

- Repair the wiring.
- Replace the servo drive unit.
- Take countermeasures against noise.

S03 Aux ax overvoltage 0033 (Axis No. 1 to 4)

Details The voltage of the converter in the servo drive unit was 400V or more.

Remedy

- Wire correctly.
- Replace the servo drive unit.
- For the internal regenerative resistor, replace the drive unit.
- For the external regenerative option, replace the regenerative option.

S03 Aux ax motor overheating 0046 (Axis No. 1 to 4)

Details An operation state causing the motor to overheat continued.

Remedy

- Reduce the motor load.
- Review the operation pattern.

S03 Aux ax overload 1 0050 (Axis No. 1 to 4)

Details The servo drive unit or servomotor overload protection function activated.

Remedy

- Reduce the motor load.
- Review the operation pattern.
- Change to a motor or drive unit with large output.
- Change the setting of the automatic tuning response characteristics.
- Correct the connection.
- Replace the servomotor.

S03 Aux ax overload 2 0051 (Axis No. 1 to 4)

Details The max. output current flowed for several seconds due to a machine collision or overload.

Remedy

- Review the operation pattern.
- Change the setting of the automatic tuning response characteristics.
- Correct the connection.
- Replace the servomotor.

S03 Aux ax excessive error 0052 (Axis No. 1 to 4)

Details A position deflection exceeding the excessive error detection setting value occurred.

Remedy

- Increase the acceleration/ deceleration time constant.
- Increase the torque limit value.
- Review the power facility capacity.
- Review the operation pattern.
- Replace the servomotor.
- Connect correctly.
- Repair or replace the cable.

I Alarms

9. Auxiliary Axis Alarms

S52 Aux ax battery voltage drop 0092 (Axis No. 1 to 4)

Details The absolute position detection battery voltage dropped.

Remedy

- Mount a battery.
- Replace the battery and initialize the absolute position.

S52 Aux ax overregeneration warning 00E0 (Axis No. 1 to 4)

Details The regeneration power may have exceeded the tolerable range of the built-in regenerative resistor or external regenerative option.

Remedy

- Lower the positioning frequency.
- Change the regenerative option to a larger one.
- Lower the load.

S52 Aux ax overload warning 00E1 (Axis No. 1 to 4)

Details The overload alarm 1 could occur.

Remedy - Refer to the items for S03 0050.

S52 Aux ax abs position counter warning 00E3 (Axis No. 1 to 4)

Details There is an error in the absolute position detector internal data.

Remedy

- Take countermeasures against noise.
- Replace the servomotor.

S52 Aux ax main circuit OFF warning 00E9 (Axis No. 1 to 4)

Details The servo ON signal was input while the main circuit power was OFF.
The contactor operation is faulty.

Remedy - Turn ON the main circuit power.

9.2 Aux ax abs position error (Z)

Z70 Aux ax abs posn base set incomplete 0001 (Axis No. 1 to 4)

Details The zero point (reference point) has not been initialized in the absolute position system.

Remedy - Initialize the zero point (reference point).

Z70 Aux ax absolute position lost 0002 (Axis No. 1 to 4)

Details The absolute position coordinate data in the drive unit has been lost.

Remedy - Initialize the zero point (reference point).

Z70 Aux ax abs posn param changed 0003 (Axis No. 1 to 4)

Details The absolute position system related parameters have been changed or lost.

Remedy - Correctly set the parameters and then initialize the zero point (reference point).

Z71 Aux ax abs encoder: back up voltage drop 0001 (Axis No. 1 to 4)

Details The data in the detector has been lost.
Battery voltage drop.
Detector cable wire breakage or looseness.

Remedy - Check the battery and detector cable and then initialize the zero point (reference point).

Z73 Aux ax battery for abs data fault 0001 (Axis No. 1 to 4)

Details Battery voltage drop.
Detector cable wire breakage or looseness.

Remedy - Check the battery and detector cable. The zero point does not need to be initialized.

Z73 Aux ax absolute position counter warning 0003 (Axis No. 1 to 4)

Details An error occurred in the detector's absolute position counter.

Remedy - Replace the detector.

9.3 Aux ax operation error (M)

M00 Aux ax dog overrun 0001 (Axis No. 1 to 4)

Details When executing dog-type reference position, the zero point return speed is too fast or the dog length is too short.

Remedy - Lower the zero point return speed or increase the dog length.

M00 Aux ax R-pnt direction illegal 0003 (Axis No. 1 to 4)

Details When executing reference position return, the axis was moved in the opposite of the designated direction.

Remedy - Move the axis in the correct direction.

M00 Aux ax external interlock 0004 (Axis No. 1 to 4)

Details The axis interlock function is valid.

Remedy - Cancel the interlock signal

M00 Aux ax internal interlock 0005 (Axis No. 1 to 4)

Details An interlock was established by the servo OFF function.

Remedy - Cancel the servo OFF.

M00 Aux ax soft limit 0007 (Axis No. 1 to 4)

Details The soft limit was reached.

Remedy - Check the soft limit setting and machine position

M00 Aux ax R ret invld at abs alm 0024 (Axis No. 1 to 4)

Details Reference position return was executed during an absolute position alarm.

Remedy - Initialize the absolute position reference point and then fix the absolute position coordinates.

M00 Aux ax R ret invld at ini 0025 (Axis No. 1 to 4)

Details Reference position return was executed while initializing the absolute position.

Remedy - Initialize the absolute position reference point and then fix the absolute position coordinates.

M01 Aux ax no operation mode 0101 (Axis No. 1 to 4)

Details The operation mode is not designated, or the operation mode was changed during axis movement.

Remedy - Correctly designate the operation mode.

M01 Aux ax feedrate 0 0103 (Axis No. 1 to 4)

Details The operation parameter's feedrate setting is zero.
The operation parameter feedrate setting is zero.
Or, the override is valid, and the override value is zero.

Remedy - Set a value other than zero in the feedrate setting or override value.

M01 Aux ax sta No. illegal 0160 (Axis No. 1 to 4)

Details A station No. exceeding the No. of indexed divisions was designated.

Remedy - Correctly designate the station No.

M01 Aux ax R-pnt ret incomplete 0161 (Axis No. 1 to 4)

Details Automatic/manual operation was started before reference position return was executed with the incremental system.

Remedy - Execute the reference position return.

M01 Aux abs position initializing 0162 (Axis No. 1 to 4)

Details The start signal was input while initializing the absolute position reference point.

Remedy - Complete the absolute position reference point initialization.

M01 Aux ax abs position error 0163 (Axis No. 1 to 4)

Details The start signal was input during an absolute position alarm.

Remedy - Initialize the absolute position reference point and then fix the absolute position coordinates.

M01 Aux ax arbitrary positioning 0164 (Axis No. 1 to 4)

Details The manual operation mode was started during the random positioning mode.

Remedy - Turn the random positioning mode OFF before switching to the manual operation mode.

M01 Aux uneven index sta No. ilgl 0165 (Axis No. 1 to 4)

Details The commanded station No. was higher than 9 or the number of indexing stations during uneven indexing.

Remedy - Check the commanded station No. and the parameter "#50100 station" setting.

9.4 Auxiliary axis MCP alarms (Y)

Y02 Aux ax sys alm: Proc time over 0050

Details Aux ax sys alm: Proc time over

Remedy The software or hardware may be damaged. Contact the service center.

Y02 Aux ax commu er:CRC error 1 0051 0000

Details Aux ax commu er:CRC error 1(10 times/910.2ms)

Remedy

- A communication error has occurred between the controller and drive unit.
- Take measures against noise.
- Check that the communication cable connector between the controller and drive unit and one between the drive unit are tight.
- Check whether the communication cable between the controller and drive unit and one between the drive units are disconnected.
- A driving drive unit may be faulty. Take a note of the 7-segment LED contents of each driving drive unit and report to the Service Center.

Y02 Aux ax commu er:CRC error 2 0051 0001

Details Aux ax commu er:CRC error 2(2 continuous times)

Remedy

- A communication error has occurred between the controller and drive unit.
- Take measures against noise.
- Check that the communication cable connector between the controller and drive unit and one between the drive unit are tight.
- Check whether the communication cable between the controller and drive unit and one between the drive units are disconnected.
- A driving drive unit may be faulty. Take a note of the 7-segment LED contents of each driving drive unit and report to the Service Center.

Y02 Aux ax commu er:Recv timing 0051 0002

Details Aux ax commu er:Recv timing(2 continuous times)

Remedy

- A communication error has occurred between the controller and drive unit.
- Take measures against noise.
- Check that the communication cable connector between the controller and drive unit and one between the drive unit are tight.
- Check whether the communication cable between the controller and drive unit and one between the drive units are disconnected.
- A driving drive unit may be faulty. Take a note of the 7-segment LED contents of each driving drive unit and report to the Service Center.

Y02 Aux ax commu er:Data ID 0051 xx03

Details Aux ax commu er:Data ID(2 continuous times)
xx: Axis No.

Remedy

- A communication error has occurred between the controller and drive unit.
- Take measures against noise.
- Check that the communication cable connector between the controller and drive unit and one between the drive unit are tight.
- Check whether the communication cable between the controller and drive unit and one between the drive units are disconnected.
- A driving drive unit may be faulty. Take a note of the 7-segment LED contents of each driving drive unit and report to the Service Center.

Y02 Aux ax commu er:Recv frame no. 0051 xx04

Details Aux ax commu er:Recv frame no.(2 continuous times)
xx: Axis No.

Remedy

- A communication error has occurred between the controller and drive unit.
- Take measures against noise.
- Check that the communication cable connector between the controller and drive unit and one between the drive unit are tight.
- Check whether the communication cable between the controller and drive unit and one between the drive units are disconnected.
- A driving drive unit may be faulty. Take a note of the 7-segment LED contents of each driving drive unit and report to the Service Center.

Y03 Aux ax drive unit unequipped (Axis No. 1 to 4)

Details bit correspondence (bit 0: 1st axis, bit 1: 2nd axis, bit 2: 3rd axis, bit 3: 4th axis)

Remedy

- Check the auxiliary axis drive unit mounting state.
- Check the end of the cable wiring.
- Check the cable for broken wires.
- Check the connector insertion.

The auxiliary axis drive unit input power is not being input. The auxiliary axis drive unit axis No. switch is illegal.

10. Computer Link Errors (L)

L01 Serial port being used -2

Details Serial port has already been opened or cannot be used.

Remedy

- Set the port not to shared by Anshin-net and so on.
- Correct the parameter settings for tape operation port.

L01 Timeout error -4

Details Communication ended with timeout.
(CNC has a 248-byte receive buffer. The time during which CNC receives 248 bytes exceeds the 'TIME-OUT' value set in the I/O device parameter.

Remedy

- Set a greater timeout value in the input/output device parameter.
- Check the software in HOST and make sure that the HOST transmits data in response to DC1(data request) from CNC.
- Set '#9614 START CODE' to '0'.

L01 Host ER signal OFF -10

Details ER signal in HOST (or DR signal in CNC) is not turned ON.

Remedy

- Check for any disconnected cable.
- Check for any broke wire.
- Make sure that the HOST power is turned ON.

L01 Parity H error -15

Details Communication ended with parity H.

Remedy

- Check the software in HOST and make sure that the data to be transmitted to CNC is ISO code.

L01 Parity V error -16

Details Communication ended with parity V.

Remedy

- Correct the data to transmit to CNC.

L01 Overrun error -17

Details CNC received 10 bytes or more data from HOST in spite of DC3 (request to stop data transfer) transmission from CNC to the HOST, which terminated the communication. CNC received 10 bytes or more data from HOST during the data transmission from CNC to the HOST.

Remedy

- Check the software in HOST and make sure that the HOST stops transmitting data within 10 bytes after receiving DC3.
- Correct the software in HOST not to transmit data such as a command or header to CNC during receiving a machining program.

11. User PLC Alarms (U)

U01 No user PLC - -

Details PLC program is not input.
(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.
(Note 2) Emergency stop (EMG) will be applied.

Remedy Download the PLC program with the format selected by the PLC environment selection parameters (bit selection "#51/bit4").

U10 Illegal PLC 0x0010 -

Details PLC scan time error
The scan time is 1 second or longer.
(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

Remedy Edit the PLC program to make the size smaller.

U10 Illegal PLC 0x0040 -

Details PLC program operation mode illegal
The downloaded PLC program is compatible with the designated mode.
(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.
(Note 2) Emergency stop (EMG) will be applied.

Remedy Turn the power ON again or download the PLC program with the same format as at the power ON.

U10 Illegal PLC 0x0080 -

Details GPPW ladder code error
(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.
(Note 2) Emergency stop (EMG) will be applied.

Remedy Download the PLC program with a correct GPPW format.

U10 Illegal PLC 0x008x -

Details PLC4B ladder code error
An illegal circuit was found in the PLC4B ladder.
bit1: PC medium-speed circuit illegal
bit2: PC high-speed circuit illegal
(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.
(Note 2) Emergency stop (EMG) will be applied.

Remedy Download the correct PLC4B format PLC program.

U10 Illegal PLC 0x0400 Number of ladder steps

Details Software illegal interrupt
An abnormal stop occurred in the PLC program process due to an illegal code for software command.
(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.
(Note 2) Emergency stop (EMG) will be applied.

Remedy Turn the power ON again. If the error is not reset, download the correct PLC program.

U10 Illegal PLC 0x800x Number of PLC program steps

Details Software exception
An abnormal stop occurred in PLC program process due to a bus error, etc.
bit0: BIN command operation error
bit1: BCD command operation error
(Note) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

Remedy Refer to the methods for using the BCD and BIN function commands.

Details Software exception
An abnormal stop occurred in PLC program process due to a bus error, etc.
bit6: CALL/CALLS/RET command error
bit7: IRET command execution error
(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.
(Note 2) Emergency stop (EMG) is applied for bit6/7.

Remedy Turn the power ON again. If the error is not reset, download the correct PLC program.

I Alarms

11. User PLC Alarms (U)

U50 PLC stopped

Details The PLC program is stopped.
(Note) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

Remedy Start the PLC program.

U55 PLC stopped / is not saved

Details The PLC program is stopped and not written into ROM.
(Note) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

Remedy Write the PLC program into ROM.

U60 Ladder is not saved

Details The PLC program is not written into ROM.
(Note) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

Remedy Write the PLC program into ROM.

12. Network Service Errors (N)

N001 Modem initial error

Details An error occurred in the modem connection at the power ON.

Remedy - Check the connection between the NC and modem, connection port and power supply to modem.

N002 Redial over

Details - The number of redials exceeded due to the dial transmission failure.

Remedy - Wait a while, and then dial again.

N003 TEL unconnect

Details - The phone line is not connected.

Remedy - Check for any disconnection in the modem's phone line.

N004 Net communication error

Details - An error other than the above occurred during communication.

Remedy - Note down how the error occurred and contact the service center.

N005 Invalid net communication

Details - The modem connection port is being used for another function such as input/output.
- The modem connection port settings are incorrect.

Remedy - Stop using the modem connection port with the other function, and then turn the power ON again.
- Correct the settings of the modem connection port.

N006 Received result of diagnosis

Details - A diagnosis data file has been received.

Remedy - Clear the message.

N007 Send data size over

Details - A file larger than Anshin-net server capacity (64Kbyte) has been transmitted in machining data sharing.

Remedy - Reduce the size of machining program file so that it won't exceed the capacity of Anshin-net server.

N008 No file on server

Details - The file reception failed in machining data sharing because no file exists on Anshin-net server.

Remedy - Confirm that a machining program file exists on Anshin-net server before receiving it.

N009 Password error

Details - The file reception failed in machining data sharing due to a wrong password.

Remedy - Input the password again.

N010 Customer number error

Details - The file reception failed in machining data sharing due to a wrong customer number.

Remedy - Input the customer number again.

N011 Storage capacity over

Details - The file reception failed in machining data sharing because the size of the file to be received is bigger than free space in the NC.

Remedy - Ensure sufficient free space in the NC.

N012 File deletion error

Details - A file on Anshin-net server cannot be deleted in machining data sharing.

Remedy - Confirm that the file exists on Anshin-net server.
- Note down how the error occurred and contact the service center.

13. Program Errors (P)

P10 No. of simultaneous axes over

Details The number of axis addresses commanded in a block exceeds the specifications.

Remedy
- Divide the alarm block command into two.
- Check the specifications.

P11 Illegal axis address

Details The axis address commanded by the program does not match any of the ones set by the parameter.

Remedy - Correct the axis names in the program.

P20 Division error

Details The issued axis command cannot be divided by the command unit.

Remedy - Correct the program.

P29 Not accept command

Details The normal line control command (G40.1, G41.1, G42.1) has been issued during the modal in which the normal line control is not acceptable.

Remedy - Correct the program.

P30 Parity H error

Details The number of holes per character on the paper tape is even for EIA code and odd for ISO code.

Remedy
- Check the paper tape.
- Check the tape puncher and tape reader.

P31 Parity V error

Details The number of characters per block on the paper tape is odd.

Remedy
- Make the number of characters per block on the paper tape even.
- Set the parameter parity V selection OFF.

P32 Illegal address

Details An address not listed in the specifications has been used.

Remedy
- Correct the program address.
- Correct the parameter settings.
- Check the specifications.

P33 Format error

Details The command format in the program is not correct.

Remedy - Correct the program.

P34 Illegal G code

Details The commanded G code is not in the specifications.
An illegal G code was commanded during the coordinate rotation command (G68).

Remedy - Correct the G code address in the program.

Details G51.2 or G50.2 was commanded when "#1501 polyax (Rotational tool axis number)" was set to "0".
G51.2 or G50.2 was commanded when the tool axis was set to the linear axis ("#1017 rot (Rotational axis)" is set to "0").

Remedy - Correct the parameter settings.

P35 Setting value range over

Details The setting range for the addresses has been exceeded.

Remedy - Correct the program.

P36 Program end error

Details "EOR" has been read during tape and memory mode.

Remedy
- Enter the M02 and M30 command at the end of the program.
- Enter the M99 command at the end of the subprogram.

P37 O, N number zero

Details "0" has been specified for program or sequence No.

Remedy
- Designate program Nos. within a range from 1 to 99999999.
- Designate sequence Nos. within a range from 1 to 99999.

P38 No spec: Add. Op block skip

Details "/n" has been issued while the optional block skip addition is not in the specifications.

Remedy - Check the specifications.

P39 No specifications

Details
- A non-specified G code was commanded.
- The selected operation mode is out of specifications.

Remedy - Check the specifications.

P40 Pre-read block error

Details The interference check is disabled due to an error in the pre-read block in tool radius compensation.

Remedy - Correct the program.

P48 Restart pos return incomplete

Details A travel command was issued before the execution of the block that had been restart-searched.

Remedy - Carry out program restart again.
Travel command cannot be executed before the execution of the block that has been restart-searched.

P49 Invalid restart search

Details - Restart search was attempted for the 3-dimensional circular interpolation.
- Restart search was attempted during the cylindrical interpolation, polar coordinate interpolation, or tool tip center control.

Remedy - Correct the program.
- Correct the restart search position.

P50 No spec: Inch/Metric change

Details Inch/Metric changeover (G20/G21) command was issued while the function is out of specifications.

Remedy - Check the specifications.

P60 Compensation length over

Details The commanded movement distance is excessive (over 231).

Remedy - Correct the command range for the axis address.

P61 No spec: Unidirectional posit.

Details Unidirectional positioning (G60) was commanded while the function is out of specifications.

Remedy - Check the specifications.

P62 No F command

Details - No feed rate command has been issued.
- There is no F command in the cylindrical interpolation or polar coordinate interpolation immediately after the G95 mode is commanded.

Remedy - The default movement modal command at power ON is G01. This causes the machine to move without a G01 command if a movement command is issued in the program, and an alarm results. Use an F command to specify the feed rate.
- Specify F with a thread lead command.

P63 No spec: High-speed machining

Details High-speed machining cancel (G5P0) was commanded while the high-speed machining is out of specifications.

Remedy - Check the specifications.

P65 No spec: High speed mode 3

Details

Remedy - Check whether the specifications are provided for the high-speed mode III.

P70 Arc end point deviation large

Details - There is an error in the arc start and end points as well as in the arc center.
- The difference of the involute curve through the start point and the end point is large.
- When arc was commanded, one of the two axes configuring the arc plane was a scaling valid axis.

Remedy - Correct the numerical values of the addresses that specify the start and end points, arc center as well as the radius in the program.
- Correct the "+" and "-" directions of the address numerical values.
- Check for the scaling valid axis.

P71 Arc center error

Details - An arc center cannot be obtained in R-specified circular interpolation.
- A curvature center of the involute curve cannot be obtained.

Remedy - Correct the numerical values of the addresses in the program.
- Correct the start and end points if they are inside of the base circle for involute interpolation. When carrying out tool radius compensation, make sure that the start and end points after compensation will not be inside of the base circle for involute interpolation.
- Correct the start and end points if they are at an even distance from the center of the base circle for involute interpolation.

P72 No spec: Herical cutting

Details A helical command has been issued though it is out of specifications.

Remedy - Check whether the specifications are provided for the herical cutting.
- An Axis 3 command has been issued by the circular interpolation command. If there is no helical specification, move the linear axis to the next block.

I Alarms

13. Program Errors (P)

P73 No spec: Spiral cutting

- Details** A spiral command was issued though it is out of specifications.
- Remedy**
- Issue the G02.1 and G03.1 commands for circular interpolation.
 - Check whether the specifications are provided for the spiral cutting.

P74 Can't calculate 3DIM arc

- Details** The 3-dimension circular cannot be obtained because the end block was not specified during 3-dimension circular interpolation supplementary modal.
The 3-dimension circular cannot be obtained due to an interruption during 3-dimension circular interpolation supplementary modal.
- Remedy**
- Correct the program.

P75 3DIM arc illegal

- Details** An illegal G code was issued during 3-dimension circular interpolation modal.
Otherwise, 3-dimension circular interpolation command was issued during a modal for which a 3-dimension circular interpolation command cannot be issued.
- Remedy**
- Correct the program.

P76 No spec: 3DIM arc interpolat

- Details** G02.4/G03.4 was commanded though there is no 3-dimension circular interpolation specification.
- Remedy**
- Check the specifications.

P80 No spec: Hypoth ax interpolat

- Details** Hypothetical axis interpolation (G07) was commanded though it is out of specifications.
- Remedy**
- Check the specifications.

P90 No spec: Thread cutting

- Details** A thread cutting command was issued though it is out of specifications.
- Remedy**
- Check the specifications.

P91 No spec: Var lead threading

- Details** Variable lead thread cutting (G34) was commanded though it is out of specifications.
- Remedy**
- Check the specifications.

P93 Illegal pitch vaule

- Details** An illegal thread lead (thread pitch) was specified at the thread cutting command.
- Remedy**
- Correct the thread lead for the thread cutting command.

P100 No spec: Cylindric interpolat

- Details** A cylindrical interpolation command was issued though it is out of specifications.
- Remedy**
- Check the specifications.

P110 Plane select during figure rot

- Details** Plane selection (G17/G18/G19) was commanded during figure rotation.
- Remedy**
- Correct the machining program.

P111 Plane selected while coord rot

- Details** Plane selection commands (G17, G18, G19) were issued during a coordinate rotation (G68) was being commanded.
- Remedy**
- Always command G69 (coordinate rotation cancel) after the G68 command, and then issue a plane selection command.

P112 Plane selected while R compen

- Details**
- Plane selection commands (G17, G18, G19) were issued while tool radius compensation (G41, G42) and nose R compensation (G41, G42, G46) commands were being issued.
 - Plane selection commands were issued after completing nose R compensation commands when there were no further axis movement commands after G40, and compensation has not been cancelled.
- Remedy**
- Issue plane selection commands after completing (axis movement commands issued after G40 cancel command) tool radius compensation and nose R compensation commands.

P113 Illegal plane select

- Details** The circular command axis does not correspond to the selected plane.
- Remedy**
- Select a correct plane before issuing a circular command.

P120 No spec: Feed per rotation

- Details** Feed per rotation (G95) was commanded though it is out of specifications.
- Remedy**
- Check the specifications.

P121 F0 command during arc modal

- Details** F0 (F 1-digit feed) was commanded during the arc modal (G02/G03).
- Remedy**
- Correct the machining program.

I Alarms

13. Program Errors (P)

P122 No spec: Auto corner override

Details An auto corner override command (G62) was issued though it is out of specifications.

Remedy

- Check the specifications.
- Delete the G62 command from the program.

P123 No spec: High-accuracy control

Details High-accuracy control command was issued though it is out of specifications.

Remedy - Check the specifications.

P124 No spec: Inverse time feed

Details - The inverse time option is not provided.

Remedy - Check the specifications.

P125 G93 mode error

Details

- The issued G code command is illegal during G93 mode.
- G93 command was issued during a modal for which inverse time feed cannot be performed.

Remedy - Correct the program.

P126 Invalid cmdn in high-accuracy

Details An illegal command was issued during the high-accuracy control mode.

- A G code group 13 command was issued during the high-accuracy control mode.
- Milling, cylindrical interpolation or pole coordinate interpolation was commanded during the high-accuracy control mode.

Remedy - Correct the program.

P127 No spec: SSS Control

Details The SSS control valid parameter has been set although there is no SSS control specification.

Remedy - Check the specifications. Set "#8090 SSS ON" to "0" when there is no SSS control specification.

P130 2nd M function code illegal

Details The 2nd miscellaneous function address, commanded in the program, differs from the address set in the parameters.

Remedy - Correct the 2nd miscellaneous function address in the program.

P131 No spec: Cnst surface ctrl G96

Details A constant surface speed control command (G96) was issued though it is out of specifications.

Remedy

- Check the specifications.
- Issue a rotation speed command (G97) instead of the constant surface speed control command (G96).

P132 Spindle rotation speed S=0

Details No spindle rotation speed command has been issued.

Remedy - Correct the program.

P133 Illegal P-No. G96

Details The illegal No. was specified for the constant surface speed control axis.

Remedy - Correct the parameter settings and program that specify the constant surface speed control axis.

P140 No spec: Pos compen cmd

Details The position compensation command (G45 to G48) is out of specifications.

Remedy - Check the specifications.

P141 Pos compen during rotation

Details Position compensation was commanded during the figure rotation or coordinate rotation command.

Remedy - Correct the program.

P142 Pos compen invalid arc

Details Position compensation cannot be executed with the issued arc command.

Remedy - Correct the program.

P150 No spec: Nose R compensation

Details

- Tool radius compensation commands (G41 and G42) were issued though they are out of specifications.
- Nose R compensation commands (G41, G42, and G46) were issued though they are out of specifications.

Remedy - Check the specifications.

I Alarms

13. Program Errors (P)

P151 Radius compen during arc mode

- Details** A compensation command (G40, G41, G42, G43, G44, or G46) has been issued in the arc modal (G02 or G03).
- Remedy** - Issue the linear command (G01) or rapid traverse command (G00) in the compensation command block or cancel block.
(Set the modal to linear interpolation.)

P152 No intersection

- Details** In interference block processing during execution of a tool radius compensation (G41 or G42) or nose R compensation (G41, G42, or G46) command, the intersection point after one block is skipped cannot be determined.
- Remedy** - Correct the program.

P153 Compensation interference

- Details** An interference error has occurred while the tool radius compensation command (G41 or G42) or nose R compensation command (G41, G42 or G46) was being executed.
- Remedy** - Correct the program.

P154 No spec: 3D compensation

- Details** A three-dimensional compensation command was issued though it is out of specifications.
- Remedy** - Check the specifications.

P155 Fixed cyc exec during compen

- Details** A fixed cycle command has been issued in the radius compensation mode.
- Remedy** - Issue a radius compensation cancel command (G40) to cancel the radius compensation mode that has been applied since the fixed cycle command was issued.

P156 R compen direction not defined

- Details** A shift vector with undefined compensation direction was found at the start of G46 nose R compensation.
- Remedy** - Change the vector to that which has the defined compensation direction.
- Change the tool to that which has a different tip point No.

P157 R compen direction changed

- Details** During G46 nose R compensation, the compensation direction is reversed.
- Remedy** - Change the G command to that which allows the reversed compensation direction (G00, G28, G30, G33, or G53).
- Change the tool to that which has a different tip point No.
- Enable "#8106 G46 NO REV-ERR".

P158 Illegal tip point

- Details** An illegal tip point No. (other than 1 to 8) was found during G46 nose R compensation.
- Remedy** - Correct the tip point No.

P159 C-CMP REMAINS

- Details** One of the followings was commanded while the compensation has not been canceled (the compensation amount remained).
- (1) Automatic tool nose R compensation (G143)
 - (2) Radius compensation (G145)
 - (3) Plane selection (G17 to G19)
 - (4) Skip (G31 or G31.1/G31.2/G31.3)
 - (5) Fixed cycle for drilling (G81 to G89)
 - (6) Compound type fixed cycle II (G74 to G76)
- Remedy** - Cancel the compensation (with compensation amount "0") before commanding.
- Command the G00 move block before the block with a command among (1) to (6).

P160 G53 CMP. ERR

- Details** - G53 was commanded during nose R compensation (by G41/G42/G46).
- G53 was commanded to the block where the nose R compensation mode is changed (with G40/G41/G42/G46).
- G53 was commanded while nose R compensation amount has not been cleared.
- Remedy** - Correct the program.
- When issuing G53 after G40 command, move the compensation plane axis by G00/G01/G02/G03 command before issuing G53.

P170 No offset number

- Details** No compensation No. (DOO, TOO or HOO) command was given when the radius compensation (G41, G42, G43 or G46) command was issued. Otherwise, the compensation No. is larger than the number of sets in the specifications.
- Remedy** - Add the compensation No. command to the compensation command block.
- Check the number of sets for the tool compensation Nos. and correct the compensation No. command to be within the number of sets.

P171 No spec:Comp input by prog G10

- Details** Compensation data input by program (G10) was commanded though it is out of specifications.
- Remedy** - Check the specifications.

I Alarms

13. Program Errors (P)

P172 G10 L number error

Details An address of G10 command is not correct.

Remedy - Correct the address L No. of the G10 command.

P173 G10 P number error

Details The compensation No. at the G10 command is not within the permitted number of sets in the specifications.

Remedy - Check the number of sets for the tool compensation Nos. and correct the address P designation to be within the number of sets.

P174 No spec:Comp input by prog G11

Details Compensation data input by program cancel (G11) was commanded though there is no specification of compensation data input by program.

Remedy - Check the specifications.

P177 Tool life count active

Details Registration of tool life management data with G10 was attempted when the "usage data count valid" signal was ON.

Remedy - The tool life management data cannot be registered during the usage data count. Turn the "usage data count valid" signal OFF.

P178 Tool life data entry over

Details The number of registration groups, total number of registered tools or the number of registrations per group exceeded the range in the specifications.

Remedy - Correct the number of registrations.

P179 Illegal group No.

Details

- A duplicate group No. was found at the registration of the tool life management data with G10.
- A group No. that was not registered was designated during the T????99 command.
- An M code command, which must be issued as a single command, coexists in the same block as that of another M code command.
- The M code commands set in the same group exist in the same block.

Remedy

- Register the tool life data once for one group: commanding with a duplicate group No. is not allowed.
- Correct to the group No.

P180 No spec: Drilling cycle

Details A fixed cycle command (G72 - G89) was issued though it is out of specifications.

Remedy

- Check the specifications.
- Correct the program.

P181 No spindle command (Tap cycle)

Details No spindle rotation speed command has been issued when the fixed cycle for drilling command is given.
"S*****" type S command does not exist in the same block with the synchronous tapping cycle.

Remedy

- Issue the spindle rotation speed command (S) when the fixed cycle for drilling command G84, G74 (G84, G88) is given.
- Command a "S*****" type S command.

P182 Synchronous tap error

Details

- Connection to the main spindle unit was not established.
- The synchronous tapping was attempted with the spindle not serially connected under the multiple-spindle control I.

Remedy

- Check connection to the main spindle.
- Check that the main spindle encoder exists.
- Set 1 to the parameter #3024 (sout).

P183 No pitch/thread number

Details The pitch or number of threads has not been commanded in the tap cycle of a fixed cycle for drilling command.

Remedy - Specify the pitch data and the number of threads by F or E command.

P184 Pitch/thread number error

Details

- The pitch or the number of threads per inch is illegal in the tap cycle of the fixed cycle for drilling command.
- The pitch is too small for the spindle rotation speed.
- The thread number is too large for the spindle rotation speed.

Remedy - Correct the pitch or the number of threads per inch.

P185 No spec: Sync tapping cycle

Details Synchronous tapping cycle (G84/G74) was commanded though it is out of specifications.

Remedy - Check the specifications.

P186 Illegal S cmd in synchro tap

Details S command was issued during synchronous tapping modal.

Remedy - Cancel the synchronous tapping before issuing the S command.

I Alarms

13. Program Errors (P)

P190 No spec: Turning cycle

Details A lathe cutting cycle command was issued though it is out of specifications.

Remedy

- Check the specification.
- Delete the lathe cutting cycle command.

P191 Taper length error

Details In the lathe cutting cycle, the specified length of taper section is illegal.

Remedy - Set the smaller radius value than the axis travel amount in the lathe cycle command.

P192 Chamfering error

Details Chamfering in the thread cutting cycle is illegal.

Remedy - Set a chamfering amount not exceeding the cycle.

P200 No spec: MRC cycle

Details The compound type fixed cycle for turning machining I (G70 to G73) was commanded though it is out of specifications.

Remedy - Check the specifications.

P201 Program error (MRC)

Details

- The subprogram, called with a compound type fixed cycle for turning machining I command, has at least one of the following commands: reference position return command (G27, G28, G29, G30); thread cutting (G33, G34); fixed cycle skip-function (G31, G31.n).
- An arc command was found in the first movement block of the finished shape program in compound type fixed cycle for turning machining I.

Remedy

- Delete G27, G28, G29, G30, G31, G33, G34, and fixed cycle G codes from the subprogram called with the compound type fixed cycle for turning machining I commands (G70 to G73).
- Delete G02 and G03 from the first movement block of the finished shape program in compound type fixed cycle for turning machining I.

P202 Block over (MRC)

Details The number of blocks in the shape program of the compound type fixed cycle for turning machining I is over 50 or 200 (the maximum number differs according to the model).

Remedy - Set a 50/200 or less value for the number of blocks in the shape program called by the compound type fixed cycle for turning machining I commands (G70 to G73). (The maximum number differs according to the model).

P203 D cmdnd figure error (MRC)

Details A proper shape will not obtained by executing the shape program for the compound type fixed cycle for turning machining I (G70 to G73).

Remedy - Correct the shape program for the compound type fixed cycle for turning machining I (G70 to G73).

P204 E cmdnd fixed cycle error

Details A command value of the compound type fixed cycle for turning machining (G70 to G76) is illegal.

Remedy - Correct the command value of the compound type fixed cycle for turning machining (G70 to G76).

P210 No spec: Pattern cycle

Details A compound type fixed cycle for turning machining II (G74 to G76) command was commanded though it is out of specifications.

Remedy - Check the specifications.

P220 No spec: Special fixed cycle

Details There are no special fixed cycle specifications.

Remedy - Check the specifications.

P221 No. of special fixed holes = 0

Details "0" has been specified for the number of holes in special fixed cycle mode.

Remedy - Correct the program.

P222 G36 angle error

Details A G36 command specifies "0" for angle intervals.

Remedy - Correct the program.

P223 G12/G13 radius error

Details The radius value specified with a G12 or G13 command is below the compensation amount.

Remedy - Correct the program.

P224 No spec: Circular (G12/G13)

Details There are no circular cutting specifications.

Remedy - Check the specifications.

I Alarms

13. Program Errors (P)

P230 Subprogram nesting over

Details Over 8 times of subprogram calls have been done in succession from a subprogram.
- A M198 command was found in the program in the data server.
- The program in the IC card has been called more than once (the program in the IC card can be called only once during nested).

Remedy - Correct the program so that the number of subprogram calls does not exceed 8 times.

P231 No sequence No.

Details The sequence No., commanded at the return from the subprogram or by GOTO in the subprogram call, was not set.

Remedy - Specify the sequence Nos. in the call block of the subprogram.

P232 No program No.

Details - The machining program has not been found when the machining program is called.
- The file name of the program registered in IC card is not corresponding to O No.

Remedy - Enter the machining program.
- Check the subprogram storage destination parameters.
- Ensure that the external device (including IC card) that contains the file is mounted.

P235 Program editing

Details Operation was attempted for the file under program editing.

Remedy - Execute the program again after completion of program editing.

P240 No spec: Variable commands

Details A variable command (with #) was issued though it is out of specifications.

Remedy - Check the specifications.

P241 No variable No.

Details The variable No. commanded is out of the range specified in the specifications.

Remedy - Check the specifications.
- Correct the program variable No.

P242 = not defined at vrble set

Details The "=" sign has not been commanded when a variable is defined.

Remedy - Designate the "=" sign in the variable definition of the program.

P243 Can't use variables

Details An invalid variable has been specified in the left or right side of an operation expression.

Remedy - Correct the program.

P244 Invalid set date or time

Details Date or time was set earlier than current date or time in the system variables (#3011, #3012) when the credit system was valid.

Remedy - Date or time cannot be changed.
- Correct the program.

P250 No spec: Figure rotation

Details Figure rotation (M98 I_J_P_H_L_) was commanded though it is out of specifications.

Remedy - Check the specifications.

P251 Figure rotation overlapped

Details Figure rotation command was issued during figure rotation.

Remedy - Correct the program.

P252 Coord rotate in fig. rotation

Details A coordinate rotation related command (G68, G69) was issued during figure rotation.

Remedy - Correct the program.

P260 No spec: Coordinates rotation

Details A coordinate rotation command was issued though it is out of specifications.

Remedy - Check the specifications.

P270 No spec: User macro

Details A macro specification was commanded though it is out of specifications.

Remedy - Check the specifications.

P271 No spec: Macro interrupt

Details A macro interruption command has been issued though it is out of specifications.

Remedy - Check the specifications.

P272 NC and macro texts in a block

Details An executable statement and a macro statement exist together in the same block.

Remedy - Place the executable statement and macro statement in separate blocks in the program.

I Alarms

13. Program Errors (P)

P273 Macro call nesting over

- Details** The number of macro call nests exceeded the limit imposed by the specifications.
- Remedy** - Correct the program so that the macro calls do not exceed the limit imposed by the specifications.

P275 Macro argument over

- Details** The number of argument sets in the macro call argument type II has exceeded the limit.
- Remedy** - Correct the program.

P276 Illegal G67 command

- Details** A G67 command was issued though it was not during the G66 command modal.
- Remedy** - Correct the program.
- Issue G66 command before G67 command, which is a call cancel command.

P277 Macro alarm message

- Details** An alarm command has been issued in #3000.
- Remedy** - Refer to the operator messages on the diagnosis screen.
- Refer to the instruction manual issued by the machine tool builder.

P280 Brackets [] nesting over

- Details** Over five times have the parentheses "[" or "]" been used in a single block.
- Remedy** - Correct the program so that the number of "[" or "]" is five or less.

P281 Brackets [] not paired

- Details** A single block does not have the same number of commanded parentheses "[" as that of "]".
- Remedy** - Correct the program so that "[" and "]" parentheses are paired up properly.

P282 Calculation impossible

- Details** The arithmetic formula is incorrect.
- Remedy** - Correct the formula in the program.

P283 Divided by zero

- Details** The denominator of the division is zero.
- Remedy** - Correct the program so that the denominator for division in the formula is not zero.

P288 IF EXCESS

- Details** Over ten times of IF statement nesting have been done.
- Remedy** Correct the program so that the number of IF statement nesting does not exceed ten.

P289 IF-ENDIF MMC.

- Details** An IF statement is not ended with ENDIF.
THEN/ELSE has been commanded while there is no IF command.
- Remedy** - Correct the program so that IF statements are ended with ENDIFs.
- Put IF[condition] before THEN/ELSE command.

P290 IF sentence error

- Details** There is an error in the "IF[<conditional>]GOTO(" statement.
- Remedy** - Correct the program.

P291 WHILE sentence error

- Details** There is an error in the "WHILE[<conditional>]DO(-END(" statement.
- Remedy** - Correct the program.

P292 SETVN sentence error

- Details** There is an error in the "SETVN(" statement when the variable name setting was made.
- Remedy** - Correct the program.
- The number of characters in the variable name of the SETVN statement must be 7 or less.

P293 DO-END nesting over

- Details** The number of DO-END nesting levels in the "WHILE[<conditional>]DO(-END(" statement has exceeded 27.
- Remedy** - Correct the program so that the nesting levels of the DO-END statement does not exceed 27.

P294 DO and END not paired

- Details** The DOs and ENDS are not paired off properly.
- Remedy** - Correct the program so that the DOs and ENDS are paired off properly.

P295 WHILE/GOTO in tape

- Details** There is a WHILE or GOTO statement on the tape during tape operation.
- Remedy** - Apply memory mode operation instead of tape mode that does not allow the execution of the program with a WHILE or GOTO statement.

I Alarms

13. Program Errors (P)

P296 No address (macro)

Details A required address has not been specified in the user macro.

Remedy - Correct the program.

P297 Address-A error

Details The user macro does not use address A as a variable.

Remedy - Correct the program.

P298 G200-G202 cmnd in tape

Details User macro G200, G201, or G202 was specified during tape or MDI mode.

Remedy - Correct the program.

P300 Variable name illegal

Details The variable names have not been commanded properly.

Remedy - Correct the variable names in the program.

P301 Variable name duplicated

Details A duplicate variable name was found.

Remedy - Correct the program so that no duplicate name exists.

P310 Not use GMSTB macro code

Details G, M, S, T, or B macro code was called during fixed cycle.

Remedy - Correct the program.
- Correct the parameter settings.

P350 No spec: Scaling command

Details The scaling command (G50, G51) was issued though it is out of specifications.

Remedy - Check the specifications.

P360 No spec: Program mirror

Details A mirror image (G50.1 or G51.1) command has been issued though the programmable mirror image specifications are not provided.

Remedy - Check the specifications.

P370 No spec: Facing t-post MR

Details The facing turret mirror image specifications are not provided.

Remedy - Check the specifications.

P371 Facing t-post MR illegal

Details - Mirror image for facing tool posts was commanded to an axis in external mirror image or parameter mirror image.
- The commanded mirror image for facing tool posts enables the mirror image for a rotary axis.

Remedy - Correct the program.
- Correct the parameter settings.

P380 No spec: Corner R/C

Details The corner R/C was issued though it is out of specifications.

Remedy - Check the specifications.
- Delete the corner chamfering/corner rounding command in the program.

P381 No spec: Arc R/C

Details Corner chamfering II or corner rounding II was commanded in the arc interpolation block though it is out of specifications.

Remedy - Check the specifications.

P382 No corner movement

Details The block next to corner chamfering/ corner rounding is not a travel command.

Remedy - Replace the block succeeding the corner chamfering/ corner rounding command by G01 command.

P383 Corner movement short

Details The travel distance in the corner chamfering/corner rounding command was shorter than the value in the corner chamfering/corner rounding command.

Remedy - Set the smaller value for the corner chamfering/corner rounding than the travel distance.

P384 Corner next movement short

Details The travel distance in the following block in the corner chamfering/corner rounding command was shorter than the value in the corner chamfering/corner rounding command.

Remedy - Set the smaller value for the corner chamfering/corner rounding than the travel distance in the following block.

P385 Corner during G00/G33

Details A block with corner chamfering/corner rounding was given during G00 or G33 modal.

Remedy - Correct the program.

I Alarms

13. Program Errors (P)

P390 No spec: Geometric

Details A geometric command was issued though it is out of specifications.

Remedy - Check the specifications.

P391 No spec: Geometric arc

Details There are no geometric IB specifications.

Remedy - Check the specifications.

P392 Angle < 1 degree (GEOMT)

Details The angular difference between the geometric line and line is 1° or less.

Remedy - Correct the geometric angle.

P393 Inc value in 2nd block (GEOMT)

Details The second geometric block has a command with an incremental value.

Remedy - Issue a command with an absolute value in the second geometric block.

P394 No linear move command (GEOMT)

Details The second geometric block contains no linear command.

Remedy - Issue the G01 command.

P395 Illegal address (GEOMT)

Details The geometric format is invalid.

Remedy - Correct the program.

P396 Plane selected in GEOMT ctrl

Details A plane switching command was issued during geometric command processing.

Remedy - Complete the plane switching command before geometric command processing.

P397 Arc error (GEOMT)

Details In geometric IB, the circular arc end point does not contact or cross the next block start point.

Remedy - Correct the geometric circular arc command and the preceding and following commands.

P398 No spec: Geometric1B

Details A geometric command was issued though the geometric IB specifications are not provided.

Remedy - Check the specifications.

P411 Illegal modal G111

Details

- G111 was issued during milling mode.
- G111 was issued during nose R compensation mode.
- G111 was issued during constant surface speed.
- G111 was issued during mixed synchronization control.
- G111 was issued during fixed cycle.
- G111 was issued during polar coordinate interpolation.
- G111 was issued during cylindrical interpolation mode.

Remedy

- Before commanding G111, cancel the following commands.
- Milling mode
- Nose R compensation
- Constant surface speed
- Mixed synchronization control
- Fixed cycle
- Polar coordinate interpolation
- Cylindrical interpolation

P412 No spec: Axis name switch

Details Axis name switch (G111) was issued though it is out of specifications.

Remedy - Check the specifications.

P420 No spec: Para input by program

Details Parameter input by program (G10) was commanded though it is out of specifications.

Remedy - Check the specifications.

P421 Parameter input error

Details

- The specified parameter No. or set data is illegal.
- An illegal G command address was input in parameter input mode.
- A parameter input command was issued during fixed cycle modal or nose R compensation.
- G10L50, G10L70, G11 were not commanded in independent blocks.

Remedy - Correct the program.

P430 R-pnt return incomplete

Details

- A command was issued to move an axis, which has not returned to the reference position, away from that reference position.
- A command was issued to an axis removal axis.

Remedy

- Execute reference position return manually.
- Disable the axis removal on the axis for which the command was issued.

I Alarms

13. Program Errors (P)

P431 No spec: 2,3,4th R-point ret

Details A command for second, third or fourth reference position return was issued though there are no such command specifications.

Remedy - Check the specifications.

P432 No spec: Start position return

Details Start position return (G29) was commanded though it is out of specifications.

Remedy - Check the specifications.

P433 No spec: R-position check

Details Reference position check (G27) was commanded though it is out of specifications.

Remedy - Check the specifications.

P434 Compare error

Details One of the axes did not return to the reference position when the reference position check command (G27) was executed.

Remedy - Correct the program.

P435 G27 and M commands in a block

Details An M command was issued simultaneously in the G27 command block.

Remedy - Place the M code command, which cannot be issued in a G27 command block, in separate block from G27 command block.

P436 G29 and M commands in a block

Details An M command was issued simultaneously in the G29 command block.

Remedy - Place the M code command, which cannot be issued in a G29 command block, in separate block from G29 command block.

P438 G52 invalid during G54.1

Details A local coordinate system command was issued during execution of the G54.1 command.

Remedy - Correct the program.

P450 No spec: Chuck barrier

Details The chuck barrier on command (G22) was specified although the chuck barrier is out of specifications.

Remedy - Check the specifications.

P451 No spec: Stroke chk bef travel

Details Stroke check before travel (G22/G23) was commanded though it is out of specifications.

Remedy - Check the specifications.

P452 Limit before travel exists

Details An illegal command, which places the axis travel start/end point in the prohibited area or moves the axis through the prohibited area, was detected when Stroke check before travel (G22) was commanded.

Remedy - Correct the coordinate values of the axis address commanded in the program.

P460 Tape I/O error

Details An error has occurred in the tape reader. Otherwise an error has occurred in the printer during macro printing.

Remedy - Check the power and cable of the connected devices.
- Correct the I/O device parameters.

P461 File I/O error

Details - A file of the machining program cannot be read.
- IC card has not been inserted.

Remedy - In memory mode, the programs stored in memory may have been destroyed. Output all of the programs and tool data and then format the system.
- Ensure that the external device (including an IC card, etc) that contains the file is mounted.
- Correct the parameter settings for HD operation or IC card operation.

P462 Computer link commu error

Details A communication error occurred during the BTR operation.

Remedy - "L01 Computer link error" is displayed simultaneously. Take the remedy corresponding to the error No.

P480 No spec: Milling

Details - Milling was commanded though it is out of specifications.
- Polar coordinate interpolation was commanded though it is out of specifications.

Remedy - Check the specifications.

P481 Illegal G code (mill)

Details - An illegal G code was used during the milling mode.
- An illegal G code was used during cylindrical interpolation or polar coordinate interpolation.
- The G07.1 command was issued during the tool radius compensation.

Remedy - Correct the program.

P482 Illegal axis (mill)

- Details**
- A rotary axis was commanded during the milling mode.
 - Milling was executed though an illegal value was set for the milling axis No.
 - Cylindrical interpolation or polar coordinate interpolation was commanded during mirror image.
 - Cylindrical interpolation or polar coordinate interpolation was commanded before the tool compensation was completed after the T command.
 - G07.1 was commanded when cylindrical interpolation was not possible (there is no rotary axis, or external mirror image is ON).
 - An axis other than a cylindrical coordinate system axis was commanded during cylindrical interpolation.

Remedy - Correct the machining program, parameters and PLC interface signals.

P484 R-pnt ret incomplete (mill)

- Details**
- Movement was commanded to an axis that had not completed reference position return during the milling mode.
 - Movement was commanded to an axis that had not completed reference position return during cylindrical interpolation or polar coordinate interpolation.

Remedy - Carry out manual reference position return.

P485 Illegal modal (mill)

- Details**
- The milling mode was turned ON during nose R compensation or constant surface speed control.
 - A T command was issued during the milling mode.
 - The mode was switched from milling to cutting during tool compensation.
 - Cylindrical interpolation or polar coordinate interpolation was commanded during the constant surface speed control mode (G96).
 - The command unacceptable in the cylindrical interpolation was issued.
 - A T command was issued during the cylindrical interpolation or polar coordinate interpolation mode.
 - A movement command was issued when the plane was not selected just before or after the G07.1 command.
 - A plane selection command was issued during the polar coordinate interpolation mode.
 - Cylindrical interpolation or polar coordinate interpolation was commanded during tool radius compensation.
 - The G16 plane in which the radius value of a cylinder is "0" was specified.
 - A cylindrical interpolation or polar coordinate interpolation command was issued during coordinate rotation by program (G68).

Remedy

- Correct the program.
- Issue G40 or G97 before issuing G12.1.
- Issue a T command before issuing G12.1.
- Issue G40 before issuing G13.1.
- Specify the radius value of a cylinder other than "0", or specify the X axis's current value other than "0" before issuing G12.1/G16.

P486 Milling error

- Details**
- The milling command was issued during the mirror image (when parameter or external input is turned ON).
 - Polar coordinate interpolation, cylindrical interpolation or milling interpolation was commanded during mirror image for facing tool posts.
 - The start command of the cylindrical interpolation or polar coordinate interpolation was issued during the normal line control.

Remedy - Correct the program.

P511 Synchronization M code error

- Details**
- Two or more synchronization M codes were commanded in the same block.
 - The synchronization M code and "I" code were commanded in the same block.
 - Synchronization with the M code was commanded in 3rd part system or more. (Synchronization with the M code is valid only in 1st part system or 2nd part system.)

Remedy - Correct the program.

P530 DEC. POINT ERR

- Details** A decimal point was added to the address where the decimal point command is not allowed. ("#1274 ext10/bit0 (Type of address enabling/disabling decimal point command)")

Remedy Do not add any decimal point to the addresses where the decimal point is not allowed.

P550 No spec: G06.2(NURBS)

- Details** There is no NURBS interpolation option.

Remedy - Check the specifications.

P551 G06.2 knot error

- Details** The knot (k) command value is smaller than the value for the previous block.

Remedy

- Correct the program.
- Specify the knot by monotone increment.

P552 Start point of 1st G06.2 err

- Details** The block end point immediately before the G06.2 command and the G06.2 first block command value do not match.

Remedy - Match the G06.2 first block coordinate command value with the previous block end point.

I Alarms

13. Program Errors (P)

P554 Invl manual interrupt in G6.2

Details Manual interruption was executed in a block that applies the G06.2 mode.

Remedy - Execute the manual interruption in the block that does not apply the G06.2 mode.

P555 Invalid restart during G06.2

Details Restart was attempted from the block that applies G06.2 mode.

Remedy - Restart from the block that does not apply the G06.2 mode.

P600 No spec: Auto TLM

Details An automatic tool length measurement command (G37) was issued though it is out of specifications.

Remedy - Check the specifications.

P601 No spec: Skip

Details A skip command (G31) was issued though it is out of specifications.

Remedy - Check the specifications.

P602 No spec: Multi skip

Details A multiple skip command (G31.1, G31.2 or G31.3) was issued though it is out of specifications.

Remedy - Check the specifications.

P603 Skip speed 0

Details The skip speed is "0".

Remedy - Specify the skip speed.

P604 TLM illegal axis

Details No axis was specified in the automatic tool length measurement block. Otherwise, two or more axes were specified.

Remedy - Specify only one axis.

P605 T & TLM command in a block

Details The T code is in the same block as the automatic tool length measurement block.

Remedy - Specify the T code before the automatic tool length measurement block.

P606 T cmnd not found before TLM

Details The T code was not yet specified in automatic tool length measurement.

Remedy - Specify the T code before the automatic tool length measurement block.

P607 TLM illegal signal

Details The measurement position arrival signal turned ON before the area specified by the D command or "#8006 ZONE d". Otherwise, the signal remained OFF to the end.

Remedy - Correct the program.

P608 Skip during radius compen

Details A skip command was issued during radius compensation processing.

Remedy - Issue a radius compensation cancel (G40) command or remove the skip command.

P610 Illegal parameter

Details

- The parameter setting is not correct.
- G114.1 was commanded while the spindle synchronization was selected with the PLC interface signal.
- G113 was commanded while the spindle-spindle polygon machining option was OFF and the spindle synchronization was selected with the PLC interface signal.

Remedy

- Check whether the values are set in descending order (from the largest value) for "#1549 lv0vR1" to "#1553 lv0vR5".
- Check whether the values are set in descending order for "#1554 lv0rd2" to "#1557 lv0rd5".
- Correct the settings of "#1514 expLinax (Exponential function interpolation linear axis)" and "#1515 expRotax (Exponential function interpolation rotary axis)".
- Correct the program.
- Correct the parameter settings.

P611 No spec: Exponential function

Details There is no specification for the exponential interpolation.

Remedy - Check the specifications.

P612 Exponential function error

Details A travel command for exponential interpolation was issued during mirror image for facing tool posts.

Remedy - Correct the program.

P700 Illegal command value

Details Spindle synchronization was commanded to a spindle that is not connected serially.

Remedy

- Correct the program.
- Correct the parameter settings.

P900 No spec: Normal line control

Details A normal line control command (G40.1, G41.1, or G42.1) was issued though it is out of specifications.

Remedy - Check the specifications.

P901 Normal line control axis G92

Details A coordinate system preset command (G92) was issued to a normal line control axis during normal line control.

Remedy - Correct the program.

P902 Normal line control axis error

Details

- The normal line control axis was set to a linear axis.
- The normal line control axis was set to the linear type rotary axis II axis.
- The normal line control axis has not been set.
- The normal line control axis is the same as the plane selection axis.

Remedy - Correct the normal line control axis setting.

P903 Plane chg in Normal line ctrl

Details The plane selection command (G17, G18, or G19) was issued during normal line control.

Remedy - Delete the plane selection command (G17, G18, or G19) from the program of the normal line control.

P920 No spec: 3D coord conv

Details There is no specification for 3-dimensional coordinate conversion.

Remedy - Check the specifications.

P921 Illegal G code at 3D coord

Details The commanded G code cannot be performed during 3-dimensional coordinate conversion modal.

Remedy

- Refer to "MITSUBISHI CNC 700/70 Series Programming Manual (Machining Center System)" for usable G commands.
- When the basic specification parameter "#1229 set01/bit3 (Initial constant surface speed)" is enabled, disable the parameter or issue the constant surface speed control cancel (G97) command.

P922 Illegal mode at 3D coord

Details A 3-dimensional coordinate conversion command was issued during a modal for which 3-dimensional coordinate conversion cannot be performed.

Remedy - Refer to "MITSUBISHI CNC 700/70 Series Programming Manual (Machining Center System)" for usable G commands.

P923 Illegal addr in 3D coord blk

Details A G code and G68 was commanded in a block though the G code cannot be commanded with G68.

Remedy - Refer to "MITSUBISHI CNC 700/70 Series Programming Manual (Machining Center System)" for usable G commands.

P930 No spec: Tool axis compen

Details A tool length compensation along the tool axis command was issued though it is out of specifications.

Remedy - Check the specifications.

P931 Executing tool axis compen

Details There is a G code that cannot be commanded during tool length compensation along the tool axis.

Remedy - Correct the program.

P932 Rot axis parameter error

Details There is an illegal linear axis name or rotary axis name set in the rotary axis configuration parameters.

Remedy - Set the correct value and turn the power ON again.

P940 No spec: Tool tip control

Details There is no specification for tool tip center control.

Remedy - Check the specifications.

P941 Invalid T tip control command

Details A tool tip center control command was issued during a modal for which a tool tip center control command cannot be issued.

Remedy - Correct the program.

P942 Invalid cmdnd during T tip ctrl

Details A G code that cannot be commanded was issued during tool tip center control.

Remedy - Correct the program.

I Alarms

13. Program Errors (P)

P943 Tool posture command illegal

Details In tool tip center control type 1, if the signs at the tool-side rotary axis or table base-side rotary axis start and finish points differ, a tool base-side rotary axis or table workpiece-side rotary axis rotation exists for the same block, and does not pass a singular point.
In tool tip center control type 2, the posture vector command is incorrect.

Remedy - Correct the program.

P990 PREPRO error

Details Combining commands that required pre-reading (nose R offset, corner chamfering/corner rounding, geometric I, geometric IB, and compound type fixed cycle for turning machining) resulted in eight or more pre-read blocks.

Remedy - Delete some or all of the combinations of commands that require pre-reading.

II Parameters

1. User Parameters

【#8001】 WRK COUNT M

Set the M code for counting the number of the workpiece repeated machining.
The number of the M-codes set by this parameter is counted.
The No. will not be counted when set to "0".

---Setting range---
0 to 99

【#8002】 WRK COUNT

Set the initial value of the number of workpiece machining. The number of current workpiece machining is displayed.

---Setting range---
0 to 999999

【#8003】 WRK COUNT LIMIT

Set the maximum number of workpiece machining.
A signal will be output to PLC when the number of machining times is counted to this limit.

---Setting range---
0 to 999999

【#8004】 SPEED

Set the feedrate during automatic tool length measurement.

---Setting range---
1 to 1000000 (mm/min)

【#8005】 ZONE r

Set the distance between the measurement point and deceleration start point.

---Setting range---
0 to 99999.999 (mm)

【#8006】 ZONE d

Set the tolerable range of the measurement point.
An alarm will occur when the sensor signal turns ON before the range, set by this parameter, has not been reached from the measurement point, or when the signal does not turn ON after the range is passed.

---Setting range---
0 to 99999.999 (mm)

【#8007】 OVERRIDE

Set the override value for automatic corner override.

---Setting range---
0 to 100 (%)

【#8008】 MAX ANGLE

Set the maximum corner opening angle where deceleration should start automatically.
When the angle is larger than this value, deceleration will not start.

---Setting range---
0 to 180 (°)

【#8009】 DSC. ZONE

Set the position where deceleration starts at the corner.
Designate at which length point before the corner deceleration should start.

---Setting range---
0 to 99999.999 (mm)

【#8010】 ABS. MAX (for L system only)

Set the maximum value when inputting the tool wear compensation amount.
A value exceeding this setting value cannot be set.
Absolute value of the input value is set.
(If a negative value is input, it is treated and set as a positive value.)
If "0" is input, this parameter will be disabled.

---Setting range---
0 to 99.999 (mm)
(Input setting increment applies)

【#8011】 INC. MAX (for L system only)

Set the maximum value for when inputting the tool wear compensation amount in the incremental mode.
A value exceeding this setting value cannot be set.
Absolute value of the input value is set.
(If a negative value is input, it is treated and set as a positive value.)
If "0" is input, this parameter will be disabled.

---Setting range---
0 to 99.999 (mm)
(Input setting increment applies)

II Parameters

1. User Parameters

【#8012】 G73 n (for M system only)

Set the return amount for G73 (step cycle).

---Setting range---

0 to 99999.999 (mm)

【#8013】 G83 n

Set the return amount for G83 (deep hole drilling cycle).

---Setting range---

0 to 99999.999 (mm)

【#8014】 CDZ-VALE (for L system only)

Set the screw cut up amount for G76 and G78 (thread cutting cycle).

---Setting range---

0 to 127 (0.1 lead)

【#8015】 CDZ-ANGLE (for L system only)

Set the screw cut up angle for G76 and G78 (thread cutting cycle).

---Setting range---

0 to 89 (°)

【#8016】 G71 MINIMUM (for L system only)

Set the minimum value of the last cutting amount by the rough cutting cycle (G71, G72). The cutting amount of the last cutting will be the remainder. When the remainder is smaller than this parameter setting, the last cycle will not be executed.

---Setting range---

0 to 999.999 (mm)

【#8017】 G71 DELTA-D (for L system only)

Set the change amount of the rough cutting cycle.

The rough cutting cycle (G71, G72) cutting amount repeats $d + \Delta d$, d , $d - \Delta d$ using the value (d) commanded with D as a reference. Set the change amount Δd .

---Setting range---

0 to 999.999 (mm)

【#8018】 G84/G74 n (for M system only)

Not used. Set to "0".

【#8019】 R COMP

Set a compensation coefficient for reducing a control error in the reduction of a corner roundness and arch radius.

The larger the setup value, the smaller the theoretical error will be. However, since the speed at the corner will go down, the cycle time will be extended.

Coefficient = 100 - setting value


(Note) This is valid when "#8021 COMP CHANGE" is set to "0".

---Setting range---

0 to 99 (%)

Theor R decrease

The value calculated with the following data is displayed for the theoretical radius reduction error amount ΔR (mm).




Theoretical radius reduction amount at arc center

【#8020】 DCC. angle

Set up the minimum value of an angle (external angle) that should be assumed to be a corner.

When an inter-block angle (external angle) in high-accuracy mode is larger than the set value, it will be determined as a corner and the speed will go down to sharpen the edge.



(Note) If "0" is set, it will be handled as 5 degrees.

---Setting range---

0 to 89 (degrees)

0: The angle will be 5°.

II Parameters

1. User Parameters

【#8021】 COMP_CHANGE

Select whether to share or separate the compensation coefficient at the corner/curve during the high-accuracy control mode.

0: Share ("#8019 R COMP" is applied.)

1: Separate

• Corner : #8022 CORNER COMP

• Curve : #8023 CURVE COMP

(Note) Set "1" when using SSS control.

【#8022】 CORNER COMP

Set the compensation coefficient to further reduce or increase the roundness at the corner during the high-accuracy control mode.

Coefficient = 100 - setting value

(Note) This is valid when "#8021 COMP CHANGE" is set to "1".

---Setting range---

-1000 to 99 (%)

【#8023】 CURVE COMP

Set the compensation coefficient to further reduce or increase the radius reduction amount at the curve (arc, involute, spline) during the high-accuracy control mode.

Coefficient = 100 - setting value

(Note) This is valid when "#8021 COMP CHANGE" is set to "1".

For theoretical radius reduction error amount, refer to "Theor R decrease" in "#8019 R COMP".

---Setting range---

-1000 to 99 (%)

【#8025】 SPLINE ON (for M system only)

Select whether to enable the spline function.

0: Disable

1: Enable

Spline interpolation is valid during G61.2 modal, regardless of this setting.

【#8026】 CANCEL ANG. (for M system only)

Set the angle where the spline interpolation is temporarily canceled.

When the angle made by blocks exceeds this parameter setting value, spline interpolation will be canceled temporarily. In consideration of the pick feed, set a value a little smaller than the pick feed angle.

---Setting range---

0 to 180 (°)

0: 180 (°)

【#8027】 Toler-1 (for M system only)

Set the maximum chord error (tolerance) in a block that includes an inflection point. Set the tolerance applicable when the applicable block is developed to fine segments by CAM. (normally about 10 μm)

When "0.000" is set, the applicable block will be linear.

---Setting range---

0.000 to 100.000 (mm)

【#8028】 Toler-2 (for M system only)

Set the maximum chord error (tolerance) in a block that includes no inflection point. Set the tolerance applicable when the applicable block is developed to fine segments by CAM. (normally about 10 μm)

When "0.000" is set, the applicable block will be linear.

---Setting range---

0.000 to 100.000 (mm)

【#8029】 FairingL (for M system only)

Set the length of the block subject to fairing.
(Enabled when "#8033 Fairing ON" is set to "1".)

---Setting range---

0 to 100.000 (mm)

【#8030】 MINUTE LENG (for M system only)

Set the fine-segment length where the spline interpolation is temporarily canceled.

When the length of one block exceeds this parameter setting value, spline interpolation is canceled temporarily and linear interpolation is performed. Set a value a little smaller than one block length of the program.

If "-1" is set, spline interpolation will be performed regardless of block length.

---Setting range---

-1 to 127 (mm)

0: 1 (mm)

【#8033】 Fairing ON (for M system only)

Select whether to use the fairing function.

0: Not use

1: Use

Fairing function is enabled during G61.2 modal, regardless of this setting.

II Parameters

1. User Parameters

【#8034】 AccClamp ON (for M system only)

Select the method for clamping the cutting speed.
0: Clamp with parameter "#2002 clamp" or the corner deceleration function.
1: Clamp the cutting speed with acceleration judgment.
(Enabled when "#8033 Fairing ON" is set to "1".)

【#8036】 CordecJudge (for M system only)

Select the condition to decide a corner.
0: A corner is decided from the angle of the neighboring block.
1: A corner is decided from the angle of the neighboring block, excluding minute blocks.
(Enabled when "#8033 Fairing ON" is set to "1".)

【#8037】 CorJudgeL (for M system only)

Set the length of the block to be excluded when deciding a corner.
(Enabled when "#8036 CordecJudge" is set to "1".)
---Setting range---
0 to 99999.999 (mm)

【#8041】 C-rot.R

Set the length from the center of the normal line control axis to the tool tip. This is used to calculate the turning speed at the block joint.
This is enabled during the normal line control type II.
---Setting range---
0.000 to 99999.999 (mm)

【#8042】 C-ins.R

Set the radius of the arc to be automatically inserted into the corner during normal line control.
This is enabled during the normal line control type I.
---Setting range---
0.000 to 99999.999 (mm)

【#8043】 Tool HDL FD OFS

Set the length from the tool holder to the tool tip.
---Setting range---
0.000 to 99999.999 (mm)

【#8044】 UNIT*10

Set the command increment scale.
The scale will be "1" when "0" is set.
---Setting range---
0 to 10000 (fold)
0: One fold

【#8051】 G71 THICK

Set the amount of cut-in by the rough cutting cycle (G71, G72)
---Setting range---
0 to 99999.999 (mm)

【#8052】 G71 PULL UP

Set the amount of pull-up when returning to the cutting start point for the rough cutting cycle (G71, G72).
---Setting range---
0 to 99999.999 (mm)

【#8053】 G73 U

Set the X-axis cutting margin of the forming rough cutting cycle (G73).
---Setting range---
-99999.999 to 99999.999 (mm)

【#8054】 G73 W

Set the Z-axis cutting margin of the forming rough cutting cycle (G73).
---Setting range---
-99999.999 to 99999.999 (mm)

【#8055】 G73 R

Set how many times cutting will be performed in the forming rough cutting cycle (G73).
---Setting range---
0 to 99999 (times)

【#8056】 G74 RETRACT

Set the amount of retract (amount of cut-up) of the cutting-off cycle (G74, G75).
---Setting range---
0 to 999.999 (mm)

【#8057】 G76 LAST-D

Set the amount of final cut-in by the compound type thread cutting (G76).
---Setting range---
0 to 999.999 (mm)

II Parameters

1. User Parameters

【#8058】 G76 TIMES

Set how many times the amount of final cut-in cycle (G76 finish margin) will be divided in the compound type thread cutting (G76).

---Setting range---
0 to 99 (times)

【#8059】 G76 ANGLE

Set the angle (thread angle) of the tool nose in the compound type thread cutting (G76).

---Setting range---
0 to 99 (°)

【#8071】 3-D CMP (for M system only)

Set the value of the denominator constants for 3-dimensional tool radius compensation. Set the value of "p" in the following formula.

$$Vx = i \times r/p, Vy = j \times r/p, Vz = k \times r/p$$

Vx, Vy, Vz : X, Y, and Z axes or vectors of horizontal axes

i, j, k : Program command value

r : Offset

$$p = \sqrt{(i^2 + j^2 + k^2)} \text{ when the set value is "0".}$$

---Setting range---
0 to 99999.999

【#8072】 SCALING P (for M system only)

Set the scale factor for reduction or magnification in the machining program specified by G50 or G51 command.

This parameter will be valid when the program specifies no scale factor.

---Setting range---
-99.999999 to 99.999999

【#8075】 SpiralEndErr (for M system only)

Set the tolerable error range (absolute value) when the end point position, commanded by the spiral or conical interpolation command with the command format type 2, differs from the end point position obtained from the speed and increment/decrement amount.

---Setting range---
0 to 99999.999 (mm)

【#8078】 Screen Saver Timer

Set the period of time before turn-OFF of the display unit backlight. When "0" is set, the backlight is not turned OFF.

---Setting range---
0 to 60 (min)
0: The backlight is not turned OFF

【#8083】 G83S modeM (for M system only)

Set the M command code for changing to the small diameter deep hole drilling cycle mode.

---Setting range---
1 to 99999999

【#8084】 G83S Clearance (for M system only)

Set the clearance amount for the small diameter deep hole drilling cycle (G83).

---Setting range---
0 to 999.999 (mm)

【#8085】 G83S Forward F (for M system only)

Set the feedrate from the R point to the cutting start position in the small diameter deep hole drilling cycle (G83).

---Setting range---
0 to 99999 (mm/min)

【#8086】 G83S Back F (for M system only)

Set the speed for returning from the hole bottom during the small diameter deep hole drilling cycle (G83).

---Setting range---
0 to 99999 (mm/min)

【#8090】 SSS ON (for M system only)

Set whether to enable the SSS control with G05 P10000.

0: Disable
1: Enable

【#8091】 StdLength (for M system only)

Set the maximum value of the range for recognizing the shape.

To eliminate the effect of steps or errors, etc., set a large value. To enable sufficient deceleration, set a small value.

If "0.000" is set, the standard value (1.000mm) will be applied.

---Setting range---
0 to 100.000 (mm)

II Parameters

1. User Parameters

【#8092】 ClampCoeff (for M system only)

Set the clamp speed at the curved section configured of fine segments.
Coefficient = $\sqrt{\text{setting value}}$
---Setting range---
1 to 100

【#8093】 StepLeng (for M system only)

Set the width of the step at which the speed is not to be decelerated. (Approximately the same as the CAM path difference [Tolerance].)
If "0" is set, the standard value (5 μ m) will be applied.
If a minus value is set, the speed will decelerate at all minute steps.
---Setting range---
-1.000 to 0.100 (mm)

【#8094】 DccWaitAdd (for M system only)

Set the time to wait for deceleration when the speed FB does not drop to the clamp speed.
---Setting range---
0 to 100 (ms)

【#8101】 MACRO SINGLE

Select how to control the blocks where the user macro command continues.
0: Do not stop while macro blocks continue.
1: Stop every block during signal block operation.

【#8102】 COLL. ALM OFF

Select the interference (bite) control to the workpiece from the tool diameter during tool radius compensation and nose R compensation.
0: An alarm will be output and operation stops when an interference is judged.
1: Changes the path to avoid interference.

【#8103】 COLL. CHK OFF

Select the interference (bite) control to the workpiece from the tool diameter during tool radius compensation and nose R compensation.
0: Performs interference check.
1: Does not perform interference check.

【#8105】 EDIT LOCK B

Select the edit lock for program Nos. 8000 to 9999 in the memory.
0: Enable the editing.
1: Prohibit the editing of above programs.

When "1" is set, the file cannot be opened.

【#8106】 G46 NO REV-ERR (for L system only)

Select the control for the compensation direction reversal in G46 (nose R compensation).
0: An alarm will be output and operation will stop when the compensation direction is reversed (G41 -> G42' G42 -> G41).
1: An alarm won't occur when the compensation direction is reversed, and the current compensation direction will be maintained.

【#8107】 R COMPENSATION

Select whether to move to the inside because of a delay in servo response to a command during arc cutting mode.
0: Move to the inside, making the arc smaller than the command value.
1: Compensate the movement to the inside.

【#8108】 R COMP Select

Select the arc radius error compensation target.
0: Perform compensation over all axes.
1: Perform compensation axis by axis.

(Note) This parameter is effective only when "#8107 R COMPENSATION" is "1".

【#8109】 HOST LINK

Select whether to enable computer link B instead of the RS-232C port.
0: Disable (Enable normal RS-232C communication.)
1: Enable (Disable normal RS-232C communication.)

【#8110】 G71/G72 POCKET

Select whether to enable the pocket machining when there is a dimple (pocket) in the rough cutting cycle (G71, G72) finishing program.
0: OFF
1: ON

【#8111】 Milling Radius

Select the diameter and radius of the linear axis for milling (cylindrical/pole coordinate) interpolation.
0: All axes radius command
1: Each axis setting (follows "#1019 dia")

(Note) This parameter is valid only in the milling (cylindrical/polar coordinate) interpolation mode.

II Parameters

1. User Parameters

【#8112】 DECIMAL PNT-P

Select whether to enable the decimal point command for G04 address P.
0: Disable
1: Enable

【#8113】 Milling Init G16

Set which plane to execute for milling machining after the power is turned ON or reset.

#8113:0, #8114:0 ---> G17 plane
#8113:0, #8114:1 ---> G19 plane
#8113:1, #8114:0 ---> G16 plane
#8113:1, #8114:1 ---> G16 plane

0: Not G16 plane
1: G16 plane

(Note) This parameter is valid for the G code system 2 or 3 ("#1037 cmdtyp"="3" or "4").

【#8114】 Milling Init G19

Set which plane to execute for milling machining after the power is turned ON or reset.

#8113:0, #8114:0 ---> G17 plane
#8113:0, #8114:1 ---> G19 plane
#8113:1, #8114:0 ---> G16 plane
#8113:1, #8114:1 ---> G16 plane

0: Not G19 plane
1: G19 plane

(Note) This parameter is valid for the G code system 2 or 3 ("#1037 cmdtyp"="3" or "4").

【#8116】 Coord rot para invd

Select whether to enable the coordinate rotation by the parameters.
0: Enable
1: Disable

【#8117】 OFS Diam DESIGN

Select tool radius or tool diameter compensation amount to be specified.

0: Tool radius compensation amount
1: Tool diameter compensation amount

【#8119】 Comp. unit switch

Select the setting unit of compensation amount that has no decimal point.

0: 1mm (or 1inch) unit
1: The minimum command unit (follows "#1003 iunit")

【#8121】 Screen Capture

Select whether to enable the screen capture function.

0: Disable
1: Enable

(Note1) By setting this parameter to "1", and by keeping pushing the [SHIFT] key, screen capture will be executed.

(Note2) This parameter is valid only with M70 Series.

【#8122】 Keep G43 MDL M-REF

Select whether to keep the tool length offset by high speed manual reference position return during tool length offset.

0: Will not be kept (Cancel)
1: Kept

【#8124】 Mirr img at reset

Select the operation type of the mirror image by parameter setting and the mirror image by external input.

0: The current mirror image is canceled, and new mirror image will start with the machine position at reset as the mirror center.
1: The mirror center is kept to continue the mirror image.

【#8145】 Validate F1 digit

Select whether to execute the F command with a 1-digit code command or with a direct numerical command.

0: Direct numerical command (command feedrate during feed per minute or rotation)
1: 1-digit code command (with the feedrate specified by the parameters "#1185 spd_F1" to "#1189 F5")

【#8154(PR)】

Not used. Set to "0".

【#8155】 Sub-pro interrupt

Select the method for the user macro interrupt.

0: The user macro interrupt of macro type
1: The user macro interrupt of sub-program type

【#8156】 Fine thread cut E

Select the address E type when cutting an inch screw.

0: Specify the number of threads per inch for inch screw cutting.
1: Specify the precision lead for inch screw cutting.

II Parameters

1. User Parameters

【#8157】 Radius comp type B (M system) / Nose R comp type B (L system)

For M system

Select the method of the arithmetic processing for the intersection point when the start-up or cancel commands are operated during radius compensation.

- 0: The processing does not handle the start-up or cancel command block: handle the offset vector in the direction vertical to that of the command instead.
- 1: The processing is executed for the intersection point between the command block and the next block.

For L system

Select the method of the arithmetic processing for the intersection point when the start-up or cancel commands are operated during nose R or radius compensation.

- 0: The processing does not handle the start-up or cancel command block: handle the offset vector in the direction vertical to that of the command instead.
- 1: The processing is executed for the intersection point between the command block and the next block.

【#8158】 Init const sur spd

Select the initial state after power-ON.

- 0: Constant surface speed control cancel mode.
- 1: Constant surface speed control mode.

【#8159】 Synchronous tap

Select whether to use the floating tap chuck in G74 and G84 tap cycles.

- 0: With a floating tapping chuck
- 1: Without a floating tapping chuck

【#8160】 Start point alarm

Select an operation when the operation start point cannot be found while moving to the next block of G117.

- 0: The auxiliary function is enabled after the block for the movement has finished.
- 1: The program error (P33) occurs.

【#8201】 AX. RELEASE

Select the function to remove the control axis from the control target.

- 0: Control as normal.
- 1: Remove from control target.

【#8202】 OT-CHECK OFF

Select whether to enable the stored stroke limit II function set in #8204 and #8205.

- 0: Enable
- 1: Disable

【#8203】 OT-CHECK-CANCEL

When the simple absolute position method ("#2049 type" is "9") is selected, the stored stroke limits I, II (or IIB) and IB can be disabled until the first reference position return is executed after the power is turned ON.

- 0: Enable (according to #8202)
- 1: Temporarily cancel

(Note) "#8203 OT-CHECK-CANCEL" affects all the stored stroke limits.

【#8204】 OT-CHECK-N

Set the coordinates of the (-) direction in the movable range of the stored stroke limit II or the lower limit coordinates of the prohibited range of stored stroke limit IIB. If the sign and value are the same as #8205, the stored stroke limit II (or IIB) will be invalid. If the stored stroke limit IIB function is selected, the prohibited range will be between two points even when #8204 and #8205 are set in reverse. When II is selected, the entire range will be prohibited if #8204 and #8205 are set in reverse.

---Setting range---
±99999.999 (mm)

【#8205】 OT-CHECK-P

Set the coordinates of the (+) direction in the movable range of the stored stroke limit II or the upper limit coordinates of the prohibited range of stored stroke limit IIB.

---Setting range---
±99999.999 (mm)

【#8206】 TOOL CHG. P

Set the coordinates of the tool change position for G30. n (tool change position return). Set with coordinates in the basic machine coordinate system.

---Setting range---
±99999.999 (mm)

【#8207】 G76/87 IGNR (for M system only)

Select whether to enable the shift operation at G76 (fine boring) and G87 (back boring).

- 0: Enable
- 1: Disable

【#8208】 G76/87 (-) (for M system only)

Select the shift direction at G76 and G87.

- 0: Shift to (+) direction
- 1: Shift to (-) direction

II Parameters

1. User Parameters

【#8209】 G60 SHIFT (for M system only)

Set the last positioning direction and distance for a G60 (unidirectional positioning) command.

---Setting range---
±99999.999 (mm)

【#8210】 OT INSIDE

Select whether the stored stroke limit function set by #8204 and #8205 prevents the machine from moving to the inside or outside of the specified range.

0: Inhibits outside area (Select stored stroke limit II.)
1: Inhibits inside area (Select stored stroke limit II B.)

【#8211】 MIRR. IMAGE

Select whether to enable the parameter mirror image function.

0: Disable
1: Enable

【#8213(PR)】 Rotation axis type

Select the rotation type (short-cut valid/invalid) or linear type (workpiece coordinate linear type/all coordinate linear type).

This parameter is enabled only when "#1017 rot" is set to "1". (Note)

0: Short-cut invalid
1: Short-cut valid
2: Workpiece coordinate linear type
3: All coordinate linear type

(Note) The movement method is as follows by the specified rotation axis type.

<Workpiece coordinate value>

0,1 : Display range 0° to 359.999°
2,3 : Display range 0° to ±99999.999°

<Machine coordinate value/relative position>

0,1,2 : Display range 0° to 359.999°
3 : Display range 0° to ±99999.999°

<ABS command>

0 : The incremental amount from the end point to the current position is divided by 360, and the axis moves by the remainder amount according to the sign.

1 : Moves with a short-cut to the end point.

2,3 : In the same manner as the normal linear axis, moves according to the sign by the amount obtained by subtracting the current position from the end point.

<INC command>

0,1,2,3 : Moves in the direction of the commanded sign by the commanded incremental amount starting at the current position.

<Reference position return>

0,1,2 : The movement to the middle point applies to the ABS command or the INC command.

Returns with movement within 360 degrees from the middle point to reference position.

3 : The movement to the middle point applies to the ABS command or the INC command.

Moves and returns in the reference position direction for the difference from the current position to the reference position.

【#8215】 TLM std length

Set the TLM standard length.

TLM standard length is the distance from a tool replacement point (reference position) to the measurement basic point (surface) which is used to measure the tool length.

---Setting range---
-99999.999 to 99999.999 (mm)

【#8216】 Type in G28 return

Select the performance after establishing the reference position in reference position return command.

0: Moves to the reference position.
1: Won't move to the reference position.

【#8217】 Check start point

Set a drawing start position in graphic check of each axis.

---Setting range---
-99999.999 to 99999.999 (mm)

【#8300】 P0

Set the reference X-coordinates of the chuck and the tail stock barrier.

Set the center coordinate (radius value) of workpiece by the basic machine coordinate system.

---Setting range---
±99999.999 (mm)

【#8301】 P1

Set the area of the chuck and tail stock barrier.

Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)

Set the coordinate value by basic machine coordinate system for Z-axis.

---Setting range---
±99999.999 (mm)

II Parameters

1. User Parameters

【#8302】 P2

Set the area of the chuck and tail stock barrier.
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)
Set the coordinate value by basic machine coordinate system for Z-axis.
---Setting range---
±99999.999 (mm)

【#8303】 P3

Set the area of the chuck and tail stock barrier.
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)
Set the coordinate value by basic machine coordinate system for Z-axis.
---Setting range---
±99999.999 (mm)

【#8304】 P4

Set the area of the chuck and tail stock barrier.
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)
Set the coordinate value by basic machine coordinate system for Z-axis.
---Setting range---
±99999.999 (mm)

【#8305】 P5

Set the area of the chuck and tail stock barrier.
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)
Set the coordinate value by basic machine coordinate system for Z-axis.
---Setting range---
±99999.999 (mm)

【#8306】 P6

Set the area of the chuck and tail stock barrier.
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)
Set the coordinate value by basic machine coordinate system for Z-axis.
---Setting range---
±99999.999 (mm)

【#8310】 Barrier ON

Select whether to enable the chuck and tailstock barrier.
0: Disable (Setting from special display unit will be enabled)
1: Enable

【#8311】 P7

Set the area of the left spindle section.
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)
Set the coordinate value by basic machine coordinate system for Z-axis.
---Setting range---
±99999.999 (mm)

【#8312】 P8

Set the area of the left spindle section.
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)
Set the coordinate value by basic machine coordinate system for Z-axis.
---Setting range---
±99999.999 (mm)

【#8313】 P9

Set the area of the right spindle section.
X axis: Set the coordinate from the workpiece center (P0). (radius value)
Z axis: Set the coordinates in the basic machine coordinate system.
---Setting range---
±99999.999 (mm)

【#8314】 P10

Set the area of the right spindle section.
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)
Set the coordinate value by basic machine coordinate system for Z-axis.
---Setting range---
±99999.999 (mm)

【#8315】 Barrier Type (L)

Select the shape of the left chuck and tailstock barrier.
0: No area
1: Chuck
2: Tailstock

【#8316】 Barrier Type (R)

Select the shape of the right chuck and tailstock barrier.
0: No area
1: Chuck
2: Tailstock

II Parameters

1. User Parameters

【#8317】 ELIV. AX. Name

Set the name of the delivery axis when the right chuck and tailstock barrier is movable.
When using the multi-part system method and the delivery axis is an axis in the other part system, designate the axis including the part system as 1A, 1B or 2A, 2B. If the part system is not designated as A and B, the set part system will be used.

---Setting range---

A/B/.. (axis name)

1A/1B/..

2A/2B/.. (with part system designated)

0: Cancel

【#8318】 Stock Angle (L)

Set the angle for the left tailstock end section.
The angle will be interpreted as 90° if there is no setting (when "0" is set).

---Setting range---

0 to 180 (°)

0: 90° (default)

【#8319】 Stock Angle (R)

Set the angle for the right tailstock end section.
The angle will be interpreted as 90° if there is no setting (when "0" is set).

---Setting range---

0 to 180 (°)

0: 90° (default)

【#8621】 Coord rot plane (H)

Set the plane (horizontal axis) for coordinate rotation control.
Usually, set the name of the 1st axis.
When not set, "X" axis will be set.

---Setting range---

Axis name

【#8622】 Coord rot plane (V)

Set the plane (vertical axis) for coordinate rotation control.
Usually, set the name of the 2nd axis.
When not set, "Y" axis will be set.

---Setting range---

Axis name

【#8623】 Coord rot centr (H)

Set the center coordinates (horizontal axis) for coordinate rotation control.

---Setting range---

-999999.999 to 999999.999 (mm)

【#8624】 Coord rot centr (V)

Set the center coordinates (vertical axis) for coordinate rotation control.

---Setting range---

-999999.999 to 999999.999 (mm)

【#8625】 Coord rot vctr (H)

Set the vector components (horizontal axis) for coordinate rotation control.
When this parameter is set, the coordinate rotation control angle (#8627) will be automatically calculated.

---Setting range---

-999999.999 to 999999.999 (mm)

【#8626】 Coord rot vctr (V)

Set the vector components (vertical axis) for coordinate rotation control.
When this parameter is set, the coordinate rotation control angle (#8627) will be automatically calculated.

---Setting range---

-999999.999 to 999999.999 (mm)

【#8627】 Coord rot angle

Set the rotation angle for coordinate rotation control.
When this parameter is set, the coordinate rotation vector (#8625, #8626) will be "0".

---Setting range---

-360.000 to 360.000 (°)

【#8701】 Tool length

Set the length to the touch tool tip.

---Setting range---

±99999.999 (mm)

【#8702】 Tool Dia

Set the diameter of the sphere at the touch tool tip.

---Setting range---

±99999.999 (mm)

II Parameters

1. User Parameters

【#8703】 OFFSET X

This sets the deviation amount (X direction) from the touch tool center to the spindle center.

---Setting range---
±99999.999 (mm)

【#8704】 OFFSET Y

Set the deviation amount (Y direction) from the touch tool center to the spindle center.

---Setting range---
±99999.999 (mm)

【#8705】 RETURN

Set the one-time return distance for contacting again.

---Setting range---
0 to 99999.999 (mm)

【#8706】 FEED

Set the feedrate when contacting again.

---Setting range---
1 to 60000 (mm/min)

【#8707】 Skip past amount (H)

Set the difference (horizontal axis direction) between the skip read value and actual skip position.

---Setting range---
±99999.999 (mm)

【#8708】 Skip past amount (V)

Set the difference (vertical axis direction) between the skip read value and actual skip position.

---Setting range---
±99999.999 (mm)

【#8709】 EXT work sign rvs

Select when using the external workpiece coordinate system with Z shift.
Select whether to reverse the sign.

- 0: External workpiece offset (Z shift) without sign reversal
- 1: External workpiece offset (Z shift) with sign reversal

【#8710】 EXT work ofs invld

Set whether to enable external workpiece offset subtraction when setting the workpiece coordinate offset.

- 0: Not subtract the external workpiece offset. (Conventional specification)
- 1: Subtract the external workpiece offset.

【#8711】 TLM L meas axis

Set the tool length measurement axis.
Set the "#1022 axname2" axis name.

---Setting range---
Axis name

(Note) If the axis name is illegal or not set, the 3rd axis name will be set as default.

【#8712】 TLM D meas axis

Set the tool diameter measurement axis.
Set the "#1022 axname2" axis name.

---Setting range---
Axis name

(Note) If the axis name is illegal or not set, the 1st axis name will be set as default.

【#8880】 Subpro stor D0: dev

Select the storage destination (device) for the subprogram.

When D0 is designated at a subprogram call, the subprogram to be called will be searched from the device selected with this parameter.

(Example)

The following will be searched:

M98 P (program No.), D0

Device: "#8880 Subpro stor D0: dev" device

Directory: "#8881 Subpro stor D0: dir" directory

(Note 1) When the called subprogram is not found in the selected storage destination, a program error will occur.

(Note 2) When D0 to D4 is not designated at a subprogram call, the subprogram will be searched from the memory.

---Setting range---
M : Memory
G : HD
F : FD
R : Memory card
D : Data server
E : Ethernet

II Parameters

1. User Parameters

【#8881】 Subpro stor D0: dir

Select the storage destination (directory) for the subprogram.
When D0 is designated at a subprogram call, the subprogram to be called will be searched from the directory selected with this parameter.
Refer to "#8880 Subpro stor D0: dev".

---Setting range---
Directory 48 characters

【#8882】 Subpro stor D1: dev

Select the storage destination (device) for the subprogram.
When D1 is designated at a subprogram call, the subprogram to be called will be searched from the device selected with this parameter.

(Example)
The following will be searched:
M98 P (program No.), D1
Device: "#8882 Subpro stor D1: dev" device
Directory: "#8883 Subpro stor D1: dir" directory

(Note 1) When the called subprogram is not found in the selected storage destination, a program error will occur.

(Note 2) When D0 to D4 is not designated at a subprogram call, the subprogram will be searched from the memory.

---Setting range---
M : Memory
G : HD
F : FD
R : Memory card
D : Data server
E : Ethernet

【#8883】 Subpro stor D1: dir

Select the storage destination (directory) for the subprogram.
When D1 is designated at a subprogram call, the subprogram to be called will be searched from the directory selected with this parameter.
Refer to "#8882 Subpro stor D1: dev".

---Setting range---
Directory 48 characters

【#8884】 Subpro stor D2: dev

Select the storage destination (device) for the subprogram.
When D2 is designated at a subprogram call, the subprogram to be called will be searched from the device selected with this parameter.

(Example)
The following will be searched:
M98 P (program No.), D2
Device: "#8884 Subpro stor D2: dev" device
Directory: "#8885 Subpro stor D2: dir" directory

(Note 1) When the called subprogram is not found in the selected storage destination, a program error will occur.

(Note 2) When D0 to D4 is not designated at a subprogram call, the subprogram will be searched from the memory.

---Setting range---
M : Memory
G : HD
F : FD
R : Memory card
D : Data server
E : Ethernet

【#8885】 Subpro stor D2: dir

Select the storage destination (directory) for the subprogram.
When D2 is designated at a subprogram call, the subprogram to be called will be searched from the directory selected with this parameter.
Refer to "#8884 Subpro stor D2: dev".

---Setting range---
Directory 48 characters

II Parameters

1. User Parameters

【#8886】 Subpro stor D3: dev

Select the storage destination (device) for the subprogram.
When D3 is designated at a subprogram call, the subprogram to be called will be searched from the device selected with this parameter.

(Example)

The following will be searched:

M98 P (program No.), D3

Device: "#8886 Subpro stor D3: dev" device

Directory: "#8887 Subpro stor D3: dir" directory

(Note 1) When the called subprogram is not found in the selected storage destination, a program error will occur.

(Note 2) When D0 to D4 is not designated at a subprogram call, the subprogram will be searched from the memory.

---Setting range---

M : Memory
G : HD
F : FD
R : Memory card
D : Data server
E : Ethernet

【#8887】 Subpro stor D3: dir

Select the storage destination (directory) for the subprogram.

When D3 is designated at a subprogram call, the subprogram to be called will be searched from the directory selected with this parameter.
Refer to "#8886 Subpro stor D3: dev".

---Setting range---

Directory 48 characters

【#8888】 Subpro stor D4: dev

Select the storage destination (device) for the subprogram.

When D4 is designated at a subprogram call, the subprogram to be called will be searched from the device selected with this parameter.

(Example)

The following will be searched:

M98 P (program No.), D4

Device: "#8888 Subpro stor D4: dev" device

Directory: "#8889 Subpro stor D4: dir" directory

(Note 1) When the called subprogram is not found in the selected storage destination, a program error will occur.

(Note 2) When D0 to D4 is not designated at a subprogram call, the subprogram will be searched from the memory.

---Setting range---

M : Memory
G : HD
F : FD
R : Memory card
D : Data server
E : Ethernet

【#8889】 Subpro stor D4: dir

Select the storage destination (directory) for the subprogram.

When D4 is designated at a subprogram calling, the subprogram to be called will be searched from the directory selected with this parameter.
Refer to "#8888 Subpro stor D4: dev".

---Setting range---

Directory 48 characters

【#8901】 Counter type 1

Set the type of counter displayed at the upper left of the AUTO/MDI display on the Monitor screen.

1: Current position
2: Work coordinate position
3: Machine position
4: Program position
8: Remain command
9: Manual interrupt amount
10: Next command
11: Restart position
12: Remain distance
16: Tip work coordinate position
18: Tool axis movement
19: Tip machine position
20: Relative position

---Setting range---

0 to 255

II Parameters

1. User Parameters

【#8902】 Counter type 2

Set the type of counter displayed at the lower left of the AUTO/MDI display on the Monitor screen.

- 1: Current position
- 2: Work coordinate position
- 3: Machine position
- 4: Program position
- 8: Remain command
- 9: Manual interrupt amount
- 10: Next command
- 11: Restart position
- 12: Remain distance
- 16: Tip work coordinate position
- 18: Tool axis movement
- 19: Tip machine position
- 20: Relative position

---Setting range---
0 to 255

【#8903】 Counter type 3

Set the type of counter displayed at the upper right of the AUTO/MDI display on the Monitor screen.

- 1: Current position
- 2: Work coordinate position
- 3: Machine position
- 4: Program position
- 8: Remain command
- 9: Manual interrupt amount
- 10: Next command
- 11: Restart position
- 12: Remain distance
- 16: Tip work coordinate position
- 18: Tool axis movement
- 19: Tip machine position
- 20: Relative position

---Setting range---
0 to 255

【#8904】 Counter type 4

Set the type of counter displayed at the lower right of the AUTO/MDI display on the Monitor screen.

- 1: Current position
- 2: Work coordinate position
- 3: Machine position
- 4: Program position
- 8: Remain command
- 9: Manual interrupt amount
- 10: Next command
- 11: Restart position
- 12: Remain distance
- 16: Tip work coordinate position
- 18: Tool axis movement
- 19: Tip machine position
- 20: Relative position

---Setting range---
0 to 255

【#8905】 Counter type 5

Set the type of counter displayed at the left of the Manual display on the Monitor screen.

- 1: Current position
- 2: Work coordinate position
- 3: Machine position
- 4: Program position
- 8: Remain command
- 9: Manual interrupt amount
- 10: Next command
- 11: Restart position
- 12: Remain distance
- 16: Tip work coordinate position
- 18: Tool axis movement
- 19: Tip machine position
- 20: Relative position

---Setting range---
0 to 255

II Parameters

1. User Parameters

【#8906】 Counter type 6

Set the type of counter displayed at the right of the Manual display on the Monitor screen.

- 1: Current position
- 2: Work coordinate position
- 3: Machine position
- 4: Program position
- 8: Remain command
- 9: Manual interrupt amount
- 10: Next command
- 11: Restart position
- 12: Remain distance
- 16: Tip work coordinate position
- 18: Tool axis movement
- 19: Tip machine position
- 20: Relative position

---Setting range---

0 to 255

【#8910】 Edit undo

Set whether to enable the Undo function during program edit on the Monitor screen or Edit screen.

- 0: Disable
- 1: Enable

【#8914】 Auto Top search

Select the operation method for restart search type 2.

- 0: It is necessary to set the top search position arbitrarily.
- 1: The restart search is executed from O No. that is designated as head.

【#8915】 Auto backup day 1

When the NC power is ON after the designated date was passed over, the automatic backup is executed.

When "-1" is set to "Auto backup day 1", the automatic backup is executed every turning NC power ON.

When "0" is set to all on "Auto backup day 1" to "4", the automatic backup is not executed. It is possible to specify the designated date up to 4 days for a month.

---Setting range---

-1 to 31("-1" can be set for "Auto backup day 1" only.)

【#8916】 Auto backup day 2

When the NC power is ON after the designated date was passed over, the automatic backup is executed.

When "-1" is set to "Auto backup day 1", the automatic backup is executed every turning NC power ON.

When "0" is set to all on "Auto backup day 1" to "4", the automatic backup is not executed. It is possible to specify the designated date up to 4 days for a month.

---Setting range---

-1 to 31("-1" can be set for "Auto backup day 1" only.)

【#8917】 Auto backup day 3

When the NC power is ON after the designated date was passed over, the automatic backup is executed.

When "-1" is set to "Auto backup day 1", the automatic backup is executed every turning NC power ON.

When "0" is set to all on "Auto backup day 1" to "4", the automatic backup is not executed. It is possible to specify the designated date up to 4 days for a month.

---Setting range---

-1 to 31("-1" can be set for "Auto backup day 1" only.)

【#8918】 Auto backup day 4

When the NC power is ON after the designated date was passed over, the automatic backup is executed.

When "-1" is set to "Auto backup day 1", the automatic backup is executed every turning NC power ON.

When "0" is set to all on "Auto backup day 1" to "4", the automatic backup is not executed. It is possible to specify the designated date up to 4 days for a month.

---Setting range---

-1 to 31("-1" can be set for "Auto backup day 1" only.)

【#8919】 Auto backup device

Select the automatic backup target device.

*The setting range differs according to the model.

---Setting range---

[M700 Series]

- 0: DS
- 1: HD
- 2: Memory card

[M70 Series]

- 0: Memory card

II Parameters

1. User Parameters

【#8920】 3D tool ofs select

Select the method to calculate the drawing position when drawing a solid. With 3D drawing, the drawing position (tool tip position) is calculated with the method designated with this parameter, and the image is drawn.

- 0: Machine position ± tool shape setting window data
- 1: Machine position ± tool compensation amount
- 2: Machine position ± tool shape setting window data
- 3: Machine position ± tool shape setting window data

【#8921】 Mass Edit select

Select the editing mode for the machining programs saved in HD, FD, and memory card. When the program size is 1.0MB (When "#8910 Edit Undo" is invalid, 2.0MB) or more, mass-editing will be applied.

- 0: Regular editing mode
- 1: Mass-editing mode

【#8922】 T-reg-dup check

Set whether to enable the duplication check in registering tools to magazine pots, and in setting tool Nos. for spindle/standby.

- 0: Duplication check valid for all valid magazines
- 1: Duplication check invalid
- 2: Duplication check valid only for the selected magazine

【#8923(PR)】 Hide Edit-IO menu

Set whether to enable the edit-in/out menu. When disabled, the edit-input/output menu won't appear. However, the maintenance-in/out menu is always enabled regardless of this parameter setting.

- 0: Enable
- 1: Disable

【#8924】 MEAS. CONFIRM MSG

Select whether to display a confirming message when attempting to write compensation data for tool measurement, or coordinate system data for workpiece measurement.

- 0: Not display a confirming message
- 1: Display a confirming message

【#8925】 SP on 1st part sys

Set a spindle No. to be displayed on the 1st part system window when 2-part system simultaneous display is valid.

- High-order: Select an upper side spindle No.
- Low-order: Select a lower side spindle No.

(Note 1) When "00" is set, spindles will be displayed in a default order (the 1st spindle on the upper side, the 2nd spindle on the lower side)

(Note 2) If you designate a bigger number than the setting of "#1039 spinno", or either the high-order or low-order setting is "0", the 1st spindle will be displayed.

---Setting range---

- High-order: 0 to 6
- Low-order: 0 to 6

【#8926】 SP on 2nd part sys

Set a spindle No. to be displayed on the 2nd part system window when 2-part system simultaneous display is valid.

- High-order: Select an upper side spindle No.
- Low-order: Select a lower side spindle No.

(Note 1) When "00" is set, spindles will be displayed in a default order (the 1st spindle on the upper side, the 2nd spindle on the lower side)

(Note 2) If you designate a bigger number than the setting of "#1039 spinno", or either the high-order or low-order setting is "0", the 1st spindle will be displayed.

---Setting range---

- High-order: 0 to 6
- Low-order: 0 to 6

【#8927】 SP on 3rd part sys

Set a spindle No. to be displayed on the 3rd part system window when 2-part system simultaneous display is valid.

- High-order: Select an upper side spindle No.
- Low-order: Select a lower side spindle No.

(Note 1) When "00" is set, spindles will be displayed in a default order (the 1st spindle on the upper side, the 2nd spindle on the lower side)

(Note 2) If you designate a bigger number than the setting of "#1039 spinno", or either the high-order or low-order setting is "0", the 1st spindle will be displayed.

---Setting range---

- High-order: 0 to 6
- Low-order: 0 to 6

II Parameters

1. User Parameters

【#8928】 SP on 4th part sys

Set a spindle No. to be displayed on the 4th part system window when 2-part system simultaneous display is valid.

High-order: Select an upper side spindle No.

Low-order: Select a lower side spindle No.

(Note 1) When "00" is set, spindles will be displayed in a default order (the 1st spindle on the upper side, the 2nd spindle on the lower side)

(Note 2) If you designate a bigger number than the setting of "#1039 spinno", or either the high-order or low-order setting is "0", the 1st spindle will be displayed.

---Setting range---

High-order: 0 to 6

Low-order: 0 to 6

【#9001】 DATA IN PORT

Select the port for inputting the data such as machine program and parameters.

1: ch1

2: ch2

【#9002】 DATA IN DEV.

Select the device No. for inputting the data. (The device Nos. correspond to the input/output device parameters.)

---Setting range---

0 to 4

【#9003】 DATA OUT PORT

Select the port for outputting the data such as machine program and parameters.

1: ch1

2: ch2

【#9004】 DATA OUT DEV.

Select the device No. for outputting the data. (The device Nos. correspond to the input/output device parameters.)

---Setting range---

0 to 4

【#9005】 TAPE MODE PORT

Select the input port for running with the tape mode.

1: ch1

2: ch2

【#9006】 TAPE MODE DEV.

Select the device No. to be run with the tape mode. (The device Nos. correspond to the input/output device parameters.)

---Setting range---

0 to 4

【#9007】 MACRO PRINT PORT

Select the output port used for the user macro DPRINT command.

1: ch1

2: ch2

【#9008】 MACRO PRINT DEV.

Select the device No. used for the DPRINT command. (The device Nos. correspond to the input/output device parameters.)

---Setting range---

0 to 4

【#9009】 PLC IN/OUT PORT

Select the port for inputting/outputting various data with PLC.

1: ch1

2: ch2

【#9010】 PLC IN/OUT DEV.

Select the device No. used for the PLC input/output. (The device Nos. correspond to the input/output device parameters.)

---Setting range---

0 to 4

【#9011】 REMOTE PRG IN PORT

Select the port for inputting remote programs.

1: ch1

2: ch2

【#9012】 REMOTE PRG IN DEV.

Select the device No. used to input remote programs. The device Nos. correspond to the input/output device parameters.

---Setting range---

0 to 4

II Parameters

1. User Parameters

【#9013】 EXT UNIT PORT

Select the port for communication with an external unit.

- 1: ch1
- 2: ch2

【#9014】 EXT UNIT DEV.

Select the unit No. used for communication with an external unit(The unit Nos. correspond to the input/output device parameters.)

---Setting range---
0 to 4

【#9017】 HANDY TERMINAL PORT

Select the port for communication with a handy terminal.

- 1: ch1
- 2: ch2

【#9018】 HANDY TERMINAL DEV.

Select the device No. used for communication with a handy terminal. (The device Nos. correspond to the input/output device parameters.)

---Setting range---
0 to 4

【#9051】 Data I/O port

Select whether to use display side serial port or NC side serial port for data input/output function.

- 0: Display side serial port
- 1: Display side serial port
- 2: NC side serial port

(Note) The setting range differs according to the model.

【#9052】 Tape mode port

Select whether to use display side serial port or NC side serial port for tape mode.

- 0: NC side serial port
- 1: Display side serial port
- 2: NC side serial port

(Note) The setting range differs according to the model.

【#9101】 DEV0 DEVICE NAME

Set the device name corresponding to the device No.
Set a simple name for quick identification.

---Setting range---

Use alphabet characters, numerals and symbols to set a name within 3 characters.

【#9102】 DEV0 BAUD RATE

Select the serial communication speed.

- 0: 19200 (bps)
- 1: 9600
- 2: 4800
- 3: 2400
- 4: 1200
- 5: 600
- 6: 300
- 7: 110

【#9103】 DEV0 STOP BIT

Select the stop bit length used in the start-stop system.

Refer to "#9104 DEV0 PARITY CHECK". At the output of data, the number of characters is always adjusted for the parity check.

- 1: 1 (bit)
- 2: 1.5
- 3: 2

【#9104】 DEV0 PARITY CHECK

Select whether to add the parity check bit to the data.



Set this parameter in accordance with the I/O device specifications.

- 0: Not add a parity bit in I/O mode
- 1: Add a parity bit in I/O mode

【#9105】 DEV0 EVEN PARITY

Select odd or even when parity is added to the data. This parameter is ignored when no parity is added.

- 0: Odd parity
- 1: Even parity

II Parameters

1. User Parameters

【#9106】 DEV0 CHR. LENGTH

Set the length of the data bit.
Refer to "#9104 DEV0 PARITY CHECK".
0: 5 (bit)
1: 6
2: 7 (NC connection not supported)
3: 8

【#9107】 DEV0 TERMINATR TYP

Select the code to terminate data reading.
0, 3: EOR
1, 2: EOB or EOR

【#9108】 DEV0 HAND SHAKE

Select the transmission control method.
No handshaking will be used when a value except 1 to 3 is set.
1: RTS/CTS method
2: No handshaking
3: DC code method

【#9109】 DEV0 DC CODE PRTY

Select the DC code type when the DC code method is selected.
0: Not add parity to DC code (DC3 = 13H)
1: Add parity to DC code (DC3 = 93H)

【#9111】 DEV0 DC2/4 OUTPUT

Select the DC code handling when outputting data to the output device.
---Setting range---
DC2 / DC4
0: None / None
1: Yes / None
2: None / Yes
3: Yes / Yes

【#9112】 DEV0 CR OUTPUT

Select whether to add the (CR) code just before the EOB (L/F) code during output.
0: Not add
1: Add

【#9113】 DEV0 EIA OUTPUT

Select ISO or EIA code for data output.
In data input mode, the ISO and EIA codes are identified automatically.
0: ISO code output
1: EIA code output

【#9114】 DEV0 FEED CHR.

Set the length of the tape feed to be output at the start and end of the data during tape output.
---Setting range---
0 to 999 (characters)

【#9115】 DEV0 PARITY V

Select whether to perform the parity check for the number of characters in a block at the input of data.
At the output of data, the number of characters is always adjusted to for the parity check.
0: Not perform parity V check
1: Perform parity V check

【#9116】 DEV0 TIME-OUT (sec)

Set the time out time to detect an interruption in communication.
Time out check will not be executed when set to "0".
---Setting range---
0 to 30 (s)

【#9117】 DEV0 DR OFF

Select whether to enable the DR data check in data I/O mode.
0: Enable
1: Disable

【#9118】 DEV0 DATA ASCII

Select the code of the output data.
0: ISO/EIA code
(Depends on whether #9113, #9213, #9313, #9413 or #9513 EIA output parameter is set up.)
1: ASCII code

【#9119】 DEV0 INPUT TYPE

Select the mode for input (verification).
0: Standard input (Data from the very first EOB is handled as significant information.)
1: EOBs following the first EOB of the input data are skipped until data other than EOB is input

II Parameters

1. User Parameters

【#9121】 DEV0 EIA CODE [

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "[".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9122】 DEV0 EIA CODE]

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "]".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9123】 DEV0 EIA CODE

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "#".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9124】 DEV0 EIA CODE *

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "*".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9125】 DEV0 EIA CODE =

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "=".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9126】 DEV0 EIA CODE :

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code ":".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9127】 DEV0 EIA CODE \$

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\$".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9128】 DEV0 EIA CODE !

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "!".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9201】 DEV1 DEVICE NAME

Set the device name corresponding to the device No.
Set a simple name for quick identification.

---Setting range---
Use alphabet characters, numerals and symbols to set a name within 3 characters.

【#9202】 DEV1 BAUD RATE

Select the serial communication speed.

- 0: 19200 (bps)
- 1: 9600
- 2: 4800
- 3: 2400
- 4: 1200
- 5: 600
- 6: 300
- 7: 110

II Parameters

1. User Parameters


【#9203】 DEV1 STOP BIT

Select the stop bit length used in the start-stop system.
Refer to "#9204 DEV1 PARITY CHECK". At the output of data, the number of characters is always adjusted to for the parity check.

- 1: 1 (bit)
- 2: 1.5
- 3: 2

【#9204】 DEV1 PARITY CHECK

Select whether to add a parity check bit to the data.



Set this parameter in accordance with the I/O device specifications.

- 0: Not add a parity bit in I/O mode
- 1: Add a parity bit in I/O mode

【#9205】 DEV1 EVEN PARITY

Select whether even or odd parity will be used when parity is used. This parameter is ignored when no parity is added.

- 0: Odd parity
- 1: Even parity

【#9206】 DEV1 CHR. LENGTH

Select the length of the data bit.
Refer to "#9204 DEV1 PARITY CHECK".

- 0: 5 (bit)
- 1: 6
- 2: 7 (NC connection not supported)
- 3: 8

【#9207】 DEV1 TERMINATR TYP

Select the code to terminate data reading.

- 0,3: EOR
- 1,2: EOB or EOR

【#9208】 DEV1 HAND SHAKE

Select the transmission control method.

No handshaking will be used when a value except 1 to 3 is set.

- 1: RTS/CTS method
- 2: No handshaking
- 3: DC code method

【#9209】 DEV1 DC CODE PRTY

Select the DC code type when the DC code method is selected.

- 0: Not add parity to DC code (DC3 = 13H)
- 1: Add parity to DC code (DC3 = 93H)

【#9211】 DEV1 DC2/4 OUTPUT

Select the DC code handling when outputting data to the output device.

---Setting range---
DC2 / DC4
0: None / None
1: Yes / None
2: None / Yes
3: Yes / Yes

【#9212】 DEV1 CR OUTPUT

Select whether to add the (CR) code just before the EOB (L/F) code during output.

- 0: Not add
- 1: Add

【#9213】 DEV1 EIA OUTPUT

Select ISO or EIA code for data output.

In data input mode, the ISO and EIA codes are identified automatically.

- 0: ISO code output
- 1: EIA code output

【#9214】 DEV1 FEED CHR.

Set the length of the tape feed to be output at the start and end of the data during tape output.

---Setting range---
0 to 999 (characters)

【#9215】 DEV1 PARITY V

Select whether to perform the parity check for the number of characters in a block at the input of data.

At the output of data, the number of characters is always adjusted to for the parity check.

- 0: Not perform parity V check
- 1: Perform parity V check

II Parameters

1. User Parameters

【#9216】 DEV1 TIME-OUT (sec)

Set the time out time to detect an interruption in communication.
Time out check will not be executed when set to "0".

---Setting range---
0 to 30 (s)

【#9217】 DEV1 DR OFF

Set whether to enable the DR data check in data I/O mode.
0: Enable
1: Disable

【#9218】 DEV1 DATA ASCII

Select the code of the output data.
0: ISO/EIA code
(Depends on whether #9113, #9213, #9313, #9413 or #9513 EIA output parameter is set up.)
1: ASCII code

【#9219】 DEV1 INPUT TYPE

Select the mode for input (verification).
0: Standard input (Data from the very first EOB is handled as significant information.)
1: EOBs following the first EOB of the input data are skipped until data other than EOB is input

【#9221】 DEV1 EIA CODE [

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "[".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9222】 DEV1 EIA CODE]

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "]".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9223】 DEV1 EIA CODE

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "#".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified. .

---Setting range---
0 to FF (hexadecimal)

【#9224】 DEV1 EIA CODE *

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "*".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9225】 DEV1 EIA CODE =

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "=".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9226】 DEV1 EIA CODE :

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code ":".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9227】 DEV1 EIA CODE \$

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\$".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

II Parameters

1. User Parameters

【#9228】 DEV1 EIA CODE !

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "!".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9301】 DEV2 DEVICE NAME

Set the device name corresponding to the device No.
Set a simple name for quick identification.

---Setting range---
Use alphabet characters, numerals and symbols to set a name within 3 characters.

【#9302】 DEV2 BAUD RATE

Select the serial communication speed.

- 0: 19200 (bps)
- 1: 9600
- 2: 4800
- 3: 2400
- 4: 1200
- 5: 600
- 6: 300
- 7: 110

【#9303】 DEV2 STOP BIT


Select the stop bit length used in the start-stop system.

Refer to "#9304 DEV2 PARITY CHECK". At the output of data, the number of characters is always adjusted to for the parity check.

- 1: 1 (bit)
- 2: 1.5
- 3: 2

【#9304】 DEV2 PARITY CHECK

Select whether to add a parity check bit to the data.



Set this parameter in accordance with the I/O device specifications.

- 0: Not add a parity bit in I/O mode
- 1: Add a parity bit in I/O mode

【#9305】 DEV2 EVEN PARITY

Select whether even or odd parity will be used when parity is used. This parameter is ignored when no parity is added.

- 0: Odd parity
- 1: Even parity

【#9306】 DEV2 CHR. LENGTH

Select the length of the data bit.
Refer to "#9304 DEV2 PARITY CHECK".

- 0: 5 (bit)
- 1: 6
- 2: 7 (NC connection not supported)
- 3: 8

【#9307】 DEV2 TERMINATR TYP

Select the code to terminate data reading.

- 0, 3: EOR
- 1, 2: EOB or EOR

【#9308】 DEV2 HAND SHAKE

Select the transmission control method.

No handshaking will be used when a value except 1 to 3 is set.

- 1: RTS/CTS method
- 2: No handshaking
- 3: DC code method

【#9309】 DEV2 DC CODE PRY

Select the DC code type when the DC code method is selected.

- 0: Not add parity to DC code (DC3 = 13H)
- 1: Add parity to DC code (DC3 = 93H)

【#9311】 DEV2 DC2/4 OUTPUT

Select the DC code handling when outputting data to the output device.

---Setting range---
DC2 / DC4
0: None / None
1: Yes / None
2: None / Yes
3: Yes / Yes

II Parameters

1. User Parameters

【#9312】 DEV2 CR OUTPUT

Select whether to add the (CR) code just before the EOB (L/F) code during output.
0: Not add
1: Add

【#9313】 DEV2 EIA OUTPUT

Select ISO or EIA code for data output.
In data input mode, the ISO and EIA codes are identified automatically.
0: ISO code output
1: EIA code output

【#9314】 DEV2 FEED CHR.

Set the length of the tape feed to be output at the start and end of the data during tape output.
---Setting range---
0 to 999 (characters)

【#9315】 DEV2 PARITY V

Select whether to perform the parity check for the number of characters in a block at the input of data.
At the output of data, the number of characters is always adjusted to for the parity check.
0: Not perform parity V check
1: Perform parity V check

【#9316】 DEV2 TIME-OUT (sec)

Set the time out time to detect an interruption in communication.
Time out check will not be executed when set to "0".
---Setting range---
0 to 30 (s)

【#9317】 DEV2 DR OFF

Select whether to enable the DR data check in data I/O mode.
0: Enable
1: Disable

【#9318】 DEV2 DATA ASCII

Select the code of the output data.
0: ISO/EIA code
(Depends on whether #9113, #9213, #9313, #9413 or #9513 EIA output parameter is set up.)
1: ASCII code

【#9319】 DEV2 INPUT TYPE

Select the mode for input (verification).
0: Standard input (Data from the very first EOB is handled as significant information.)
1: EOBs following the first EOB of the input data are skipped until data other than EOB is input

【#9321】 DEV2 EIA CODE [

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "[".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.
---Setting range---
0 to FF (hexadecimal)

【#9322】 DEV2 EIA CODE]

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "]".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.
---Setting range---
0 to FF (hexadecimal)

【#9323】 DEV2 EIA CODE

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "#".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.
---Setting range---
0 to FF (hexadecimal)

【#9324】 DEV2 EIA CODE *

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "*".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.
---Setting range---
0 to FF (hexadecimal)

II Parameters

1. User Parameters

【#9325】 DEV2 EIA CODE =

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "=".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9326】 DEV2 EIA CODE :

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code ":".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9327】 DEV2 EIA CODE \$

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\$".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9328】 DEV2 EIA CODE !

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "!".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9401】 DEV3 DEVICE NAME

Set the device name corresponding to the device No.
Set a simple name for quick identification.

---Setting range---
Use alphabet characters, numerals and symbols to set a name within 3 characters.

【#9402】 DEV3 BAUD RATE

Select the serial communication speed.

- 0: 19200 (bps)
- 1: 9600
- 2: 4800
- 3: 2400
- 4: 1200
- 5: 600
- 6: 300
- 7: 110


【#9403】 DEV3 STOP BIT

Select the stop bit length used in the start-stop system.
Refer to "#9404 DEV3 PARITY CHECK". At the output of data, the number of characters is always adjusted to for the parity check.

- 1: 1 (bit)
- 2: 1.5
- 3: 2

【#9404】 DEV3 PARITY CHECK

Select whether to add a parity check bit to the data.



Set this parameter in accordance with the I/O device specifications.

- 0: Not add a parity bit in I/O mode
- 1: Add a parity bit in I/O mode

【#9405】 DEV3 EVEN PARITY

Select whether even or odd parity will be used when parity is used. This parameter is ignored when no parity is added.

- 0: Odd parity
- 1: Even parity

【#9406】 DEV3 CHR. LENGTH

Select the length of the data bit.
Refer to "#9404 DEV3 PARITY CHECK".

- 0: 5 (bit)
- 1: 6
- 2: 7 (NC connection not supported)
- 3: 8

II Parameters

1. User Parameters

【#9407】 DEV3 TERMINATR TYP

Select the code to terminate data reading.
0, 3: EOR
1, 2: EOB or EOR

【#9408】 DEV3 HAND SHAKE

Select the transmission control method.
No handshaking will be used when a value except 1 to 3 is set.
1: RTS/CTS method
2: No handshaking
3: DC code method

【#9409】 DEV3 DC CODE PRTY

Select the DC code type when the DC code method is selected.
0: Not add parity to DC code (DC3 = 13H)
1: Add parity to DC code (DC3 = 93H)

【#9411】 DEV3 DC2/4 OUTPUT

Select the DC code handling when outputting data to the output device.
---Setting range---
DC2 / DC4
0: None / None
1: Yes / None
2: None / Yes
3: Yes / Yes

【#9412】 DEV3 CR OUTPUT

Select whether to add the (CR) code just before the EOB (L/F) code during output.
0: Not add
1: Add

【#9413】 DEV3 EIA OUTPUT

Select ISO or EIA code for data output.
In data input mode, the ISO and EIA codes are identified automatically.
0: ISO code output
1: EIA code output

【#9414】 DEV3 FEED CHR.

Set the length of the tape feed to be output at the start and end of the data during tape output.
---Setting range---
0 to 999 (characters)

【#9415】 DEV3 PARITY V

Select whether to perform the parity check for the number of characters in a block at the input of data.
At the output of data, the number of characters is always adjusted to for the parity check.
0: Not perform parity V check
1: Perform parity V check

【#9416】 DEV3 TIME-OUT (sec)

Set the time out time to detect an interruption in communication.
Time out check will not be executed when set to "0".
---Setting range---
0 to 30 (s)

【#9417】 DEV3 DR OFF

Select whether to enable the DR data check in data I/O mode.
0: Enable
1: Disable

【#9418】 DEV3 DATA ASCII

Select the code of the output data.
0: ISO/EIA code
(Depends on whether #9113, #9213, #9313, #9413 or #9513 EIA output parameter is set up.)
1: ASCII code

【#9419】 DEV3 INPUT TYPE

Select the mode for input (verification).
0: Standard input (Data from the very first EOB is handled as significant information.)
1: EOBs following the first EOB of the input data are skipped until data other than EOB is input.

【#9421】 DEV3 EIA CODE [

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "[".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.
---Setting range---
0 to FF (hexadecimal)

II Parameters

1. User Parameters

【#9422】 DEV3 EIA CODE]

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "]"".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9423】 DEV3 EIA CODE

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "#".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9424】 DEV3 EIA CODE *

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "*".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9425】 DEV3 EIA CODE =

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "=".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9426】 DEV3 EIA CODE :

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code ":".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9427】 DEV3 EIA CODE \$

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\$".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9428】 DEV3 EIA CODE !

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "!".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---
0 to FF (hexadecimal)

【#9501】 DEV4 DEVICE NAME

Set the device name corresponding to the device No.
Set a simple name for quick identification.

---Setting range---
Use alphabet characters, numerals and symbols to set a name within 3 characters.

【#9502】 DEV4 BAUD RATE

Select the serial communication speed.

- 0: 19200 (bps)
- 1: 9600
- 2: 4800
- 3: 2400
- 4: 1200
- 5: 600
- 6: 300
- 7: 110

【#9503】 DEV4 STOP BIT

Select the stop bit length used in the start-stop system.
Refer to "#9504 DEV4 PARITY CHECK". At the output of data, the number of characters is always adjusted to for the parity check.


- 1: 1 (bit)
- 2: 1.5
- 3: 2

II Parameters

1. User Parameters

【#9504】 DEV4 PARITY CHECK

Select whether to add a parity check bit to the data.



Set this parameter in accordance with the I/O device specifications.

- 0: Not add a parity bit in I/O mode
- 1: Add a parity bit in I/O mode

【#9505】 DEV4 EVEN PARITY

Select whether even or odd parity will be used when parity is used. This parameter is ignored when no parity is added.

- 0: Odd parity
- 1: Even parity

【#9506】 DEV4 CHR. LENGTH

Select the length of the data bit.

Refer to "#9504 DEV4 PARITY CHECK".

- 0: 5 (bit)
- 1: 6
- 2: 7 (NC connection not supported)
- 3: 8

【#9507】 DEV4 TERMINATR TYP

Select the code to terminate data reading.

- 0, 3: EOR
- 1, 2: EOB or EOR

【#9508】 DEV4 HAND SHAKE

Select the transmission control method.

No handshaking will be used when a value except 1 to 3 is set.

- 1: RTS/CTS method
- 2: No handshaking
- 3: DC code method

【#9509】 DEV4 DC CODE PRTY

Select the DC code type when the DC code method is selected.

- 0: Not add parity to DC code (DC3 = 13H)
- 1: Add parity to DC code (DC3 = 93H)

【#9511】 DEV4 DC2/4 OUTPUT

Select the DC code handling when outputting data to the output device.

- Setting range---
- DC2 / DC4
 - 0: None / None
 - 1: Yes / None
 - 2: None / Yes
 - 3: Yes / Yes

【#9512】 DEV4 CR OUTPUT

Select whether to add the (CR) code just before the EOB (L/F) code during output.

- 0: Not add
- 1: Add

【#9513】 DEV4 EIA OUTPUT

Select ISO or EIA code for data output.

In data input mode, the ISO and EIA codes are identified automatically.

- 0: ISO code output
- 1: EIA code output

【#9514】 DEV4 FEED CHR.

Set the length of the tape feed to be output at the start and end of the data during tape output.

- Setting range---
- 0 to 999 (characters)

【#9515】 DEV4 PARITY V

Select whether to perform the parity check for the number of characters in a block at the input of data.

At the output of data, the number of characters is always adjusted to for the parity check.

- 0: Not perform parity V check
- 1: Perform parity V check

【#9516】 DEV4 TIME-OUT (sec)

Set the time out time to detect an interruption in communication.

Time out check will not be executed when set to "0".

- Setting range---
- 0 to 30 (s)

II Parameters

1. User Parameters

【#9517】 DEV4 DR OFF

Select whether to enable the DR data check in data I/O mode.

- 0: Enable
- 1: Disable

【#9518】 DEV4 DATA ASCII

Select the code of the output data.

- 0: ISO/EIA code
(Depends on whether #9113, #9213, #9313, #9413 or #9513 EIA output parameter is set up.)
- 1: ASCII code

【#9519】 DEV4 INPUT TYPE

Select the mode for input (verification).

- 0: Standard input (Data from the very first EOB is handled as significant information.)
- 1: EOBs following the first EOB of the input data are skipped until data other than EOB is input.

【#9521】 DEV4 EIA CODE [

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "[".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

- Setting range---
- 0 to FF (hexadecimal)

【#9522】 DEV4 EIA CODE]

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "]".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

- Setting range---
- 0 to FF (hexadecimal)

【#9523】 DEV4 EIA CODE

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "#".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

- Setting range---
- 0 to FF (hexadecimal)

【#9524】 DEV4 EIA CODE *

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "*".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

- Setting range---
- 0 to FF (hexadecimal)

【#9525】 DEV4 EIA CODE =

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "=".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

- Setting range---
- 0 to FF (hexadecimal)

【#9526】 DEV4 EIA CODE :

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code ":".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

- Setting range---
- 0 to FF (hexadecimal)

【#9527】 DEV4 EIA CODE \$

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\$".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

- Setting range---
- 0 to FF (hexadecimal)

【#9528】 DEV4 EIA CODE !

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "!".
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

- Setting range---
- 0 to FF (hexadecimal)

II Parameters

1. User Parameters

【#9601】 BAUD RATE

Select the rate at which data is transferred.

---Setting range---

- 0: 19200 (bps)
- 1: 9600
- 2: 4800
- 3: 2400
- 4: 1200
- 5: 600
- 6: 300
- 7: 110
- 8: 38400

【#9602】 STOP BIT

Select the stop bit length used in the start-stop system.


Refer to "#9603 PARITY EFFECTIVE". At the output of data, the number of characters is always adjusted to for the parity check.

- 1: 1 (bit)
- 2: 1.5
- 3: 2

【#9603】 PARITY EFFECTIVE

Select whether to add the parity bit to the data.

The parameter is set when using a parity bit separately from the data bit.



Set this parameter according to the specifications of input/output device.

- 0: Not add a parity bit at the input/output
- 1: Add a parity bit at the input/output

【#9604】 EVEN PARITY

Select odd or even when parity is added to the data. This parameter is ignored when no parity is added.

- 0: Odd parity
- 1: Even parity

【#9605】 CHR. LENGTH

Select the length of the data bit.

Refer to "#9603 PARITY EFFECTIVE".

- 0: 5 (bit)
- 1: 6
- 2: 7 (NC connection not supported)
- 3: 8

【#9606】 HAND SHAKE

Select the transmission control method.

"3" (DC code method) should be set for computer link B.

- 0: No control
- 1: RTS/CTS method
- 2: No handshaking
- 3: DC code method

【#9607】 TIME-OUT SET

Set the time-out time at which an interruption of data transfer during data input/output should be detected.

"0" means infinite time-out.

---Setting range---
0 to 999 (1/10s)

【#9608】 DATA CODE

Set the code to be used for the data description.

Refer to "#9603 PARITY EFFECTIVE".

- 0: ASCII code
- 1: ISO code

【#9609】 LINK PARAM. 1

bit1: DC1 output after NAK or SYN

Select whether to output the DC1 code after the NAK or SYN code is output.

- 0: Not output the DC1 code.
- 1: Output the DC1 code.

bit7: Enable/disable resetting

Select whether to enable the resetting in the computer link.

- 0: Enable
- 1: Disable

II Parameters

1. User Parameters

【#9610】 LINK PARAM. 2

Bit 2: Specify the control code parity (even parity for the control code).

Select whether to add an even parity to the control code, in accordance with the I/O device specifications.

- 0: Not add a parity bit to the control code
- 1: Add a parity bit to the control code

Bit 3: Parity V

Select whether to enable checking of parity V in one block at the input of the data.

- 0: Disable
- 1: Enable

【#9611】 Link PARAM. 3

Not used. Set to "0".

【#9612】 Link PARAM. 4

Not used. Set to "0".

【#9613】 Link PARAM. 5

Not used. Set to "0".

【#9614】 START CODE

Select the code used to command the first transfer of file data.

This parameter is used for a specific user. Normally set "0".

- 0: DC1 (11H)
- 1: BEL (07H)

【#9615】 CTRL. CODE OUT

bit 0: NAK output

Select whether to send the NAK code to the host if a communication error occurs in computer link B.

- 0: Not output the NAK code
- 1: Output the NAK code.

bit 1: SYN output

Select whether to send the SYN code to the host if NC resetting or an emergency stop occurs in computer link B.

- 0: Not output the SYN code.
- 1: Output the SYN code.

bit 3: DC3 output

Select whether to send the DC3 code to the host when the communication ends in computer link B.

- 0: Not output the DC3 code.
- 1: Output the DC3 code.

【#9616】 CTRL. INTERVAL

Not used. Set to "0".

【#9617】 WAIT TIME

Not used. Set to "0".

【#9618】 PACKET LENGTH

Not used. Set to "0".

【#9619】 BUFFER SIZE

Not used. Set to "0".

【#9620】 START SIZE

Not used. Set to "0".

【#9621】 DC1 OUT SIZE

Not used. Set to "0".

【#9622】 POLLING TIMER

Not used. Set to "0".

【#9623】 TRANS. WAIT TMR

Not used. Set to "0".

【#9624】 RETRY COUNTER

Not used. Set to "0".

【#9701(PR)】 IP addr auto set

The IP address is automatically assigned from the server.

- 0: Manual setting
- 1: Automatic setting

(Note) When the automatic setting is selected, "#11005 PC IP address, PC Subnet, PC Gateway" will be invalid.

II Parameters

1. User Parameters

【#9706】 Host No.

Select the No. of the host to be used from host 1 to host 4.

---Setting range---
1 to 4 : Host No.

【#9711】 Host1 host name

Set the host computer name.

This parameter allows the NC to easily recognize the host computer on the network. Set the host computer's name (name registered in C:\windows\hosts) or the IP address.

<Setting example>

For host name: mspc160
For IP address: 150.40.0.111

(Note) Set the host computer's TCP/IP address if communication is not carried out correctly.

---Setting range---
15 characters (alphanumeric) or less

【#9712】 Host1 user name

Set the user name when logging into the host computer.

---Setting range---
15 characters (alphanumeric) or less

【#9713】 Host1 password

Set the password when logging into the host computer.

---Setting range---
15 characters (alphanumeric) or less

【#9714】 Host1 directory

Set the directory name of the host computer.

The directory released to the client (NC unit) with the host computer's server is handled as root directory by the NC unit.

---Setting range---
31 characters (alphanumeric) or less

【#9715】 Host1 host type

Select the type of the host computer.

0: UNIX/PC automatic judgment
1: UNIX
2: PC (DOS)

(Note) When "0" is set, the settings for the following parameters will be invalid.

- #9716 Wrd pos: name
- #9717 Wrd pos: size
- #9718 Wrd pos: Dir
- #9719 Wrd pos: cmnt
- #9720 Wrd num: cmnt

【#9716】 Host 1 Wrd pos: name

Set the file name display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---
0 to 100
0: Default value

【#9717】 Host 1 Wrd pos: size

Set the size display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---
0 to 100
0: Default value

【#9718】 Host 1 Wrd pos: Dir

Set the <DIR> display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---
0 to 100
0: Default value

【#9719】 Host 1 Wrd pos: cmnt

Set the comment (date, time, etc.) display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---
0 to 100
0: Default value

II Parameters

1. User Parameters

【#9720】 Host 1 Wrđ num: cmnt

Set the number of words to be displayed as a comment.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9721】 Host 1 no total siz

Set whether to display the total number of characters registered in the machining programs of host1 when displaying the file list.

If there are many files in the directory to be referred to, the list can be updated quickly by setting "1".

0: Display

1: Not display

【#9731】 Host2 host name

Set the host computer name.

This parameter allows the NC to easily recognize the host computer on the network. Set the host computer's name (name registered in C:\windows\hosts) or the IP address.

<Setting example>

For host name: mspc160

For IP address: 150.40.0.111

(Note) Set the host computer's TCP/IP address if communication is not carried out correctly.

---Setting range---

15 characters (alphanumeric) or less

【#9732】 Host2 user name

Set the user name when logging into the host computer.

---Setting range---

15 characters (alphanumeric) or less

【#9733】 Host2 password

Set the password when logging into the host computer.

---Setting range---

15 characters (alphanumeric) or less

【#9734】 Host2 directory

Set the directory name of the host computer.

The directory released to the client (NC unit) with the host computer's server is handled as the root directory by the NC unit.

---Setting range---

31 characters (alphanumeric) or less

【#9735】 Host2 host type

Select the type of the host computer.

0: UNIX/PC automatic judgment

1: UNIX

2: PC (DOS)

(Note) When "0" is set, the settings for the following parameters will be invalid.

- #9736 Wrđ pos: name

- #9737 Wrđ pos: size

- #9738 Wrđ pos: Dir

- #9739 Wrđ pos: cmnt

- #9740 Wrđ num: cmnt

【#9736】 Host 2 Wrđ pos: name

Set the file name display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9737】 Host 2 Wrđ pos: size

Set the size display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9738】 Host 2 Wrđ pos: Dir

Set the <DIR> display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

II Parameters

1. User Parameters

【#9739】 Host 2 Wrđ pos: cmnt

Set the comment (date, time, etc.) display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9740】 Host 2 Wrđ num: cmnt

Set the number of words to be displayed as a comment.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9741】 Host 2 no total siz

Set whether to display the total number of characters registered in the machining programs of host1 when displaying the file list.

If there are many files in the directory to be referred to, the list can be updated quickly by setting "1".

0: Display

1: Not display

【#9751】 Host3 host name

Set the host computer name.

This parameter allows the NC to easily recognize the host computer on the network. Set the host computer's name (name registered in C:\windows\hosts) or the IP address.

<Setting example>

For host name: mspc160

For IP address: 150.40.0.111

(Note) Set the host computer's TCP/IP address if communication is not carried out correctly.

---Setting range---

15 characters (alphanumeric) or less

【#9752】 Host3 user name

Set the user name when logging into the host computer.

---Setting range---

15 characters (alphanumeric) or less

【#9753】 Host3 password

Set the password when logging into the host computer.

---Setting range---

15 characters (alphanumeric) or less

【#9754】 Host3 directory

Set the directory name of the host computer.

The directory released to the client (NC unit) with the host computer's server is handled as the root directory by the NC unit.

---Setting range---

31 characters (alphanumeric) or less

【#9755】 Host3 host type

Select the type of the host computer.

0: UNIX/PC automatic judgment

1: UNIX

2: PC (DOS)

(Note) When "0" is set, the settings for the following parameters will be invalid.

- #9756 Wrđ pos: name

- #9757 Wrđ pos: size

- #9758 Wrđ pos: Dir

- #9759 Wrđ pos: cmnt

- #9760 Wrđ num: cmnt

【#9756】 Host 3 Wrđ pos: name

Set the file name display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9757】 Host 3 Wrđ pos: size

Set the size display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

II Parameters

1. User Parameters

【#9758】 Host 3 Wrđ pos: Dir

Set the <DIR> display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9759】 Host 3 Wrđ pos: cmnt

Set the comment (date, time, etc.) display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9760】 Host 3 Wrđ num: cmnt

Set the number of words to be displayed as a comment.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9761】 Host 3 no total siz

Set whether to display the total number of characters registered in the machining programs of host1 when displaying the file list.

If there are many files in the directory to be referred to, the list can be updated quickly by setting "1".

0: Display

1: Not display

【#9771】 Host4 host name

Set the host computer name.

This parameter allows the NC to easily recognize the host computer on the network. Set the host computer's name (name registered in C:\windows\hosts) or the IP address.

<Setting example>

For host name: mspc160

For IP address: 150.40.0.111

(Note) Set the host computer's TCP/IP address if communication is not carried out correctly.

---Setting range---

15 characters (alphanumeric) or less

【#9772】 Host4 user name

Set the user name when logging into the host computer.

---Setting range---

15 characters (alphanumeric) or less

【#9773】 Host4 password

Set the password when logging into the host computer.

---Setting range---

15 characters (alphanumeric) or less

【#9774】 Host4 directory

Set the directory name of the host computer.

The directory released to the client (NC unit) with the host computer's server is handled as the root directory by the NC unit.

---Setting range---

31 characters (alphanumeric) or less

【#9775】 Host4 host type

Select the type of the host computer.

0: UNIX/PC automatic judgment

1: UNIX

2: PC (DOS)

(Note) When "0" is set, the settings for the following parameters will be invalid.

- #9776 Wrđ pos: name

- #9777 Wrđ pos: size

- #9778 Wrđ pos: Dir

- #9779 Wrđ pos: cmnt

- #9780 Wrđ num: cmnt

【#9776】 Host 4 Wrđ pos: name

Set the file name display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

II Parameters

1. User Parameters

【#9777】 Host 4 Wrđ pos: size

Set the size display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9778】 Host 4 Wrđ pos: Dir

Set the <DIR> display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9779】 Host 4 Wrđ pos: cmnt

Set the comment (date, time, etc.) display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9780】 Host 4 Wrđ num: cmnt

Set the number of words to be displayed as a comment.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---

0 to 100

0: Default value

【#9781】 Host 4 no total siz

Set whether to display the total number of characters registered in the machining programs of host1 when displaying the file list.

If there are many files in the directory to be referred to, the list can be updated quickly by setting "1".

0: Display

1: Not display

【#10801】 Notice tel num 1

Set the call-back telephone No. used for one-touch call and operator notification.

Begin with the No. from an area code for domestic call.

Begin with a communication company No. for international call.

Hyphens "-" can be used as a delimiting character.

---Setting range---

Within 28 characters

【#10802】 Comment 1

Set a comment, such as a party's name, for the notification party telephone No.1.

---Setting range---

Within 20 alphanumerical characters

(excluding spaces)

【#10803】 Notice tel num 2

Set the call-back telephone No. used for one-touch call and operator notification.

Begin with the No. from an area code for domestic call.

Begin with a communication company No. for international call.

Hyphens "-" can be used as a delimiting character.

---Setting range---

Within 28 characters

【#10804】 Comment 2

Set a comment, such as a party's name, for the notification party telephone No.2.

---Setting range---

Within 20 alphanumerical characters

(excluding spaces)

【#10805】 Notice tel num 3

Set the call-back telephone No. used for one-touch call and operator notification.

Begin with the No. from an area code for domestic call.

Begin with a communication company No. for international call.

Hyphens "-" can be used as a delimiting character.

---Setting range---

Within 28 characters

II Parameters

1. User Parameters

【#10806】 Comment 3

Set a comment, such as a party's name, for the notification party telephone No.3.

---Setting range---

Within 20 alphanumerical characters
(excluding spaces)

【#10807】 Password

Set the password for sharing of machining data.

---Setting range---

4 characters (one-byte alphanumeric characters, without space)

【#10808】 Customer number

Set the user No. for sharing of machining data.

---Setting range---

Within 8 characters (one-byte alphanumeric characters, without space)

【#10812】 Anshin-net valid

Select whether to enable the Anshin-net function.

0: Disable

1: Enable

【#10813】 MTBnet enable

Select whether to enable the machine tool builder network system.

0: Disable

1: Enable

Standard setting: 0

(Note) Values other than "0" and "1" are invalid.

【#19001】 Syn.tap(,S)cancel

0: Retain the spindle speed (,S) in synchronous tap return

1: Cancel the spindle speed (,S) in synchronous tap return with G80

【#19002】 Zero-point mark

Select the position for displaying the zero point mark in the graphic trace and 2D check.

0: Machine coordinates zero point (same as conventional method)

1: Workpiece coordinate zero point

【#19003】 PRG coord rot type

Select the start point of the initial travel command after G68 command.

0: Calculate the end position using the current position on the local coordinate system before rotating, without rotating the start point in accordance with the coordinates rotation.

1: Calculate the end position, assuming that the start point rotates in accordance with the coordinates rotation.

【#19425】 ManualB Std R1

Set a radius used as standard for the rotary axis speed.

When the setting value of #19425 is larger than that of "#19427 ManualB Std R2", #19425 setting will be used as surface speed control standard radius 2: #19427 setting will be used as surface speed control standard radius 1.

---Setting range---

0 to 99999.999 (mm)

【#19426】 ManualB Std F1

This sets the rotary axis speed for surface speed control standard radius 1 (ManualB Std R1).

When the setting value of #19426 is larger than that of "#19428 ManualB Std F2", #19426 setting will be used as surface speed control standard speed 2: #19427 setting will be used as surface speed control standard speed 1.

---Setting range---

1 to 1000000 (°/min)

【#19427】 ManualB Std R2

Set a radius used as standard for the rotary axis speed.

When the same value is set as "#19425 ManualB Std R1", the surface speed control standard speed 1 (ManualB Std F1) will be selected as the rotary axis speed if the radius is less than that value. The surface speed control standard speed 2 (ManualB Std F2) is selected if larger than the set value.

---Setting range---

0 to 99999.999 (mm)

【#19428】 ManualB Std F2

Set the rotary axis speed for surface speed control standard radius 2 (ManualB Std R2).

---Setting range---

1 to 1000000 (°/min)

2. Base Specifications Parameters

【#1001(PR)】 SYS_ON System validation setup

Select the existence of PLC axes and part systems.
0: Not exist
1: Exist

【#1002(PR)】 axisno Number of axes

Set the number of control axes and PLC axes.
A total of 16 axes can be set.
Control axis: 0 to 8
PLC axis: 0 to 2

When set to "0", the number of control axes in the part system will be "0". Do not set the number of control axes of the first part system to "0".

(Note) The setting range differs according to the model.

【#1003(PR)】 iunit Input setup unit

Select the input setting value for each part system and the PLC axis.
Increments in parameters will follow this selection.

B: 1 μm
C: 0.1 μm
D: 0.01 μm (10nm)
E: 0.001 μm (1nm)

【#1004(PR)】 ctrl_unit Control unit

Select the control increment for each part system and PLC axis.
Select the increment for the NC internal position data, communication data between the NC and drive unit, and the servo travel data. Increments for some parameters, such as the pitch error and backlash, will follow this selection.

B: 1 μm
C: 0.1 μm
D: 0.01 μm (10nm)
E: 0.001 μm (1nm)

【#1005(PR)】 plcunit PLC unit

Select the PLC interface setting and display increment.
The PLC interface setting and display increment will follow this specification. Note that the PLC axis will follow "#1003 iunit".

B: 1 μm
C: 0.1 μm
D: 0.01 μm (10nm)
E: 0.001 μm (1nm)

【#1006(PR)】 mcmpunit Machine error compensation unit

Select the machine error compensation setting and display increment.
The parameters related to machine error compensation (backlash, pitch error compensation, etc.) and PLC interface (external machine coordinate system compensation) will follow this selection.

B: 1 μm
C: 0.1 μm
D: 0.01 μm (10nm)
E: 0.001 μm (1nm)

【#1007(PR)】 System type select System type select

Select the NC system type.
0: Machining center system (M system)
1: Lathe system (L system)

(Note 1) If the setting value is out of range, M system will be selected.

(Note 2) This parameter is exclusively for 70 series. 700 series doesn't support this parameter.

【#1010(PR)】 srvunit Output unit (servo)

Select the output increment to servo. The standard value is "E".

B: 1 μm
C: 0.1 μm
D: 0.01 μm (10nm)
E: 0.001 μm (1nm)

【#1013(PR)】 axname Axis name

Set each axis's name with an alphabetic character.
Use the characters X, Y, Z, U, V, W, A, B or C.

(Note 1) Do not set the same name twice in one part system. The same name which is used in another part system can be set.

(Note 2) The PLC name does not need to be set. (The axis name is displayed as 1 and 2.)

---Setting range---
X, Y, Z, U, V, W, A, B, C

II Parameters

2. Base Specifications Parameters

【#1014(PR)】 incax Increment command axis name

Set the axis name when commanding an incremental value for the axis travel amount. Available alphabets are the same as in "#1013 axname".

(Note 1) Set an alphabet that is different from that of "#1013 axname".

(Note 2) Setting is not required if absolute/incremental specification with axis names is not performed ("#1076 Absinc" = "0").

---Setting range---

X, Y, Z, U, V, W, A, B, C

【#1015(PR)】 cunit Program command unit

Set the minimum increment of program travel command.

cunit Travel amount for travel command 1

0: Follow "#1003 iunit"

1: 0.0001 mm (0.1 μ m)

10: 0.001 mm (1 μ m)

100: 0.01 mm (10 μ m)

1000: 0.1 mm (100 μ m)

10000: 1.0 mm

If there is a decimal point in travel command, the decimal point position will be handled as 1mm regardless of this setting.

【#1017(PR)】 rot Rotational axis

Select whether the axis is a rotary axis or linear axis.

When rotary axis is set, the axis will be controlled with the rotary axis's coordinate system.

Set the rotary axis type with "#8213 Rotation axis type".

0: Linear axis

1: Rotary axis

【#1018(PR)】 ccw Motor CCW

Select the direction of the motor rotation to the command direction.

0: Clockwise (looking from motor shaft) with the forward rotation command

1: Counterclockwise (looking from motor shaft) with the forward rotation command

【#1019(PR)】 dia Diameter specification axis

Select the command method of program travel amount.

When the travel amount is commanded with the diameter dimensions, the travel distance will be 5mm when the command is 10mm of travel distance.

The travel amount per pulse will also be halved during manual pulse feed.

If diameter is selected, tool length, the wear compensation amount, and the workpiece coordinate offset will be displayed in diameter value. Other parameters concerning length will always be displayed in radius value.

0: Command with travel amount

1: Command with diameter dimension

【#1020(PR)】 sp_ax Spindle Interpolation


Select "1" when using the spindle for the contour control of NC axis (C-axis).

0: Servo axis is used for contour control.

1: Spindle is used for contour control.

【#1021(PR)】 mcp_no Drive unit I/F channel No. (servo)

Using a 4-digit number, set the drive unit interface channel No. and which axis in that channel is to be used when connecting a servo drive unit.



【#1022(PR)】 axname2 2nd axis name

Set the name of the axis displayed on the screen with two characters. (X1, Z2, etc.) Always use an alphabetic character (A to Z) for the first character.

---Setting range---

A to Z and 1 to 9 (Two digits)

(Setting will be cleared when "0" is set)

【#1023(PR)】 crsadr Command address during cross machining

Set the axis name for issuing a command to this axis during cross machining control.

---Setting range---

A to Z

(Setting will be cleared when "0" is set)

【#1024(PR)】 crsinc Incremental command address during cross machining

Set the axis name for issuing an incremental command to this axis during cross machining control.

---Setting range---

A to Z

(Setting will be cleared when "0" is set)

【#1025】 l_plane Initial plane selection

Select the plane to be selected when the power is turned ON or reset.

0: X-Y plane (G17 command state)

1: X-Y plane (G17 command state)

2: Z-X plane (G18 command state)

3: Y-Z plane (G19 command state)

II Parameters

2. Base Specifications Parameters

【#1026】 base_I Base axis I

Set the names of the basic axes that compose the plane.
Set the axis name set in "#1013 axname".
If all three items ("base_I", "base_J" and "base_K") do not need to be set, such as for 2-axis specifications, input "0", and the parameter will be blank.
Normally, when X, Y and Z are specified respectively for base_I, _J, _K, the following relation will be established:
G17: X-Y
G18: Z-X
G19: Y-Z
Specify the desired axis name to set an axis address other than above.
---Setting range---
Axis names such as X, Y or Z

【#1027】 base_J Base axis J

Set the names of the basic axes that compose the plane.
Set the axis name set in "#1013 axname".
If all three items ("base_I", "base_J" and "base_K") do not need to be set, such as for 2-axis specifications, input "0", and the parameter will be blank.
Normally, when X, Y and Z are specified respectively for base_I, _J, _K, the following relation will be established:
G17: X-Y
G18: Z-X
G19: Y-Z
Specify the desired axis name to set an axis address other than above.
---Setting range---
Axis names such as X, Y or Z

【#1028】 base_K Base axis K

Set the names of the basic axes that compose the plane.
Set the axis name set in "#1013 axname".
If all three items ("base_I", "base_J" and "base_K") do not need to be set, such as for 2-axis specifications, input "0", and the parameter will be blank.
Normally, when X, Y and Z are specified respectively for base_I, _J, _K, the following relation will be established:
G17: X-Y
G18: Z-X
G19: Y-Z
Specify the desired axis name to set an axis address other than above.
---Setting range---
Axis names such as X, Y or Z

【#1029】 aux_I Flat axis I

Set the axis name when there is an axis parallel to "#1026 base_I".
---Setting range---
Axis names such as X, Y or Z

【#1030】 aux_J Flat axis J

Set the axis name when there is an axis parallel to "#1027 base_J".
---Setting range---
Axis names such as X, Y or Z

【#1031】 aux_K Flat axis K

Set the axis name when there is an axis parallel to "#1028 base_K".
---Setting range---
Axis names such as X, Y or Z

【#1037(PR)】 cmdtyp Command type

Set the G code list and compensation type for programs.

1 : List1(for M)	Type A(one compensation amount for one compensation No.)
2 : List1(for M)	Type B(shape and wear compensation amounts for one compensation No.)
3 : List2(for L)	Type C(shape and wear compensation amounts for one compensation No.)
4 : List3(for L)	Ditto
5 : List4(for special L)	Ditto
6 : List5(for special L)	Ditto
7 : List6(for special L)	Ditto
8 : List7(for special L)	Ditto
9 : List8(for M)	
M2 form at type A	Type A(one compensation amount for one compensation No.)
10 : List8(for M)	
M2 form at type B	Type B(shape and wear compensation amounts for one compensation No.)

There are some items in the specifications that can be used or cannot be used according to the value set in this parameter.
The file structure may also change depending on the compensation data type.

【#1038】 plcsl Ladder selection

Not used. Set to "0".

II Parameters

2. Base Specifications Parameters

【#1039(PR)】 spinno Number of spindles

Select the number of spindles.
0: No spindle
1 to 6: One to six spindles

(Note) The setting range differs according to the model.

【#1040(PR)】 M_inch Constant input (inch)

Select the unit system for setting and display regarding machine parameter and PLC interface's position, length and speed.
0: Metric system
1: Inch system

【#1041(PR)】 I_inch Initial state (inch)

Select the unit system for the program travel amount when the power is turned ON or reset and for position display.
0: Metric system
1: Inch system

(Note) Selection of inch and metric unit

When the setting value of "#1041 I_inch" is changed, the unit of length is changed after reset. The following parameters concerning length, however, are not changed automatically. Change the setting values of following parameters according to the new unit system.

- (1) Tool compensation amount (Tool length compensation amount, tool wear compensation amount and tool tip compensation amount)
- (2) Workpiece coordinate offset
- (3) Machining parameter
 - #8004 SPEED ("#8004 SPEED" is 10 inches/min. unit for the inch system.)
 - #8005 ZONE r #8006 ZONE d #8009 DSC. ZONE
 - #8010 ABS. MAX. #8011 INC. MAX. #8012 G73n
 - #8013 G83n #8016 G71 MINIMUM #8017 G71 DELTA-D
 - #8018 G84/G74n #8027 Toler-1 #8028 Toler-2
 - #8029 FairingL #8030 MINUTE LENG S #8037 CorJudgeL
 - #8041 C-rot. R #8042 C-ins. R #8051 G71 THICK
 - #8052 G71 PULL UP #8053 G73 U #8054 G73 W
 - #8056 G74 RETRACT #8057 G76 LAST-D #8075 SpiralEndErr
 - #8084 G83S Clearance #8085 G83S Forward F #8086 G83S Back F
- (4) Axis parameter
 - #8204 OT-CHECK-N #8205 OT-CHECK-P
 - #8206 TOOL CHG.P #8209 G60 Shift
- (5) Barrier data #8300-#8306, #8311-#8314
- (6) Base specifications parameter #1084 RadErr

【#1042(PR)】 pcinch PLC axis command (inch)

Select the unit system for the commands to the PLC axis.
0: Metric system
1: Inch system

【#1043】 lang Select language displayed

Select the display language.
0: English (Standard)
1: Japanese (Standard)
11: German (Option)
12: French (Option)
13: Italian (Option)
14: Spanish (Option)
15: Traditional Chinese (Option)
16: Korean (Option)
17: Portuguese (Option)
18: Dutch (Option)
19: Swedish (Option)
20: Hungarian (Option)
21: Polish (Option)
22: Simplified Chinese (Option)
23: Russian (Option)
24: Turkish (Option)
25: Czech (Option)

(Note) A language which can be displayed is different according to each series.

【#1044(PR)】 auxno MR-J2-CT Connections

Set the number of MR-J2-CTs connected.

(Note) The number of MR-J2-CTs possible to connect and setting range are different according to the model.
Check the specifications of each series.

【#1045(PR)】 nskno Megatorque motor connections

Set the number of NSK megatorque motors connected. When a value other than "0" is set, 2nd miscellaneous function data will be output as signed binary data.

---Setting range---
0 to 16

II Parameters

2. Base Specifications Parameters

【#1050(PR)】 MemPrg Definition of program save area

Select part system common or independent for the usage of the save area for machining programs or MDI data.

- For machining programs
 - 0 or 2: Part system common
 - 1 or 3: Part system independent
- For MDI data
 - 0 or 1: Part system common
 - 2 or 3: Part system independent

【#1051(PR)】 MemTol Tool compensation memory common for part systems

- 0: Tool compensation memory separate for part systems
- 1: Tool compensation memory common for part systems

【#1052(PR)】 MemVal No. of common variables shared in part system designation

- 0: Common variables common for part systems (number fixed)
 - #100 - : Per part system
 - #500 - : Common for part systems
- 1: Common variables common for part systems (number designation)
 - #100 - : Designate with V1comN
 - #500 - : Designate with V0comN

(Note) When this parameter is changed, the file system will be changed after the power is turned ON.

So always execute format.

The new format will be enabled after turning the power ON again.

Setting order

- (1) MemVal changeover -> (2) Turn power ON again -> (3) Format ->(4) Turn power ON again

【#1061(PR)】 intabs Manual ABS updating

Select whether to update the absolute position data during automatic handle interrupt.

This parameter is enabled only when "#1145 I_abs" is set to "1".

- 0: Do not update (coordinate system shifted the amount of the interruption)
- 1: Update (same coordinates as when interrupt did not occur will be applied)

【#1062】 T_cmp Tool compensation function

Select whether the tool length compensation and wear compensation are enabled during T command execution.

- | | |
|-------------------------------------|---------------------------|
| 0: Tool length compensation enable | Wear compensation enable |
| 1: Tool length compensation enable | Wear compensation disable |
| 2: Tool length compensation disable | Wear compensation enable |
| 3: Tool length compensation disable | Wear compensation disable |

【#1063】 mandog Manual dog-type

Select the manual reference position return method for the second return (after the coordinate system is established) and later.

The initial reference position return after the power ON is performed with dog-type return, and the coordinate system will be established.

(This setting is not required when the absolute position detection is used.)

- 0: High speed return
- 1: Dog-type

【#1064(PR)】 svof Error correction

Select whether to correct the error when the servo is OFF.

- 0: Not correct the error
- 1: Correct the error

【#1068(PR)】 slavno Slave axis number

Set the axis number of the slave axis in synchronous control.

The axis number is an NC number excluding the spindle and PLC axis.

Two or more slave axes cannot be set for one master axis.

This parameter cannot be set for a slave axis.

When using the multi-part system, the relation of the master axis and slave axis cannot extend over part systems.

- 0: No slave axis
- 1 to 16: First to sixteenth axis

【#1069】 no_dsp Axis with no counter display

Select whether to display the axis counter or not.

This setting is enabled on the counter display screen (relative position counter, etc.).

- 0: Display
- 1: Not display

【#1070】 axoff Axis removal

Select whether to enable or disable axis removal control.

- 0: Disable
- 1: Enable

【#1072】 chop_ax Chopping axis

Select the chopping axis.

- 0: Non-chopping axis
- 1: Chopping axis

II Parameters

2. Base Specifications Parameters

【#1073】 I_Absm Initial absolute setting

Select the mode (absolute or incremental) at turning ON the power or reset.
0: Incremental setting
1: Absolute setting

【#1074】 I_Sync Initial synchronous feed

Select the feedrate mode at turning ON the power or reset.
0: Asynchronous feed (feed per minute)
1: Synchronous feed (feed per revolution)

【#1075】 I_G00 Initial G00

Select the linear command mode at turning ON the power or reset.
0: Linear interpolation (G01 command state)
1: Positioning (G00 command state)

【#1076】 AbsInc ABS/INC address (for L system only)

Select the command method for the absolute and incremental commands.
0: Use G command for the absolute and incremental commands.
1: Use axis name for the absolute and incremental commands.
(The axis name in "#1013 axname" will be the absolute command, "#1014 incax" will be the incremental command.)

When "1" is selected, using two axis names, one each for the absolute and incremental commands, allows to issue the absolute and incremental commands appropriately to an axis.

【#1077】 radius Incremental command for diameter specification axis

Select whether the incremental command of the diameter specification axis ("#1019 dia" is set to "1") uses the diameter value or radius value.
0: Diameter value
1: Radius value

【#1078】 Decpt2 Decimal point type 2

Select the increment of position commands that do not have a decimal point.
0: Minimum input command unit (follows "#1015 cunit")
1: 1mm (or 1inch) unit (For the dwell time, 1s unit is used.)

【#1079】 F1digit Validate F1 digit

Select the F command method.
0: Direct numerical command (command feedrate during feed per minute or rotation)
1: 1-digit code command (feedrate set with "#1185 spd_F1" – "#1189 F5")

【#1080】 Dril_Z Specify boring axis (for M system only)

Select a fixed cycle hole drilling axis.
0: Use an axis vertical to the selected plane as hole drilling axis.
1: Use the Z axis as the hole drilling axis regardless of the selected plane.

【#1081】 Gmac_P Give priority to G code parameter

Select the G code priority relationship during the macro call with G command.
0: Priority is on G code used in the system
1: Priority is on registered G code for call

【#1082】 Geomet Geometric

Select the type of geometric to use.
0: Not use
1: Use only geometric I
2: Use geometric I and IB

With geometric, specific address codes are used for exclusive meanings. Thus, if A or C is used for the axis name or 2nd miscellaneous command code, the A used for the axis name may function as the geometric's angle designation. Pay special attention to axis names, etc., when using this function.

【#1084】 RadErr Arc error

Set the tolerable error range when the end point deviates from the center coordinate in the circular command.

---Setting range---
0 to 1.000 (mm)

【#1085】 G00Drn G00 dry run

Select whether to apply dry run (feed at manual setting speed instead of command feedrate) to the G00 command.
0: Not apply to G00. (move at rapid traverse rate)
1: Apply to G00. (move at manual setting speed)

【#1086】 G0Intp G00 non-interpolation

Select the G00 travel path type.
0: Move linearly toward the end point. (interpolation type)
1: Move to the end point of each axis at the rapid traverse feedrate for each axis. (non-interpolation)

(Note) If this parameter is set to "1", neither of the following functions will be available: rapid traverse constant inclination acceleration/deceleration and rapid traverse constant inclination multi-step acceleration/deceleration.

II Parameters

2. Base Specifications Parameters

【#1087】 G96_G0 Constant surface speed control by rapid traverse feed command

Select how to handle the surface speed for the G00 command when using the constant surface speed control function.

- 0: Calculate the surface speed constantly even during G00 movement
- 1: Calculate the surface speed at the block end point in the G00 command

【#1088】 G30SL Disable G30 soft limit

Select how to handle the soft limit during G30 (2nd reference position return).

- 0: Enable
- 1: Disable

【#1091】 Mpoint Ignore middle point

Select how to handle the middle point during G28 and G30 reference position return.

- 0: Pass the middle point designated in the program and move to the reference position.
- 1: Ignore the middle point designated in the program and move straight to the reference position.

【#1092】 Tchg_A Replace tools for additional axis

Select the movement of the additional axis at the tool change position return command.

- 0: The additional axis will not move
- 1: After the standard axis returns, the additional axis will also return to the tool change position

【#1093】 Wmvfin Synchronization between part systems method

Select the timing of synchronization between part systems when using the multi-part system. When the travel command is found in the synchronization command (I, M) block:

- 0: Synchronize before executing travel command
- 1: Synchronize after executing travel command

【#1094】 TI_SBK Select life count for single block (for L system only)

Select whether to count the data units to be used for single block operation when using the tool life management II function (L system).

- 0: Not count
- 1: Count

【#1095】 T0tfof TF output

Select how to handle TF for T00 command.

- 0: TF will be output
- 1: TF won't be output

【#1096(PR)】 T_Ltyp Tool life management type (for L system only)

Select the tool life management type.

- 1: Life management I
In this type, how long and how many times the program commanded tool is used are accumulated to monitor the usage state.
- 2: Life management II
This method is the same as tool life management I, but with the spare tool selection function.
A spare tool is selected from a group of tool commands commanded in the program. Tool compensation (tool length compensation and tool radius compensation) is carried out for the selected tool.

【#1097】 T1digit Tool wear compensation number 1-digit command

Select the number of digits of the tool wear compensation No. in the T command.

- 0: The 2 high-order digits are the tool No., and the 2 low-order digits are the wear compensation No.
- 1: The 3 high-order digits are the tool No., and the 1 low-order digit is the wear compensation No.

This parameter will be fixed to "0" when tool life management II is selected.

【#1098】 Tlno. Tool length offset number

Select the number of digits of the tool length compensation No. in the T command.

- 0: The 2 or 3 high-order digits are the tool No.
The 2 or 1 low-order digits are the tool length compensation and wear compensation Nos.
- 1: The 2 or 3 high-order digits are the tool No. and tool length compensation Nos.
The 2 or 1 low-order digits are the wear compensation No.

【#1099】 Treset Cancel tool compensation amount

Select how to handle the tool compensation vector when resetting the system.

- 0: Clear the tool length and wear compensation vectors when resetting
- 1: Hold the tool length and wear compensation vectors when resetting

When the values are cleared, the compensation will not be applied, so the axis will be shifted by the compensation amount in the next compensation operation.

When the values are kept, the compensation will be applied, so the axis will shift the differential amount of the compensation amount in the next compensation operation.

II Parameters

2. Base Specifications Parameters

【#1100】 Tmove Tool compensation

Select when to perform tool length compensation and wear compensation.

0: Compensate when T command is executed.

1: Superimpose and compensate with the travel command in the block where the T command is located. If there is no travel command in the same block, compensation will be executed after the travel command is superimposed in the next travel command block.

2: Compensate the wear amount when the T command is executed. Superimpose and compensate the tool length compensation amount with the travel command in the same block. If there is no travel command in the same block, compensation will be executed after the travel command is superimposed in the next travel command block.

【#1101】 Tabsmv Tool compensation method

Select the type of travel command when "#1100 Tmove" is set to "1" or "2".

0: Compensate regardless of the travel command type

1: Compensate only at the travel command in the absolute command

【#1102】 tlm Manual tool length measuring system (for L system only)

Select the measurement method for manual tool measurement I.

0: Align tool with basic point

1: Input measurement results

(Note) Interpreted as "0" when other than "0" or "1" is set.

【#1103】 T_life Validate life management

Select whether to use the tool life management.

0: Not use

1: Use

【#1104】 T_Com2 Tool command method 2

Select how to handle the tool command in the program when "#1103 T_Life" is set to "1".

0: Handle the command as group No.

1: Handle the command as tool No.

【#1105】 T_Sel2 Tool selection method 2

Select the tool selection method when "#1103 T_Life" is set to "1".

0: Select in order of registered No. from the tools used in the same group.

1: Select the tool with the longest remaining life from the tools used or unused in the same group.

【#1106】 Tcount Life management (for L system only)

Select the input method when address N is omitted in inputting the data (G10 L3 command) for tool life management function II.

0: Time specified input

1: Number of times specified input

【#1107】 TlIfsc Split life management display screen (for L system only)

Set the number of groups to be displayed on the tool life management II (L system) screen.

0: Displayed group count 1, maximum number of registered tools: 16

1: Displayed group count 2, maximum number of registered tools: 8

2: Displayed group count 4, maximum number of registered tools: 4

【#1108】 TirectM Life management re-count M code (for L system only)

Set the M code for tool life management II (L system) re-count.

---Setting range---

0 to 99

【#1109】 subs_M Validate alternate M code

Select the user macro interrupt with the substitute M code.

0: Disable alternate M code

1: Enable alternate M code

【#1110】 M96_M M96 alternate M code

Set an M code to replace M96 when "#1109 subs_M" is set to "1".

---Setting range---

3 to 97 (excluding 30)

【#1111】 M97_M M97 alternate M code

Specify an M code to replace M97 when #1109 subs_M is set to 1.

---Setting range---

3 to 97 (excluding 30)

【#1112(PR)】 S_TRG Validate status trigger method

Select the enable conditions for the user macro interrupt signal (UIT).

0: Enable when interrupt signal (UIT) turns ON

1: Enable when interrupt signal (UIT) is ON

【#1113(PR)】 INT_2 Validate interrupt method type 2

Select the performance after user macro interrupt signal (UIT) input.

0: Execute interrupt program without waiting for block being executed to end

1: Execute interrupt program after completing block being executed

II Parameters

2. Base Specifications Parameters

【#1114】 mcrint Macro argument initialization

Select whether to clear statements other than specified arguments by macro call.
Also select whether to clear local variables by power-ON and resetting.

- 0: Clear the non-specified arguments by macro call.
- 1: Hold non-specified arguments by macro call
- 2: Hold non-specified arguments by macro call, and clear local variables by power-ON and resetting

【#1115】 thwait Waiting for thread cutting

Set the queue number during screw thread cutting when chamfering is disabled.

---Setting range---

- 0 to 99 (Approx. 4 ms)
- Standard setting value: 4

【#1116】 G30SLM Invalidate soft limit (manual operation)

Enable this function when disabling the soft limit check function at the second to fourth reference position return.

- 0: Enable soft limit function
- 1: Disable soft limit function

【#1117(PR)】 H_sens Handle response switch

Select the handle response mode during handle feed.

- 0: Standard
- 1: High-speed

【#1118】 mirr_A Select how to set up the length of tools on cutter tables (opposed tables) (for L system only)

Select one of the following two methods:

- Set the current length of tools on each facing turret.
- Set a value, assuming that the tools on each facing turret are in the same direction as that of those on the base turret.

- 0: Current length of the tools on each facing turret
- 1: Value, assuming that the tools on each facing turret are in the same direction as that of those on the base turret

【#1119】 Tmiron Select the mirror image of each facing turret with T command (for L system only)

Select whether to enable the mirror image of each facing turret with the T command.

- 0: Disable
- 1: Enable

【#1120(PR)】 TofVal Change macro variable

Select whether to change the macro variable (tool offset) numbers for shape compensation and wear compensation.

- 0: Not change (Conventional specification)
- 1: Change the shape and wear compensation variable numbers each for X, Z, and R

【#1121】 edlk_c Edit lock C

Select the edit lock for program Nos. 9000 to 9999 in memory.

- 0: Editing possible
- 1: Editing prohibited. The file cannot be opened.

(Note) If "#1122" is set to "1" or "2", "1" will be set in "#1121" when the power is turned ON.

【#1122(PR)】 pglk_c Program display lock C

Select whether to prohibit the program display and search for program Nos. 9000 to 9999 in memory.

- 0: Program display and search is possible
- 1: Program display is impossible. Search is possible.
- 2: Program display and search is impossible

(Note) If "#1122" is set to "1" or "2", "1" will be set in "#1121" when the power is turned ON.

【#1123】 origin Origin set prohibit

Select whether to use the origin set function.

- 0: Use
- 1: Not use

【#1124】 ofsfix Fix tool compensation No.

Select how to handle the compensation No. when the input key is pressed on the tool compensation screen.

- 0: Increment the compensation No. by 1 (Same as general parameters)
- 1: # compensation No. does not change

When setting in sequence, "0" is handier. When changing and setting repeatedly while adjusting one compensation value, "1" is handier

【#1125】 real_f Actual feedrate display

Select the feedrate display on the monitor screen.

- 0: Command speed
- 1: Actual travel feedrate

II Parameters

2. Base Specifications Parameters

【#1126】 PB_G90 Playback G90

Select the method to command the playback travel amount in the playback editing.
0: Incremental value
1: Absolute value

【#1127】 DPRINT DPRINT alignment

Select the alignment for printing out with the DPRINT function.
0: No alignment, output s printed with left justification
1: Align the minimum digit and output

【#1128】 RstVCI Clear variables by resetting

Select how to handle the common variables when resetting.
0: Common variables won't change after resetting.
1: The following common variables will be cleared by resetting:
#100 to #149 when 100 sets of variables are provided.
#100 to #199 when 200 sets or more of variables are provided.

【#1129】 PwrVCI Clear variables by power-ON

Select how to handle the common variables when the power is turned ON.
0: The common variables are in the same state as before turning the power OFF.
1: The following common variables will be cleared when the power is turned ON:
#100 to #149 when 100 sets of variables are provided.
#100 to #199 when 200 sets or more of variables are provided.

【#1130】 set_t Display selected tool number

Select the tool command value display on the POSITION screen.
0: Display T-modal value of program command
1: Display Tool No. sent from PLC

【#1132】 CRT

Not used. Set to "0".

【#1133】 ofsmem

Not used. Set to "0".

【#1134】 LCDneg

Not used. Set to "0".

【#1135】 unt_nm Unit name

Set the unit name.
Set with 4 or less characters consisting of both alphabets and numbers.
If "0" is set, the unit name won't be displayed.
---Setting range---
4 or less characters consisting of both alphabets and numbers

【#1136】 optype

Not used. Set to "0".

【#1137】 Cntsel

Not used. Set to "0".

【#1138】 Pnosel

Not used. Set to "0".

【#1139】 edtype

Not used. Set to "0".

【#1140】 Mn100 M code number

Set the first number of M code that corresponds to the setup Nos. from 100 to 199.
---Setting range---
0 to 99999999

【#1141】 Mn200 M code number

Set the first number of M code that corresponds to the setup Nos. from 200 to 299.
---Setting range---
0 to 99999999

【#1142】 Mn300 M code number

Set the first number of M code that corresponds to the setup Nos. from 300 to 399.
---Setting range---
0 to 99999999

【#1143】 Mn400 M code number

Set the first number of M code that corresponds to the setup Nos. from 400 to 499.
---Setting range---
0 to 99999999

II Parameters

2. Base Specifications Parameters

【#1144】 mdlkof MDI setup lock

Select whether to enable MDI setting in non-MDI mode.

- 0: Disable MDI setting
- 1: Enable MDI setting

【#1145】 l_abs Manual ABS parameter

Select how to handle the absolute position data during automatic handle interrupt.

- 0: Absolute position data will be renewed if manual ABS switch is ON. If it is OFF, data won't be renewed.
- 1: Follow the "intabs" state when "#1061 intabs" is enabled

【#1146】 Sclamp Spindle rotation speed clamp function

Select how to handle the spindle rotation speed clamp function with the G92S command.

- 0: G92S command is handled as a clamp command only in the G96 state (during constant surface speed control). G92S will be handled as normal S command in G97 state (constant surface speed OFF).
- 1: The S command in the same block as G92 is constantly handled as a clamp command

【#1147】 smin_v Minimum spindle rotation speed clamp type

Specify the type of spindle min. rotation speed clamp value.

- 0: Rotation speed setting
- 1: Output voltage coefficient setting

Set "#3023 smini" according to this type setting.

【#1148】 l_G611 Initial high precision

Set the high accuracy control mode for the modal state when the power is turned ON.

- 0: G64 (cutting mode) at power ON
- 1: G61.1 (high-accuracy control mode) at power ON

【#1149】 cireft Arc deceleration speed change

Select whether to decelerate at the arc entrance or exit.

- 0: Not decelerate
- 1: Decelerate

【#1151】 rstint Reset initial

Select whether to initialize (power ON state) the modals by resetting.

- 0: Not initialize modal state
- 1: Initialize modal state

【#1153】 FixbDc Hole bottom deceleration check

Select whether to perform a deceleration check or in-position check at the hole bottom in a hole drilling cycle. This parameter is enabled only for a hole drilling cycle in which no dwell command can be issued at the hole bottom.

- 0: Perform no deceleration check and in-position check
- 1: Perform deceleration check
- 2: Perform in-position check

【#1154(PR)】 pdoor

Not used. Set to "0".

【#1155】 DOOR_m

Not used. Set to "100".

---Setting range---
100

【#1156】 DOOR_s

Not used. Set to "100".

---Setting range---
100

【#1157】 F0atrn

Not used. Set to "0".

【#1158】 F0atno

Not used. Set to "0".

【#1163(PR)】 No rio RIO connection detection invalid

Select whether to enable or disable RIO connection detection.

- 0: Enable
- 1: Disable

If your I/O consists of only cards such as CC-LINK, setting this parameter to "1" will avoid the RIO communication cutoff alarm.

【#1164(PR)】 ATS Automatic tuning function

Select whether to enable or disable the automatic tuning function.

- 0: Disable
- 1: Enable

II Parameters

2. Base Specifications Parameters

【#1166】 fixpro Fixed cycle editing

Select a type of program dealt on the edit/program list/data in/out screen, general program fixed cycle, or machine tool builder macro program.

0: General programs can be edited, etc.

1: Fixed cycles can be edited, etc.

Password No.: The machine tool builder macro programs can be edited, etc.

---Setting range---

0 to 99999999

【#1167】 e2rom

Not used. Set to "0".

【#1168】 test Simulation test

Select the test mode for the control unit.

In the test mode, test is performed with a hypothetical reference position return complete even though the real reference position return hasn't been completed. This is limited to test operation of the control unit itself, and must not be used when the machine is connected.

0: Normal operation mode

1: Test mode

【#1169】 part system name Part system name

Set the name of each part system.

This must be set only when using multi-part system.

This name will be displayed on the screen only when the part systems must be identified.

Use a max. of four alphabetic characters or numerals.

---Setting range---

A max. of four alphabetic characters or numerals.

【#1170】 M2name Second miscellaneous code

Set this address code when using the 2nd miscellaneous command. Set an address with A, B or C that is not used for "#1013 axname" or "#1014 incax".

---Setting range---

A, B, C

【#1171】 taprov Tap return override

Set the tap return override value for the synchronous tapping.

When "0" is set, it will be regarded as 100%.

---Setting range---

1 to 100 (%)

【#1172】 tapovr Tap return override

Set the override value when leaving the tap end point in the synchronous tapping cycle.

The setting range is 1 to 999, and the unit is %.

When a value less than 100 is set, it will be judged as 100%.

---Setting range---

1 to 999 (%)

【#1173】 dwlskp G04 skip condition

Set the skip signal for ending the G04 (dwell) command.

---Setting range---

PLC interface input signal

Skip3 Skip2 Skip1

0: - - -

1: - - *

2: - * -

3: - * *

4: * - -

5: * - *

6: * * -

7: * * *

(* : Enable - : Disable)

【#1174】 skip_F G31 skip speed

Set the feedrate when there is no F command in the program at G31 (skip) command.

---Setting range---

1 to 999999 (mm/min)

【#1175】 skip1 G31.1 skip condition

Designate the skip signal in multi-step skip G31.1.

---Setting range---

The setting method is same as "#1173".

【#1176】 skip1f G31.2 skip speed

Set the skip feedrate in multi-step skip G31.1.

---Setting range---

1 to 999999 (mm/min)

【#1177】 skip2 G31.2 skip condition

Set the skip signal in multi-step skip G31.2.

---Setting range---

The setting method is same as "#1173".

II Parameters

2. Base Specifications Parameters

【#1178】 skip2f G31.2 skip speed

Set the skip signal in multi-step skip G31.2.

---Setting range---
1 to 999999 (mm/min)

【#1179】 skip3 G31.3 skip condition

Set the skip signal in multi-step skip G31.3

---Setting range---
The setting method is same as "#1173".

【#1180】 skip3f G31.3 skip speed

Set the skip signal in multi-step skip G31.3.

---Setting range---
1 to 999999 (mm/min)

【#1181】 G96_ax Constant surface speed axis

Select the axis to be targeted for constant surface speed control.

0: Program setting will be disabled, and the axis will always be fixed to the 1st axis
1: 1st axis
2: 2nd axis
3: 3rd axis
:
:
8: 8th axis

However, when set to other than "0", the priority will be on the program setting.

【#1182】 thr_F Thread cutting speed

Set the screw cut up speed when not using chamfering in the thread cutting cycle.

0: Cutting feed clamp feedrate
1 to 60000 mm/min: Setting feedrate
---Setting range---
0 to 60000 (mm/min)

【#1183】 clmp_M M code for clamp

Set the M code for C axis clamp in hole drilling cycle.

---Setting range---
0 to 99999999

【#1184】 clmp_D Dwelling time after outputting M code for unclamp

Set the dwell time after outputting the M code for C axis unclamp in hole drilling cycle.

---Setting range---
0.000 to 99999.999 (s)

【#1185】 spd_F1 F1 digit feedrate F1

Set the feedrate for the F command in the F 1-digit command ("#1079 F1digit" is set to "1").
Feedrate when F1 is issued (mm/min)

---Setting range---
1 to 60000 (mm/min)

【#1186】 spd_F2 F1 digit feedrate F2

Set the feedrate for the F command in the F 1-digit command ("#1079 F1digit" is set to "1").
Feedrate when F2 is issued (mm/min)

---Setting range---
1 to 60000 (mm/min)

【#1187】 spd_F3 F1 digit feedrate F3

Set the feedrate for the F command in the F 1-digit command ("#1079 F1digit" is set to "1").
Feedrate when F3 is issued (mm/min)

---Setting range---
1 to 60000 (mm/min)

【#1188】 spd_F4 F1 digit feedrate F4

Set the feedrate for the F command in the F 1-digit command ("#1079 F1digit" is set to "1").
Feedrate when F4 is issued (mm/min)

---Setting range---
1 to 60000 (mm/min)

【#1189】 spd_F5 F1 digit feedrate F5

Set the feedrate for the F command in the F 1-digit command ("#1079 F1digit" is set to "1").
Feedrate when F5 is issued (mm/min)

---Setting range---
1 to 60000 (mm/min)

【#1190(PR)】 s_xcnt Validate inclined axis control (for L system only)

Select whether to enable or disable inclined axis control.

0: Disable inclined axis control
1: Enable inclined axis control

II Parameters

2. Base Specifications Parameters

【#1191(PR)】 s_angl Inclination angle (for L system only)

Set the inclination angle (θ).

(Note) When set to "0", the angle determined by three-side setting will be applied.

---Setting range---

± 80.000 (°)

【#1192(PR)】 s_zrmv Compensation at reference position return (for L system only)

Select whether to perform compensation for the base axis corresponding to the inclined axis at reference position return.

0: Perform compensation

1: Not perform compensation

【#1193】 inpos Deceleration check method 1/ Validate in-position check

The definitions are changed with the setting of "#1306 InpsTyp Deceleration check specification type".

<When Deceleration check method 1 is selected>

Select the deceleration check method for G0.

0: Command deceleration check

1: In-position check

<When Deceleration check method 2 is selected>

Select the deceleration confirmation method for the positioning or cutting command.

0: G0, G1+G9 Command deceleration check

1: G0, G1+G9 In-position check

【#1194】 H_accd Time constant 0 for handle feed

Select the time constant for manual handle feed.

0: Use time constant for G01

1: Time constant 0 (step)

【#1195】 Mmac Macro call for M command

Select whether to enable or disable M command macro call of user macro.

0: Disable

1: Enable

【#1196】 Smac Macro call for S command

Select whether to enable or disable S command macro call of user macro.

0: Disable

1: Enable

【#1197】 Tmac Macro call for T command

Select whether to enable or disable T command macro call of user macro.

0: Disable

1: Enable

【#1198】 M2mac Macro call with 2nd miscellaneous code

Select whether to enable or disable 2nd miscellaneous command macro call of user macro.

0: Disable

1: Enable

【#1199】 Sselect Select initial spindle control

Select the initial condition of spindle control after power is turned ON.

0: 1st spindle control mode (G43.1)

1: Selected spindle control mode (G44.1)

2: All spindle simultaneously control mode (G47.1)

(Note) Spindle No. when G44.1 is commanded is selected with "#1534 SnG44.1".

【#1200(PR)】 G0_acc Validate acceleration and deceleration with inclination angle constant G0

Select the acceleration and deceleration type when a rapid traverse command is issued.

0: Acceleration and deceleration with constant time (conventional type)

1: Acceleration and deceleration with a constant angle of inclination

(Note) When rapid traverse constant inclination multi-step acceleration/deceleration is valid, this parameter will be invalid.

【#1201(PR)】 G1_acc Validate acceleration and deceleration with inclination constant G1

Select the acceleration and deceleration type when a linear interpolation command is issued.

0: Acceleration and deceleration with constant time (conventional type)

1: Acceleration and deceleration with a constant angle of inclination

【#1202】 mirofs Distance between facing turrets (for L system only)

Set the distance between tools (edges) (between facing turrets).

---Setting range---

0 to 99999.999 (mm)

【#1203】 TmirS1 Select turrets as facing turrets with T command (for L system only)

Select the turrets, which correspond to the tool Nos. 1 to 32, as facing turrets for T code mirror image.

---Setting range---

0 to FFFFFFFF

II Parameters

2. Base Specifications Parameters

【#1204】 TmirS2 Select turrets as facing turrets with T command (for L system only)

Select the turrets, which correspond to the tool Nos. 33 to 64, as facing turrets for T code mirror image.

---Setting range---
0 to FFFFFFFF

【#1205】 G0bdcc Acceleration and deceleration before G0 interpolation

- 0: Post-interpolation acceleration/deceleration is applied to G00.
- 1: Pre-interpolation acceleration/deceleration is applied to G00 even in the high accuracy control mode.
- 2: Rapid traverse constant inclination multi-step acceleration/deceleration is enabled.

(Note) "1" cannot be set for the 2nd part system and the following.


【#1206】 G1bF Maximum speed

Set a cutting feedrate when applying pre-interpolation acceleration/deceleration. When high-accuracy control time constant expansion is valid, set the maximum of cutting feed clamp speed of each axis.

---Setting range---
1 to 999999 (mm/min)

【#1207】 G1btL Time constant

Set a cutting feed time constant when applying pre-interpolation acceleration/deceleration. When "0" is set, the time constant will be clamped at 1ms.



---Setting range---
Without high-accuracy control time constant expansion : 0 to 5000 (ms)
With high-accuracy control time constant expansion : 0 to 30000 (ms)

【#1208】 RCK Arc radius error compensation factor

Set a coefficient for arc radius error compensation. An arc radius error compensation amount can be increased or decreased between -60.0 and +20.0%.

---Setting range---
-60.0 to +20.0 (%)

【#1209】 cirdcc Arc deceleration speed

Set the deceleration speed at the arc entrance or exit.

---Setting range---
1 to 999999 (mm/min)

II Parameters

2. Base Specifications Parameters

#1210] RstGmd Modal G code reset

Select whether to initialize G code group modals and H and D codes, which corresponds to bits as follows, when the system is reset.

0: Initialize.

1: Not initialize.

<Description of bits for M system>

1F	1E	1D	1C	1B	1A	19	18	17	16	15	14	13	12	11	10
0	0	0	0	0	0	-	-	0	0	0	0	-	-	-	-

F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
0	-	0	-	-	0	-	0	-	-	-	-	0	-	-	-

- bit 1F: (Not used)
- bit 1E: (Not used)
- bit 1D: (Not used)
- bit 1C: (Not used)
- bit 1B: (Not used)
- bit 1A: (Not used)
- bit 19: Spindle clamp rotation speed initialization
- bit 18: H, D codes initialization
- bit 17: (Not used)
- bit 16: (Not used)
- bit 15: (Not used)
- bit 14: (Not used)
- bit 13: Group 20 2nd spindle control modal initialization
- bit 12: Group 19 G command mirror modal initialization
- bit 11: Group 18 Polar coordinate command modal initialization
- bit 10: Group 17 Constant surface speed control command modal initialization
- bit F: (Not used)
- bit E: Group 15 Normal line control modal initialization
- bit D: (Not used)
- bit C: Group 13 Cutting modal initialization
- bit B: Group 12 Workpiece coordinate system modal initialization
- bit A: (Not used)
- bit 9: Group 10 Fixed cycle return command modal initialization
- bit 8: (Not used)
- bit 7: Group 8 Length compensation modal initialization
- bit 6: Group 7 Radius compensation modal initialization
- bit 5: Group 6 Inch/metric modal initialization
- bit 4: Group 5 Feed G modal initialization
- bit 3: (Not used)
- bit 2: Group 3 Absolute/incremental command modal initialization
- bit 1: Group 2 Plane selection modal initialization
- bit 0: Group 1 Move G modal initialization

II Parameters

2. Base Specifications Parameters

The H code indicates the tool length offset number, and the D code indicates the tool radius compensation number.

When bit 18 is set to ON, the H and D codes and group 8 G modal are retained.

When bit 7 is set to ON, the H code and group 8 G modal are retained.

<Description of bits for L system>

1F	1E	1D	1C	1B	1A	19	18	17	16	15	14	13	12	11	10
0	0	0	0	0	0	-	0	0	0	0	-	-	0	-	-

F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
0	0	0	-	-	0	-	0	0	-	-	-	-	-	-	-

- bit 1F: (Not used)
- bit 1E: (Not used)
- bit 1D: (Not used)
- bit 1C: (Not used)
- bit 1B: (Not used)
- bit 1A: (Not used)
- bit 19: Spindle clamp rotation speed initialization
- bit 18: (Not used)
- bit 17: (Not used)
- bit 16: (Not used)
- bit 15: (Not used)
- bit 14: Group 15 Facing turret mirror image initialization
- bit 13: Group 20 2nd spindle control modal initialization
- bit 12: (Not used)
- bit 11: Group 18 Balance cut initialization
- bit 10: Group 17 Constant surface speed control command modal initialization
- bit F: (Not used)
- bit E: (Not used)
- bit D: (Not used)
- bit C: Group 13 Cutting modal initialization
- bit B: Group 12 Workpiece coordinate system modal initialization
- bit A: (Not used)
- bit 9: Group 10 Fixed cycle return command modal initialization
- bit 8: (Not used)
- bit 7: (Not used)
- bit 6: Group 7 Nose R compensation modal initialization
- bit 5: Group 6 Inch/metric modal initialization
- bit 4: Group 5 Feed G modal initialization
- bit 3: Group 4 Barrier check modal initialization
- bit 2: Group 3 Absolute/incremental command modal initialization
- bit 1: Group 2 Plane selection modal initialization
- bit 0: Group 1 Move G modal initialization

【#1213(PR)】 proaxy Side 1 of inclination angle (for L system only)

Set the length within the orthogonal coordinate of the inclined axis, a side of the triangle formed with the inclination angle.

---Setting range---
±9999.999

【#1214(PR)】 macaxy Side 2 of inclination angle (for L system only)

Set the actual length of the base axis corresponding to the inclined axis, a side of the triangle formed with the inclination angle.

---Setting range---
±9999.999

【#1215(PR)】 macaxx Side 3 of inclination angle (for L system only)

Set the actual length of the inclined axis, a side of the triangle formed with the inclination angle.

---Setting range---
±9999.999

【#1216】 extdcc External deceleration level

Set the upper limit value of the feedrate when the external deceleration signals are enabled. This parameter is valid when "#1239 set11/bit6" is set to "0".

---Setting range---
1 to 999999 (mm/min)

【#1217】 aux01

Not used. Set to "0".

【#1218】 aux02**bit3: Parameter input/output format**

Select the parameter input/output format.

- 0: Type I
- 1: Type II (related to "#1218 aux02/bit5")

bit4: External workpiece coordinate offset tool number selection

Select the R register that contains the tool number used for automatic calculation when measuring the coordinate offset of an external workpiece.

- 0: Follow the setting of "#1130 set_t".
- 1: Use the tool number indicated by user PLC.

bit5: Parameter I/O II spindle specification address

Select the spindle specification address of parameter I/O type II.

- 0: C
- 1: T

This parameter is also applied to the spindle specification address for input and verification. (Note) This parameter is valid only for parameter I/O type II (when "#1218 aux02/bit3" is set to "1").

bit6: Set No. valid when program input

Select which program No. is applied when inputting programs in "#1 MAIN PROGRAM" on Data I/O screen.

- 0: The No. in the input data
- 1: The No. set in the data setting area

bit7: Input by program overwrite

(1) Select the operation when the program to be input in "#1 MAIN PROGRAM" on Data I/O screen, has already been registered.

- 0: An operation error (E65) occurs.
- 1: Input by overwrite.

(2) Select the operation in the high-speed program server mode, when the name of the file to be transmitted with (IC -> host) transmission already exists in the host.

- 0: Prohibit overwrite
- 1: Enable overwrite

【#1219】 aux03**bit1: Stop high-speed PC monitoring function**

Set "1" to disable the function that triggers the emergency stop when the PC high-speed processing time is extended.

Disable the monitoring function only as a temporary measure.

bit5: Dog-type intermediate point

Select whether to move to the intermediate point during automatic dog-type reference position return.

- 0: Not move.
- 1: Move.

bit7: Time constant setting changeover for soft acceleration/deceleration

Select the time constant for soft acceleration/deceleration.

- 0: Accelerating time is obtained with G0tL (G1tL).
- 1: Accelerating time is obtained with G0tL + G0t1 (G1tL + G1t1).

II Parameters

2. Base Specifications Parameters

【#1220】 aux04 (for L system only)

bit 0: Tool life check timing selection

Select the criterion to judge the tool life end when the use count is incremented in tool life management II.

- 0: Determine the tool life end when the incremented use count has exceeded the life count. (Default)
(Use count > life count)
- 1: Determine the tool life end when the incremented use count has reached the life count.
(Use count \geq life count)

【#1221】 aux05

Not used. Set to "0".

【#1222】 aux06

bit4: Minimum cut-in amount selection

Select the minimum cut-in amount command value for the compound thread cutting cycle (G76 command).

- 0: The minimum cut-in amount (Q) will be "0".
- 1: The minimum cut-in amount (Q) will be set in the CNC internal data.

bit5: Fixed cycle for compound lathe command format check selection

Select the operation when the 1st block of the fixed cycle for compound lathe is omitted while the conventional format is selected ("#1265 ext01/bit0" is set to "0").

- 0: Program error (P33) will occur.
- 1: Parameter setting value will be used.

bit7: Reference position return deceleration check method

Select the deceleration check method to be used during automatic reference position return.

- 0: In-position check
- 1: Commanded deceleration check

II Parameters

2. Base Specifications Parameters

【#1223】 aux07

bit1: Deceleration check method 2

Select the deceleration check method in G1+G9.
0: Command deceleration check in G1+G9
1: In-position check in G1+G9

The deceleration check is not performed for the commands except G1+G9.
When "#1306 InpsTyp deceleration check specification type" is set to "1" (Deceleration check specification type 2), this parameter will be invalid.

bit2: Synchronous tap R-point in-position check

Select whether to enable the synchronous tap I-point -> R-point in-position check.
0: Disable
1: Enable

(Note) This parameter is valid only when "1" (Enable in-position check) is set for "#1223 aux07/bit3 Synchronous tap in-position check improvement".

bit3: Synchronous tap in-position check improvement

Select whether to enable the synchronous tap in-position check improvement.
0: Disable
1: Enable

Related parameters:

#1223/bit2 Synchronous tap R-point in-position check
#1223/bit4 Synchronous tap hole bottom in-position check
#1223/bit5 Synchronous tap R-point in-position check 2

bit4: Synchronous tap hole bottom in-position check

Select whether to enable the synchronous tap hole bottom in-position check.
0: Disable
1: Enable

(Note) This parameter is valid only when "1" (Enable in-position check) is set for "#1223 aux07/bit3 Synchronous tap in-position check improvement".

bit5: Synchronous tap R-point in-position check 2

Select whether to enable the synchronous tap R-point in-position check.
0: Disable
1: Enable

(Note) This parameter is valid only when "1" (Enable in-position check) is set for "#1223 aux07/bit3 Synchronous tap in-position check improvement".

bit6: Cancel synchronous tap (, S) return

0: Retain the spindle speed (, S) in synchronous tap return
1: Cancel the spindle speed (, S) in synchronous tap return with G80

bit7: Synchronous tap method

Select the synchronous tapping method.
0: Synchronous tapping with multi-step acceleration/deceleration and rapid return
1: Conventional type synchronous tapping

【#1224】 aux08

bit0: Sampling data output

Select whether to enable the sampling data output.
0: Disable
1: Enable

【#1225】 aux09

bit6: Enable/disable spindle rotation speed clamp 2

Select whether to enable the spindle rotation speed clamp by the G92 Q command for the spindle command rotation speed (R7000) set with the user ladder.
0: Follow the setting of "aux09/bit7".
1: Only G92 S is valid for R7000. G92 Q is invalid.

When this parameter is set to "1", setting of "aux09/bit7" is invalid.

bit7: Enable/disable spindle rotation speed clamp

Select whether to enable the spindle rotation speed clamp by the G92 S or Q command for the spindle command rotation speed (R7000) set with the user ladder.
0: Enable
1: Disable

II Parameters

2. Base Specifications Parameters

【#1226】 aux10

bit0: Tool compensation data for external workpiece coordinate offset measurement

Select the tool compensation data to be used for external workpiece coordinate offset measurement.

- 0: Tool length data and tool nose wear data
- 1: Tool length data

bit1: Optional block skip type

Select whether to enable the optional block skip in the middle of a block.

- 0: Enable only at the beginning of a block.
- 1: Enable in the middle of a block, as well as at the beginning of the block.

bit2: Single block stop timing

Select the timing at which the single block signal is activated.

- 0: When the signal goes ON while automatic operation is starting, the block will stop after finished.
- 1: When the signal is ON at the end of the block, the block will stop.

bit3: C-axis reference position return type

Select the C-axis reference position return type.

- 0: Basic position return is performed by the G28 reference position return command or by activating the manual reference position return. The basic point dog is used.
- 1: When the first C-axis command is issued after the C-axis mode is entered in automatic mode, reference position return is performed before the execution of the block. The reference position return is also performed by the G28 reference position return command or by activating the manual reference position return. The Z phase of the encoder is used.

bit4: S command during constant surface speed

Select whether to output a strobe signal when the S command is issued in constant surface speed mode.

- 0: Not output any strobe signal in constant surface speed mode.
- 1: Output strobe signals in constant surface speed mode.

bit5: Arbitrary allocation of dog signal

Select whether to enable the arbitrary allocation parameter for the origin dog and H/W OT.

- 0: Disable (Fixed device is used.)
- 1: Enable (Device is specified by the parameter.)

bit7: Shorten JOG stop time

Select whether to shorten the JOG stop time.

- 0: Not shorten (Conventional specification)
- 1: Shorten

【#1227】 aux11

bit0: Select PLC signal or spindle feedrate attained

Set up this option when disabling the cutting start interlock by spindle feedrate attained.

- 0: Cutting start interlock by PLC signal
- 1: Cutting start interlock by spindle feedrate attained

bit1: Select H or D code

Set up this option to validate the data that is set up on the tool life management screen when issuing the H99 or D99 command.

- 0: The H and D codes validate the data that is set up on the management setup screen.
- 1: Validates the data that is set up on the management setup screen when issuing the H99 or D99 command.

bit2: Measures against tool setter chattering

Select a condition where a relieving operation completes after measurement with tools.

- 0: Sensor signals have stopped for 500 ms or longer.
- 1: 100 μ m or longer has passed after sensor signals stopped.

bit3: Absolute coordinate switching (nose R)

Select whether to display a nose position or coordinate value with the absolute coordinate counter.

- 0: Displays the nose position.
- 1: Displays the position specified by program command. Select a condition where a relieving operation completes after measurement with tools.

bit5: Spindle rotation speed clamp

Specify whether to clamp the rotation speed in constant surface speed mode when the spindle rotation clamp command is issued.

- 0: Clamps the rotation regardless of the constant surface speed mode.
- 1: Clamps the rotation only in constant surface speed mode.

bit7: Switch the range of tool life data to be input

Set up the range of tool life data to be input or compared.

- 0: Inputs or compares all of the data output.
- 1: Inputs or compares part of the data output

- 1) Tool life management I data to be input or compared tool number (D), lifetime (E), life count (F), and auxiliary data (B).
- 2) Tool life management II data to be input or compared Group number (G), method (M), life (E/F), tool number (D), and compensation number (H)

II Parameters

2. Base Specifications Parameters

【#1228】 aux12

bit1: Switch "offset and parameter" screen

Select to switch the "offset and parameter" screen to the parameter screen.

- 0: Display the "offset and parameter" screen.
- 1: Display the "parameter" screen.

bit2: Switch data protection in data transmission mode

Select the range of data protection in data transmission mode.

- 0: Enable the protection for both send and receive data.
- 1: Enable the protection for receive data only.

bit3: Nose R specification

Select the method to specify the nose R compensation.

- 0: Specify the nose R compensation by shape number.
- 1: Specify the nose R compensation by wear number.

bit4: Select operation error or stop code

Select operation error or stop code to provide for both block start and cutting start interlocks.

- 0: Operation error
- 1: Stop code

bit5: Select constant surface speed coordinates

Select the constant surface speed coordinate.

- 0: Workpiece coordinate
- 1: Absolute value coordinate

bit6: Switch relative values displayed

Select whether to preset the relative coordinates with workpiece coordinate preset (G92.1) or counter preset (G92).

- 0: Preset the relative coordinates.
- 1: Not preset the relative coordinates.

bit7: Protection with manual value command

Select whether to protect a manual value command.

- 0: Not protect. (Conventional specification)
- 1: Protect.

II Parameters

2. Base Specifications Parameters

【#1229】 set01

bit0: Subprogram interrupt

Select the type of the user macro interrupt.
0: Macro type user macro interrupt
1: Sub-program type user macro interrupt

bit1: Accurate thread cutting E

Select what the address E specifies in inch screw cutting.
0: Number of threads per inch
1: Precision lead

bit2: Radius compensation type B (for M system only)

Select the method of the arithmetic processing for the intersection point when the start-up or cancel command is operated during radius compensation.
0: The processing does not handle the start-up or cancel command block: handle the offset vector in the direction vertical to that of the command instead.
1: The processing is executed for the intersection point between the command block and the next block.

bit2: Nose R compensation type B (for L system only)

Select the method of the arithmetic processing for the intersection point when the start-up or cancel commands are operated during nose R or radius compensation.
0: The processing does not handle the start-up or cancel command block: handle the offset vector in the direction vertical to that of the command instead.
1: The processing is executed for the intersection point between the command block and the next block.

bit3: Initial constant surface speed

Select the initial state after the power-ON.
0: Constant surface speed control cancel mode
1: Constant surface speed control mode

bit4: Synchronous tap

Select whether to use the floating tap chuck in G74 and G84 tapping cycles.
0: With a floating tap chuck
1: Without a floating tap chuck

bit5: Start point alarm

Select the operation when the operation start point cannot be found while executing the next block of G117.
0: Enables the auxiliary function after the block has been executed.
1: Outputs the program error (P33).

bit6: Grid display selection

Select the grid display type on the servo monitor screen during the dog type reference position return.
0: Distance between dog OFF and basic point (including a grid mask amount)
1: A value given by reducing a grid mask amount from the distance between dog OFF and basic point

【#1230】 set02

bit7: Macro interface input/output for each part system

Select the specification of the macro interface input/output.
0: Shared by all part systems.
1: Used independently by the part systems.

【#1231】 set03

bit0: Graphic check compatibility parameter

Select whether to return the data to the pre-starting data after having checked a machining program that rewrites the common variables, workpiece offsets and tool offsets.
0: Return the data.
1: Not return the data.

bit4: Switch zero point mark display position

Select the position for displaying the basic point mark in the graphic trace and 2D check.
0: Machine coordinate basic point (same as conventional method)
1: Workpiece coordinate basic point

bit5: Switch graphic check counter display

Select the type of counter displayed on the Graphic Check screen.
0: Machine position counter
1: Workpiece coordinate position counter

【#1232】 set04

Not used. Set to "0".

【#1233】 set05

Not used. Set to "0".

【#1234】 set06

Not used. Set to "0".

II Parameters

2. Base Specifications Parameters

【#1235】 set07

bit0: Helical interpolation speed 2

- 0: Select normal speed designation also for 3rd axis
- 1: Select arc plane element speed designation

bit2: Fixed type chopping compensation valid only at start

When the fixed type compensation value is selected, the method can be changed to the compensation value sequential update type after the first four cycles.

- 0: Disable the method changeover
- 1: Enable the method changeover

bit4: Selection condition of synchronous tapping gear step

Select the parameters that determine the gear step for synchronous tapping.

- 0: #3005 through #3008 (smax1 to 4) when "#1223 aux07/bit7" is "0".
- Or #3013 through #3016 (stap1 to 4) when "#1223 aux07/bit7" is "1".
- 1: Always #3013 through #3016 (stap1 to 4)

【#1236】 set08

bit0: Manual rotary axis feedrate unit

Select the unit of manual rotary axis feedrate.

- 0: Fixed to [°/min]
- 1: Same speed as before (When inch command, the speed is the command speed divided by 25.4.)

bit1: Spindle speed detection

Select the pulse input source of actual spindle rotation speed (R6506/R6507) when the spindle encoder serial connection is selected ("#3025 enc-on" is set to "2").

- 0: Serial input
- 1: Encoder input connector

bit2: Current limit droop cancel invalid

Select whether to cancel the position droop when the current limit changeover signal is canceled.

- 0: Cancel the droop.
- 1: Not cancel the droop.

bit3: Rotary axis command speed scale

Select to multiply the rotary axis command speed by 10 times.

- 0: Invalid
 - 1: During initial inching, the rotary axis command speed is multiplied by 10. In other words, if "F100" is commanded, the speed will be the same as when 1000°/min is commanded.
- The rotary axis speed display unit will be 10°/min.

【#1237(PR)】 set09

Not used. Set to "0".

【#1238(PR)】 set10

bit0: Switch G36 function

Select the function, the automatic tool length measurement or arc thread cutting (CCW), to be applied to G36 when the G code system 6 or 7 is selected.

- 0: Automatic tool length measurement
- 1: Arc thread cutting (CCW)

bit7: Switch operation alarm

Select whether to enable the NC alarm 5 (AL5) signal output.

- 0: Disable NC alarm 5 (AL5)
 - All operation alarms will be output to NC alarm 4 (AL4).
 - All operation alarms will be recorded in the alarm history.
- 1: Enable NC alarm 5 (AL5)
 - The following operation alarms will be output to NC alarm 5 (AL5), not to NC alarm 4 (AL4).
 - The operation alarms output to NC alarm 5 (AL5) will not be recorded in the alarm history.

- External interlock axis found
- Cutting override zero
- External feedrate zero
- Block start interlock
- Cutting block start interlock
- Cutting interlock for spindle-spindle polygon (G51.2)

II Parameters

2. Base Specifications Parameters

【#1239(PR)】 set11

bit0: Coil switching method

Select the coil switching method.

- 0: Via PLC (Y189F).
- 1: NC internal processing. (Y189F is invalid.)

bit1: Handle I/F selection

Select the handle connection destination.

- 0: Use the handle connected to the encoder communication connector.
- 1: Use the remote I/O unit as a priority.

When HN391/HN392 is mounted, the handle connected to the operation panel I/O unit will be used regardless of this parameter setting.

bit3: Polygon machining mode at reset

Select whether to cancel the polygon machining mode when reset is applied.

- 0: Not cancel.
- 1: Cancel.

bit4: Invalidate G51.1 phase command

Select whether to enable the phase control with the spindle-spindle polygon function.

- 0: Always enable. (When R is not commanded, it will be handled as R0.)
- 1: Enable only at the R command.

bit5: Door interlock spindle speed clamp valid

Select whether to enable the spindle clamp speed changeover by the PLC signal.

- 0: Disable
- 1: Enable

【#1240(PR)】 set12

bit0: Handle input pulse

Select the handle input pulse.

- 0: MITSUBISHI CNC standard handle pulse
- 1: Handle 400 pulse

bit2: Zero point shift amount magnification

When "1" is set, the following magnification will be applied on the "#2027 G28sft Reference position shift distance", "#2057 Near zero point +" and "#2058 Near zero point -" settings.

- For 0.1 μ m: 10-fold
- For 0.01 μ m: 100-fold

bit4: Optical communication automatic channel detection invalid

Select whether to enable the optical communication automatic channel detection.

- 0: Enable
- 1: Disable

【#1265(PR)】 ext01

bit0: Command format 1

Select the command format for the fixed cycle for compound lathe.

- 0: Conventional format
- 1: MITSUBISHI CNC special format (1 block command method)

bit1: Command format 2

Select the command format for the lathe fixed cycle.

- 0: Conventional format
- 1: MITSUBISHI CNC special format

bit2: Command format 3

Select the command format for the hole drilling fixed cycle.

- 0: Conventional format
- 1: MITSUBISHI CNC special format

【#1266(PR)】 ext02

Not used. Set to "0".

【#1267(PR)】 ext03

bit0: G code type

Select the high-speed high-accuracy G code type.

- 0: Conventional format (G61.1)
- 1: MITSUBISHI special format (G08P1)

【#1268(PR)】 ext04

Not used. Set to "0".

【#1269(PR)】 ext05

Not used. Set to "0".

II Parameters

2. Base Specifications Parameters

【#1270(PR)】 ext06

bit6: Switch continuous thread cutting Z phase wait operation

Select when to start the 2nd block thread cutting when there is a command with no movement (MST command, etc.) between the thread cutting blocks.

0: Wait for the spindle's single rotation synchronization signal before starting the movement.

1: Start movement without waiting for the spindle's single rotation synchronization signal.

bit7: Handle C axis coordinate during cylindrical interpolation

Specify whether to keep the rotary axis coordinate as before the cylindrical interpolation start command is issued during the cylindrical interpolation.

0: Not keep

1: Keep

【#1271(PR)】 ext07

bit0: Mirror image operation

Select the type of mirror image operation.

0: Type 1

• The program mirror image, external mirror image, and parameter mirror image are exclusive to each other.

• An increment command moves the image to the position indicated by the travel amount with the sign inverted.

1: Type 2

• Mirror image operation is enabled when the program mirror image (G51.1) command is issued or when the external signal or parameter is ON.

• An increment command moves the image to the position determined by applying the mirror image to the absolute program coordinates.

bit1: Address specifying fixed cycle repetition count (for M system only)

Select the address that specifies the fixed cycle repetition count.

0: Address L only (Default)

1: Addresses K and L

If addresses K and L are specified simultaneously, the data at address K will be used for operation.

bit2: F-command unit

Select the unit to be used when a thread cutting lead command does not contain decimal point.

0: Type 1 (conventional specifications)

F1 -> 1 mm/rev, 1 inch/rev

1: Type 2

F1 -> 0.01 mm/rev, 0.0001 inch/rev

bit3: G-code group for unidirectional positioning (for M system only)

Select the G-code group for unidirectional positioning.

0: Unmodal G code (group 00)

1: Modal G code (group 01)

Related parameter: "#8209 G60 Shift" (Set the last positioning direction and distance for each axis applicable when the unidirectional positioning command is issued.)

bit4: Operation by independent G40 command

Select whether the radius compensation vector is canceled by the independent G40 command.

0: Type 1 (conventional specification) (Default)

The radius compensation vector will be canceled by the independent G40 command.

1: Type 2

The radius compensation vector won't be canceled by the independent G40 command: it will be canceled by the next travel command for the radius compensation plane.

bit5: Cut start position (for L system only)

Select the position from where cutting begins in a fixed cycle for compound lathe.

0: Conventional specification (Default)

The cut start position will be determined by the final shaping program.

1: Extended specification

The cut start position will be determined from the cycle start point.

bit6: Nose R compensation (for L system only)

Select whether to apply nose R compensation for shapes in a rough cutting cycle.

0: Conventional specification (Default)

The shape after nose R compensation in the final shaping program will be used as rough cutting shape (when the nose R compensation for the final shaping program).

1: Extended specifications

The shape without nose R compensation in the final shaping program will be used as rough cutting shape.

bit7: Cut amount (for L system only)

Select the operation to be performed when the program-specified cut amount exceeds the cut amount of the final shaping program.

0: Conventional specification (Default)

A program error will occur when the program-specified cut amount exceeds the cut amount of the final shaping program.

1: Extended specification

Rough cutting will be performed by one cut when the program-specified cut amount exceeds the cut amount of the final shaping program.

II Parameters

2. Base Specifications Parameters

【#1272(PR)】 ext08

bit0: Switch pocket machining operation

Select the pocket machining specification.

0: Conventional specification

Pocket machining will be selected with the H designation.

The pull direction when pocket machining is ON will be the Z direction.

1: Extended specification

Pocket machining will start only when both X and Z axes are specified in the first travel block after the finished shape start block.

The pull direction when pocket machining is ON will be the X direction.

bit1: M function synchronous tap cycle

Specify whether to enable the M function synchronous tapping cycle.

0: Disable

1: Enable

bit2: Spiral/conical interpolation command format 2

Select the command format for spiral and conical interpolation.

0: Type 1 (conventional specification)

1: Type 2 (with the number of spiral rotation L designation and the increment designation)

bit3: Switch macro call function

Select whether to shift the argument to the subprogram if nests are overlapped when per block call (G66.1) is commanded.

0: Shift

1: Not shift (Conventional specification)

bit4: Tap cycle selection

Select the tapping cycle.

0: Pecking tapping cycle

1: Deep hole tapping cycle

bit5: Deep hole tap cycle override selection

Select whether to enable override on the pulling operation during synchronized tapping with the deep hole tapping cycle.

0: Disable

1: Enable

bit6: Switch corner chamfering/ corner R command format

Select the command format of the corner chamfering/corner R.

0: Command format I (conventional format)

Issue a command with comma (,C and ,R).

1: Command format II

In addition to command format I, addresses without comma can be used to command.

I/K or C can be used for corner chamfering, while R can be used for corner R.

bit7: Return position after macro interrupt in fixed cycle selection

Select the destination to return to after a macro interrupt in the fixed cycle.

0: Return to the block in the fixed cycle.

1: Return to the block next to the fixed cycle.

【#1273(PR)】 ext09

bit0: Switch ASIN calculation results range

Select the ASIN calculation results range.

0: -90° to 90°

1: 90° to 270°

bit1: Switch system variable unit

Select the unit for the system variable #3002 (time during automatic start).

0: 1 ms unit

1: 1 hour unit

bit2: Switch G71, G72, G73 cutting direction judgment

Select the cutting direction when the longitudinal rough cutting cycle (G71), face rough cutting cycle (G72) or closed loop cutting cycle (G73) is commanded.

0: Conventional specification

Determined according to the finished shape program.

1: Extended specification

Determined according to the finishing allowance and cutting allowance commanded in the program.

bit3: Facing turret mirror image coordinate value type

Select how to show the workpiece coordinate values of the axis for which the facing turret mirror image is valid.

0: Movements in the workpiece coordinate system are in the same direction as those in the workpiece machine coordinate system.

1: Movements in the workpiece coordinate system are in the opposite direction to those in the workpiece machine coordinate system.

bit4: Facing turret mirror image valid axis selection

Select the axis for which the facing turret mirror image is valid.

0: Fixed to 1st axis.

1: Determined according to the plane selected when the facing turret mirror image is commanded.

II Parameters

2. Base Specifications Parameters

【#1274(PR)】 ext10

bit7: Word range check

Select whether to check that the operation expression of the word data in the program is enclosed in brackets ([]) when the machine program is executed.
This check is also applied to the 08000 to 09999 and the machine tool builder macro program.

- 0: Check
- 1: Not check

【#1275(PR)】 ext11

Not used. Set to "0".

【#1276(PR)】 ext12

Not used. Set to "0".

【#1277(PR)】 ext13

bit0: Tool life management II count type 2

Select how and when the mount or use count will be incremented in tool life management II. The condition to output "tool group life over (TGLO)" signal will be changed accordingly.

- 0: Type 1 (Default)
 - Counts up when the spindle tool is used for cutting.
 - TGLO signal will be output when the last tool in selected group is judged as expired.
- 1: Type 2
 - Counts up by one for a tool used or mounted in a program at the time of resetting.
 - TGLO signal will be output when any of tool groups has reached its lifetime limit.

bit1: Tool life management II life prediction

Select whether to enable tool life prediction function in tool life management II.

- 0: Disable
- 1: Enable

bit2: Tool life management II life end signal timing

Select the timing at which tool life prediction signal is output in tool life management II.

- 0: Output only when the ["life value" - "used value"] matches the remaining life.
("life value" - "used value" = "remaining life")
- 1: Output when the ["life value" - "used value"] is less than the remaining life.
("life value" - "used value" \leq "remaining life")

bit3: Tool life management II life end signal tool

Select the tool for which the tool life prediction signal is output in tool life management II.

- 0: Output the signal tool by tool.
- 1: Output the signal at the last tool in the group.

bit4: Tool life management II count changeover (For M system only)

Select the tool life count method and its timing.

- 0: Conforms to "ext13/bit0" setting.
 - 1: When "ext13/bit0" is set to "0":
 - Counts up by one for a tool used or mounted in a program at the time of resetting.
 - When "ext13/bit0" is set to "1":
 - Follow the setting of "Method (Mthd)" on Tool life screen.
- The output condition of "tool group life over" signal conforms to "ext13/bit0".

【#1278(PR)】 ext14

bit0: Program restart method selection

Select the program restart type.

- 0: Restart type A
- 1: Restart type B

【#1279(PR)】 ext15

bit0: Part system synchronization method

Select the part system synchronization method.

- 0: If one part system is not in the automatic operation, the synchronization command will be ignored and the next block will be executed.
 - 1: Operate according to the "waiting ignore" signal.
- If the "waiting ignore" signal is set to "1", the synchronization command will be ignored. When set to "0", synchronization will be applied.

bit1: Interrupt amount during machine lock

Select when to cancel the interruption amount during machine lock.

- 0: When resetting
- 1: During manual reference position return (not when resetting)

bit2: Selection of cutting start interlock target block

Select whether to enable the cutting start interlock for successive cutting blocks.

- 0: Enable
- 1: Disable

II Parameters

2. Base Specifications Parameters

【#1280(PR)】 ext16

bit0: I/F per axis during cross machining control

Select how to handle the following PLC interface for axes interchanged with cross machining control.

- Mirror image
 - Manual/automatic interlock
 - Manual/automatic machine lock
- 0: Follows axis configuration before cross machining control.
1: Follows axis configuration after cross machining control.

(Example)

The device No. of automatic interlock (+) for X1 will be as follows when the cross machining is executed with the 1st axis (X1) in the 1st part system and 1st axis (X2) in the 2nd part system.

When "0" is set: Y820 (interface for 1st axis in 1st part system)

When "1" is set: Y828 (interface for 1st axis in 2nd part system)

(Note) If the number of axes in the part system changes with cross machining, the interface of the target axis may change when this parameter is set to "1".

(Example)

When 1st part system's C axis is moved to 2nd part system with a 1st part system (X, Z, C, Y) and 2nd part system (X, Z) configuration:

When "1" is set: Y82A, Y7CA, Y8AA and later will be the interface for the C axis moved to the 2nd part system. Y7C2, Y822, Y8A2 and later will be the interface of the Y axis in the 1st part system, because the axes following the removed C axis (third place) are shifted up.

bit1: Cross machining control cancel with reset

Select whether to cancel the cross machining control when reset is applied.

- 0: Cancel.
1: Not cancel.

bit2: Interchange coordinate position display

Select whether to display interchanged (or moved) coordinate positions in the cross machining control.

This setting will be applied when the axes are moved, as well as when the axes are interchanged.

- 0: Display interchanged (or moved) coordinate positions.
1: Display coordinate positions without being interchanged (nor moved).

(Example)

When 1st part system's C axis is moved to 2nd part system with a 1st part system (X, Z, C, Y) and 2nd part system (X, Z) configuration:

1st part system: X, Z and Y coordinate positions are displayed.

2nd part system: X, Z and C coordinate positions are displayed.

bit3: Reset operation for synchronization/super-imposition control

Select whether to cancel synchronization/superimposition control when reset is applied.

- 0: Cancel.
1: Not cancel.

【#1281(PR)】 ext17

bit0: Zero point return operation changeover parameter

(Zero point setting operation)

The "Operation error 1036" will occur regardless of this parameter, and regardless of manual or automatic operation.

(High-speed zero point return)

0: <During manual operation>

The master axis and slave axis will simultaneously start zero point return. Even if one of the axes reaches the zero point, the other axis will continue to move until it reaches the zero point. Thus, if the difference of the master axis and slave axis feedback position before zero point return is larger than the tolerable synchronization error amount, the error "Operation error 0051" will occur during zero point return.

0: <During automatic operation>

The master axis and slave axis will simultaneously start zero point return. When the master axis reaches the zero point, the slave axis will stop. Thus, the positional relation of the master axis and slave axis established before zero point return is maintained.

1: <During manual operation> <During automatic operation>

The master axis and slave axis will simultaneously start zero point return. When the master axis reaches the zero point, the slave axis will stop. Thus, the positional relation of the master axis and slave axis established before zero point return is maintained.

bit3: Synchronous control Operation setting

Select whether to automatically align the positioning of slave axis with that of master axis when the axis subject to synchronous control is changed from servo OFF to servo ON.

- 0: Not align.
1: Align.

bit5: High-speed synchronous tapping valid

Select whether to enable high-speed synchronous tapping.

- 0: Disable
1: Enable

【#1282(PR)】 ext18

Not used. Set to "0".

II Parameters

2. Base Specifications Parameters

【#1283(PR)】 ext19

Not used. Set to "0".

【#1284(PR)】 ext20

Not used. Set to "0".

【#1285(PR)】 ext21

bit0: Multi-part system program generation and operation

Select whether to use Multi-part system program management.

0: Not use

1: Use

(Note) When this parameter is changed, the power must be turned OFF and ON, and the system formatted. When "1" is not set to two or more "#1001 SYS_ON" [1] to [4], this parameter will not be valid even if this parameter is set to "1".

bit1: Changeover of method to select operation program

Select how to search a program to operate.

0: Select a program in the selected part system with operation search.

1: Select a common part system program with operation search. (A common part system program No. will be selected.)

【#1286(PR)】 ext22

bit0: Program input/output method selection

Select the program input/output method.

0: Only the programs in the selected part system are input/output.

1: The designated programs are output for all part systems.

bit2: O No. for program input No.

Select the operation when the same program No. is input during data input.

0: The O No. is handled as a character string data.

1: The O No. is handled as a program No. Whether to overwrite the program or cause an error is decided by "#1218 bit7 Input by program overwrite".

bit3: No O No. at machining program input

Select whether to enable the machining program input even if there is no program No. (O No.).

The program No. is fixed to 01 in this case.

0: Disable

1: Enable

【#1287(PR)】 ext23

bit4: Relative coordinate display

(M system)

0: Display the actual position including tool length offset.

1: Display the machining position in terms of a program command excluding tool length offset.

(L system)

0: Display the actual position including tool shape compensation.

1: Display the machining position in terms of a program command excluding tool shape compensation.

bit5: Relative coordinate display

(M system)

0: Display the actual position including tool radius compensation.

1: Display the machining position in terms of a program command excluding tool radius compensation.

(L system)

0: Display the actual position including nose R compensation.

1: Display the machining position in terms of a program command excluding nose R compensation.

【#1288(PR)】 ext24

bit0: MDI program clear

Select whether to clear the MDI programs when MDI operation ends, the power is turned ON again, reset is input, or emergency stop is canceled.

0: Not clear.

1: Clear (save only % programs).

II Parameters

2. Base Specifications Parameters

【#1289(PR)】 ext25

bit0: Tool radius compensation switch corner judgment method (Nose R compensation)

Select the criterion to execute the outer rounding at the small corner in tool radius compensation.

(L system)

0: The corner angle is 0°; linear-linear; G02-G03/G03-G02; the radius is the same. (Conventional method)

1: The corner angle is 1° or smaller; linear-linear; G02-G03/G03-G02; the radius is almost the same. (Method for rounding minute corner angle)

(M system)

0: The corner angle is 1° or smaller; linear-linear; G02-G03/G03-G02. (Conventional method)

1: The corner angle is 1° or smaller; linear-linear; G02-G03/G03-G02; the radius is almost the same. (Method for rounding minute corner angle)

【#1290(PR)】 ext26

Not used. Set to "0".

【#1291(PR)】 ext27

Not used. Set to "0".

【#1292(PR)】 ext28

Not used. Set to "0".

【#1293(PR)】 ext29

Not used. Set to "0".

【#1294(PR)】 ext30

Not used. Set to "0".

【#1295(PR)】 ext31

Not used. Set to "0".

【#1296(PR)】 ext32

Not used. Set to "0".

【#1297(PR)】 ext33

Not used. Set to "0".

【#1298(PR)】 ext34

Not used. Set to "0".

【#1299(PR)】 ext35

Not used. Set to "0".

【#1300(PR)】 ext36

bit0: Multiple spindle control II

Select multiple spindle control I or II.

0: Multiple spindle control I (L system only)

1: Multiple spindle control II (select from ladder)

bit7: Spindle synchronization command method

Select the spindle synchronization command method.

0: Spindle synchronization with PLC I/F

1: Spindle synchronization with machining program

【#1301】 nrfchk Near reference position check method

Select the method to judge the "near reference position".

0: Conventional method

1: Command machine position is used.

2: Feedback position is used.

【#1302】 AutoRP Automatic return by program restart

Select the method to move to the restart position when restarting the program.

0: Move the system manually to the restart position and then restart the program.

1: The system automatically moves to the restart position at the first activation after the program restarts.

【#1303(PR)】 V1comN No. of #100 address part system common variables

Set the number of common variables, common for part systems, starting from address #100.

This is valid only when "#1052 MemVal" is set to "1".

---Setting range---

0 to 100

II Parameters

2. Base Specifications Parameters

【#1304(PR)】 V0comN No. of #500 address part system common variables

Set the number of common variables, common for part systems, starting from address #500.

This is valid only when "#1052 MemVal" is set to "1".

---Setting range---
0 to 500

【#1306】 InpsTyp Deceleration check specification type

Select the parameter specification type for the G0 or G1 deceleration check.

0: Deceleration check specification type 1

G0 is specified with "#1193 inpos", and G1+G9 with "#1223 aux07/bit1".

1: Deceleration check specification type 2

G0 or G1+G9 is specified with "#1193 inpos".

【#1309(PR)】 GType Switch command format

Select which is used to command the reverse tap.

0: G84.1/G88.1

1: D command with the value changed to negative

【#1310】 WtMmin Minimum value for synchronization M code

Set the minimum value for the M code. When "0" is set, the synchronization M code will be invalid.

---Setting range---
0, 100 to 99999999

【#1311】 WtMmax Maximum value for synchronization M code

Set the maximum value for the M code. When "0" is set, the synchronization M code will be invalid.

---Setting range---
0, 100 to 99999999

【#1312】 T_base Tool life management standard number

Set the standard No. for the tool life management.

When the value specified by the T code command exceeds the set value in this parameter, the set value will be subtracted from the command value, which will be used as tool group No. for tool life management.

When the value specified by the T code command is equal to or less than the set value, the T code will be handled as a normal T code and not subjected to tool life management.

When "0" is set in this parameter, the T code command will always specify a group No.

(Valid for M-system tool life management II.)

---Setting range---
0 to 9999

【#1313】 TapDw1 Synchronous tap hole bottom wait time

Set the hole bottom wait time for synchronous tapping.

When P address is specified, the greater value will be used as the hole bottom wait time.

When an in-position check is performed at the hole bottom, the wait time will be provided after the completion of the in-position check.

(Note) This parameter is valid only when "1" is set in "#1223 aux07/bit3" (synchronous tap in-position check improvement) and "#1223 aux07/bit4" (synchronous tap hole bottom in-position check).

---Setting range---
0 to 999 (ms)

【#1314】 TapInp Synchronous tap in-position check width (tap axis)

Set the hole bottom in-position check width for synchronous tapping.

(Note) This parameter is valid only when "1" is set in "#1223 aux07/bit3" (synchronous tap in-position check improvement) and "#1223 aux07/bit4" (synchronous tap hole bottom in-position check).

---Setting range---
0.000 to 99.999

【#1316(PR)】 CrossCom Reference of common variables common for part systems

Select whether to use the common variables from #100100 to #800199.

0: Not use

1: Use

This parameter is valid only when the number of variable sets is set to 600 or more.

When this parameter is set to "1", variables from #100100 to #100110 will not be available as the system variables for PLC data read function, and the setting of "#1052 MemVal" will be invalid.

【#1324(PR)】 Chop_R Chopping compensation value fixing method

Set the head No. of the R register used as the compensation amount save area during fixed compensation amount method.

When the first number is an odd number, the operation message "Setting error" appears.

When the value overlaps with the chopping control data area, the operation message "Setting error" appears.

---Setting range---
8300 to 9782
(Only the even number)
(Within backup area)

II Parameters

2. Base Specifications Parameters

【#1326】 PLC Const Ext. Number PLC constant extension number

Set the number of PLC constant extension points.

---Setting range---
0 to 750

【#1327】 3D ATC type Tool change method specification

Select the tool change method for determining the tool to draw solids.
With 3D drawing, the tool will be changed by the method designated with this parameter, and then the image will be drawn.

0: With one standby tool
1: With two standby tools
2: With no standby tool

【#1328】 TLM type Tool measurement standard positions election

Select the tool measurement method.

0: Use the machine position at TLM switch ON as 0.
1: Use the machine basic point as standard.

【#1329】 Emgcnt Emergency stop contactor shut-off time

Set the time taken for the drive section's main power to be shut-off when the confirmation of all the axes' stop failed after the emergency stop state.

The contactor shut-off signal is output as soon as all the axes are confirmed stopped if the confirmation is done prior to the set time.

When there is no safety observation option or "0" is set, the shut-off time will be 30(s).

---Setting range---
0 to 60 (s)

【#1330(PR)】 MC_dp1 Contactor weld detection device 1

When safety observation is executed, set the I/O device to input the contactor's auxiliary B contact signal used for the contactor weld detection.

If "0" is set, weld detection will not be executed.

---Setting range---
000 to 02FF (HEX)

【#1331(PR)】 MC_dp2 Contactor weld detection device 2

When safety observation is executed, set the I/O device to input the contactor's auxiliary B contact signal used for the contactor weld detection.

If "0" is set, weld detection will not be executed.

---Setting range---
000 to 02FF (HEX)

【#1332(PR)】 F-bus init delay Fieldbus communication error invalid time

Tuning the power ON, start the communication, and then set the time where Fieldbus communication error is not detected.

Set this in 0.1 second increment.

---Setting range---
0 to 255 (0.1s)
Standard: 0

【#1333】 LMC restrain Lost motion compensation restraint in handle mode

Select whether to restrain the lost motion compensation in handle mode.

0: Restrain
1: Not restrain

【#1334】 DI/DO refresh cycl DI/DO refresh cycle

Select the DI/DO refresh cycle.

0: Standard mode
1: High-speed mode 1
2: High-speed mode 2

(Note 1) This parameter is valid for M700 and M70 (typeA) series. "Standard mode" is applied to M70 (typeB) regardless of this parameter.

(Note 2) The speed may not be high if number of ladder steps is excessive.

(Note 3) If high-speed mode is selected, the fine segment processing performance may degrade.

【#1335】 man_smg Manual feed acceleration/deceleration selection

Select the acceleration/deceleration mode in jog feed, incremental feed and manual reference position return (when rapid traverse signal OFF).

0: Acceleration/Deceleration for rapid traverse
1: Acceleration/Deceleration for cutting feed

【#1336(PR)】 #400_Valtype #400 address variable type

Select whether the #400-level variables are used as machine tool builder macro variables or as common variables.

0: #400 to #449 are not available; #450 to #499 are used as machine tool builder macro variables.
1: #400 to #499 are used as common variables

(Note) 700 sets of common variables are required for using #400 to #499 as common variables. If this parameter is set to "1" while the number of common variables is not set to 700, this parameter setting will be regarded as "0".

II Parameters

2. Base Specifications Parameters

【#1338(PR)】 rev_data_save_trg Trigger switching to save arbitrary reverse run data

Select the condition to start/stop saving reverse run data.

- 0: Start when the reverse run control mode signal is turned ON. Stop when turned OFF.
- 1: Start when the reverse run control mode signal is ON and macro interrupt is valid (M96/ION).
Stop when the reverse run control mode signal is OFF or macro interruption is finished (M97/IOF) (compatible with M500M).

【#1361(PR)】 aux_acc Auxiliary axis acceleration/deceleration type

Select the acceleration/deceleration type of auxiliary axis in PLC axis indexing.

- 0: Acceleration/deceleration with constant time
- 1: Acceleration/deceleration with a constant angle of inclination

【#1493(PR)】 ref_syn Synchronization at zero point initialization

0: Master axis and slave axis determine their zero points individually.

- 1: The zero points of both master and slave axes are determined by initializing the master axis's zero point.

The slave axis moves in perfect synchronization with the master axis.
Set this to "1" for speed/current command synchronization control.

【#1494(PR)】 dsp_ax_change Axis order of counter display

Set this in order to change the axis order of counter display.

The axes will be displayed in ascending order of the setting values "1" to "8".

However, axis whose setting is "0" will be displayed after axes whose settings are between "1" and "8" are displayed.

(Note 1) When the same value is set for more than one axis, axis that is displayed on the left side on the parameter screen will be first displayed.

(Note 2) When both of mixed synchronization control (option) and interchange coordinate position display ("1280 ext16/bit2" OFF) are valid, and when there are two or more valid part systems, this parameter will be ignored.

---Setting range---

1 to 8: Axes are displayed in ascending order.

Other than 1 to 8: Axes are displayed after the display of the axes with setting value "1" to "8".

【#1501】 polyax Rotational tool axis number (for L system only)

Set the number of the rotational tool axis used for polygon machining (G51.2). Set "0" when not using polygon machining (spindle-servo axis), or when using spindle-spindle polygon machining. A value exceeding the base specification parameter "#1002 axisno" cannot be specified.

This parameter is valid when the G code system is 6 or 7 (7 or 8 is set in base specification parameter "#1037 cmdtyp").

【#1502】 G0lpfg G1 -> G0 deceleration check

Select whether to perform a deceleration check when the travel direction is changed from G1 to G0.

- 0: Not perform
- 1: Perform

【#1503】 G1lpfg G1 -> G1 deceleration check

Select whether to perform a deceleration check when the travel direction is changed from G1 to G1.

- 0: Not perform
- 1: Perform

【#1505】 ckref2 Second reference position return check

Select whether the check is carried out at the specified position in manual second reference position return mode upon completion of spindle orientation or at second reference position return interlock signal.

- 0: Upon completion of spindle orientation
- 1: At second reference position return interlock signal

【#1506】 F1_FM Upper limit of F1-digit feedrate

Set the maximum value up to which the F 1-digit feedrate can be changed.

---Setting range---

0 to 60000 (mm/min)

【#1507】 F1_K F 1-digit feedrate change constant

Set the constant that determines the speed change rate per manual handle graduation in F 1-digit feedrate change mode.

---Setting range---

0 to 32767

【#1510】 DOOR_H Shorten door interlock II axis stop time

Select whether to shorten the time during which the axis is stopped when the door is opened.

- 0: Use the conventional axis stop time.
- 1: Shorten the axis stop time.

(Note) When the door interlock II signal is input via a ladder, the conventional axis stop time will be used.

II Parameters

2. Base Specifications Parameters

【#1511】 DOORpm Signal input device 1 for door interlock II: for each part system

Set the fixed device number (X??) for door interlock II signal input for each part system. A device number from X01 to XFF can be specified.

Device number "000" is invalid.

Set device number "100" when using no fixed device number for door interlock II signal input.

Related parameter: "#1154 pdoor (Door interlock II for each part system) "

---Setting range---

000 to 2FF (hexadecimal)

【#1512】 DOORps Signal input device 2 for door interlock II: for each part system

Set the fixed device number (X??) for door interlock II signal input for each part system. (Set the same value as that of #1155.)

Related parameter: "#1154 pdoor (Door interlock II for each part system)"

---Setting range---

000 to 2FF (hexadecimal)

【#1513】 stapM M code for synchronous tap selection

Set the M code for the synchronous tapping selection.

Select the synchronous tapping mode using the miscellaneous function code of the value set in this parameter. The M function command can be issued immediately before the tap command or in the same block. This function is valid only when "1" is set in "#1272 ext08/bit1 (Enable/disable M-function synchronous tap cycle)".

(Note) Do not use M00, 01 02, 30, 98, and 99.

---Setting range---

0 to 99999999

【#1514】 expLinax Exponential function interpolation linear axis

Set the axis name for the linear axis used in exponential function interpolation.

---Setting range---

A to Z

【#1515】 expRotax Exponential function interpolation rotary axis

Set the axis name for the rotary axis used in exponential function interpolation.

---Setting range---

A to Z

【#1516】 mill_ax Milling axis name

Set the name of the rotary axis used in milling interpolation. Only one rotary axis can be set. When there is no E command in issuing the G12.1 command, this parameter will be followed.

---Setting range---

A to Z

【#1517】 mill_C Milling interpolation hypothetical axis name

Select the hypothetical axis command name for milling interpolation.

When there is no D command in issuing the milling interpolation command, this parameter will be followed.

0: Y axis command

1: Command rotary axis name.

【#1518】 polm Spindle-spindle polygon Workpiece spindle No.

Set the workpiece axis No. used in spindle-spindle polygon machining.

(Note) The 1st spindle will be selected when "0" is set.

【#1519】 pols Spindle-spindle polygon Tool spindle No.

Set the number of the rotary tool spindle used in spindle-spindle polygon machining.

(Note) The 2nd spindle will be selected when "0" is set.

【#1520(PR)】 Tchg34 Additional axis tool compensation operation

Select axis to carry out the additional axis' tool compensation function.

0: 3rd axis.

1: 4th axis.

【#1521】 C_min Minimum turning angle

Set the minimum turning angle of the normal line control axis at the block joint during normal line control.

---Setting range---

0.000 to 360.000 (°) (Input setting increment applies)

【#1522(PR)】 C_axis Normal line control axis

Set the number of the axis for normal line control.

Set a rotary axis No.

0: Normal line control disabled

1 to 8: Axis No. (number of control axes)

II Parameters

2. Base Specifications Parameters

【#1523】 C_feed Normal line control axis turning speed

Set the turning speed of the normal line control axis at the block joint during normal line control.
Set a value that does not exceed the normal line control axis' clamp speed ("#2002 clamp"). This is valid with normal line control type I.
---Setting range---
0 to 1000000 (°/min)

【#1524】 C_type Normal line control type

Select the normal line control type.
0: Normal line control type I
1: Normal line control type II

【#1533】 millPax Pole coordinate linear axis name

Set the linear axis name used for pole coordinate interpolation.
---Setting range---
Axis name such as X, Y or Z

【#1534】 SnG44.1 Spindle No. for G44.1 command

Set the selected spindle No. for the G44.1 command.
The setting range differs according to the model.
If a spindle that does not exist is set, the 2nd spindle will be used. Note that if there is only one spindle, the 1st spindle will be used.
0: 2nd spindle
1: 1st spindle
2: 2nd spindle
3: 3rd spindle
4: 4th spindle

【#1535】 C_leng Minimum turning movement amount

Set the minimum turning movement amount of the normal line control axis at the block joint during normal line control.
---Setting range---
0.000 to 99999.999 (mm) (Input setting increment applies)

【#1537】 crsax[1] Cross machining control axis

Set the axis to be interchanged during cross machining control.
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed synchronization control (cross machining control) request signal is input, or the name of the axis to be shifted to that part system.
---Setting range---
Two digits between A to Z and 1 to 9
(Setting will be cleared when "0" is set)

【#1538】 crsax[2]

Set the axis to be interchanged during cross machining control.
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed synchronization control (cross machining control) request signal is input, or the name of the axis to be shifted to that part system.
---Setting range---
Two digits between A to Z and 1 to 9
(Setting will be cleared when "0" is set)

【#1539】 crsax[3]

Set the axis to be interchanged during cross machining control.
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed synchronization control (cross machining control) request signal is input, or the name of the axis to be shifted to that part system.
---Setting range---
Two digits between A to Z and 1 to 9
(Setting will be cleared when "0" is set)

【#1540】 crsax[4]

Set the axis to be interchanged during cross machining control.
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed synchronization control (cross machining control) request signal is input, or the name of the axis to be shifted to that part system.
---Setting range---
Two digits between A to Z and 1 to 9
(Setting will be cleared when "0" is set)

【#1541】 crsax[5]

Set the axis to be interchanged during cross machining control.
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed synchronization control (cross machining control) request signal is input, or the name of the axis to be shifted to that part system.
---Setting range---
Two digits between A to Z and 1 to 9
(Setting will be cleared when "0" is set)

II Parameters

2. Base Specifications Parameters

【#1542】 crsax[6]

Set the axis to be interchanged during cross machining control.
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed synchronization control (cross machining control) request signal is input, or the name of the axis to be shifted to that part system.

---Setting range---

Two digits between A to Z and 1 to 9
(Setting will be cleared when "0" is set)

【#1543】 crsax[7]

Set the axis to be interchanged during cross machining control.
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed synchronization control (cross machining control) request signal is input, or the name of the axis to be shifted to that part system.

---Setting range---

Two digits between A to Z and 1 to 9
(Setting will be cleared when "0" is set)

【#1544】 crsax[8]

Set the axis to be interchanged during cross machining control.
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed synchronization control (cross machining control) request signal is input, or the name of the axis to be shifted to that part system.

---Setting range---

Two digits between A to Z and 1 to 9
(Setting will be cleared when "0" is set)

【#1561】 3Dcdc Switch workpiece coordinate display during 3D coordinate conversion

Select the workpiece coordinate display during 3D coordinate conversion.

0: Workpiece coordinate system
1: G68 program coordinate system

(Note) The special display unit's absolute coordinates also follow this parameter setting.

【#1562】 3Dremc Switch remaining command display during 3D coordinate conversion

Select the remaining command display during 3D coordinate conversion.

0: Workpiece coordinate system
1: G68 program coordinate system

【#1563】 3Dcdrc Switch coordinate reading during 3D coordinate conversion

Select the coordinate system of the workpiece/skip coordinate read value in the 3D coordinate conversion modal.

0: G68 program coordinate system
1: Workpiece (local) coordinate system

【#1564】 3Dspd Hole drilling speed during 3D coordinate conversion

Select the rapid traverse rate for the hole drilling cycle during 3D coordinate conversion.

0: The cutting feed clamp speed is used.
Other than 0: The set speed is used.

Note that if the rapid traverse rate is exceeded, the speed will be clamped at the rapid traverse rate.

---Setting range---

0 to 1000000mm/min

【#1565】 helgear Helical machining base axis

Set the base axis for helix angle calculation in helical machining. When no setting, Z axis will be used.

---Setting range---

Axis name such as X, Y, Z, U, V, W, A, B, and C

【#1566】 3DselctDrillaxMode Switch drill axis's mode from rapid traverse during 3D coordinate conversion

Select the rapid traverse mode in non-drilling blocks among a drilling cycle to the cutting feed mode during 3-dimensional coordinate conversion.

0: Rapid traverse mode. The speed follows the setting of "#2001 rapid".
1: Cutting feed mode. The speed follows the setting of "#1564 3Dspd".

【#1568】 SfiltG1 G01 soft acceleration/deceleration filter

Set the filter time constant for smoothly changing the acceleration rate for the cutting feed acceleration/deceleration in pre-interpolation acceleration/deceleration.

---Setting range---

0 to 200 (ms)

【#1569】 SfiltG0 G00 soft acceleration/deceleration filter

Set the filter time constant for smoothly changing the acceleration rate for the rapid traverse acceleration/deceleration in pre-interpolation acceleration/deceleration.

---Setting range---

0 to 200 (ms)

II Parameters

2. Base Specifications Parameters

【#1570】 Sfilt2 Soft acceleration/deceleration filter 2

Set the filter time constant for smoothly changing the acceleration rate in pre-interpolation acceleration/deceleration.
This will be invalid when "0" or "1" is set.

---Setting range---
0 to 26 (ms)

【#1571】 SSSdis SSS control adjustment coefficient fixed value selection

Fix the shape recognition range for SSS control.

【#1572】 Cirorp Arc command overlap

This eliminates speed fluctuations at the joint of the arc and straight line and arc and arc. Set as a bit unit.

0: Do not overlap the arc command blocks
1: Overlap the arc command blocks

bit0 : Arc command during high-speed high-accuracy control II

bit1 : Arc command during high-speed machining mode II

bit2 : Arc command during high-accuracy control (G61.1)

bit3 : Arc command during cutting mode (G64)

The line command block and arc command block won't be overlapped during G61.2 modal regardless of this setting.

(Note) This parameter is invalid during SSS control.

【#1573】 Ret1 Return type 1

Select the axis to be moved later after tool return.
This is referred to with the movement path (transit point #1 -> interrupt point).
Up to eight axes can be specified by expressing one axis with one bit.

bit0 : Transit point #1 1st axis

bit1 : Transit point #1 2nd axis

bit2 : Transit point #1 3rd axis

bit3 : Transit point #1 4th axis

bit4 : Transit point #1 5th axis

bit5 : Transit point #1 6th axis

bit6 : Transit point #1 7th axis

bit7 : Transit point #1 8th axis

---Setting range---
00000000 to 11111111 (Binary)

【#1574】 Ret2 Return type 2

Select the axis to be moved later after tool return.
This is referred to with the movement path (return start point -> transit point #2).
Up to eight axes can be specified by expressing one axis with one bit.

bit0 : Transit point #2 1st axis

bit1 : Transit point #2 2nd axis

bit2 : Transit point #2 3rd axis

bit3 : Transit point #2 4th axis

bit4 : Transit point #2 5th axis

bit5 : Transit point #2 6th axis

bit6 : Transit point #2 7th axis

bit7 : Transit point #2 8th axis

---Setting range---
00000000 to 11111111 (Binary)

II Parameters

2. Base Specifications Parameters

【#1590】 Animate ax direct Machine status animated display axis ± direction

<bit0>

0: 1st axis + direction is set to the right direction.
1: 1st axis + direction is set to the left direction.

<bit1>

0: 2nd axis + direction is set to the rear direction.
1: 2nd axis + direction is set to the front direction.

<bit2>

0: 3rd axis + direction is set to the top direction.
1: 3rd axis + direction is set to the bottom direction.

【#1591】 Animate ax-1 Machine status animated display axis name (1st axis)

Set the name of the 1st axis displayed with the machine status animation. When the axis name is not specified, the current 1st axis name ("#1013 axname") will be used.

---Setting range---

Axis name such as X, Y, Z

【#1592】 Animate ax-2 Machine status animated display axis name (2nd axis)

Set the name of the 2nd axis displayed with the machine status animation. When the axis name is not specified, the current 2nd axis name ("#1013 axname") will be used.

---Setting range---

Axis name such as X, Y, Z

【#1593】 Animate ax-3 Machine status animated display axis name (3rd axis)

Set the name of the 3rd axis displayed with the machine status animation. When the axis name is not specified, the current 3rd axis name ("#1013 axname") will be used.

---Setting range---

Axis name such as X, Y, Z

【#1901(PR)】 station addr

Not used. Set to "0".

【#1902(PR)】 Din size

Not used. Set to "0".

【#1903(PR)】 Dout size

Not used. Set to "0".

【#1904(PR)】 data length

Not used. Set to "0".

【#1905(PR)】 baud rate

Not used. Set to "0".

【#1906(PR)】 stop bit

Not used. Set to "0".

【#1907(PR)】 parity check

Not used. Set to "0".

【#1908(PR)】 even parity

Not used. Set to "0".

【#1909(PR)】 Tout (ini)

Not used. Set to "0".

【#1910(PR)】 Tout (run)

Not used. Set to "0".

【#1911(PR)】 clock select

Not used. Set to "0".

【#1925】 EtherNet Start of service

Start or stop the Ethernet communication function.

0: Stop

1: Start

【#1926(PR)】 Global IP address IP address

Set the main CPU's IP address.

Set the NC IP address seen from an external source.

【#1927(PR)】 Global Subnet mask Subnet mask

Set the subnet mask for the IP address.

II Parameters

2. Base Specifications Parameters

【#1928(PR)】 Global Gateway Gateway

Set the IP address for the gateway.

【#1929】 Port number Port No.

Set the port No. for the service function.

---Setting range---

1 to 9999

(Set 2000 when not connected to the Ethernet.)

【#1930(PR)】 Host address Host address

Set the host's IP address.

【#1931(PR)】 Host number Host No.

Set the host's port No.

---Setting range---

1 to 9999

【#1934(PR)】 Local IP address

Set the HMI side CPU's IP address.

【#1935(PR)】 Local Subnet mask

Set the HMI side CPU's subnet mask.

【#11001(PR)】 APC type APC screen display type selection

Set the type of screen displayed with the pallet program registration screen.

0: Standard pallet registration screen

1: Pallet 4-page registration screen

【#11002(PR)】 Valid pallet num Number of pallets setting

Set the number of pallets validated on the pallet program registration screen.

---Setting range---

2 to 12 (Interpreted as 2 when 0 is set.)

【#11003(PR)】 APLC valid APLC valid

Temporarily disable APLC.

Normally set "1".

0: Disable

1: Enable

【#11004(PR)】 PLCauto-run enable PLC automatic startup valid

Select starting condition of the built-in PLC.

0: Start PLC after NC screen startup

1: Start PLC at NC startup

(Note) When standard NC screen is not used, set "1".

【#11005(PR)】 PC IP address IP address setting

Set the IP address for the display unit or PC in which machining programs are stored.

Set the IP address for the display unit on which the automatic power OFF will be executed.

(Note) When "0.0.0.0" is input, "192.168.100.2" is automatically set.

*This parameter is used only for 700 Series.

PC subnet

Set the subnet mask for the display unit or PC in which machining programs are stored.

PC Gateway

Set the gateway for the display unit or PC in which machining programs are stored.

【#11006】 PC Port number Port No. setting

Set the port No. for the display unit or PC in which machining programs are stored.

(Note 1) When "0" is input, "55555" is automatically set.

(Note 2) When changing the parameter, set the same value in "PD_Control_Port" in the PC side environment setting file.

---Setting range---

0 to 65535

【#11007】 PC Timeout Communication timeout time setting

Set the NC side communication timeout time.

(Note 1) When "0" is input, "30" is automatically set.

(Note 2) When the value greater than "300" is set, a setting error occurs.

(Note 3) When changing the parameter, set the same value in "PD_Time_out" in the PC side environment setting file.

---Setting range---

0 to 300 (s)

II Parameters

2. Base Specifications Parameters

【#11009(PR)】 M2 label O M2 label O

Select the program number label when using the M2 format.

- 0: Label L
- 1: Label O

【#11010(PR)】 Software keyboard Software keyboard

Select with touch panel whether to use software keyboard.

- 0: Do not use
- 1: Use
- 2: Use (Note1)

(Note1) Software keyboard automatically appears on a specific screen. (for M70 Series only).

【#11011】 Handy TERM. PW. Handy terminal password

Set the password used for the handy terminal customized downloading.

Blank (when "0" is set) and "0000" are regarded as no password.

Not the password of a new customizing file but the password of the customizing file downloaded to the last handy terminal is set.

Set blank or "0000" when initially downloading.

---Setting range---
0000 to 9999

【#11012(PR)】 16 axes for 1ch Connecting 16 axes for 1ch

Select the maximum number of axes (sum of the NC axis, spindle, and PLC axis) connected to the drive unit interface (channel 1) when not using the extension unit (FCU7-EX891+HN552)

- 0: Up to 8 axes can be connected to channel 1.
- 1: Up to 16 axes can be connected to channel 1. Note that "OMR-DD function" cannot be used. This parameter is disabled when the extension unit is connected. It is possible to connect only up to eight axes or less per channel.

【#11013】 3D_MChk Invalidate 3D machine interference check

Select whether to enable the 3D machine interference check function.

- 0: Enable
- 1: Disable

【#11014】 Chk_len1 1st-step interference check distance

Set the 1st-step check distance when in 3D machine interference check mode.

---Setting range---
0.000 to 99999.999(mm)

【#11015】 Chk_len2 2nd-step interference check distance

Set the 2nd-step check distance when in 3D machine interference check mode.

---Setting range---
0.000 to 99999.999(mm)

【#11016】 Expand_Rate Shape expansion rate

Set the model shape expansion rate to be used for 3D machine interference check. This parameter is used for expanding a model shape to be used for 3D machine interference check. The interference check is performed using a shape expanded by the amount of [Check length (mm) x Shape expansion rate (%)].

---Setting range---
0 to 300(%)

【#11017】 T-ofs set at run

Select whether to enable the tool compensation amount setting during automatic operation and operation pause.

- 0: Disable
- 1: Enable

【#11018】 M password hold

Select whether to enable the "Machine user" password holding. When this is set to "1", the "Machine user" password will be held.

- 0: Enable
- 1: Disable

【#11019】 2-system display 2-part system simultaneous display

Select whether to validate 2-part system simultaneous display on operation screen.

- 0: Display one part system on operation screen
- 1: Display two part systems simultaneously on operation screen

(Note 1) Unless you set "1" in two or more of "#1001 SYS_ON [1] to [4]", two-part system simultaneous display will fail regardless of this parameter.

【#11021】 PLC msg disp type Format of PLC alarm and operator message

Select the format of PLC alarms and operator messages to be displayed on the bottom right of the screen.

- 0: Display up to the first 40 characters.
- 1: If text is longer than 40 characters, divide it into two and display separately. (Classification No. is displayed together)

II Parameters

2. Base Specifications Parameters

【#11028】 Tolerance Arc Cent Tolerable correction value of arc center error

Set the tolerable correction value for the calculated coordinate value error of R-specified circular center.

When a difference between "a line between the start and end points" and "commanded radius x 2" is the tolerance or smaller, the error is corrected so that the middle of a line between the start and end points will be the arc center.

When [Setting value < 0] : 0 (Not correct)

When [Setting value = 0] : 2 x minimum setting increment

When [Setting value > 0] : Setting value

---Setting range---

-1 to 0.100(mm)

【#11029】 Arc to G1 no Cent Change command from arc to linear when no arc center designation

Select the operation when arc center or radius designation is omitted from arc command.

0: Program error

1: Change into linear command

【#12001】 ManualB RectanA xH Manual feed rate B constant surface control intersecting part system axis name (horizontal)

Set the part system axis name ("#1013 axname") for the two axes that intersect with the rotary axis direction. When one of the two axes is blank, a constant speed will be applied without using constant surface speed control.

---Setting range---

Axis addresses such as X, Y, Z, U, V, W, A, B, and C

【#12002】 ManualB RectanA xV Manual feed rate B constant surface control intersecting part system axis name (vertical)

Set the part system axis name ("#1013 axname") for the two axes that intersect with the rotary axis direction. When one of the two axes is blank, a constant speed will be applied without using constant surface speed control.

---Setting range---

Axis addresses such as X, Y, Z, U, V, W, A, B, and C

【#12003】 ManualB RotCent erH Manual feed rate B constant surface control rotation center machine position (horizontal)

Set the machine coordinate position (horizontal axis) at the center of the rotary axis.

---Setting range---

-99999.999 to 99999.999 (mm)

【#12004】 ManualB RotCent erV Manual feed rate B constant surface control rotation center machine position (vertical)

Set the machine coordinate position (vertical axis) at the center of the rotary axis.

---Setting range---

-99999.999 to 99999.999 (mm)

【#12005(PR)】 Mfig Number of M

Set the number of M that can be specified within the same block.

---Setting range---

1 to 4

【#12006(PR)】 Mbin M binary

Data type 0 BCD

Data type 1 Unsigned binary

Data type -1 Signed binary

<For unsigned binary>

The absolute value "1" is output for "-1".

<For signed binary>

"-1" is output as "0xFFFFFFFF".

---Setting range---

Data type

(-1,0,1)

【#12007(PR)】 Sfig Number of S

Set the number of spindles.

(Note 1) The setting range differs according to the model.

(Note 2) Sfig is set in the range of 1 to 4. However, the number of outputs by Sfig cannot be controlled. Thus, only one S command is output regardless of the Sfig setting value.

---Setting range---

1 to 6

II Parameters

2. Base Specifications Parameters

【#12008(PR)】 Sbin S binary

Data type 0 BCD
Data type 1 Unsigned binary
Data type -1 Singed binary

<For unsigned binary>

The absolute value "1" is output for "-1".

<For singed binary>

"-1" is output as "0xFFFFFFFF".

(Note 1) Sbin can be set with "-1", "0" and "1", but the S command cannot be BCD output.
If BCD (0) is selected for Sbin, it will be handled as a singed binary (-1).

---Setting range---

Data type
(-1,0,1)

【#12009(PR)】 Tfig Number of T

Set the number of T that can be specified within the same block.

---Setting range---

1 to 4

【#12010(PR)】 Tbin T binary

Data type 0 BCD
Data type 1 Unsigned binary
Data type -1 Singed binary

<For unsigned binary>

The absolute value "1" is output for "-1".

<For singed binary>

"-1" is output as "0xFFFFFFFF".

---Setting range---

Data type
(-1,0,1)

【#12011(PR)】 Bfig Number of B

Set the number of T that can be specified within the same block.

---Setting range---

1 to 4

【#12012(PR)】 Bbin B binary

Data type 0 BCD
Data type 1 Unsigned binary
Data type-1 Singed binary

<For unsigned binary>

The absolute value "1" is output for "-1".

<For singed binary>

"-1" is output as "0xFFFFFFFF".

---Setting range---

Data type
(-1,0,1)

3. Axis Specifications Parameters

【#2001】 rapid Rapid traverse rate

Set the rapid traverse feedrate for each axis.
(Note) The maximum value to be set depends on the machine specifications.

---Setting range---
1 to 1000000 (mm/min)

【#2002】 clamp Cutting feedrate for clamp function

Set the maximum cutting feedrate for each axis.
Even if the feedrate in G01 exceeds this value, the clamp will be applied at this feedrate.

---Setting range---
1 to 1000000 (mm/min)

【#2003(PR)】 smgst Acceleration and deceleration modes

Set acceleration and deceleration control modes.

bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0	
							OT3	OT2	OT1	C3		C1	L	R3		R1	LR

(Note) Set "0" in null bits (excluding bit2 and bit6 when the soft acceleration/deceleration is selected.)

<Combination of acceleration/deceleration patterns and bit patterns>

(1) Rapid traverse acceleration/deceleration type

- bit3,2,1,0 = 0000 : Step
- bit3,2,1,0 = 0001 : Linear acceleration/deceleration
- bit3,2,1,0 = 0010 : Primary delay
- bit3,2,1,0 = 1000 : Exponential acceleration and linear deceleration
- bit3,2,1,0 = 1111 : Soft acceleration/deceleration


(2) Cutting feed acceleration/deceleration type

- bit7,6,5,4 = 0000 : Step
- bit7,6,5,4 = 0001 : Linear acceleration/deceleration
- bit7,6,5,4 = 0010 : Primary delay
- bit7,6,5,4 = 1000 : Exponential acceleration and linear deceleration
- bit7,6,5,4 = 1111 : Soft acceleration/deceleration

(Note) R1 > R3 when both R1 and R3 contain 1.

<Stroke end stop types>

- bitA,9 = 00 : Linear deceleration
- bitA,9 = 01 : Position loop step stop
- bitA,9 = 10 : Speed loop step stop
- bitA,9 = 11 : Position loop step stop




(Note) OT1 is valid under the following conditions (valid for dog type zero point return):
- Stop type: Linear deceleration
- Acceleration/Deceleration mode: Exponential acceleration and Linear deceleration

---Setting range---
0/1

【#2004】 G0tL G0 time constant (linear)

Set a linear control time constant for rapid traverse acceleration and deceleration.
The time constant will be enabled when LR (rapid traverse feed with linear acceleration/deceleration) or F (soft acceleration/deceleration) is selected in "#2003 smgst Acceleration and deceleration modes".



---Setting range---
1 to 4000 (ms)


II Parameters

3. Axis Specifications Parameters


【#2005】 G0t1 G0 time constant(primary delay) / Second-step time constant for soft acceleration/deceleration

Set a primary-delay time constant for rapid traverse acceleration and deceleration. The time constant will be enabled when R1 (rapid traverse feed with primary delay) or R3 (exponential acceleration and linear deceleration) is selected in "#2003 smgst Acceleration and deceleration modes". When the soft acceleration/deceleration is selected, the second-step time constant will be used.


<Rapid traverse feed with primary delay>



<Rapid traverse feed with exponential acceleration and linear deceleration>



<Soft acceleration/deceleration>




---Setting range---
1 to 5000 (ms)

【#2006】 G0t2

Not used. Set to "0".

【#2007】 G1tL G1 time constant (linear)

Set a linear control time constant for cutting acceleration and deceleration. The time constant will be enabled when LC (cutting feed with linear acceleration/deceleration) or F (soft acceleration/deceleration) is selected in "#2003 smgst Acceleration or deceleration modes".



---Setting range---
1 to 4000 (ms)


II Parameters

3. Axis Specifications Parameters


#2008] G1t1 G1 time constant (primary delay)/Second-step time constant for soft acceleration/deceleration

Set the primary delay time constant for cutting acceleration and deceleration. The time constant will be enabled when C1 (cutting feed with the primary delay) or C3 (cutting feed with exponential acceleration and linear deceleration) is selected in "#2003 smgst acceleration/deceleration modes". When the soft acceleration or deceleration is selected, the second-step time constant will be used.


<Cutting feed with primary delay>



<Cutting feed with exponential acceleration and linear deceleration>



<Soft acceleration/deceleration>



---Setting range---
1 to 5000 (ms)

#2009] G1t2

Not used. Set to "0".

#2010] fwd_g Feed forward gain

Set a feed forward gain for pre-interpolation acceleration/deceleration. The larger the set value, the smaller the theoretical control error will be. However, if a machine vibration occurs, set the smaller value.

---Setting range---
0 to 200 (%)

#2011] G0back G0 backlash

Set up the backlash compensation amount when the direction is reversed with the movement command in rapid traverse feed mode or in manual mode.

---Setting range---
-9999999 to 9999999

#2012] G1back G1 backlash

Set up the backlash compensation amount when the direction is reversed with the movement command in cutting mode.


---Setting range---
-9999999 to 9999999

#2013] OT - Soft limit I -

Set a soft limit area with reference to the zero point of the basic machine coordinate. Set the coordinate in the negative direction for the movable area of stored stroke limit 1. The coordinate in the positive direction is set in "#2014 OT+".

To narrow the available range in actual use, use the parameters "#8204 OT-" and "#8205 OT+".

When the same value (other than "0") is set in this parameter and "#2014 OT+", this function will be disabled.



---Setting range---
±99999.999 (mm)

II Parameters


3. Axis Specifications Parameters

【#2014】 OT+ Soft limit I +

Set a soft limit area with reference to the zero point of the basic machine coordinate. Set the coordinate in the positive direction for the movable area of stored stroke limit 1. The coordinate in the negative direction is set in "#2013 OT-".

To narrow the available range in actual use, use the parameters "#8204 OT-" and "#8205 OT+".

When the same value (other than "0") is set in this parameter and "#2013 OT-", this function will be disabled.



---Setting range---
±99999.999 (mm)

【#2015】 t1m1- Negative direction sensor of tool setter

Set a sensor position in the negative direction when using the tool setter.

---Setting range---
±99999.999 (mm)

【#2016】 t1m1+ Positive direction sensor of tool setter or TLM standard length

Set the sensor position in the positive direction when using the tool setter.

When the TLM is used, set the distance from a tool change point (reference position) to the measurement basic point (surface) in order to measure the tool length.

---Setting range---
±99999.999 (mm)

【#2017】 tap_g Axis servo gain

Set the position loop gain for special operations (synchronized tapping, interpolation with spindle C axis, etc.).

Set the value in 0.25 increments.
The standard setting value is "10".

---Setting range---
0.25 to 200.00 (rad/s)

【#2018(PR)】 no_srv Operation with no servo control

Select when performing test operation without connecting the drive unit and motor.

- 0: Normal operation
- 1: Test operation

When "1" is set, the operation will be possible even if drive units and motor are not connected, because the drive system alarm will be ignored.

This parameter is used for test operation during start up: Do not use during normal operation. If "1" is set during normal operation, errors will not be detected even if they occur.

【#2019】 revnum Return steps

Set the steps required for reference position return for each axis.

- 0: Not execute reference position return.
- 1 to max. number of NC axes: Steps required for reference position return

【#2020】 o_chkp Spindle orientation completion check during second reference position return

Set the distance from the second reference position to the position for checking that the spindle orientation has completed during second reference position return.
When the set value is "0", the above check will be omitted.

---Setting range---
0 to 99999.999 (mm)

【#2021】 out_f Maximum speed outside soft limit range

Set the maximum speed outside the soft limit range.

---Setting range---
0 to 1000000 (mm/min)

【#2022】 G30SLX Validate soft limit (automatic and manual)

Select whether to disable a soft limit check during the second to the fourth reference position return in both automatic and manual operation modes.

- 0: Enable
- 1: Disable

【#2023】 ozfmin Set up ATC speed lower limit

Set the minimum speed outside the soft limit range during the second to the fourth reference position return.

---Setting range---
0 to 1000000 (mm/min)

II Parameters

3. Axis Specifications Parameters

【#2024】 synerr Allowable error

Set the maximum synchronization error, allowable at the synchronization error check, for the master axis.
When "0" is set, the error check will not be carried out.

---Setting range---
0 to 99999.999 (mm)

【#2025】 G28rap G28 rapid traverse rate

Set a rapid traverse rate for the dog type reference position return command.
This is not used for the distance-coded reference position detection.

---Setting range---
1 to 1000000 (mm/min)

【#2026】 G28crp G28 approach speed

Set the approach speed to the reference position.

(Note) The G28 approach speed unit is (10°/min) only when using the Z-phase type encoder (#1226 aux10/bit3=1) for the spindle/C-axis reference position return type.
The same unit is used for both the micrometric and sub-micrometric specifications.

---Setting range---
1 to 60000 (mm/min)

【#2027】 G28sft Reference position shift distance


Set the distance from the electrical zero-point detection position to the reference position.
This is not used for the distance-coded reference position detection.

(Note) When "#1240 set12/bit2" is ON, a magnification (C: 10-fold, D: 100-fold and E: 1000-fold) corresponding to the input setting unit ("#1003 iunit") will be applied to the setting value.

---Setting range---
0.000 to 99.999 (mm)

【#2028】 grmask Grip mask amount

Set the distance where the grid point will be ignored when near-point dog OFF signals are close to that grid point during reference position return.



The grid mask is valid for one grid.
This is not used for the distance-coded reference position detection.

---Setting range---
0.000 to 99.999 (mm)

【#2029】 grspc Grid interval

Set a detector grid interval.
Generally, set the value equal to the ball screw pitch. However, if the detector grid interval is not equal to the screw pitch when measured with a linear scale, set the detector grid interval.


To reduce the grid interval, use its divisors.
This is not used for the distance-coded reference position detection.

---Setting range---
0.000 to 999.999 (mm)

【#2030(PR)】 dir (-) Reference position direction (-)

Select which side of the near-point dog the reference position is established.
0: Positive direction
1: Negative direction

Directions in which reference position is established as viewed from the near-point dog



II Parameters

3. Axis Specifications Parameters

【#2031】 noref Axis without reference position

Select whether the reference position is provided for the axis.
0: Reference position is provided. (Normal controlled axis)
1: No reference position is provided.

When "1" is set, reference position return is not required before automatic operation starts.

【#2032】 nochk Whether reference position return is completed not checked

Select whether to check the reference position return completion.

0: Check the reference position return completion.
1: Not check the reference position return completion.

When "1" is set, the absolute and incremental commands can be executed even if dog type (or Z phase pulse system) reference position return is not completed.

Note that this setting is available for a rotary axis only.

【#2033】 zp_no Z phase pulse system reference position return spindle encoder No.

Set the spindle encoder No. to be used when the reference position return is performed with the Z phase pulse of the spindle encoder.

0: Dog type
1 to 6: Spindle No.

*The setting range differs according to the model.

---Setting range---

0 to 6

【#2034】 rfpofs Distance-coded reference position detection offset

Set the offset value from the position for the initial reference position setting to the machine's actual basic point in reference position return in the distance-coded reference position detection.

Input the value of the machine value counter that is displayed immediately after the reference position is established.

When the power is turned ON and this parameter is set to "0", the manual reference position return is regarded as initial reference position setting.

If this parameter is set to "0", automatic operation won't be available.

---Setting range---

-99999.999 to 99999.999 (mm)

【#2035】 srchmax Distance-coded reference position detection scan distance

Set the maximum distance for scanning the reference marks when the reference position is not established in the distance-coded reference position detection.

For the scan distance, set the distance that fully covers the number of reference marks as you wish to detect.

(Example) When adding about 10% of additional coverage:

Scan distance = Base reference mark interval [mm] * 2 * 1.1

---Setting range---


0.000 to 99999.999 (mm)

II Parameters

3. Axis Specifications Parameters

【#2036】 slv_adjust Reference position adjustment value

Set the distance from the first grid point after leaving the near point dog on the slave axis to the position where the reference position is actually established in dog-type reference position return in synchronous control. (Reference position shift amount is not included.) The adjustment value will be automatically set in the slave axis's parameter according to the reference position adjustment complete signal from PLC. Fine adjustment is also available from the parameter screen. In the distance-coded reference position detection, the reference position adjustment value will be invalid.



(Note 1) This parameter is enabled when the synchronization at zero point initialization ("#1493 ref_syn" = "1" of the master axis) is applied.

(Note 2) This parameter can be set when one of the following settings is applied.

- Relative position detection ("#2049 type" = "0")
- Dog-type absolute position detection ("#2049 type" = "3")
- Simple absolute position ("#2049 type" = "9")

(Note 3) Set "0" when using the speed/current command synchronization control.

(Note 4) A setting unit of this parameter is [mm]. It is not influenced by the content of the following parameters setting.

- "#1003 iunit"
- "#1004 ctrl_unit"
- "#1005 plcunit"
- "#1040 M_inch"
- "#1041 l_inch"
- "#1240 set12/bit2" (Zero point shift amount magnification)


(Note 5) The number of the significant digits after decimal point follows "#1004 ctrl_unit"

(Note 6) A change of this parameter requires reference position return. When the automatic operation starts without reference position return, an alarm will occur.

---Setting range---
0 to 99999.999999 (mm)

【#2037】 G53ofs Reference position #1

Set the position of the first reference position from the zero point of the basic machine coordinate.




---Setting range---
±999999.999 (mm)

II Parameters

3. Axis Specifications Parameters

【#2038】 #2_rfp Reference position #2


Set the position of the second reference position from the zero point of the basic machine coordinate.



---Setting range---
±999999.999 (mm)

【#2039】 #3_rfp Reference position #3


Set the position of the third reference position from the zero point of the basic machine coordinate.



---Setting range---
±999999.999 (mm)

【#2040】 #4_rfp Reference position #4

Set the position of the fourth reference position from the zero point of the basic machine coordinate.



---Setting range---
±999999.999 (mm)

【#2049(PR)】 type Absolute position detection method

Select the absolute position zero point alignment method.

- 0: Not absolute position detection
- 1: Stopper method (push against mechanical stopper)
- 2: Marked point alignment method (align to alignment point)
- 3: Dog-type (align with dog and near point detection switch)
- 4: Marked point alignment method II (Align to alignment mark. Grid return won't be performed after marked point alignment)
- 9: Simple absolute position (Not absolute position detection, but the position when the power is turned off is registered.)

【#2050】 absdir Basic point of Z direction

Select the direction of the grid point immediately before the machine basic position (basic point of detector) in the marked point alignment.

- 0: Positive direction
- 1: Negative direction

【#2051】 check Check

Set the tolerable range of travel distance (deviation distance) while the power is turned OFF.

If the difference of the positions when the power is turned OFF and when turned ON again is larger than this value, an alarm will be output.

Set "0" to omit the check.

---Setting range---
0 to 99999.999 (mm)

II Parameters

3. Axis Specifications Parameters

【#2054】 clpush Current limit (%)

Set the current limit value during the stopper operation in the dogless-type absolute position detection.
The setting value is the ratio of the current limit value to the rated current value.

---Setting range---
0 to 100 (%)

【#2055】 pushf Push speed

Set the feedrate for the automatic initial setting during stopper method.

---Setting range---
1 to 999 (mm/min)

【#2056】 aproch Approach

Set the approach distance of the stopper when deciding the absolute position basic point with the stopper method.
After using stopper once, the tool returns with this distance, and then use stopper again.

---Setting range---
0 to 999.999 (mm)

【#2057】 nrefp Near zero point +

Set the positive direction width where the near reference position signal is output.
When set to "0", the width will be equivalent to the grid width setting.
(Note) When "#1240 set12/bit2" is ON, a magnification (C: 10-fold, D: 100-fold, E:1000-fold) corresponding to the input setting increment ("#1003 iunit") will be applied to the setting value.

---Setting range---
0 to 999.999 (mm)
(Input setting increment applied)

【#2058】 nrefn Near zero point -

Set the negative direction width where the near reference position signal is output.
When set to "0", the width will be equivalent to the grid width setting.
(Note) When "#1240 set12/bit2" is ON, a magnification (C: 10-fold, D: 100-fold, E:1000-fold) corresponding to the input setting increment ("#1003 iunit") will be applied to the setting value.

---Setting range---
0 to 999.999 (mm)
(Input setting increment applied)

【#2059】 zerbas Select zero point parameter and basic point

Select which is to be the zero point coordinate position during absolute position initial setting.

- 0: Position where the axis was stopped.
- 1: Grid point just before stopper.

【#2061】 OT_1B- Soft limit IB-

Set the coordinate of the lower limit of the area where the stored stroke limit IB is inhibited.
Set a value from zero point in the basic machine coordinate system.
If the same value (non-zero) with the same sign as that of "#2062 OT_1B+" is set, the stored stroke limit IB function will be disabled.

---Setting range---
±99999.999 (mm)

【#2062】 OT_1B+ Soft limit IB+

Set the coordinate of the upper limit of the area where the stored stroke limit IB is inhibited.
Set a value from zero point in the basic machine coordinate system.

---Setting range---
±99999.999 (mm)

【#2063】 OT_1B type Soft limit IB type

Select the type that applies the settings of "#2062 OT_1B+" and "#2061 OT_1B-" in stored stroke limit I.

- 0: Soft limit IB
- 1: The settings are invalid
- 2: Soft limit IC
- 3: Soft limit is checked for the inclined axis control axis with the program coordinate system.

(Note) This is valid only for inclined axis' base axis and inclined axis.

【#2068】 G0fwdg G00 feed forward gain

Set a feed forward gain for G00 pre-interpolation acceleration/deceleration.
The larger the setting value, the shorter the positioning time during in-position checking.
If a machine vibration occurs, set the smaller value.

---Setting range---
0 to 200 (%)

【#2069】 Rcoeff Axis arc radius error correction coefficient

Set the percentage to increase or decrease the arc radius error correction amount for each axis.

---Setting range---
-100.0 to +100.0 (%)

II Parameters

3. Axis Specifications Parameters

【#2070(PR)】 div_RT Rotational axis division count

Set the number of divisions of one turn of the rotary axis under control.

(Example)

When "36" is set, one turn is supposed to be 36.000.

(Note 1) When "0" is set, the normal rotary axis (360.000 degrees for one turn) is assumed.

(Note 2) If this parameter is changed when the absolute position detection specification is used, absolute position data will be lost. Initialization must be performed again.

---Setting range---

0 to 999

【#2071】 s_axis Inclined axis selection (for L system only)

Select whether the axis is to be under the inclined-axis control or to be the base axis corresponding to the inclined axis.

0: Not to be under the inclined-axis control

1: Inclined axis

2: Base axis corresponding to inclined axis

(Note) Each of "1" and "2" values must be set for only one axis. If either value is set for two or more axes, inclined-axis control does not work.

【#2072】 rslimt Restart limit

Set the most minus (-) side position where restart search is possible.

If the machine is positioned on the more minus (-) side than the set value in T-command restart mode, restart search in type 3 will be disabled.

---Setting range---

±9999.999 (mm)

【#2073】 zrn_dog Origin dog Random assignment device

Under the standard specifications, the origin dog signal is assigned to a fixed device. Set the input device in this parameter when it is desired to assign the origin dog signal to a position other than the fixed device.

(Note 1) This parameter is valid when "1" is set in "#1226 aux10/bit5".

(Note 2) When this parameter is valid, do not set the existing device number. If the existing device number is set, an emergency stop will occur. However, no device number check will be performed for an axis to which the "near-point dog ignored" signal is input.

---Setting range---

0000 to 02FF (HEX)

【#2074】 H/W_OT+ H/W OT+ Random assignment device

Under the standard specifications, the OT (+) signal is assigned to a fixed device. Set the input device in this parameter when it is desired to assign the OT (+) g signal to a position other than the fixed device.

(Note 1) This parameter is valid when "1" is set in "#1226 aux10/bit5".

(Note 2) When this parameter is valid, do not set the existing device number. If the existing device number is set, an emergency stop will occur. However, no device number check will be performed for an axis to which the "OT ignored" signal is input.

---Setting range---

0000 to 02FF (HEX)

【#2075】 H/W_OT- H/W OT- Random assignment device

Under the standard specifications, the OT (-) signal is assigned to a fixed device. Set the input device in this parameter when it is desired to assign the OT (-) signal to a position other than the fixed device.

(Note 1) This parameter is valid when "1" is set in "#1226 aux10/bit5".

(Note 2) When this parameter is valid, do not set the existing device number. If the existing device number is set, an emergency stop will occur. However, no device number check will be performed for an axis to which the "OT ignored" signal is input.

---Setting range---

0000 to 02FF (HEX)

【#2076】 index_x Index table indexing axis

Select whether the axis is a normal axis or an index table indexing axis.

0: Normal axis

1: Index table indexing axis

(Note) This parameter is valid only for the NC axis. The parameter is invalid if set for the PLC axis.

【#2077】 G0inps G0 in-position width

Set the in-position width for G0.

Between SV024 and this parameter, the parameter with a larger value will be applied.

When "0" is set, this parameter will be invalid: only SV024 will be available.

---Setting range---

0.000 to 99.999 (mm)

【#2078】 G1inps G1 in-position width

Set the in-position width for G1.

Between SV024 and this parameter, the parameter with a larger value will be applied.

When "0" is set, this parameter will be invalid: only SV024 will be available.

---Setting range---

0.000 to 99.999 (mm)

II Parameters

3. Axis Specifications Parameters

【#2079(PR)】 chcomp Chopping compensation coefficient

Set the coefficient to be applied to the compensation amount for the insufficient amount caused by servo delay during chopping.

---Setting range---
0 to 10 (standard value: 8)

【#2080】 chwid Bottom dead center position width

Set the tolerance between the commanded stroke and actual stroke.
Compensation will be applied during chopping so that the result of [command width - maximum stroke of top or bottom dead point/ 2] will be within this tolerance.

---Setting range---
0 to 10.000 (mm)

【#2081】 chclsp Maximum chopping speed

Set the clamp speed in chopping operation.
When "0" is set, the clamp speed will be determined by "#2002 clamp".

---Setting range---
0 to 60000 (mm/min)

【#2082】 a_rstax Restart position return order

Set the No. for each axis in order from the 1st automatically returning axis to the restart position.

When "0" is set, the axis will not return.
Note that when "0" is set for all axes, all of the axes will return simultaneously.

---Setting range---
0 to 8

【#2084】 G60_ax Unidirectional positioning operation selection

Select how to operate the unidirectional positioning when the positioning command (G00) is issued.

0: Carry out unidirectional positioning according to the command and modal.

1: Carry out unidirectional positioning regardless of the command and modal.

Set "1" for the axis to carry out the unidirectional positioning at every positioning command, regardless of whether the unidirectional positioning command and modal are issued.

<Related parameters>
"#8209 G60 SHIFT" and "#2076 index_x"

【#2087】 syncnt Synchronization/super-imposition control setting for each axis

Set the polarity of synchronous axis with respect to basic axis to the bit corresponding to each axis.

0: Polarity with respect to basic axis is positive

1: Polarity with respect to basic axis is negative

---Setting range---
0 to FF (hexadecimal)

【#2088】 bsax_sy Reference axis for synchronous control

Set the basic axis for synchronous control with the 2nd axis name (axname2). A numerical character cannot be set as the 1st character.

---Setting range---
Axis name

【#2089】 bsax_pl Reference axis for superimposition control

Set the basic axis for superimposition control with the 2nd axis name (axname2). A numerical character cannot be set as the 1st character.

---Setting range---
Axis name

【#2090】 plrapid Rapid traverse rate for super-imposition control

Set the rapid traverse rate for superimposition control.
(Equivalent to "#2001 rapid Rapid traverse rate".)

---Setting range---
1 to 1000000 (mm/min)

【#2091】 plclamp Cutting feed clamp speed for super-imposition control

Set the cutting feed clamp speed for superimposition control.
(Equivalent to "#2002 clamp Cutting feed clamp speed".)

---Setting range---
1 to 1000000 (mm/min)

【#2092】 pIG0tL G0 time constant for superimposition control (linear)

Set the G0 time constant (linear) for superimposition control.
(Equivalent to "#2004 G0tL G0 time constant (linear)".)

---Setting range---
1 to 4000 (ms)

【#2093】 pIG0t1 G0 time constant for superimposition control (primary delay)

Set the G0 time constant (primary delay) for superimposition control.
(Equivalent to "#2005 G0t1 G0 time constant (primary delay)".)

---Setting range---
1 to 5000 (ms)

II Parameters

3. Axis Specifications Parameters

【#2094】 plG1tL G1 time constant for superimposition control (linear)

Set the G1 time constant (linear) for superimposition control.
(Equivalent to "#2007 G1tL G1 time constant (linear)".)

---Setting range---
1 to 4000 (ms)

【#2095】 plG1t1 G1 time constant for superimposition control (primary delay)

Set the G1 time constant (primary delay) for superimposition control.
(Equivalent to "#2008 G1t1 G1 time constant (primary delay)".)

---Setting range---
1 to 5000 (ms)

【#2096】 crncsp Minimum corner deceleration speed

Set the minimum clamp speed for corner deceleration in the high-accuracy control mode.
Normally set "0".

(Note) This parameter is invalid during SSS control.
---Setting range---
0 to 1000000 (mm/min)

【#2097】 tlm12- Sub side tool setter - direction sensor

Set the sensor position (on sub side) in the (-) direction when using the tool setter on the sub spindle side.

---Setting range---
±99999.999 (mm)

【#2098】 tlm12+ Sub side tool setter + direction sensor

Set the sensor position (on sub side) in (+) direction when using the tool setter on the sub spindle side.

---Setting range---
±99999.999 (mm)

【#2102】 skip_tL Skip time constant linear

Set a linear control time constant for variable speed skip acceleration and deceleration.
The time constant will be enabled when LC (cutting feed with linear acceleration and deceleration) or "F" (soft acceleration/deceleration) is selected in "#2003 smgst Acceleration and deceleration modes".

---Setting range---
1 to 4000 (ms)

【#2103】 skip_t1 Skip time constant primary delay / Second-step time constant for soft acceleration/deceleration

Set a primary-delay time constant for variable speed skip acceleration and deceleration.
The time constant will be enabled when C1 (cutting feed with primary delay) or C3 (exponential acceleration and linear deceleration) is selected in "#2003 smgst Acceleration and deceleration modes". When the soft acceleration/deceleration is selected, the second-step time constant will be used.

---Setting range---
1 to 5000 (ms)

【#2106】 Index unit Indexing unit

Set the indexing unit to which the rotary axis can be positioned.

---Setting range---
0 to 360 (°)

【#2109】 Rapid (H-precision) Rapid traverse rate for high-accuracy control mode

Set the rapid traverse rate for each axis in the high-accuracy control mode. "#2001 rapid" will be used when "0" is set.

---Setting range---
0 to 1000000 (mm/min)

【#2110】 Clamp (H-precision) Cutting feed clamp speed for high-accuracy control mode

Set the cutting feed maximum speed for each axis in the high-accuracy control mode.
"#2002 clamp" will be used when "0" is set.

---Setting range---
0 to 1000000 (mm/min)

【#2111】 Blf valid Quadrant protrusion compensation valid

Set whether to enable the quadrant protrusion compensation.
0: Disable
1: Enable

If either of "#2112 Blf motor inertia", "#2115 Blf motor stl trq" or "#2113 Blf visc friction" is set to "0", quadrant protrusion compensation will not work even if this parameter is set to "1".

【#2112】 Blf motor inertia Motor inertia

Set the motor inertia for quadrant protrusion compensation.
Refer to the servo manual and input the value appropriate for the motor.

---Setting range---
1 to 32000 (10⁻⁶kgm²)

II Parameters

3. Axis Specifications Parameters

【#2113】 Blf visc friction Viscous friction

Set the viscous friction for quadrant protrusion compensation.
After setting the other parameters to the appropriate values, monitor the machine end and gradually adjust the value.
If this parameter setting is small, a recess will form on the inner side of the circle, and if large, a protrusion will form on the outer side of the circle. When the value is appropriate, a spike-shaped quadrant protrusion will form based on normal step-shaped backlash.

---Setting range---
1 to 32767 (1/16 Nm/(rad/s))

【#2114】 Blf fwdg Compensation FF gain

Set the feed forward gain for quadrant protrusion compensation.
After setting the other parameters to the appropriate values, monitor the machine end and gradually adjust the value.
If this parameter setting is small, a large quadrant protrusion will form, and if large, a recess will form on the inner side of the circle.

---Setting range---
0 to 1000 (%)

【#2115】 Blf motor stl trq Motor stall torque

Set the motor rated current for quadrant protrusion compensation.
Refer to the servo manual and input the value appropriate for the motor.

---Setting range---
1 to 16000 (1/256 Nm)

【#2118(PR)】 SscDrSel Speed monitor Door selection

Select which door group of the speed monitoring the spindle belongs to.

- 0000: Door 1 group.
- 0001: Door 1 group.
- 0002: Door 2 group.
- 0003: Door 1 and 2 group.

The speed monitoring will not be executed when "#2313 SV113 SSF8/BitF" is OFF regardless of this parameter.

The selected door group must be set when setting the synchronous control.
The spindle/C axis control enables the door selection in "#3071 SscDrSelSp" for the corresponding spindle.

【#2121】 vbacklash valid Variable backlash valid/continuous

Select whether the variable backlash is to be invalid/valid/continuous.

- 0: Invalid
- 1: Valid
- 2: Continuous

("#2011 G0back" and "#2012 G1back" will not work when valid or continuous status is selected.)

【#2122】 G0vback+ Variable G0 backlash +

Set the compensation amount for the range of each position during rapid traverse.
(+: B1, =: B2, -: B3 on the compensation amount table)

---Setting range---
-99999999 to 99999999 (Interpolation unit)

【#2123】 G0vback= Variable G0 backlash =

Set the compensation amount for the range of each position during rapid traverse.
(+: B1, =: B2, -: B3 on the compensation amount table)

---Setting range---
-99999999 to 99999999 (Interpolation unit)

【#2124】 G0vback- Variable G0 backlash -

Set the compensation amount for the range of each position during rapid traverse.
(+: B1, =: B2, -: B3 on the compensation amount table)

---Setting range---
-99999999 to 99999999 (Interpolation unit)

【#2125】 G1vback+ Variable G1 backlash +

Set the compensation amount for the range of each position during cutting feed.
(+: A1, =: A2, -: A3 on the compensation amount table)

---Setting range---
-99999999 to 99999999(Interpolation unit)

【#2126】 G1vback= Variable G1 backlash =

Set the compensation amount for the range of each position during cutting feed.
(+: A1, =: A2, -: A3 on the compensation amount table)

---Setting range---
-99999999 to 99999999 (Interpolation unit)

【#2127】 G1vback- Variable G1 backlash -

Set the compensation amount for the range of each position during cutting feed.
(+: A1, =: A2, -: A3 on the compensation amount table)

---Setting range---
-99999999 to 99999999 (Interpolation unit)

II Parameters

3. Axis Specifications Parameters

【#2128】 G1vback feed1 G1 variable backlash compensation amount changeover speed 1

Set the speed range during cutting feed.
(The speed less than 1 is the low speed, and the speed exceeding 2 is the high speed.)
Note that the speed range is identified in the order of low, high and medium speed.
Consider whether the set value should be larger or smaller than other values.

---Setting range---
0 to 480000 (mm/min)

【#2129】 G1vback feed2 G1 variable backlash compensation amount changeover speed 2

Set the range of the speed during cutting feed.
(The speed less than 1 is the low speed, and the speed exceeding 2 is the high speed.)
Note that the speed range is identified in the order of low, high and medium speed.
Consider whether the set value should be larger or smaller than other values.

---Setting range---
0 to 480000 (mm/min)

【#2130】 G1vback dist1 G1 variable backlash compensation amount changeover distance 1

Set the range of the distance during cutting feed.
(The distance less than 1 is the small distance, and the distance exceeding 2 is the large distance.)
Note that the distance range is identified in the order of small, large and medium. Consider whether the set value should be larger or smaller than other values.

---Setting range---
0 to 999999.999999 (mm)

【#2131】 G1vback dist2 G1 variable backlash compensation amount changeover distance 2

Set the range of the distance during cutting feed.
(The distance less than 1 is the small distance, and the distance exceeding 2 is the large distance.)
Note that the distance range is identified in the order of small, large and medium. Consider whether the set value should be larger or smaller than other values.

---Setting range---
0 to 999999.999999 (mm)

【#2132】 vback pos1 Variable backlash compensation amount changeover end point position 1

Set the range of the center of the end point position.
(The range less than position 1 is the - range, and the range exceeding position 2 is the + range.)

The end point position range is determined in the order of -, +, and center. Consider whether the set value should be larger or smaller than other values.

(Note 1) If continuous variable backlash is set with "#2121 vbacklash valid", position 1 will be set as the position - point and position 2 will be set as the position + point.

(Note 2) When the size relation of the compensation amount changeover speed and distance 1 and 2 is not appropriate while the variable backlash compensation is valid, the followings will be applied: If the backlash speed and distance are smaller than the compensation amount changeover speed and distance 1, both the speed and distance will be small; if larger than the compensation amount changeover speed and distance 2, both the speed and distance will be large.

---Setting range---
-999999.999999 to 999999.999999 (mm)

【#2133】 vback pos2 Variable backlash compensation amount changeover end point position 2

Set the range of the center of the end point position.
(The range less than position 1 is the - range, and the range exceeding position 2 is the + range.)

The end point position range is determined in the order of -, +, and center. Consider whether the set value should be larger or smaller than other values.

(Note 1) If continuous variable backlash is set with "#2121 vbacklash valid", position 1 will be set as the position - point and position 2 will be set as the position + point.

(Note 2) When the size relation of the compensation amount changeover speed and distance 1 and 2 is not appropriate while the variable backlash compensation is valid, the followings will be applied: If the backlash speed and distance are smaller than the compensation amount changeover speed and distance 1, both the speed and distance will be small; if larger than the compensation amount changeover speed and distance 2, both the speed and distance will be large.

---Setting range---
-999999.999999 to 999999.999999 (mm)

【#2134】 vback arc K Variable backlash arc compensation coefficient

Set the arc compensation coefficient.

---Setting range---
0 to 300 (%)

【#2135】 vback feed refpt Variable backlash reference position selection (speed)

Select the speed range to be used as the reference position.

0: Low speed
1: Medium speed
2: High speed

II Parameters

3. Axis Specifications Parameters

【#2136】 vback pos refpt Variable backlash reference position selection (end point position)

Select the end point range to be used as the reference position.

- 0: Position + range
- 1: Position center range
- 2: Position - range

【#2137】 vback dir refpt Variable backlash reference position selection (entry direction)

Select the entry direction to be used as the reference position.

- 0: Entry direction +
- 1: Entry direction -

【#2138】 vback pos center Continuous variable backlash position center point

Set the position center point. (This is used only when continuous variable backlash is set with "#2121 vbacklash valid".) Set a value between "#2132 vback pos1" and "#2133 vbackpos2" for the position center point.

(Note) When the size relation of the compensation amount changeover speed and distance 1 and 2 is not appropriate while the variable backlash compensation is valid, the followings will be applied:

If the backlash speed and distance are smaller than the compensation amount changeover speed and distance 1, both the speed and distance will be small; if larger than the compensation amount changeover speed and distance 2, both the speed and distance will be large.

---Setting range---

-999999.999999 to 999999.999999 (mm)

【#2139】 omrff_off OMR-FF invalid

Select whether to enable or temporarily disable the OMR-FF control when OMR-FF is valid.

- 0: Enable
- 1: Temporarily disable

When "1" is selected while OMR-FF is valid, OMR-FF can be temporarily disabled and conventional feed forward control can be applied instead.

【#2140(PR)】 Ssc Svof Filter Speed monitor Error detection time during servo OFF

Set the error detection time of command speed monitoring and feedback speed monitoring during servo OFF.

An alarm will occur if the time, for which the speed has been exceeding the safe speed or safe rotation speed, exceeds the error detection time set in this parameter.

If "0" is set, it will be handled as 200 (ms).

---Setting range---


0 to 9999 (ms)

【#2141】 chtL Chopping first-step time constant for soft acceleration and deceleration

Set the first-step time constant for the chopping axis when soft acceleration/deceleration is applied.

Note that, however, there may be cases where actual time constant is shorter than the set time constant, because the time constant is automatically calculated according to the feedrate so that the acceleration rate during acceleration/deceleration (clamp speed/ chopping time constant) will be constant.

When "0" is set, "#2007 G11L" will be valid.



---Setting range---

0 to 4000 (ms)

【#2142】 cht1 Chopping second-step time constant for soft acceleration and deceleration

Set the second-step time constant for the chopping axis when soft acceleration/deceleration is applied.

Note that, however, there may be cases where actual time constant is shorter than the set time constant, because the time constant is automatically calculated so that the ratio between first-step and second-step time constant will be constant.

When "0" is set, "#2008 G111" will be valid.

---Setting range---


0 to 4000 (ms)

II Parameters

3. Axis Specifications Parameters

【#2146】 Blf_L1 Reference distance for position-dependent increasing-type backlash compensation 1

Set the distance for specifying the compensation change rate in position-dependent increasing-type backlash compensation.




When "#2146 Blf_E1" is set to "0", the position-dependent increasing-type backlash compensation function will be disabled.

---Setting range---

0 to 99999.999 (mm)

【#2147】 Blf_L2 Reference distance for position-dependent increasing-type backlash compensation 2

Set the distance for specifying the compensation change rate in position-dependent increasing-type backlash compensation.




When "#2146 Blf_E1" is set to "0", the position-dependent increasing-type backlash compensation function will be disabled.

---Setting range---

0 to 99999.999 (mm)

【#2148】 Blf_E1 Reference amount of position-dependent increasing-type backlash compensation 1

Set the compensation amount for specifying the compensation change rate in position-dependent increasing-type backlash compensation.




When "#2146 Blf_E1" is set to "0", the position-dependent increasing-type backlash compensation function will be disabled.

---Setting range---

0 to 9999999 (Machine error compensation unit)

【#2149】 Blf_E2 Reference amount of position-dependent increasing-type backlash compensation 2

Set the compensation amount for specifying the compensation change rate in position-dependent increasing-type backlash compensation.



When "#2146 Blf_E1" is set to "0", the position-dependent increasing-type backlash compensation function will be disabled.

---Setting range---

0 to 9999999 (Machine error compensation unit)

【#2150】 Rot_len Farthest distance from rotary axis center

Set the farthest distance of the rotating part from the rotation center. When "0" is set, this distance will conform to the rotary axis' specification speed.

---Setting range---

0.000 to 99999.999(mm)

II Parameters


3. Axis Specifications Parameters

【#2151】 rated_spd Rated speed

Set the maximum speed which can be driven with the motor's maximum torque.

(Note 1) This parameter's setting value must be smaller than "#2001 rapid Rapid traverse". If bigger, constant inclination acceleration/deceleration will be applied.

(Note 2) If rapid traverse constant inclination multi-step acceleration/deceleration is valid, and also if this parameter is set to "0", constant inclination acceleration/deceleration will be applied.




---Setting range---
0 to 1000000(mm/min)

【#2152】 acc_rate Acceleration rate in proportion to the maximum acceleration rate

Set the rate in proportion to the maximum acceleration rate in rapid traverse.

(Note) If this parameter is set to "0" or "100", constant inclination acceleration/deceleration will be applied.



---Setting range---
0 to 100(%)

【#2153】 G0t_rated G0 time constant up to rated speed (multi-step acceleration/

deceleration)

Set the acceleration rate up to the rated speed of rapid traverse constant inclination multi-step acceleration/deceleration.

(Note) If this parameter is set to "0", constant inclination acceleration/deceleration will be applied.

---Setting range---
0 to 4000(ms)

(G0t_rapid) G0 time constant up to rapid traverse speed (multi-step acceleration/

deceleration)

Set the acceleration time until the rapid traverse speed of rapid traverse constant inclination multi-step acceleration/deceleration is applied.

(Note) Set the acceleration time when a pertinent axis is operated independently.

【#2155】 hob_fwd_g Feed forward gain for hobbing machining

Set the feed forward gain when controlling as workpiece axis of tool spindle synchronization II (hobbing).

---Setting range---
0 to 200 (%)

4. Servo Parameters

【#2201(PR)】 SV001 PC1 Motor side gear ratio

Set the gear ratio in the motor side when there is the gear between the servomotor's shaft and machine (ball screw, etc.).

For the rotary axis, set the total deceleration (acceleration) ratio.

Even if the gear ratio is within the setting range, the electronic gears may overflow and an initial parameter error (servo alarm 37) may occur.

---Setting range---
1 to 32767

【#2202(PR)】 SV002 PC2 Machine side gear ratio

Set the gear ratio in the motor side when there is the gear between the servomotor's shaft and machine (ball screw, etc.).

For the rotary axis, set the total deceleration (acceleration) ratio.

Even if the gear ratio is within the setting range, the electronic gears may overflow and an initial parameter error (servo alarm 37) may occur.

---Setting range---
1 to 32767

【#2203】 SV003 PGN1 Position loop gain 1

Set the position loop gain. The standard setting is "33".

The higher the setting value is, the more accurately the command can be followed, and the shorter the settling time in positioning gets, however, note that a bigger shock will be applied to the machine during acceleration/deceleration.

When using the SHG control, also set SV004 (PGN2) and SV057 (SHGC).

---Setting range---
1 to 200 (rad/s)

【#2204】 SV004 PGN2 Position loop gain 2

When using the SHG control, set this parameter with SV003 (PGN1) and SV057 (SHGC). When not using the SHG control, set to "0".

---Setting range---
0 to 999 (rad/s)

【#2205】 SV005 VGN1 Speed loop gain 1

Set the speed loop gain.

The higher the setting value is, the more accurate the control will be; however, vibration tends to occur.

When vibration occurs, adjust by lowering by 20 - 30%.

The value should be determined to be 70 - 80% of the value at which the vibration stops.


---Setting range---
1 to 9999

【#2206】 SV006 VGN2 Speed loop gain 2

Set the speed loop gain at the motor limitation speed with "SV029 (VCS) Speed at the change of speed loop gain".

Use this to suppress noise at high speed during rapid traverse, etc. Then, the speed loop gain decreases at faster speed than the setting value of "SV029 (VCS) Speed at the change of speed loop gain".

When not using, set to "0".



---Setting range---
-1000 to 9999

【#2207】 SV007 VIL Speed loop delay compensation

Set this parameter when the limit cycle occurs in the full-closed loop, or overshooting occurs in positioning.

Select the method of the speed loop delay compensation with the parameter "#2207 SV027(SSF1)/Bit1,0(vcnt)".

When setting this parameter, make sure to set the torque offset "SV032 (TOF)".

---Setting range---
0 to 32767

【#2208】 SV008 VIA Speed loop lead compensation

Set the gain of the speed loop integral control.

Standard setting: 1364

Standard setting in the SHG control: 1900

Adjust the value by increasing/decreasing this by about 100 at a time.

Raise this value to improve contour tracking accuracy in high-speed cutting.

Lower this value when the position droop does not stabilize (10 - 20Hz).

---Setting range---
1 to 9999

II Parameters

4. Servo Parameters

【#2209】 SV009 IQA Current loop q axis lead compensation

Set the fixed value of each motor.
Set the standard value for each motor described in the standard parameter list.
---Setting range---
1 to 20480

【#2210】 SV010 IDA Current loop d axis lead compensation

Set the fixed value of each motor.
Set the standard value for each motor described in the standard parameter list.
---Setting range---
1 to 20480

【#2211】 SV011 IQG Current loop q axis gain

Set the fixed value of each motor.
Set the standard value for each motor described in the standard parameter list.
---Setting range---
1 to 8192

【#2212】 SV012 IDG Current loop d axis gain

Set the fixed value of each motor.
Set the standard value for each motor described in the standard parameter list.
---Setting range---
1 to 8192

【#2213】 SV013 ILMT Current limit value

Set the current (torque) limit value in a normal operation.
This is a limit value in both forward run and reverse run directions.
When the standard setting value "800" is set, the maximum torque will be determined by the specification of the motor.
Set this parameter as a proportion (%) to the stall torque.
---Setting range---
0 to 999

【#2214】 SV014 ILMTsp Current limit value in special control

Set the current (torque) limit value in a special operation (absolute position initial setting, stopper control, etc).
This is a limit value in both forward run and reverse run directions.
Set to "800" when not using.
Set this parameter as a proportion (%) to the stall torque.
---Setting range---
0 to 999

【#2215】 SV015 FFC Acceleration rate feed forward gain

When a relative error in the synchronous control is large, set this parameter to the axis that is delaying. The standard setting value is "0".
The standard setting in the SHG control is "100".
To adjust a relative error in acceleration/deceleration, increase the value by 50 - 100 at a time.
---Setting range---
0 to 999 (%)

【#2216】 SV016 LMC1 Lost motion compensation 1


Set this parameter when the protrusion (that occurs due to the non-sensitive band by friction, torsion, backlash, etc.) at quadrant change is too large.
This compensates the torque at quadrant change (when an axis feed direction is reversed) by the proportion (%) to the stall torque.
Select whether to enable the lost motion compensation and the compensation method with the parameter "#2227 SV027 (SSF1)/ Bit9, 8".
---Setting range---
-1 to 200
Note that the range will be "-1 to 20000" when SV082/bit2 is "1".

II Parameters

4. Servo Parameters

【#2217(PR)】 SV017 SPEC1 Servo specification selection 1

Select the servo specifications.
A function is assigned to each bit.
Set this parameter by converting to hexadecimal.



Bit-0

Not used. Set to "0".

Bit-1 dfbx Dual feedback control

0: Stop 1: Start

- For MDS-DM Series
Not used. Set to "0".

Bit-2 seqh sequence

0: Normal 1: High-speed

Bit-3 vfb Speed feedback filter

0: Stop 1: Start (2250Hz)

Bit-4 fdir Position feedback

0: Forward polarity 1: Reverse polarity

- For MDS-DM Series
Not used. Set to "0".

Bit-5, 6

Not used. Set to "0".

Bit-7 abs Position control

0: Incremental 1: Absolute position control

Bit-8 - B

Not used. Set to "0".

Bit-F - C spm Motor series selection

0000: HF, HP motor (200V specifications) 0010: HF-H, HP-H motor (400V specifications)

【#2218(PR)】 SV018 PIT Ball screw pitch

Set the ball screw pitch. Set to "360" for the rotary axis.

---Setting range---
1 to 32767 (mm/rev)

【#2219(PR)】 SV019 RNG1 Position detector resolution

For the semi-closed loop control
Set the same value as SV020 (RNG2).

For the full-closed loop control
Set the number of pulses per ball screw pitch.
OSA18 (Hxn-A48) (260,000 p/rev) ----- SV019 = 260
OSA105 (Hxn-A51) (1,000,000 p/rev) ----- SV019 = 1000
OSA166 (Hxn-A74) (16,000,000 p/rev) ----- SV019 = 16000
MDS-B-HR (Analog cycle/512 division) ----- SV019 = Set them with SV117 (RNG1ex).

For the setting value when using a linear scale, etc., refer to the section related to the detector setting in the drive unit instruction manual

【#2220(PR)】 SV020 RNG2 Speed detector resolution

Set the number of pulses per revolution of the motor side detector.

OSA18 (Hxn-A48) (260,000 p/rev) ----- SV020 = 260
OSA105 (Hxn-A51) (1,000,000 p/rev) ----- SV020 = 1000
OSA166 (Hxn-A74) (16,000,000 p/rev) ----- SV020 = 16000

---Setting range---
0 to 32767 (kp/rev)

【#2221】 SV021 OLT Overload detection time constant

Normally set this parameter to "60".

---Setting range---
1 to 999 (s)

II Parameters

4. Servo Parameters

【#2222】 SV022 OLL Overload detection level

Set the current detection level of "Overload 1" (Alarm 50) as a percentage in respect to the stall current.
Normally set this parameter to "150". (For machine tool builder adjustment.)

---Setting range---
110 to 500 (Stall current %)

【#2223】 SV023 OD1 Excessive error detection width during servo ON

Set the excessive error detection width in servo ON.

<Standard setting value>

$OD1=OD2= (\text{Rapid traverse rate [mm/min]}) / (60 \times \text{PGN1}) / 2 \text{ [mm]}$

If this parameter is set to "0", the excessive error detection will not be performed.

---Setting range---
0 to 32767 (mm)

【#2224】 SV024 INP In-position detection width

Set the in-position detection width.

Set the positioning accuracy required for the machine.


The lower the setting is, the higher the positioning accuracy will be. However, the cycle time (settling time) becomes longer. The standard setting value is "50".

---Setting range---
0 to 32767 (μm)

【#2225(PR)】 SV025 MTYP Motor/Detector type

Set the position detector type, speed detector type and motor type.

The setting value is a four-digit hex (HEX).



HEX-1, 2 mtyp Motor type

Set the motor type. Set this according to SV017/bitC-F.

For SV017/bitC-F(spm)=0 (200V standard motor series)

HF75xxx-yyy	: HEX2, 1 = 01h	HP54xxx-yyy	: HEX2, 1 = 11h
HF105xxx-yyy	: HEX2, 1 = 02h	HP104xxx-yyy	: HEX2, 1 = 12h
HF54xxx-yyy	: HEX2, 1 = 03h	HP154xxx-yyy	: HEX2, 1 = 13h
HF104xxx-yyy	: HEX2, 1 = 04h	HP224xxx-yyy	: HEX2, 1 = 1Bh
HF154xxx-yyy	: HEX2, 1 = 05h	HP204xxx-yyy	: HEX2, 1 = 14h
HF224xxx-yyy	: HEX2, 1 = 06h	HP354xxx-yyy	: HEX2, 1 = 15h
HF204xxx-yyy	: HEX2, 1 = 07h	HP454xxx-yyy	: HEX2, 1 = 16h
HF354xxx-yyy	: HEX2, 1 = 08h	HP704xxx-yyy	: HEX2, 1 = 17h
HF453xxx-yyy	: HEX2, 1 = 09h	HP903xxx-yyy	: HEX2, 1 = 18h
HF703xxx-yyy	: HEX2, 1 = 0Ah	HP1103xxx-yyy	: HEX2, 1 = 19h
HF903xxx-yyy	: HEX2, 1 = 0Bh		
HF123xxx-yyy	: HEX2, 1 = 24h		
HF142xxx-yyy	: HEX2, 1 = 25h		
HF223xxx-yyy	: HEX2, 1 = 26h		
HF302xxx-yyy	: HEX2, 1 = 27h		
HF303xxx-yyy	: HEX2, 1 = 28h		

For SV017/bitC-F(spm)=2 (400V standard motor series)

HF-H75xxx-yyy	: HEX2, 1 = 01h	HP-H 54xxx-yyy	: HEX2, 1 = 11h
HF-H 105xxx-yyy	: HEX2, 1 = 02h	HP-H 104xxx-yyy	: HEX2, 1 = 12h
HF-H 54xxx-yyy	: HEX2, 1 = 03h	HP-H 154xxx-yyy	: HEX2, 1 = 13h
HF-H 104xxx-yyy	: HEX2, 1 = 04h	HP-H 224xxx-yyy	: HEX2, 1 = 1Bh
HF-H 154xxx-yyy	: HEX2, 1 = 05h	HP-H 204xxx-yyy	: HEX2, 1 = 14h
HF-H 204xxx-yyy	: HEX2, 1 = 07h	HP-H 354xxx-yyy	: HEX2, 1 = 15h
HF-H 354xxx-yyy	: HEX2, 1 = 08h	HP-H 454xxx-yyy	: HEX2, 1 = 16h
HF-H 453xxx-yyy	: HEX2, 1 = 09h	HP-H 704xxx-yyy	: HEX2, 1 = 17h
HF-H 703xxx-yyy	: HEX2, 1 = 0Ah	HP-H 903xxx-yyy	: HEX2, 1 = 18h
HF-H 903xxx-yyy	: HEX2, 1 = 0Bh	HP-H 1103xxx-yyy	: HEX2, 1 = 19h

(xxx: Code of brake, shaft shape, etc., yyy: Detector code)

HEX-3 ent Speed detector

OSA18(HFaaaxxx-A48): HEX3=2
OSA105(HFaaaxxx-A51): HEX3=2
OSA166(HFaaaxxx-A74): HEX3=2

HEX-4 pen Position detector

For semi-closed loop

OSA18(HFaaaxxx-A48): HEX4=2
OSA105(HFaaaxxx-A51): HEX4=2
OSA166(HFaaaxxx-A74): HEX4=2

For full-closed loop

OSA105-ET2, OSA166-ET2: HEX4 = 6h MDS-B-HR: HEX4 = Ah

【#2226】 SV026 OD2 Excessive error detection width during servo OFF

Set the excessive error detection width when servo OFF.

For the standard setting, refer to the explanation of SV023 (OD1).

When "0" is set, the excessive error detection will not be performed.


---Setting range---
0 to 32767 (mm)

II Parameters

4. Servo Parameters

【#2227】 SV027 SSS1 Servo function selection 1

Select the servo specifications.
A function is assigned to each bit.
Set this parameter by converting to hexadecimal.



Bit-1,0 vcnt Speed loop delay compensation execution changeover

00: Disable 01: Changeover type 1 10: Changeover type 2 11: Setting prohibited

Bit-2

Not used. Set to "0".

Bit-3

Not used. Set to "0".

Bit-5,4 vfct Jitter compensation pulse number

00: Disable 01: 1 pulse 10: 2 pulses 11: 3 pulses

Bit-6

Not used. Set to "0".

Bit-7

Not used. Set to "0".

Bit-9,8 lmc Lost motion compensation type selection

00: Compensation stop 01: Setting prohibited 10: Type 2 11: Setting prohibited
(Set the compensation amount in SV016 and SV041.)

(Note) When "SV082/lmc3" is set to "1", the lost motion compensation type 3 will be selected.

Bit-B,A ovs Overshoot compensation type selection

00: Compensation stop 01: Setting prohibited 10: Setting prohibited 11: Type 3
(Set the compensation amount in SV031 and SV042.)

Bit-C

Not used. Set to "0".

Bit-D

Not used. Set to "0".

Bit-E zrn2

Set to "1". (Fixed)

Bit-F

Not used. Set to "0".

【#2228】 SV028

Not used. Set to "0".

【#2229】 SV029 VCS Speed at the change of speed loop gain

If the noise is bothersome at high speed during rapid traverse, etc, this noise can be reduced by lowering the speed loop gain at high speed.
Set the speed at which the speed loop gain changes, and use this together with SV006 (VGN2). (Refer to SV006.)
When not using, set to "0".

---Setting range---
0 to 9999 (r/min)

【#2230】 SV030 IVC Voltage non-sensitive band compensation

When 100% is set, the voltage equivalent to the logical non-energized time will be compensated.

When "0" is set, 100% compensation will be performed.

If adjustment is necessary, adjust the value by 10% at a time from 100%.

If the value is too large, vibration or vibration noise may be generated.

---Setting range---
0 to 255 (%)

【#2231】 SV031 OVS1 Overshooting compensation 1

Set the compensation amount of the motor torque during positioning.

This is enabled only when the overshooting compensation SV027 (SS1/ovs) is selected.

---Setting range---

-1 to 100 (Stall current %)

Note that the range will be "-1 - 10000" (Stall current 0.01%) when "SV082/bit2" is "1",

II Parameters

4. Servo Parameters


【#2232】 SV032 TOF Torque offset 1

Set the unbalance torque of vertical axis and inclined axis.
When the vertical axis pull up function is enabled, the pull up compensation direction is determined by this parameter's sign. When set to "0", the vertical axis pull up will not be executed.

---Setting range---
-100 to 100 (Stall current %)

【#2233】 SV033 SSF2 Servo function selection 2

Select the servo specifications.
A function is assigned to each bit.
Set this parameter by converting to hexadecimal.



Bit-0

Not used. Set to "0".

Bit-1,2,3 nfd1 Depth of Notch filter 1

Set the filter depth of Notch filter 1.

Bit3,2,1=000: -∞	Bit3,2,1=001: -18.1[dB]
Bit3,2,1=010: -12.0[dB]	Bit3,2,1=011: -8.5[dB]
Bit3,2,1=100: -6.0[dB]	Bit3,2,1=101: -4.1[dB]
Bit3,2,1=110: -2.5[dB]	Bit3,2,1=111: -1.2[dB]

Set the adaptive frequency of Notch filter 1 in "#2238 SV0038 FHz1".

Bit-4 nf3 Notch filter 3

0: Stop 1: Start (1125Hz)

Bit-5,6,7 nfd2 Depth of Notch filter 2

Set the filter depth of Notch filter 2.

Bit7,6,5=000: -∞	Bit7,6,5=001: -18.1[dB]
Bit7,6,5=010: -12.0[dB]	Bit7,6,5=011: -8.5[dB]
Bit7,6,5=100: -6.0[dB]	Bit7,6,5=101: -4.1[dB]
Bit7,6,5=110: -2.5[dB]	Bit7,6,5=111: -1.2[dB]

Set the adaptive frequency of Notch filter 2 in "#2246 SV0046 FHz2".

Bit-8,9,A,B,C

Not used. Set to "0".

Bit-D rps Safety observation safety speed setting increment

0: mm/min 1: 100mm/min

Bit-E zup Vertical axis pull up function


0: Stop 1: Enable

Bit-F lmc2a Lost motion compensation 2 timing

0: Normal 1: Change

【#2234】 SV034 SSF3 Servo function selection 3

Select the servo specifications.
A function is assigned to each bit.
Set this parameter by converting to hexadecimal.



Bit-0 - B

Not used. Set to "0".

Bit-C,D,E,F ovsn Overshooting compensation type 3 non-sensitive ban

Set the non-sensitive band of the model position droop in increments of 2μm.
When using feed forward control, set the non-sensitive band for the model position droop and ignore the model overshooting.


Bit-F,E,D,C=0000: 0μm Bit-F,E,D,C=0001: 2μm Bit-F,E,D,C=0010: 4μm

II Parameters

4. Servo Parameters

【#2235】 SV035 SSF4 Servo function selection 4

Select the servo specifications.
A function is assigned to each bit.
Set this parameter by converting to hexadecimal.



Bit-0 - 6

Not used. Set to "0".

Bit-7 ckab No signal detection 2

0: Disable 1: Enable

- For MDS-DM Series
Not used. Set to "0".

Bit-8 - E

Not used. Set to "0".

Bit-F clt Inertia ratio display

0: Setting for normal use
1: Display the total inertia ratio estimated at acceleration/deceleration at the inertia ratio on the servo monitor screen


II Parameters

4. Servo Parameters

【#2236(PR)】 SV036 P TYP Power supply type/ Regenerative resistor type

Power supply type

When connecting a power supply unit, set a code for each power supply unit.



- For MDS-DM Series
Not used. Set to "0".

Bit-0 - 7 ptyp External emergency stop setting

When the emergency stop input signal of the power supply unit is "disabled"

Power supply unit is not connected	: 0000h
MDS-D-CV-37 / MDS-DH-CV-37	: 0004h
MDS-D-CV-75 / MDS-DH-CV-75	: 0008h
MDS-D-CV-110 / MDS-DH-CV-110	: 0011h
MDS-D-CV-185 / MDS-DH-CV-185	: 0019h
MDS-D-CV-300 / MDS-DH-CV-300	: 0030h
MDS-D-CV-370 / MDS-DH-CV-370	: 0037h
MDS-D-CV-450 / MDS-DH-CV-450	: 0045h
MDS-D-CV-550	: 0055h
MDS-DH-CV-750	: 0075h

When the emergency stop input signal of the power supply unit is "enabled"

Power supply unit is not connected	: 0000h
MDS-D-CV-37 / MDS-DH-CV-37	: 0044h
MDS-D-CV-75 / MDS-DH-CV-75	: 0048h
MDS-D-CV-110 / MDS-DH-CV-110	: 0051h
MDS-D-CV-185 / MDS-DH-CV-185	: 0059h
MDS-D-CV-300 / MDS-DH-CV-300	: 0070h
MDS-D-CV-370 / MDS-DH-CV-370	: 0077h
MDS-D-CV-450 / MDS-DH-CV-450	: 0085h
MDS-D-CV-550	: 0095h
MDS-DH-CV-750	: 00B5h

Bit-8 - B rtyp

Not used. Set to "0".


Bit-C - F amp

Not used. Set to "0".

Regenerative resistor type

Set the regenerative resistor type.

(Note) These bits are used only in MDS-D-SVJ3/SPJ3 series.



Bit-0 - 3

Not used. Set to "0".

Bit-4 - 7 emgx External emergency stop function

Set the external emergency stop function. (Do not set a value other than specified.)

0: Disable 4: Enable

Bit-8 - B rtyp

Bit-C - F amp

For "amp = 1"

"rtyp" setting value

- 0: Resistor built-in drive unit
- 1: Setting prohibited
- 2: MR-RB032
- 3: MR-RB12 or GZG200W39OHMK
- 4: MR-RB32 or GZG200W120OHMK 3 units connected in parallel
- 5: MR-RB30 or GZG200W39OHMK 3 units connected in parallel
- 6: MR-RB50 or GZG300W39OHMK 3 units connected in parallel
- 7: MR-RB31 or GZG200W20OHMK 3 units connected in parallel
- 8: MR-RB51 or GZG300W20OHMK 3 units connected in parallel
- 9 - F: Setting prohibited

For "amp = 2"

"rtyp" setting value

- 0 - 3: Setting prohibited
- 4: FCUA-RB22
- 5: FCUA-RB37
- 6: FCUA-RB55
- 7, 8: Setting prohibited
- 9: R-UNIT2
- A - C: Setting prohibited
- D: FCUA-RB75/2 2 units
- E, F: Setting prohibited

II Parameters

4. Servo Parameters

【#2237】 SV037 JL Load inertia scale

Set "the motor inertia + motor axis conversion load inertia" in respect to the motor inertia.
 $SV037(JL) = (J_m + J_l / J_m) \times 100$
J_m : Motor inertia
J_l : Motor axis conversion load inertia

For linear motor, set the gross mass of the moving sections in kg unit.

---Setting range---
0 to 5000 (%)
(For linear motor, the unit is "kg".)

【#2238】 SV038 FHz1 Notch filter frequency 1

Set the vibration frequency to suppress when machine vibration occurs. (Enabled at 80 or more)

When not using, set to "0".

---Setting range---
0 to 2250 (Hz)

【#2239】 SV039 LMCD Lost motion compensation timing

Set this parameter when the lost motion compensation timing does not match.
Adjust by increasing the value by 10 at a time.

---Setting range---
0 to 2000 (ms)

【#2240】 SV040 LMCT Lost motion compensation non-sensitive band

Set the non-sensitive band of the lost motion compensation in the feed forward control.
When "0" is set, the actual value to be set is 2μm. Adjust by increasing by 1μm at a time.

---Setting range---
0 to 255 (μm)

【#2241】 SV041 LMC2 Lost motion compensation 2

Set this parameter as well as SV016 (LMC1) only when you wish to vary the lost motion compensation amount depending on the command directions.
Normally set this parameter to "0".

---Setting range---
-1 to 200 (Stall current %)
Note that when SV082/bit2 is "1", -1 - 20000 (Stall current 0.01%)

【#2242】 SV042 OVS2 Overshooting compensation 2

Set this parameter as well as SV031 (OVS1) only when you wish to vary the overshooting compensation amount depending on the command directions.
Normally set this parameter to "0".

---Setting range---
-1 to 100 (Stall current %)
Note that the range will be "-1 - 10000" (Stall current 0.01%) when SV082/bit2 is "1".

【#2243】 SV043 OBS1 Disturbance observer filter frequency

Set the disturbance observer filter band.
Normally set this parameter to "100".
To use the disturbance observer, also set SV037 (JL) and SV044 (OBS2).
When not using, set to "0".

---Setting range---
0 to 1000 (rad/s)

【#2244】 SV044 OBS2 Disturbance observer gain

Set the disturbance observer gain. The standard setting is "100 - 300".
To use the disturbance observer, also set SV037 (JL) and SV043 (OBS1).
When not using, set to "0".

---Setting range---
0 to 500 (%)

【#2245】 SV045

Not used. Set to "0".

【#2246】 SV046 FHz2 Notch filter frequency 2

Set the vibration frequency to suppress when machine vibration occurs. (Enabled at 80 or more.)

When not using, set to "0".

---Setting range---
0 to 2250 (Hz)

【#2247】 SV047 EC Inductive voltage compensation gain

Set the inductive voltage compensation gain. Normally set this parameter to "100".
If the current FB peak exceeds the current command peak, lower the gain.

---Setting range---
0 to 200 (%)

II Parameters

4. Servo Parameters

【#2248】 SV048 EMGrT Vertical axis drop prevention time

Input a length of time to prevent the vertical axis from dropping by delaying READY OFF until the brake works when the emergency stop occurs.
Increase the setting by 100ms at a time and set the value where the axis does not drop. When using a motor with a break of HF(-H) Series or HP(-H) Series, set to "200ms" as a standard.

---Setting range---
0 to 20000 (ms)

【#2249】 SV049 PGN1sp Position loop gain 1 in spindle synchronous control

Set the position loop gain during spindle synchronization control (synchronous tapping and synchronization control with spindle C-axis).
Set the same value as the value of the position loop gain for spindle synchronous tapping control.

When performing the SHG control, set this parameter with SV050 (PGN2sp) and SV058 (SHGCsp).

- For C70 Series

When changing the value, change the value of "#2017 tap_g Axis servo gain".

---Setting range---
1 to 200 (rad/s)

【#2250】 SV050 PGN2sp Position loop gain 2 in spindle synchronous control

When using SHG control during spindle synchronous control (synchronous tapping and synchronization control with spindle C-axis), set this parameter with SV049 (PGN1sp) and SV058 (SHGCsp).

When not performing the SHG control, set to "0".

---Setting range---
0 to 999 (rad/s)

【#2251】 SV051 DFBT Dual feed back control time constant

Set the control time constant in dual feed back.

When "0" is set, the actual value to be set is 1ms.

The higher the time constant is, the closer it gets to the semi-closed control, so the limit of the position loop gain will be raised.

- For MDS-DM Series
Not used. Set to "0".

---Setting range---
0 to 9999 (ms)

【#2252】 SV052 DFBN Dual feedback control non-sensitive band

Set the non-sensitive band in the dual feedback control.
Normally set this parameter to "0".

- For MDS-DM Series
Not used. Set to "0".

---Setting range---
0 to 9999 (μm)

【#2253】 SV053 OD3 Excessive error detection width in special control

Set the excessive error detection width when servo ON in a special control (initial absolute position setting, stopper control, etc.).

When "0" is set, excessive error detection won't be performed when servo ON during a special control.

---Setting range---
0 to 32767 (mm)

【#2254】 SV054 ORE Overrun detection width in closed loop control

Set the overrun detection width in the full-closed loop control.

When the gap between the motor side detector and the linear scale (machine side detector) exceeds the value set by this parameter, it will be judged to be overrun and "Alarm 43" will be detected.

When "-1" is set, the alarm detection will not be performed.

When "0" is set, overrun will be detected with a 2mm width.

- For MDS-DM Series
Not used. Set to "0".

---Setting range---
-1 to 32767 (mm)

【#2255】 SV055 EMGx Max. gate off delay time after emergency stop

Set a length of time from the point when the emergency stop is input to the point when READY OFF is compulsorily executed.

Set the maximum value "+ 100ms" of the SV056 setting value of the servo drive unit which the power supply unit and the main circuit are connected with.

In preventing the vertical axis from dropping, the gate off will be delayed for the length of time set by SV048 even if SV055's value is smaller than that of SV048.

---Setting range---
0 to 20000 (ms)

II Parameters

4. Servo Parameters

【#2256】 SV056 EMGt Deceleration time constant at emergency stop

Set the time constant used for the deceleration control at emergency stop.
Set the value of 0.9-fold rapid traverse acceleration/deceleration time constant used in the acceleration/deceleration. This is because the friction torque will act as a deceleration torque when the motor decelerates, which enables the machine to stop quickly.
When preventing an impact at the acceleration/deceleration from being given to the machine, set the same value as the rapid traverse acceleration/deceleration time constant.

---Setting range---
0 to 20000 (ms)

【#2257】 SV057 SHGC SHG control gain

When performing the SHG control, set this parameter with S003 (PGN1) and SV004 (PGN2).

When not performing the SHG control, set to "0".

---Setting range---
0 to 1200 (rad/s)

【#2258】 SV058 SHGCsp SHG control gain in spindle synchronous control

When using SHG control during spindle synchronization control (synchronous tapping and synchronous control with spindle C-axis), set this parameter with SV049 (PGN1sp) and SV050 (PGN2sp).

When not performing the SHG control, set to "0".

---Setting range---
0 to 1200 (rad/s)

【#2259】 SV059

Not used. Set to "0".

【#2260】 SV060

Not used. Set to "0".

【#2261】 SV061 DA1NO D/A output channel 1 data No.

Input the data number you wish to output to D/A output channel.

When using the 2-axis drive unit, set "-1" for the axis on the side to which the data will not be output.

---Setting range---
-1 to 127

【#2262】 SV062 DA2NO D/A output channel 2 data No.

Input the data number you wish to output to D/A output channel.

When using the 2-axis drive unit, set "-1" for the axis on the side to which the data will not be output.

---Setting range---
-1 to 127

【#2263】 SV063 DA1MPY D/A output channel 1 output scale

Set the output scale in increment of 1/100.

When "0" is set, the magnification is the same as when "100" is set.

---Setting range---
-32768 to 32767 (1/100-fold)

【#2264】 SV064 DA2MPY D/A output channel 2 output scale

Set the output scale with a 1/100 increment.

When "0" is set, the magnification is the same as when "100" is set.

---Setting range---
-32768 to 32767 (1/100-fold)

【#2265】 SV065 TLC Machine side compensation spring constant

Set the machine side compensation spring constant.

For semi-closed loop control, the machine side compensation amount can be approximated with the following expression.

Compensation amount = Command speed $F(\text{mm}/\text{min})^2 \times \text{SV065} / (\text{Radius } R(\text{mm}) \times 10^9)$
(μm)

When not using, set to "0".

---Setting range---
-32768 to 32767

【#2266 - 2280】 SV066 - SV080

These parameters are set automatically by the NC system.

【#2281(PR)】 SV081

Not used. Set to "0".

II Parameters

4. Servo Parameters

【#2285】 SV085 LMCK Lost motion compensation 3 spring constant

Set the machine system's spring constant when using lost motion compensation type 3. When not using, set to "0".

---Setting range---
0 to 32767 (0.01%/μm)

【#2286】 SV086 LMCc Lost motion compensation 3 viscous coefficient

Set the machine system's viscous coefficient when using lost motion compensation type 3. When not using, set to "0".

---Setting range---
0 to 32767 (0.01%/μm)

【#2287】 SV087 FHZ4 Notch filter frequency 4

Set the vibration frequency to suppress when machine vibration occurs. (Enabled at 80 or more)

When not using, set to "0".

---Setting range---
0 to 2250 (Hz)

【#2288】 SV088 FHZ5 Notch filter frequency 5

Set the vibration frequency to suppress when machine vibration occurs. (Enabled at 80 or more)

When not using, set to "0".

---Setting range---
0 to 2250 (Hz)

【#2289】 SV089 TQMAX Kq Torque maximizing control Kp

Normally set this parameter to "0".

---Setting range---
0 - 32767 (0.01%/μm)

【#2290】 SV090 TQMAX Kd Torque maximizing control Kd

Normally set this parameter to "0".

---Setting range---
0 to 32767 (0.01%/s/mm)

【#2291】 SV091

Not used. Set to "0".

【#2292】 SV092

Not used. Set to "0".

【#2293】 SV093

Not used. Set to "0".

【#2294】 SV094 MPV Magnetic pole position error detection speed

In the magnetic polar position detection function, the command motor speed and motor speed at the position command stop are monitored. The command motor speed level and motor speed level at the position command stop are set with "r/min" increment.

When the command motor speed level is set to "0", the magnetic polar position error is detected at 10r/min. Set to "10" as a standard setting applied when the magnetic polar position error detection function is enabled. This will detect the magnetic polar position error when the motor speed is "100r/min".

When not using, set to "0".

Ten-thousands digit, Thousands digit ----- Command motor speed level (10r/min)
Hundreds digit, Tens digit, Ones digit ----- Motor speed level (10r/min)

---Setting range---
0 to 31999

【#2295】 SV095 ZUPD Vertical axis pull up distance

Set this parameter to adjust the pull up distance when the vertical axis pull up function is enabled.

For a rotary motor, 8/1000 of a rotation at the motor end is internally set as the pull up distance, when the pull up function is enabled and this parameter is set to "0".

---Setting range---
0 to 2000 (μm)

【#2296】 SV096

Not used. Set to "0".

【#2297】 SV097

Not used. Set to "0".

【#2298】 SV098

Not used. Set to "0".

【#2299】 SV099

Not used. Set to "0".

II Parameters

4. Servo Parameters

【#2300】 SV100

Not used. Set to "0".

【#2301】 SV101

Not used. Set to "0".

【#2302】 SV102

Not used. Set to "0".

【#2303】 SV103

Not used. Set to "0".

【#2304】 SV104

Not used. Set to "0".

【#2305】 SV105

Not used. Set to "0".

【#2306】 SV106

Not used. Set to "0".

【#2307】 SV107

Not used. Set to "0".

【#2308】 SV108

Not used. Set to "0".

【#2309】 SV109

Not used. Set to "0".

【#2310】 SV110

Not used. Set to "0".

【#2311】 SV111

Not used. Set to "0".

【#2312】 SV112

Not used. Set to "0".

【#2313】 SV113 SSF8 Servo function selection 8

Select the servo specifications.
A function is assigned to each bit.
Set this parameter by converting to hexadecimal.

Bit- F E D C B A 9 8 7 6 5 4 3 2 1 0

	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
--	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

ssc

Bit-0 - E

Not used. Set to "0".

Bit-F ssc Safety observation function

0: Stop 1: Start

【#2314】 SV114 SSF9 Servo function selection 9

Select the servo specifications.
A function is assigned to each bit.
Set this parameter by converting to hexadecimal.

Bit- F E D C B A 9 8 7 6 5 4 3 2 1 0

		0	0	0	0	0	0	0	0	0	0	0	0	0	0
--	--	---	---	---	---	---	---	---	---	---	---	---	---	---	---

pclk

Bit-0-D

Not used. Set to "0".

Bit-E,F pclk PWM

Not used. Set to "0".

- For MDS-DM Series
PWM carrier selection (When 9KHz is applied, set all the axes in the servo drive section of the MDS-SPVx to "9KHz".)
00: 4.5KHz (Unit specification) 01: Selecting 4.5KHz 10: Selecting 9KHz 11: 4.5KHz

【#2315】 SV115 SSF10 Servo function selection 10

Not used. Set to "0".

【#2316】 SV116 SSF11 Servo function selection 11

Not used. Set to "0".

II Parameters

4. Servo Parameters

【#2317(PR)】 SV117 RNG1ex Expansion position detector resolution

Set this parameter when using a special position detector.
Normally set this parameter to "0".
Refer to the section related to the detector setting in the drive unit instruction manual.

- For MDS-DM Series
Not used. Set to "0".

【#2318(PR)】 SV118 RNG2ex Expansion speed detector resolution

Set the number of pulses per revolution of the motor side detector.
OSA18 ----- SV118 = 0
OSA105 ---- SV118 = 0
OSA166 ---- SV118 = 0

- For MDS-DM Series
Not used. Set to "0".
- Setting range---
0 - 32767 ($\times 2^{16}$ p/rev)

【#2319 - 2437】 SV119 - SV237

Not used. Set to "0".

【#2438】 SV238 SSCFEED Safety observation Safety speed

Set the machine's safety speed for the safety observation function.
Set this parameter within the following setting ranges.
For linear axis: 2000mm/min or less
For rotary axis: 18000°/min (50r/min) or less
When not using, set to "0".

- Setting range---
0 to 18000 (mm/min) or (°/min)

【#2439】 SV239 SSCRPM Safety observation Safety motor speed

Set the motor's safety speed for the safety observation function.
When not using, set to "0".

- Setting range---
0 to 32767 (r/min)

【#2440 - 2456】 SV240 - SV256

Not used. Set to "0".

5. Spindle Parameters

【#3001】 slimt 1 Limit rotation speed (Gear: 00)

Set the spindle speed for maximum motor speed with gear 00.
(Set the spindle speed for the S analog output 10V.)

---Setting range---
0 to 99999 (r/min)

【#3002】 slimt 2 Limit rotation speed (Gear: 01)

Set the spindle speed for maximum motor speed with gear 01.
(Set the spindle speed for the S analog output 10V.)

---Setting range---
0 to 99999 (r/min)

【#3003】 slimt 3 Limit rotation speed (Gear: 10)

Set the spindle speed for maximum motor speed with gear 10.
(Set the spindle speed for the S analog output 10V.)

---Setting range---
0 to 99999 (r/min)

【#3004】 slimt 4 Limit rotation speed (Gear: 11)

Set the spindle speed for maximum motor speed with gear 11.
(Set the spindle speed for the S analog output 10V.)

---Setting range---
0 to 99999 (r/min)

【#3005】 smax 1 Maximum rotation speed (Gear: 00)

Set the maximum spindle speed with gear 00.
Set this as slimt \geq smax.
By comparing the S command value and the values of gear 1 - 4, a spindle gear shift command will be output automatically.

---Setting range---
0 to 99999 (r/min)

【#3006】 smax 2 Maximum rotation speed (Gear: 01)

Set the maximum spindle speed with gear 01.
Set this as slimt \geq smax.
By comparing the S command value and the values of gear 1 - 4, a spindle gear shift command will be output automatically.

---Setting range---
0 to 99999 (r/min)

【#3007】 smax 3 Maximum rotation speed (Gear: 10)

Set the maximum spindle speed with gear 10.
Set this as slimt \geq smax.
By comparing the S command value and the values of gear 1 - 4, a spindle gear shift command will be output automatically.

---Setting range---
0 to 99999 (r/min)

【#3008】 smax 4 Maximum rotation speed (Gear: 11)

Set the maximum spindle speed with gear 11.
Set this as slimt \geq smax.
By comparing the S command value and the values of gear 1 - 4, a spindle gear shift command will be output automatically.

---Setting range---
0 to 99999 (r/min)

【#3009】 ssift 1 Shift rotation speed (Gear: 00)

Set the spindle speed for gear shifting with gear 00.
(Note) Setting too large value may cause a gear nick when changing gears.

---Setting range---
0 to 32767 (r/min)

【#3010】 ssift 2 Shift rotation speed (Gear: 01)

Set the spindle speed for gear shifting with gear 01.
(Note) Setting too large value may cause a gear nick when changing gears.

---Setting range---
0 to 32767 (r/min)

【#3011】 ssift 3 Shift rotation speed (Gear: 10)

Set the spindle speed for gear shifting with gear 10.
(Note) Setting too large value may cause a gear nick when changing gears.

---Setting range---
0 to 32767 (r/min)

II Parameters

5. Spindle Parameters

【#3012】 sssf4 Shift rotation speed (Gear: 11)

Set the spindle speed for gear shifting with gear 11.
(Note) Setting too large value may cause a gear nick when changing gears.

---Setting range---
0 to 32767 (r/min)

【#3013】 stap1 Tap rotation speed (Gear: 00)

Set the maximum spindle speed during tapping cycle with gear 00.

---Setting range---
0 to 99999 (r/min)

【#3014】 stap2 Tap rotation speed (Gear: 01)

Set the maximum spindle speed during tapping cycle with gear 01.

---Setting range---
0 to 99999 (r/min)

【#3015】 stap3 Tap rotation speed (Gear: 10)

Set the maximum spindle speed during tapping cycle with gear 10.

---Setting range---
0 to 99999 (r/min)

【#3016】 stap4 Tap rotation speed (Gear: 11)

Set the maximum spindle speed during tapping cycle with gear 11.

---Setting range---
0 to 99999 (r/min)

【#3017】 stapt1 Tap time constant (Gear: 00)

Set the time constant for constant inclination synchronous tapping cycle with gear 00 (linear acceleration/deceleration pattern).

---Setting range---
1 to 5000 (ms)

【#3018】 stapt2 Tap time constant (Gear: 01)

Set the time constant for constant inclination synchronous tapping cycle with gear 01 (linear acceleration/deceleration pattern).

---Setting range---
1 to 5000 (ms)

【#3019】 stapt3 Tap time constant (Gear: 10)

Set the time constant for constant inclination synchronous tapping cycle with gear 10 (linear acceleration/deceleration pattern).

---Setting range---
1 to 5000 (ms)

【#3020】 stapt4 Tap time constant (Gear: 11)

Set the time constant for constant inclination synchronous tapping cycle with gear 11 (linear acceleration/deceleration pattern).

---Setting range---
1 to 5000 (ms)

【#3021】 sori Orientation rotation speed

Set the spindle orientation speed.
Set the speed for when the spindle rotates at the constant speed.

---Setting range---
0 to 32767 (r/min)

【#3022】 sgear Encoder gear ratio

Set the gear ratio of the spindle to the detector.
Setting value 0 ---> Detector : Spindle = 1:1
Setting value 1 ---> Detector : Spindle = 1:2
Setting value 2 ---> Detector : Spindle = 1:4
Setting value 3 ---> Detector : Spindle = 1:8

---Setting range---
0 to 8

【#3023】 smini Minimum rotation speed

Set the minimum spindle speed.
If an S command below this setting is issued, the spindle will rotate at the minimum speed set by this parameter.

---Setting range---
0 to 32767 (r/min)

【#3024(PR)】 sout Spindle connection

Select the type of interface with a spindle drive unit.
0: No connection with a spindle
1: Dedicated network, dedicated optical communication
2 - 5: S-analog

---Setting range---
0 to 5

II Parameters

5. Spindle Parameters

【#3025(PR)】 enc-on Spindle encoder

Set the connection condition of a spindle's detector.
 Setting 0 ----> Not connected
 Setting 1 ----> Connected (Spindle detector connection check function is enabled.)
 Setting 2 ----> Serially connected
 ---Setting range---
 0 to 2

【#3026】 cs_ori Selection of winding in orientation mode

0: Perform orientation using the coil selected when the orientation command is issued.
 1: Use the coil L whenever the orientation command is issued.

【#3027】 cs_syn Selection of winding in spindle synchronous mode

0: Select the coil H or L based on the actual spindle motor speed (calculated from commanded speed) when spindle synchronization starts. (Coil switch is not performed during spindle synchronous tapping control. This control is carried out using the coil selected at start.)
 If the actual spindle motor speed is less than the setting of SP020, the coil L is selected. But if the actual speed exceeds the setting of SP020, the coil H is selected.
 1: Use the coil H whenever the spindle synchronization command is issued.

【#3028】 sprcmm Tap cycle spindle forward run/reverse run M command

Set the M codes for the spindle forward run/reverse run commands.
 High-order 3 digits: Set the M code for spindle forward run command.
 Low-order 3 digits: Set the M code for spindle reverse run command.
 When "0" is set, the M code for spindle forward run command is handled as "3" and the M code for spindle reverse run command as "4".
 ---Setting range---
 0 to 999999

【#3029】 tapsel Asynchro-nous tap gear selection


Select whether to use the tapping speed or maximum speed for the gear that is selected when an asynchronous tapping command is issued.
 0: Tapping speed
 1: Maximum speed
 This parameter is enabled only when the M-function synchronous tapping cycle enable parameter "#1272 ext08/bit1" is ON.

【#3030】

Not used. Set to "0".

【#3031(PR)】 smcp_no Drive unit I/F channel No. (spindle)

Set the interface channel No. of CNC control unit to which the spindle is connected and the axis No. within each channel.
 Set this parameter in 4-digit (hexadecimal) format.



HEX-4 : Drive unit interface channel No.
 HEX-3 : Not used. Set to "0".
 HEX-2, 1 : Axis No.

For a spindle to be connected to CNC via analog interface, set to "0000".

---Setting range---
 1001 to 1010, 2001 to 2010

【#3032】

Not used. Set to "0".

【#3035(PR)】 spunit Output unit

Select the data unit for communication with the spindle drive unit.
 This selection is applied to the data communicated between the NC and spindle drive unit as well as the spindle movement data. Note, however, that this parameter is enabled only for the MDS-D Series spindle drive unit.
 Spindle/C axis depends on this parameter setting and the C axis output unit (servo) is ignored.
 When MDS-D Series is used, follow the setting of "#1003 ctrl_unit".
 B: 1 μ m
 C: 0.1 μ m
 D: 10nm
 E: 1nm

II Parameters

5. Spindle Parameters

【#3037】 taps21 Synchronous tap switching spindle speed 2 (Gear: 00)

Set the spindle speed at which the 2nd step acceleration/deceleration time constant is to be switched with gear 00.

---Setting range---
0 to 99999 (r/min)

【#3038】 taps22 Synchronous tap switching spindle speed 2 (Gear: 01)

Set the spindle speed at which the 2nd step acceleration/deceleration time constant is to be switched with gear 01.

---Setting range---
0 to 99999 (r/min)

【#3039】 taps23 Synchronous tap switching spindle speed 2 (Gear: 10)

Set the spindle speed at which the 2nd step acceleration/deceleration time constant is to be switched with gear 10.

---Setting range---
0 to 99999 (r/min)

【#3040】 taps24 Synchronous tap switching spindle speed 2 (Gear: 11)

Set the spindle speed at which the 2nd step acceleration/deceleration time constant is to be switched with gear 11.

---Setting range---
0 to 99999 (r/min)

【#3041】 tapt21 Synchronous tap switching time constant 2 (Gear: 00)

Set the time constant to reach synchronous tapping switching spindle speed 2 (taps21 - 24) with gear 00.

---Setting range---
1 to 5000 (ms)

【#3042】 tapt22 Synchronous tap switching time constant 2 (Gear: 01)

Set the time constant to reach synchronous tapping switching spindle rotation speed 2 (taps21 - 24) with gear 01.

---Setting range---
1 to 5000 (ms)

【#3043】 tapt23 Synchronous tap switching time constant 2 (Gear: 10)

Set the time constant to reach synchronous tapping switching spindle rotation speed 2 (taps21 - 24) with gear 10.

---Setting range---
1 to 5000 (ms)

【#3044】 tapt24 Synchronous tap switching time constant 2 (Gear: 11)

Set the time constant to reach synchronous tapping switching spindle rotation speed 2 (taps21 - 24) with gear 11.

---Setting range---
1 to 5000 (ms)

【#3045】 tapt31 Synchronous tap switching time constant 3 (Gear: 00)

Set the time constant to reach the maximum speed (smax1 - 4) with gear 00.

---Setting range---
1 to 5000 (ms)

【#3046】 tapt32 Synchronous tap switching time constant 3 (Gear: 01)

Set the time constant to reach the maximum speed (smax1 - 4) with gear 01.

---Setting range---
1 to 5000 (ms)

【#3047】 tapt33 Synchronous tap switching time constant 3 (Gear: 10)

Set the time constant to reach the maximum speed (smax1 - 4) with gear 10.

---Setting range---
1 to 5000 (ms)

【#3048】 tapt34 Synchronous tap switching time constant 3 (Gear: 11)

Set the time constant to reach the maximum speed (smax1 - 4) with gear 11.

---Setting range---
1 to 5000 (ms)

【#3049】 spt Spindle synchronization acceleration/deceleration time constant

Set the acceleration/deceleration time constant for when the commanded spindle synchronization speed changes under spindle synchronization control.

---Setting range---
0 to 9999 (ms)

II Parameters

5. Spindle Parameters

【#3050】 sprlv Spindle synchronization rotation speed attainment level

Set the level of difference between the commanded synchronization spindle speeds and actual speeds of both the basic and synchronous spindles during spindle synchronization, below which the spindle speed synchronization complete signal will go ON.

---Setting range---

0 to 4095 (pulse) (1 pulse = 0.088°)

【#3051】 spplv Spindle phase synchroniza-tion attainment level

Set the level of phase difference between the basic and synchronous spindles during spindle synchronization, below which the spindle phase synchronization complete signal will go ON.

---Setting range---

0 to 4095 (pulse) (1 pulse = 0.088°)

【#3052】 spplr Spindle motor spindle relative polarity

Set the spindle motor and spindle's relative polarity.

0: Positive polarity

Spindle CW rotation at motor CW rotation

1: Negative polarity

Spindle CCW rotation at motor CW rotation

---Setting range---

0000/0001 (HEX)

【#3053】 sppst Spindle encoder Z -phase position

Set the deviation amount from the spindle's basic point to the spindle detector's Z phase. Obtain the deviation amount, considering a clockwise direction as positive when viewed from the spindle's front side.

---Setting range---

0 to 359999 (1/1000°)

【#3054】 sptc1 Spindle synchronization multi-step acceleration/deceleration changeover speed 1

Set the spindle speed for changing the 1st step's acceleration/deceleration time constant.

---Setting range---

0 to 99999 (r/min)

【#3055】 sptc2 Spindle synchronization multi-step acceleration/deceleration changeover speed 2

Set the spindle speed for changing the 2nd step's acceleration/deceleration time constant.

---Setting range---

0 to 99999 (r/min)

【#3056】 sptc3 Spindle synchronization multi-step acceleration/deceleration changeover speed 3

Set the spindle speed for changing the 3rd step's acceleration/deceleration time constant.

---Setting range---

0 to 99999 (r/min)

【#3057】 sptc4 Spindle synchronization multi-step acceleration/deceleration changeover speed 4

Set the spindle speed for changing the 4th step's acceleration/deceleration time constant.

---Setting range---

0 to 99999 (r/min)

【#3058】 sptc5 Spindle synchronization multi-step acceleration/deceleration changeover speed 5

Set the spindle speed for changing the 5th step's acceleration/deceleration time constant.

---Setting range---

0 to 99999 (r/min)

【#3059】 sptc6 Spindle synchronization multi-step acceleration/deceleration changeover speed 6

Set the spindle speed for changing the 6th step's acceleration/deceleration time constant.

---Setting range---

0 to 99999 (r/min)

【#3060】 sptc7 Spindle synchronization multi-step acceleration/deceleration changeover speed 7

Set the spindle speed for changing the 7th step's acceleration/deceleration time constant.

---Setting range---

0 to 99999 (r/min)

II Parameters

5. Spindle Parameters

【#3061】 spdiv1 Magnification for time constant changeover speed 1

Set the acceleration/deceleration time constant from the spindle synchronization multi-step acceleration/deceleration changeover speed 1 (sptc1) to the spindle synchronization multi-step acceleration/deceleration changeover speed 2 (sptc2). Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

---Setting range---
0 to 127

【#3062】 spdiv2 Magnification for time constant changeover speed 2

Set the acceleration/deceleration time constant from the spindle synchronization multi-step acceleration/deceleration changeover speed 2 (sptc2) to the spindle synchronization multi-step acceleration/deceleration changeover speed 3 (sptc3). Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

---Setting range---
0 to 127

【#3063】 spdiv3 Magnification for time constant changeover speed 3

Set the acceleration/deceleration time constant from the spindle synchronization multi-step acceleration/deceleration changeover speed 3 (sptc3) to the spindle synchronization multi-step acceleration/deceleration changeover speed 4 (sptc4). Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

---Setting range---
0 to 127

【#3064】 spdiv4 Magnification for time constant changeover speed 4

Set the acceleration/deceleration time constant from the spindle synchronization multi-step acceleration/deceleration changeover speed 4 (sptc4) to the spindle synchronization multi-step acceleration/deceleration changeover speed 5 (sptc5). Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

---Setting range---
0 to 127

【#3065】 spdiv5 Magnification for time constant changeover speed 5

Set the acceleration/deceleration time constant from the spindle synchronization multi-step acceleration/deceleration changeover speed 5 (sptc5) to the spindle synchronization multi-step acceleration/deceleration changeover speed 6 (sptc6). Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

---Setting range---
0 to 127

【#3066】 spdiv6 Magnification for time constant changeover speed 6

Set the acceleration/deceleration time constant from the spindle synchronization multi-step acceleration/deceleration changeover speed 6 (sptc6) to the spindle synchronization multi-step acceleration/deceleration changeover speed 7 (sptc7). Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

---Setting range---
0 to 127

【#3067】 spdiv7 Magnification for time constant changeover speed 7

Set the acceleration/deceleration time constant for the spindle synchronization multi-step acceleration/deceleration changeover speed 7 (sptc7) and higher. Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

---Setting range---
0 to 127

【#3068】 symtm1 Phase synchronization start confirmation time

Set the time to confirm that synchronization is attained before phase synchronization control is started.

When "0" is set, the time will be 0.5 seconds. When "100" or less is set, the time will be 100ms.

---Setting range---
0 to 9999 (ms)

【#3069】 symtm2 Phase synchronization end confirmation time

Set a period of waiting time for phase synchronization control's completion as a time in which the speed stays within the attainment range.

When "0" is set, the time will be 0.5 seconds. When "100" or less is set, the time will be 100ms.

---Setting range---
0 to 9999 (ms)

【#3070】 syprt Phase synchronization speed

Set the amount of speed fluctuation of synchronous spindle during phase synchronization control. Set this as a proportion to commanded speed.

When "0" is set, the amount will be 100%.

---Setting range---
0 to 100 (%)

II Parameters

5. Spindle Parameters

【#3071(PR)】 SscDrSelSp Speed monitor Door selection

Select which door group of the speed monitoring a spindle belongs to.

- 0000: Belong to the door 1 group.
- 0001: Belong to the door 1 group.
- 0002: Belong to the door 2 group.
- 0003: Belong to the door 1 and 2 groups.

(Note) Speed monitoring is not executed when SP229:SFNC9/bitF is "OFF".

---Setting range---
0000 to 0003 (HEX)

【#3072(PR)】 SscSvof Filter Sp Speed monitor Error detection time during servo OFF

Set the error detection time for when an error of command speed monitoring or feedback speed monitoring is detected during servo OFF.
The alarm will occur if actual speed exceeds safe speed or safe rotation speed for a period of time longer than this setting.

When "0" is set, the detection time will be 200 (ms).

---Setting range---
0 to 9999 (ms)

【#3101】 sp_t 1 Time constant for spindle rotation with S command (Gear: 00)

Set the acceleration/deceleration time constant for spindle rotation using the S command (spindle control mode = speed operation mode) with gear 00 (Linear acceleration/deceleration pattern).

---Setting range---
0 to 30000 (ms)

【#3102】 sp_t 2 Time constant for spindle rotation with S command (Gear: 01)

Set the acceleration/deceleration time constant for spindle rotation using the S command (spindle control mode = speed operation mode) with gear 01 (Linear acceleration/deceleration pattern).

---Setting range---
0 to 30000 (ms)

【#3103】 sp_t 3 Time constant for spindle rotation with S command (Gear: 10)

Set the acceleration/deceleration time constant for spindle rotation using the S command (spindle control mode = speed operation mode) with gear 10 (Linear acceleration/deceleration pattern).

---Setting range---
0 to 30000 (ms)

【#3104】 sp_t 4 Time constant for spindle rotation with S command (Gear: 11)

Set the acceleration/deceleration time constant for spindle rotation using the S command (spindle control mode = speed operation mode) with gear 11 (Linear acceleration/deceleration pattern).

---Setting range---
0 to 30000 (ms)

【#3105】 sut Speed reach range

Set the speed deviation rate with respect to the commanded speed, at which the speed reach signal will be output.


---Setting range---
0 to 100 (%)

II Parameters

5. Spindle Parameters

【#3106】 zrn_typ Zero point return specifications

Select the zero point return specification.
Functions are allocated to each bit.
Set this in hexadecimal format.



Bit-F Spindle zero point detection with contactless switch

0: Normal 1: Enable spindle zero point detection using proximity switch

Bit-E Interpolation mode selection in orientation

0: Interpolation mode (Use the interpolation mode gain "SP002 PGN".)
1: Non-interpolation mode (Use the non-interpolation mode gain "SP001 PGV")
Select this when vibration occurs since the gain is too high during the orientation.

Bit-D,C,B

Not used. Set to "0".

Bit-A,9 Spindle/C axis zero point return direction

00: Short-cut 01: Forward run 10: Reverse run

Bit-8 Designate zero point return/deceleration stop of spindle/C axis

0: Zero point return 1: Deceleration stop

Bit-7 Synchronous tapping command polarity

0: Forward direction 1: Reverse direction

Bit-6,5 Synchronous tapping zero point return direction

00: Short-cut 01: Forward run 10: Reverse run

Bit-4 Designate zero point return/deceleration stop in synchronous tapping

0: Zero point return 1: Deceleration stop

Bit-3

Not used. Set to "0".

Bit-2,1 Orientation direction

00: Short-cut 01: Forward run 10: Reverse run

Bit-0 Z phase detection direction

0: Forward direction 1: Reverse direction

【#3107】 ori_spd Orientation command speed

Set the spindle speed during orientation command.

---Setting range---
1 to 99999 (r/min)

【#3108】 ori_sft In-position shift amount for orientation

Set the orientation stop position.

The clockwise direction when viewed from the load side is considered as minus (-).

---Setting range---
-35999 to 35999 (0.01°)

【#3109】 zdetspd Z phase detection speed

When "#3106/bitF = 0" (Normal), set the spindle speed at initial Z phase detection.

When "#3106/bitF = 1" (Spindle zero point proximity switch detection enabled), set the spindle speed at initial spindle zero point proximity switch detection.

(Note) When spindle zero point proximity switch detection is enabled, the rotation direction of the orientation/zero point return (synchronous tapping, spindle/C axis) will follow Z phase detection direction. And the speed will follow Z phase detection speed.

---Setting range---
1 to 99999 (r/min)

【#3110】 tap_spd Synchronous tapping zero point return speed

Set the synchronous tapping zero point return speed.

---Setting range---
1 to 99999 (r/min)

【#3111】 tap_sft Synchronous tapping zero point return shift amount

Set the synchronous tapping zero point return shift amount.

---Setting range---
0.00 to 35999 (0.01°)

II Parameters

5. Spindle Parameters

【#3112】 cax_spd Spindle C axis zero point return speed

Set the spindle C axis zero point return speed.

---Setting range---
1 to 99999 (r/min)

【#3113】 cax_sft Spindle C axis zero point return shift amount

Set the spindle C axis zero point return shift amount

---Setting range---
0.00 to 359999 (0.001°)

【#3114】 cax_para_chg Spindle/C axis parameter switch

Select whether to switch detector's parameters between spindle control and C axis control during spindle/C axis control.

0: Not switch
1: Switch

---Setting range---
0/1 (Standard: 0)

【#3115】 sp2_t1 Time constant in orientation/position loop reference position return (Gear: 00)

Set the acceleration/deceleration time constant to reach the spindle's limit speed (slimt) when spindle rotates in orientation/position loop zero point return method (C axis, tapping) using gear 00 (Linear acceleration/deceleration pattern).

(Note) Set a value that is bigger than the values set by "#3101 sp_t1 - #3104 sp_t4".

---Setting range---
0 to 30000 (ms)

【#3116】 sp2_t2 Time constant in orientation/position loop reference position return (Gear: 01)

Set the acceleration/deceleration time constant to reach the spindle's limit speed (slimt), when spindle rotates in the orientation/position loop zero point return method (C axis, tapping) using gear 01 (Linear acceleration/deceleration pattern).

(Note) Set a value that is bigger than the values set by "#3101 sp_t1 - #3104 sp_t4".

---Setting range---
0 to 30000 (ms)

【#3117】 sp2_t3 Time constant in orientation/position loop reference position return (Gear: 10)

Set the acceleration/deceleration time constant to reach the spindle's limit speed (slimt), when spindle rotates in the orientation/position loop zero point return method (C axis, tapping) using gear 10 (Linear acceleration/deceleration pattern).

(Note) Set a value that is bigger than the values set by "#3101 sp_t1 - #3104 sp_t4".

---Setting range---
0 to 30000 (ms)

【#3118】 sp2_t4 Time constant in orientation/position loop reference position return (Gear: 11)

Set the acceleration/deceleration time constant to reach the spindle's limit speed (slimt), when spindle rotates in the orientation/position loop zero point return method (C axis, tapping) using gear 11 (Linear acceleration/deceleration pattern).

(Note) Set a value that is bigger than the values set by "#3101 sp_t1 - #3104 sp_t4".

---Setting range---
0 to 30000 (ms)

【#3120】 staptr Time constant reduction rate in high-speed synchronous tapping

When performing high-speed synchronous tapping, set the reduction rate of the time constant compared to the time constant in normal synchronous tapping.

(Setting "0" or "100" will be regarded as reduction rate zero, so the time constant won't be reduced.)

E.g.) When set to "10", time constant in high-speed synchronous tapping will be 90% of that in normal synchronous tapping.

---Setting range---
0 to 100(%)

【#3121】 tret Turret indexing

Select the validity of turret indexing.

---Setting range---
0: Invalid
1: Valid

【#3122】 GRC Turret side gear ratio

Set the number of teeth on the turret side when the gear selection command (control input 4/bit6, 5) is set to 00. Set a value of GRC so that the ratio of GRC to the spindle side gear ratio (#13057 SP057) will be 1:N (an integer).

If this parameter is set to "0", it will be regarded as "1".

---Setting range---
0 to 32767

II Parameters

5. Spindle Parameters

【#3123】 tret_spd Turret indexing speed

Set the turret end indexing speed when in turret indexing.
When this parameter is set to 0, the value of Orientation command speed (#3107 ori_spd) will be used for the turret indexing speed.

---Setting range---
0 to 32767(r/min)

【#3124】 tret_t Turret indexing time constant

Set the acceleration/deceleration time constant to reach Limit rotation speed (#3001 slimt) at gear 00 when in turret indexing (linear acceleration/deceleration pattern). Set this parameter to a larger value than #3115 sp2_t1 at gear 00.

---Setting range---
0 to 30000 (ms)

【#3125】 tret_inpos Turret indexing in-position width

Set the position error range in which the index positioning complete signal is output when in turret indexing. When this parameter is set to 0, the value of In-position width (#13024 SP024) will be used for this width.

---Setting range---
0 to 32767(1°/1000)

【#3126】 tret_fin_off Index positioning complete signal OFF time

Set the time to forcibly turn OFF the index positioning complete signal since the indexing start signal turns ON. If this period of time has not passed yet, the index positioning complete signal will not turn ON even at the completion of index positioning.

---Setting range---
0 to 10000 (ms)

【#3127】 SPECSP Spindle specification

bit0: Select the gear changeover method.

0: Gear change type 1
1: Gear change type 2

---Setting range---
0x0000 to 0xffff(hexadecimal)

【#3128】 ori_spec Orientation specification

bit0: Orientation imposition advance output

0: Invalid
1: Valid

---Setting range---
0x0000 to 0xffff (hexadecimal)

【#3129】 cax_spec Spindle/C axis specification

Not used. Set to "0".

【#3130】 syn_spec Spindle synchronization specification

bit0: Tool spindle synchronization II (hobbing) automatic compensation selection

1: Compensate hobbing axis delay (advance) with workpiece axis.
0: No compensation.

【#3131】 tap_spec Synchronous tapping specification

Not used. Set to "0".

【#3132】 ori_inp2 2nd in-position width for orientation

Use this when detecting a different in-position from the normal in-position detection, such as advancing the inposition signal. When using, set a bigger value than the value of the spindle parameter SP024.

---Setting range---
0 to 32767 (1deg/1000)

【#3133】 spherr Hobbing axis delay (advance) allowable angle

Set the allowable angle between the commanded position and actual position of hobbing axis when it is in tool spindle synchronization II (hobbing) mode (X18AE ON), and also when hobbing axis and workpiece axis are synchronizing (X18A9 ON).

---Setting range---
0 to 32767 (1deg/1000)

【#3134】 sphtc Primary delay time constant for hobbing axis automatic compensation

Set the primary delay time constant of hobbing axis automatic compensation primary delay filter control in tool spindle synchronization II (hobbing).
When set to 0, primary delay filter control is invalid.

---Setting range---
0 to 32767 (ms)

II Parameters

5. Spindle Parameters

【#3135】 sfwd_g Feed forward gain for hobbing axis

Set the feed forward gain for the hobbing axis in tool spindle synchronization II (hobbing) mode.

---Setting range---
0 to 200 (%)

【#3137】 stap_ax_off High-speed synchronous tapping disabled axis

Set the high-speed synchronous tapping disabled axis.

bit0 to bit16: High-speed synchronous tapping disabled axis

0: Enabled
1: Disabled

If communication between drive units is disabled for a certain axis, set the axis's bits of all the spindles as disabled.

If communication between drive units is disabled for a certain spindle, set all the bits of the spindle as disabled (0xFFFF).

(Note) Each bit (bit0 -) corresponds to the order of the axis name parameter (#1013 axname) setting.

【#13001】 SP001 PGV Position loop gain Non-interpolation mode

Set the position loop gain for "Non-interpolation" control mode. The standard setting is "33". When the setting value increases, the tracking ability to commands will be higher and the settling time during positioning can be shorter. However, the impact applied on the machine during acceleration/deceleration will increase.

The position loop gain will be selected according to the control mode selection command set with control input 4/bit 2, 1, 0.

Control input 4 bit2, 1, 0 = 000: Non-interpolation
bit 2, 1, 0 = 001: Spindle synchronization
bit 2, 1, 0 = 010: Interpolation
bit 2, 1, 0 = 100: Interpolation

(Note) Control mode is commanded from NC. When carrying out SHG control, set SP035 (SFNC3)/bitC (shgn) or SP036 (SFNC4)/bit4 (shgs) to "1".

---Setting range---
1 to 200 (1/s)

【#13002】 SP002 PGN Position loop gain interpolation mode

Set the position loop gain for "Interpolation" control mode. The standard setting is "33". When the setting value increases, the tracking ability to commands will be higher and the settling time during positioning can be shorter. However, the impact applied on the machine during acceleration/deceleration will increase.

The position loop gain will be selected according to the control mode selection command set with control input 4/bit 2, 1, 0.

Control input 4 bit2, 1, 0 = 000: Non-interpolation
bit 2, 1, 0 = 001: Spindle synchronization
bit 2, 1, 0 = 010: Interpolation
bit 2, 1, 0 = 100: Interpolation

(Note) Control mode is commanded from NC. When carrying out SHG control, set SP035 (SFNC3)/bitC (shgn) or SP036 (SFNC4)/bit4 (shgs) to "1".

---Setting range---
1 to 200 (1/s)

【#13003】 SP003 PGS Position loop gain spindle synchronization

Set the position loop gain for "Spindle synchronization" control mode. The standard setting is "33".

When the setting value increases, the tracking ability to commands will be higher and the settling time during positioning can be shorter. However, the impact applied on the machine during acceleration/deceleration will increase.

The position loop gain can be selected according to the control mode selection command set with control input 4/bit 2, 1, 0.

Control input 4 bit2, 1, 0 = 000: Non-interpolation
bit 2, 1, 0 = 001: Spindle synchronization
bit 2, 1, 0 = 010: Interpolation
bit 2, 1, 0 = 100: Interpolation

(Note) Control mode is commanded from NC. When carrying out SHG control, set SP035 (SFNC3)/bitC (shgn) or SP036 (SFNC4)/bit4 (shgs) to "1".

---Setting range---
1 to 200 (1/s)

【#13004】 SP004

Not used. Set to "0".

【#13005】 SP005 VGN1 Speed loop gain 1

Set the speed loop gain.

Set this according to the load inertia size.

The higher the setting value is, the more accurate the control will be. However, vibration tends to occur.

If vibration occurs, adjust by lowering by 20 - 30%.

The value should be determined to be 70 to 80% of the value at which the vibration stops.

---Setting range---
1 to 9999

II Parameters

5. Spindle Parameters

【#13006】 SP006 VIA1 Speed loop lead compensation 1

Set the speed loop integral control gain.
The standard setting is "1900". Adjust the value by increasing/decreasing by about 100 at a time.

Raise this value to improve contour tracking accuracy in high-speed cutting.
Lower this value when the position droop does not stabilize (10 - 20Hz).

---Setting range---
1 to 9999

【#13007】 SP007 VIL1 Speed loop delay compensation 1

Set this parameter when the limit cycle occurs in the full-closed loop, or overshooting occurs in positioning.

Select the control method with SP033 (SFNC1)/bit1, 0 (vcnt).

Normally, use "Changeover type 2".

When setting this parameter, make sure to set the torque offset "SP050 (TOF)".

When not using, set to "0".

---Setting range---
0 to 32767

【#13008】 SP008 VGN2 Speed loop gain 2

Normally, SP005 (VGN1), SP006 (VIA1) and SP007 (VIL1) are used.

By setting SP035 (SFNC3)/bit1 (vgin), SP035 (SFNC3)/bit9 (vgn) or SP036 (SFNC4)/bit1 (vgs) to "1", Gain 2 can be used according to the application.

Gain 2 can also be used by setting "Speed gain set 2 changeover request (control input 5/bitC)" to "1".

Refer to SP005 (VGN1), SP006 (VIA1) and SP007 (VIL1) for the procedures.

---Setting range---
1 to 9999

【#13009】 SP009 VIA2 Speed loop lead compensation 2

Normally, SP005 (VGN1), SP006 (VIA1) and SP007 (VIL1) are used.

By setting SP035 (SFNC3)/bit1 (vgin), SP035 (SFNC3)/bit9 (vgn) or SP036 (SFNC4)/bit1 (vgs) to "1", Gain 2 can be used according to the application.

Gain 2 can also be used by setting "Speed gain set 2 changeover request (control input 5/bitC)" to "1".

Refer to SP005 (VGN1), SP006 (VIA1) and SP007 (VIL1) for the procedures.

---Setting range---
1 to 9999

【#13010】 SP010 VIL2 Speed loop delay compensation 2

Normally, SP005 (VGN1), SP006 (VIA1) and SP007 (VIL1) are used.

By setting SP035 (SFNC3)/bit1 (vgin), SP035 (SFNC3)/bit9 (vgn) or SP036 (SFNC4)/bit1 (vgs) to "1", Gain 2 can be used according to the application.

Gain 2 can also be used by setting "Speed gain set 2 changeover request (control input 5/bitC)" to "1".

Refer to SP005 (VGN1), SP006 (VIA1) and SP007 (VIL1) for the procedures.

---Setting range---
0 to 32767

【#13011】 SP011

Not used. Set to "0".

【#13012】 SP012

Not used. Set to "0".

【#13013】 SP013

Not used. Set to "0".

【#13014】 SP014 PY1 Minimum excitation rate 1

Set the minimum value for the variable excitation rate. The standard setting is "50".

Set to "0" when using an IPM spindle motor.

If the gear noise, etc., is large, select a small value. However, a larger setting value is more effective for impact response.

(Note) When setting a value "50 or more", check if there is no gear noise, motor excitation noise, vibration during low-speed rotation or vibration when the servo is locked during orientation stop, etc. When setting a value "less than 50", check if there is no problem with the impact load response or rigidity during servo lock.

---Setting range---
0 to 100 (%)

【#13015】 SP015 PY2 Minimum excitation rate 2

Normally, SP014 (PY1) is used.

Excitation rate 2 can be used according to the application by setting SP035 (SFNC3)/bit2 (pyin), SP035 (SFNC3)/bitA (pyn) or SP036 (SFNC4)/bit2 (psy) to "1".

Excitation rate 2 can also be used by setting "Minimum excitation rate 2 changeover request (control input 5/bitB)" to "1". Refer to SP014 (PY1) for the procedures.

Set to "0" when using an IPM spindle motor.

---Setting range---
0 to 100 (%)

II Parameters

5. Spindle Parameters

【#13016】 SP016 DDT Phase alignment deceleration rate

Set the single-rotation position alignment deceleration rate for orientation stopping, phase alignment during rotation and changing from non-interpolation to spindle synchronization mode during rotation.

If the load inertia is large, decrease the setting.

When the setting value increases, the orientation in-position and single-rotation position alignment will end earlier, but the impact applied on the machine will increase.

To change the deceleration rate only during rotation command (command F Δ T \neq 0), set this parameter together with SP070 (KDDT).

---Setting range---


1 to 32767 (0.1 (r/mn)/ms)

【#13017(PR)】 SP017 SPEC1 Spindle specifications 1

Select the spindle specifications.

Functions are allocated to each bit.

Set this in hexadecimal format.



Bit-F,E,D,C spm Motor series selection

0000(0xxxh): 200V specification IM spindle motor 0001(1xxxh): 200V specification IPM spindle motor

0010(2xxxh): 400V specification IM spindle motor 0011(3xxxh): 400V specification IPM spindle motor

Bit-5 - B

Not used. Set to "0".

Bit-4 fdir Position feedback

0: Forward polarity 1: Reverse polarity

Bit-3 vfb Speed feedback filter

0: Disable 1: Enable (2250Hz)

Bit-2 seqh High-speed READY ON sequence

0: Disable 1: Enable

Bit-1

Not used. Set to "0".

Bit-0 fdir2 Speed feedback polarity


0: Forward polarity 1: Reverse polarity

【#13018(PR)】 SP018 SPEC2 Spindle specifications 2

Select the spindle specifications.

Functions are allocated to each bit.

Set this in hexadecimal format.



Bit-F - 9

Not used. Set to "0".

Bit-8 spsu Speed setting unit

0: rev/min 1: x4r/min

Bit-7,6

Not used. Set to "0".

Bit-5 mkch Coil switch function

0: Disable 1: Enable

Bit-4,3,2

Not used. Set to "0".

Bit-1 oplp Open loop

0: Disable 1: Enable

Bit-0

Not used. Set to "0".

【#13019(PR)】 SP019 RNG1 Position detector resolution

Set the same value as SP020 (RNG2).

(Refer to the explanation for SP020.)

---Setting range---

0 to 32767 (kp/rev)

II Parameters

5. Spindle Parameters

【#13020(PR)】 SP020 RNG2 Speed detector resolution

Set the number of pulses per revolution of the motor side detector.

Detector TS5691 (128 teeth): SP020 = 2000
TS5691 (180 teeth): SP020 = 2880
TS5691 (256 teeth): SP020 = 4000
TS5691 (384 teeth): SP020 = 6000
TS5691 (512 teeth): SP020 = 8000

TS5690 (64 teeth): SP020 = 2000
TS5690 (128 teeth): SP020 = 4000
TS5690 (256 teeth): SP020 = 8000

【#13021(PR)】 SP021 OLT Overload detection time constant

Set the detection time constant of the overload 1 (Alarm 50).

Set to "60" as a standard.

Set to "300" when using an IPM spindle motor.

---Setting range---

1 to 15300 (s)

【#13022】 SP022 OLL Overload detection level

Set the current detection level of "Overload 1" (Alarm 50) as a percentage in respect to the motor short-time rated output current.

Set to "120" as a standard.

Set to "100" when using an IPM spindle motor.

---Setting range---

1 to 200 (Short-time rated %)

【#13023】 SP023 OD1 Excessive error detection width (interpolation mode, spindle synchronization)

Set the excessive error detection width for the interpolation mode and spindle synchronization.

Set to "120" as a standard.

If this parameter is set to "0", excessive error detection won't be performed.

---Setting range---

0 to 32767 (°)

【#13024】 SP024 INP In-position width

Set the in-position detection width. Set the positioning accuracy required for the machine. The lower the setting is, the higher the positioning accuracy will be.

However, the cycle time (settling time) will be longer. The standard setting is "875".

---Setting range---

0 to 32767 (1°/1000)

【#13025】 SP025 INP2 2nd in-position width

Use this when detecting an in-position different from normal in-position width, such as advancing the in-position signal. The procedure is the same as SP024 (INP). The standard setting is "875".

---Setting range---

0 to 32767 (°/1000)

【#13026(PR)】 SP026 TSP Maximum motor speed

Set the maximum motor speed. If the actual motor speed exceeds the set maximum speed, an overspeed alarm will occur.

---Setting range---

1 to 32767 (r/min)

【#13027】 SP027 ZSP Motor zero speed

Set the motor speed for detecting zero speed. If the actual motor speed drops below the set speed, the zero speed detection will go ON. The standard setting is "50".

---Setting range---

1 to 1000 (r/min)

【#13028】 SP028 SDTS Speed detection set value

Set the motor speed for detecting the speed. If the actual motor speed drops below the set value, the speed detection will go ON. The standard setting is 10% of the maximum motor speed.

---Setting range---

10 to 32767 (r/min)

【#13029】 SP029 SDTR Speed detection reset width

Set the hysteresis width in which the speed detection changes from ON to OFF. If the setting value is small, the speed detection will chatter easily. The standard setting is "30".

---Setting range---

10 to 1000 (r/min)

【#13030】 SP030

Not used. Set to "0".

【#13031(PR)】 SP031 MTYP Motor type

Set the position detector type, speed detector type and motor type.

Set to "2200" (fixed value).


II Parameters

5. Spindle Parameters

[#13032(PR)] SP032 PTYP Power supply type/ Regenerative resistor type

Power supply type

When connecting a power supply unit, set a code for each power supply unit.



Bit-0 - 7 ptyp External emergency stop setting

When the emergency stop input signal of the power supply unit is "disabled"

Power supply unit is not connected	: 0000h
MDS-D-CV-37 / MDS-DH-CV-37	: 0004h
MDS-D-CV-75 / MDS-DH-CV-75	: 0008h
MDS-D-CV-110 / MDS-DH-CV-110	: 0011h
MDS-D-CV-185 / MDS-DH-CV-185	: 0019h
MDS-D-CV-300 / MDS-DH-CV-300	: 0030h
MDS-D-CV-370 / MDS-DH-CV-370	: 0037h
MDS-D-CV-450 / MDS-DH-CV-450	: 0045h
MDS-D-CV-550	: 0055h
MDS-DH-CV-750	: 0075h

When the emergency stop input signal of the power supply unit is "enabled"

Power supply unit is not connected	: 0000h
MDS-D-CV-37 / MDS-DH-CV-37	: 0044h
MDS-D-CV-75 / MDS-DH-CV-75	: 0048h
MDS-D-CV-110 / MDS-DH-CV-110	: 0051h
MDS-D-CV-185 / MDS-DH-CV-185	: 0059h
MDS-D-CV-300 / MDS-DH-CV-300	: 0070h
MDS-D-CV-370 / MDS-DH-CV-370	: 0077h
MDS-D-CV-450 / MDS-DH-CV-450	: 0085h
MDS-D-CV-550	: 0095h
MDS-DH-CV-750	: 00B5h

- For MDS-DM Series

Set as follows for the spindle drive section of the MDS-DM-SPVx.

Normal	: 0019h
External emergency stop connection	: 0059h

Bit-8 - B rtyp

Not used. Set to "0".


Bit-C - F amp

Not used. Set to "0".

Regenerative resistor type

Set the regenerative resistor type.

(Note) These bits are used only in MDS-D-SVJ3/SPJ3 series.



Bit-0 - 3

Not used. Set to "0".

Bit-4 - 7 emgx External emergency stop function

Set the external emergency stop function. (Do not set a value other than specified.)

0: Disable 4: Enable

Bit-8 - B rtyp

Bit-C - F amp

For "amp = 1"

"rtyp" setting value

- 0: Resistor built-in drive unit
- 1: Setting prohibited
- 2: MR-RB032
- 3: MR-RB12 or GZG200W39OHMK
- 4: MR-RB32 or GZG200W120OHMK 3 units connected in parallel
- 5: MR-RB30 or GZG200W39OHMK 3 units connected in parallel
- 6: MR-RB50 or GZG300W39OHMK 3 units connected in parallel
- 7: MR-RB31 or GZG200W20OHMK 3 units connected in parallel
- 8: MR-RB51 or GZG300W20OHMK 3 units connected in parallel
- 9 - F: Setting prohibited

For "amp = 2"

"rtyp" setting value


- 0 - 3: Setting prohibited
- 4: FCUA-RB22
- 5: FCUA-RB37
- 6: FCUA-RB55
- 7, 8: Setting prohibited
- 9: R-UNIT2
- A - C: Setting prohibited
- D: FCUA-RB75/2 2 units
- E, F: Setting prohibited

II Parameters

5. Spindle Parameters

【#13033】 SP033 SFNC1 Spindle function 1

Select the spindle functions.
Functions are allocated to each bit.
Set this in hexadecimal format.



Bit-F - C

Not used. Set to "0".

Bit-B,A ovs Overshoot compensation

00: Compensation stop 01: Setting prohibited 10: Setting prohibited 11: Compensation type 3

(Note) Set the compensation amount in SP043(OVS1) and SP042(OVS2).

Bit-9,8 lmc Lost motion compensation

00: Compensation stop 01: Setting prohibited 10: Compensation type 2 11: Setting prohibited

(Note) Set the compensation amount in SP048(LMC1) and SP041(LMC2).
When "SP227/lmc3" is set to "1", the lost motion compensation type 3 will be selected regardless of this setting.

Bit-7 lmc2a Lost motion compensation 2 timing

0: Normal timing 1: Timing changed

Bit-6

Not used. Set to "0".

Bit-5,4 vfct Jitter compensation

00: Disable 01: 1 pulse 10: 2 pulse 11: 3 pulse

Bit-3,2

Not used. Set to "0".

Bit-1,0 vcnt Delay compensation changeover

00: Disable 01: Changeover type 1 10: Changeover type 2 11: Changeover type 2


- For MDS-DM Series
Not used. Set to "0".

II Parameters

5. Spindle Parameters

#13034 SP034 SFNC2 Spindle function 2

Select the spindle functions.
Functions are allocated to each bit.
Set this in hexadecimal format.



Bit-F,E,D nfd5 Depth of Notch filter 5

Set the filter depth of Notch filter 5.

Bit F,E,D=000: -∞	Bit F,E,D=001: -18[dB]
Bit F,E,D=010: -12[dB]	Bit F,E,D=011: -9[dB]
Bit F,E,D=100: -6[dB]	Bit F,E,D=101: -4[dB]
Bit F,E,D=110: -3[dB]	Bit F,E,D=111: -1 [dB]

Bit-C

Not used. Set to "0".

Bit-B,A,9 nfd4 Depth of Notch filter 4

Set the filter depth of Notch filter 4.

Bit B,A,9=000: -∞	Bit B,A,9=001: -18[dB]
Bit B,A,9=010: -12[dB]	Bit B,A,9=011: -9[dB]
Bit B,A,9=100: -6[dB]	Bit B,A,9=101: -4[dB]
Bit B,A,9=110: -3[dB]	Bit B,A,9=111: -1 [dB]

Bit-8 pwm Current control

0: Standard current control 1: High frequency current control

- For MDS-DM Series
Not used. Set to "0".

Bit-7,6,5 nfd2 Depth of Notch filter 2

Set the filter depth of Notch filter 2.

Bit 7,6,5=000: -∞	Bit 7,6,5=001: -18[dB]
Bit 7,6,5=010: -12[dB]	Bit 7,6,5=011: -9[dB]
Bit 7,6,5=100: -6[dB]	Bit 7,6,5=101: -4[dB]
Bit 7,6,5=110: -3[dB]	Bit 7,6,5=111: -1 [dB]

Bit-4 nfd3 Notch filter 3(1125Hz)

0: Stop 1: Start

Bit-3,2,1 nfd1 Depth of Notch filter 1

Set the filter depth of Notch filter 1.

Bit 3,2,1=000: -∞	Bit 3,2,1=001: -18[dB]
Bit 3,2,1=010: -12[dB]	Bit 3,2,1=011: -9[dB]
Bit 3,2,1=100: -6[dB]	Bit 3,2,1=101: -4[dB]
Bit 3,2,1=110: -3[dB]	Bit 3,2,1=111: -1 [dB]

Bit-0 zck Z phase check (ALM42)


0: Enable 1: Disable

II Parameters

5. Spindle Parameters

【#13035(PR)】 SP035 SFNC3 Spindle function 3

Select the spindle functions.
Functions are allocated to each bit.
Set this in hexadecimal format.



bit-F - D

Not used. Set to "0".

bit-C shgn SHG control

0: Stop 1: Start

bit-B

Not used. Set to "0".

bit-A pyn Excitation rate selection

0: Select Excitation rate 1 1: Select Excitation rate 2

bit-9 vgn Speed loop gain set selection

0: Select Set 1 1: Select Set 2

bit-8

Not used. Set to "0".

bit-7 nopc Phase alignment

0: Start 1: Stop

bit-6 - 3

Not used. Set to "0".

bit-2 pyin Excitation rate selection

0: Select Excitation rate 1 1: Select Excitation rate 2

bit-1 vgin Speed loop gain set selection


0: Select Set 1 1: Select Set 2

bit-0

Not used. Set to "0".

【#13036(PR)】 SP036 SFNC4 Spindle function 4

Select the spindle functions.
Functions are allocated to each bit.
Set this in hexadecimal format.



bit-F - 8

Not used. Set to "0".

bit-7 mksl Spindle coil selection

0: Select the coil commanded during synchronization 1: Select high-speed coil

bit-6,5

Not used. Set to "0".

bit-4 shgs SHG control

0: Stop 1: Start

bit-3

Not used. Set to "0".

bit-2 pys Excitation rate selection

0: Select Excitation rate 1 1: Select Excitation rate 2

bit-1 vgs Speed loop gain set selection

0: Select Gain set 1 1: Select Gain set 2

bit-0

Not used. Set to "0".

II Parameters

5. Spindle Parameters

【#13037】 SP037 JL Load inertia scale

Set "the motor inertia + motor axis conversion load inertia" in respect to the motor inertia.
 $SP037(JL) = (J_m + J_l / J_m) \times 100$
J_m : Motor inertia
J_l : Motor axis conversion load inertia
---Setting range---
0 to 5000 (%)

【#13038】 SP038 FHZ1 Notch filter frequency 1

Set the vibration frequency to suppress when machine vibration occurs.
(Enabled at 50 or more) When not using, set to "0".
---Setting range---
0 to 2250 (Hz)

【#13039】 SP039 LMCD Lost motion compensation timing

Set this parameter when the lost motion compensation timing does not match.
Adjust by increasing the value by 10 at a time.
---Setting range---
0 to 2000 (ms)

【#13040】 SP040 LMCT Lost motion compensation non-sensitive band

Set the non-sensitive band of the lost motion compensation in the feed forward control.
When "0" is set, the actual value to be set is 2°/1000. Adjust by increasing by 1°/1000 at a time.
---Setting range---
- 32768 to 32767 (1°/1000)

【#13041】 SP041 LMC2 Lost motion compensation 2

Set this parameter as well as SP048 (LMC1) only when you wish to vary the lost motion compensation amount depending on the command directions.
Normally set to "0".
---Setting range---
-1 to 200 (Short-time rated %)
Note that the range will be "-1 - 20000" (Short-time rated 0.01%) when SP227/bit2 is "1".

【#13042】 SP042 OVS2 Overshooting compensation 2

Set this parameter as well as SP043 (OVS1) only when you wish to vary the overshooting compensation amount depending on the command directions.
Normally set to "0".
---Setting range---
-1 to 100 (Short-time rated %)
Note that the range will be "-1 - 10000" (Short-time rated 0.01%) when SP227/bit2 is "1".

【#13043】 SP043 OVS1 Overshooting compensation 1

Set this parameter when overshooting occurs during positioning. This compensates the motor torque during positioning.
This is enabled only when the overshooting compensation SP033 (SFNC1/ovs) is selected.
Type 3: When "SP033 (SFNC1)/bitB, A (ovs) = 11"
Set the compensation amount based on the motor short-time rated current.
Increase in increments of 1%, and find the value where overshooting does not occur.
Other than Type 3: When "SP033 (SFNC1)/bitB, A (ovs) ¼ 11"
Overshooting compensation (Type 3) is not executed.
When you wish to vary compensation amount depending on the direction
When SP042 (OVS2) is "0", compensate with the value of SP043 (OVS1) in both of the + and - directions.
If you wish to change the compensation amount depending on the command direction, set this parameter as well as SP042 (OVS2).
(SP043: + direction, SV042: - direction. However, the directions may be opposite depending on other settings.)
When "-1" is set, the compensation won't be performed in the direction of the command.
---Setting range---
-1 to 100 (Short-time rated %)
Note that the range will be "-1 - 10000" (Short-time rated 0.01%) when SP227/bit2 is "1".

【#13044】 SP044 OBS2 Disturbance observer gain

Set the disturbance observer gain. The standard setting is "100".
To use the disturbance observer, also set SP037 (JL) and SP045 (OBS1).
When not using, set to "0".
---Setting range---
0 to 500 (%)

【#13045】 SP045 OBS1 Disturbance observer filter frequency

Set the disturbance observer filter band.
Normally set to "100".
To use the disturbance observer, also set SP037 (JL) and SP044 (OBS2). When not using, set to "0".
---Setting range---
0 to 1000 (rad/s)

II Parameters

5. Spindle Parameters

【#13046】 SP046 FHz2 Notch filter frequency 2

Set the vibration frequency to suppress when machine vibration occurs.
(Enabled at 50 or more) When not using, set to "0".

---Setting range---
0 to 2250 (Hz)

【#13047】 SP047 EC Inductive voltage compensation gain

Set the inductive voltage compensation gain. Normally set to "100".
If the current FB peak exceeds the current command peak, lower the gain.

---Setting range---
0 to 200 (%)

【#13048】 SP048 LMC1 Lost motion compensation 1

Set this parameter when the protrusion (that occurs due to the non-sensitive band by friction, torsion, backlash, etc) at quadrant change is too large.
This compensates the torque at quadrant change.
This is enabled only when the lost motion compensation SP033 (SFNC1/lmc) is selected.

Type 2: When "SP033 (SFNC1)/bit9, 8 (lmc) = 10"

Set the compensation amount based on the motor short-time rated current.

The standard setting is double the friction torque. The compensation amount will be 0 when "0" is set.

Other than type 2: When "SP033 (SFNC1)/bit9, 8 (lmc) $\frac{1}{4}$ 10"

Lost motion compensation (Type 2) is not executed.

When you wish to vary compensation amount depending on the direction

When SP041 (LMC2) is "0", compensate with the value of SP048 (LMC1) in both of the + and - directions.

If you wish to change the compensation amount depending on the command direction, set this parameter as well as SP041 (LMC2).

(SP048: + direction, SP041: - direction. However, the directions may be opposite depending on other settings.)

When "-1" is set, the compensation won't be performed in the direction of the command.

---Setting range---

-1 to 200 (Short-time rated %)

Note that the range will be "-1 - 20000" (Short-time rated 0.01%) when SP227/bit2 is "1".

【#13049】 SP049 FFC Acceleration rate feed forward gain

When a relative error during synchronization control is too large, set this parameter to the axis that is delaying.

The standard setting value is "0". The standard setting for the SHG control is "100".

To adjust a relative error in acceleration/deceleration, increase the value by 50 - 100 at a time.

---Setting range---
0 to 999 (%)

【#13050】 SP050 TOF Torque offset

Set the unbalance torque.

---Setting range---
-100 to 100 (Short-time rated %)

【#13051】 SP051

Not used. Set to "0".

【#13052】 SP052

Not used. Set to "0".

【#13053】 SP053 ODS Excessive error detection width (non-interpolation mode)

Set the excessive error detection width for the non-interpolation mode.

Standard setting value: ODS = Maximum motor speed [r/min]x60/PGV/2

If this parameter is set to "0", excessive error detection won't be performed.

---Setting range---
0 to 32767 (°)

【#13054】 SP054

Not used. Set to "0".

【#13055】 SP055 EMGx Max. gate off delay time after emergency stop

Set a period of time from the point when the emergency stop is input to the point when READY OFF is compulsorily executed.

Normally, set the same value as the absolute value of SP056.

When "0" is set, READY OFF is compulsorily executed after "7000ms".

---Setting range---
0 to 20000 (ms)

【#13056】 SP056 EMGt Deceleration time constant at emergency stop

Set the time constant used for deceleration control during emergency stop. Set the time to stop from the maximum motor speed (TSP).

When "0" is set, the deceleration control is executed with "7000ms".

---Setting range---
-20000 to 20000 (ms)

II Parameters

5. Spindle Parameters

【#13057(PR)】 SP057 GRA1 Spindle side gear ratio 1

Set the number of teeth on the spindle side when the gear selection command (control input 4/bit6, 5) is set to "00".

---Setting range---
1 to 32767

【#13058(PR)】 SP058 GRA2 Spindle side gear ratio 2

Set the number of teeth on the spindle side when the gear selection command (control input 4/bit6, 5) is set to "01".

---Setting range---
1 to 32767

【#13059(PR)】 SP059 GRA3 Spindle side gear ratio 3

Set the number of teeth on the spindle side when the gear selection command (control input 4/bit6, 5) is set to "10".

---Setting range---
1 to 32767

【#13060(PR)】 SP060 GRA4 Spindle side gear ratio 4

Set the number of teeth on the spindle side when the gear selection command (control input 4/bit6, 5) is set to "11".

---Setting range---
1 to 32767

【#13061(PR)】 SP061 GRB1 Motor side gear ratio 1

Set the number of teeth on the motor side when the gear selection command (control input 4/bit6, 5) is set to "00".

---Setting range---
1 to 32767

【#13062(PR)】 SP062 GRB2 Motor side gear ratio 2

Set the number of teeth on the motor side when the gear selection command (control input 4/bit6, 5) is set to "01".

---Setting range---
1 to 32767

【#13063(PR)】 SP063 GRB3 Motor side gear ratio 3

Set the number of teeth on the motor side when the gear selection command (control input 4/bit6, 5) is set to "10".

---Setting range---
1 to 32767

【#13064(PR)】 SP064 GRB4 Motor side gear ratio 4

Set the number of teeth on the motor side when the gear selection command (control input 4/bit6, 5) is set to "11".

---Setting range---
1 to 32767

【#13065】 SP065 TLM1 Torque limit 1

Set the torque limit value when the torque limit (control input 1/bitA, 9, 8) is set to "001".

---Setting range---
0 to 999 (Short-time rated %)

【#13066】 SP066 TLM2 Torque limit 2

Set the torque limit value when the torque limit (control input 1/bitA, 9, 8) is set to "010".

---Setting range---
0 to 999 (Short-time rated %)

【#13067】 SP067 TLM3 Torque limit 3

Set the torque limit value when the torque limit (control input 1/bitA, 9, 8) is set to "011".

---Setting range---
0 to 999 (Short-time rated %)

【#13068】 SP068 TLM4 Torque limit 4

Set the torque limit value when the torque limit (control input 1/bitA, 9, 8) is set to "100".

---Setting range---
0 to 999 (Short-time rated %)

【#13069】 SP069 PCMP Phase alignment completion width

Set the single-rotation position alignment completion width for phase alignment and changing from non-interpolation to spindle synchronization mode during rotation. Set the rotation error that is required for machine. When the setting value decreases, the rotation error will also decrease, but the cycle time (settling time) will increase. The standard setting is "875".

---Setting range---
0 to 32767 (1°/1000)

II Parameters

5. Spindle Parameters

【#13070】 SP070 KDDT Phase alignment deceleration rate scale

Set the scale for SP016 (DDT) when you wish to change the deceleration rate only during rotation command (command $F\Delta T\frac{1}{4}0$).

When the setting value increases, the single-rotation position alignment will be completed earlier, but the impact applied on the machine will also increase. Set to "0" when not using this function.


---Setting range---
0 to 255 (1/16-fold)

【#13071】 SP071 DIQM Variable current limit during deceleration, lower limit value

Set this parameter to adjust the deceleration time by changing the current limit value during deceleration according to the motor speed.

As shown below, set the lower limit rate of the current limit in SP071 (DIQM), and use this together with SP072 (DIQN).

When DIQM is set to 100%, the current limit value for deceleration (TMRL) set in the motor constants will be applied.




---Setting range---
0 to 999 (%)

【#13072】 SP072 DIQN Variable current limit during deceleration, break point speed

Set this parameter to adjust the deceleration time by changing the current limit value during deceleration according to the motor speed.

As shown below, set the lower limit rate of the current limit in SP071 (DIQM), and use this together with SP072 (DIQN).

When DIQM is set to 100%, the current limit value for deceleration (TMRL) set in the motor constants will be applied.



---Setting range---
1 to 32767 (r/min)

【#13073】 SP073 VGVN Variable speed gain target value


If noise is bothersome during high-speed rotation, this noise can be reduced by lowering the speed loop gain at high speeds.

As shown below, set the speed loop gain rate for the overspeed detection speed in SP073 (VGVN), and use this together with SP074 (VGVS).

Set to "0" when not using this function.

The overspeed detection speed (VLMT) is 115% of the maximum motor speed (TSP).

This function can be used when either VGN1 or VGN2 is selected.



---Setting range---
0 to 100 (%)

【#13074】 SP074 VGVS Variable speed gain change start speed


If noise is bothersome during high-speed rotation, this noise can be reduced by lowering the speed loop gain at high speeds.

As shown below, set the speed loop gain rate for the overspeed detection speed in SP073 (VGVN), and use this together with SP074 (VGVS).

Set to "0" when not using this function.

The overspeed detection speed (VLMT) is 115% of the maximum motor speed (TSP).

This function can be used when either VGN1 or VGN2 is selected.



---Setting range---
0 to 32767 (r/min)

II Parameters

5. Spindle Parameters

【#13075】 SP075 DWSH Slip compensation scale during regeneration High-speed coil

Set the slip frequency scale for deceleration.
Normally, set this to "0".

---Setting range---
0 - 255 (1/16-fold)

【#13076】 SP076 DWSL Slip compensation scale during regeneration Low-speed coil

Set the slip frequency scale at deceleration when using the low-speed coil.
Normally, set this to "0".

---Setting range---
0 to 255 (1/16-fold)

【#13077】 SP077 IQA Q axis current advance compensation

Set the current loop gain.
When using coil switch function, set the current loop gain for when the high-speed coil is selected.
The setting value is determined by the motor's electrical characteristics, so the value is fixed by the motor used.
Set the value given in the spindle parameter list.

---Setting range---
1 to 20480

【#13078】 SP078 IDA D axis current advance compensation

Set the current loop gain.
When using coil switch function, set the current loop gain for when the high-speed coil is selected.
The setting value is determined by the motor's electrical characteristics, so the value is fixed by the motor used.
Set the value given in the spindle parameter list.

---Setting range---
1 to 20480

【#13079】 SP079 IQG Q axis current gain

Set the current loop gain.
When using coil switch function, set the current loop gain for when the high-speed coil is selected.
The setting value is determined by the motor's electrical characteristics, so the value is fixed by the motor used.
Set the value given in the spindle parameter list.

---Setting range---
1 to 8192

【#13080】 SP080 IDG D axis current gain

Set the current loop gain.
When using coil switch function, set the current loop gain for when the high-speed coil is selected.
The setting value is determined by the motor's electrical characteristics, so the value is fixed by the motor used.
Set the value given in the spindle parameter list.

---Setting range---
1 to 8192

【#13081】 SP081 IQAL Q axis current advance compensation Low-speed coil

When using coil switch function, set the current loop gain for when the low-speed coil is selected.
The setting value is determined by the motor's electrical characteristics, so the value is fixed by the motor used.
Set the value given in the spindle parameter list.

---Setting range---
1 to 20480

【#13082】 SP082 IDAL D axis current advance compensation Low-speed coil

When using coil switch function, set the current loop gain for when the low-speed coil is selected.
The setting value is determined by the motor's electrical characteristics, so the value is fixed by the motor used.
Set the value given in the spindle parameter list.

---Setting range---
1 to 20480

【#13083】 SP083 IQGL Q axis current gain Low-speed coil

When using coil switch function, set the current loop gain for when the low-speed coil is selected.
The setting value is determined by the motor's electrical characteristics, so the value is fixed by the motor used.
Set the value given in the spindle parameter list.

---Setting range---
1 to 8192

II Parameters

5. Spindle Parameters

【#13084】 SP084 IDGL D axis current gain Low-speed coil

When using coil switch function, set the current loop gain for when the low-speed coil is selected.
The setting value is determined by the motor's electrical characteristics, so the value is fixed by the motor used.
Set the value given in the spindle parameter list.

---Setting range---
1 to 8192

【#13085】 SP085

Not used. Set to "0".

【#13086】 SP086

Not used. Set to "0".

【#13087】 SP087 FHz4 Notch filter frequency 4

Set the vibration frequency to suppress if machine vibration occurs.
(Enabled at 50 or more)
When not using, set to "0".

---Setting range---
0 to 2250 (Hz)

【#13088】 SP088 FHz5 Notch filter frequency 5

Set the vibration frequency to suppress if machine vibration occurs .
(Enabled at 50 or more)
When not using, set to "0".

---Setting range---
0 to 2250 (Hz)

【#13089】 SP089

Not used. Set to "0".

【#13090】 SP090

Not used. Set to "0".

【#13091】 SP091

Not used. Set to "0".

【#13092】 SP092

Not used. Set to "0".

【#13093】 SP093

Not used. Set to "0".

【#13094】 SP094

Not used. Set to "0".

【#13095】 SP095

Not used. Set to "0".

【#13096】 SP096

Not used. Set to "0".

【#13097】 SP097

Not used. Set to "0".

【#13098】 SP098

Not used. Set to "0".

【#13099】 SP099

Not used. Set to "0".

【#13100】 SP100

Not used. Set to "0".

【#13101】 SP101

Not used. Set to "0".

【#13102】 SP102

Not used. Set to "0".

【#13103】 SP103

Not used. Set to "0".

【#13104】 SP104

Not used. Set to "0".

II Parameters

5. Spindle Parameters

【#13105】 SP105

Not used. Set to "0".

【#13106】 SP106

Not used. Set to "0".

【#13107】 SP107

Not used. Set to "0".

【#13108】 SP108

Not used. Set to "0".

【#13109】 SP109

Not used. Set to "0".

【#13110】 SP110

Not used. Set to "0".

【#13111】 SP111

Not used. Set to "0".

【#13112】 SP112

Not used. Set to "0".

【#13113】 SP113 OPLP Current command value for open loop

Set the current command value for when open loop control is enabled.
When "0" is set, the state will be the same as when "50" is set.
Set to "0" when not using this function.
Open loop control is enabled when SP018 (SPEC2)/bit1 (opl) is set to "1".

---Setting range---
0 to 999 (Short-time rated %)

【#13114】 SP114 MKT Coil changeover gate cutoff timer

Set the time to cut off the gate when turning the coil switch contactor OFF and ON.
Set a value longer than the coil switch contactor's OFF/ON time.
The standard setting is "150".

---Setting range---
0 to 3500 (ms)

【#13115】 SP115 MKT2 Coil changeover current limit timer

Set the time to limit the current immediately after the coil switch contactor ON/OFF is completed and the gate is turned ON.
The standard setting is "25".

---Setting range---
0 to 3500 (ms)

【#13116】 SP116 MKIL Coil changeover current limit value

Set the time to limit the current immediately after the coil switch contactor ON/OFF is completed and the gate is turned ON.
The standard setting is "120".

---Setting range---
0 to 999 (Short-time rated %)

【#13117】 SP117 SETM Excessive speed deviation timer

Set the time to detect the speed excessive error alarm.
Set the time required for the machine.
The standard setting is "12".

---Setting range---
0 to 60 (s)

【#13118】 SP118

Not used. Set to "0".

【#13119】 SP119

Not used. Set to "0".

【#13120】 SP120

Not used. Set to "0".

【#13121】 SP121 MP Kpp Magnetic pole detection position loop gain

Set the position loop gain for the magnetic polar detection loop.
This is used for the initial magnetic polar detection when the IPM spindle motor is turned ON.
Set to "0" when using an IM spindle motor.

---Setting range---
0 to 32767

II Parameters

5. Spindle Parameters

【#13122】 SP122 MP Kvp Magnetic pole detection speed loop gain

Set the speed loop gain for the magnetic polar detection loop.
This is used for the initial magnetic polar detection when the IPM spindle motor is turned ON.

Set to "0" when using an IM spindle motor.

---Setting range---
0 to 32767

【#13123】 SP123 MP Kvi Magnetic pole detection speed loop advance compensation

Set the speed loop advance compensation for the magnetic polar detection loop.
This is used for the initial magnetic polar detection when the IPM spindle motor is turned ON.

Set to "0" when using an IM spindle motor.

---Setting range---
0 to 32767

【#13124】 SP124 ILMTsp Magnetic pole detection current limit value

Set the current limit value for the magnetic polar detection loop.
This is used for the initial magnetic polar detection when the IPM spindle motor is turned ON.

Set to "0" when using an IM spindle motor.

---Setting range---
0 to 999 (Short-time rated %)

【#13125】 SP125 DA1NO D/A output channel 1 data No.

Set the data No. you wish to output to D/A output channel.

---Setting range---
-1 - 3, 50, 60 or 127

【#13126】 SP126 DA2NO D/A output channel 2 data No.

Set the data No. you wish to output to D/A output channel.

---Setting range---
-1 - 3, 50, 60 or 127

【#13127】 SP127 DA1MPY D/A output channel 1 output scale

Set the output scale in increments of 1/100.
When "0" is set, the scale will be the same as when "100" is set.

---Setting range---
-32768 to 32767 (1/100-fold)

【#13128】 SP128 DA2MPY D/A output channel 2 output scale

Set the output scale in increments of 1/100.
When "0" is set, the scale will be the same as when "100" is set.

---Setting range---
-32768 to 32767 (1/100-fold)

【#13129(PR)】 SP129

Set the unique constants for the spindle motor. (High-speed coil)
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13130(PR)】 SP130

Set the unique constants for the spindle motor. (High-speed coil)
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13131(PR)】 SP131

Set the unique constants for the spindle motor. (High-speed coil)
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13132(PR)】 SP132

Set the unique constants for the spindle motor. (High-speed coil)
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13133(PR)】 SP133

Set the unique constants for the spindle motor. (High-speed coil)
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13134(PR)】 SP134

Set the unique constants for the spindle motor. (High-speed coil)
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13135(PR)】 SP135

Set the unique constants for the spindle motor. (High-speed coil)
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

II Parameters

5. Spindle Parameters

【#13185(PR)】 SP185

Set the unique constants for the spindle motor (Low-speed coil).
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13186(PR)】 SP186

Set the unique constants for the spindle motor (Low-speed coil).
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13187(PR)】 SP187

Set the unique constants for the spindle motor (Low-speed coil).
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13188(PR)】 SP188

Set the unique constants for the spindle motor (Low-speed coil).
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13189(PR)】 SP189

Set the unique constants for the spindle motor (Low-speed coil).
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13190(PR)】 SP190

Set the unique constants for the spindle motor (Low-speed coil).
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13191(PR)】 SP191

Set the unique constants for the spindle motor (Low-speed coil).
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13192(PR)】 SP192

Set the unique constants for the spindle motor (Low-speed coil).
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

【#13193】 SP193

Not used. Set to "0".

【#13194】 SP194

Not used. Set to "0".

【#13195】 SP195

Not used. Set to "0".

【#13196】 SP196

Not used. Set to "0".

【#13197】 SP197

Not used. Set to "0".

【#13198】 SP198

Not used. Set to "0".

【#13199】 SP199

Not used. Set to "0".

【#13200】 SP200

Not used. Set to "0".

【#13201】 SP201

Not used. Set to "0".

【#13202】 SP202

Not used. Set to "0".

【#13203】 SP203

Not used. Set to "0".

【#13204】 SP204

Not used. Set to "0".

【#13205】 SP205

Not used. Set to "0".

II Parameters

5. Spindle Parameters

【#13206】 SP206

Not used. Set to "0".

【#13207】 SP207

Not used. Set to "0".

【#13208】 SP208

Not used. Set to "0".

【#13209】 SP209

Not used. Set to "0".

【#13210】 SP210

Not used. Set to "0".

【#13211】 SP211

Not used. Set to "0".

【#13212】 SP212

Not used. Set to "0".

【#13213】 SP213

Not used. Set to "0".

【#13214】 SP214

Not used. Set to "0".

【#13215】 SP215

Not used. Set to "0".

【#13216】 SP216

Not used. Set to "0".

【#13217】 SP217

Not used. Set to "0".

【#13218】 SP218

Not used. Set to "0".

【#13219】 SP219

Not used. Set to "0".

【#13220】 SP220

Not used. Set to "0".

【#13221】 SP221

Not used. Set to "0".

【#13222】 SP222

Not used. Set to "0".

【#13223】 SP223

Not used. Set to "0".

【#13224】 SP224


Not used. Set to "0".

II Parameters

5. Spindle Parameters

【#13225】 SP225 SFNC5 Spindle function 5

Select the spindle functions.
Functions are allocated to each bit.
Set this in hexadecimal format.



Bit-F,E,D,C ovsn Overshooting compensation type 3 non-sensitive band

Set the non-sensitive band for overshooting compensation type 3 in increments of $2^2/1000$.
When using feed forward control, set the non-sensitive band for the model position droop and ignore the model overshooting. Set to "2"/1000" as a standard.

Bit-B - 6

Not used. Set to "0".

Bit-5 ddir Proximity switch signal enable edge

0: Falling edge 1: Rising edge

Bit-4 - 0


Not used. Set to "0".

【#13226】 SP226

Not used. Set to "0".

【#13227】 SP227 SFNC7 Servo function 7

Select the spindle functions.
Functions are allocated to each bit.
Set this in hexadecimal format.



Bit-F,E,D,C dis Digital signal input selection

0: No signal 1: Safety observation function door state signal 4: Proximity switch signal detection

Bit-B - 3

Not used. Set to "0".

Bit-2 ccu Lost motion/overshoot compensation compensation amount setting unit


0: Short-time rated % 1: Short-time rated 0.01%

Bit-1,0

Not used. Set to "0".

【#13228】 SP228 SFNC8 Spindle function 8

Select the spindle functions.
Functions are allocated to each bit.
Set this in hexadecimal format.



Bit-F - 1

Not used. Set to "0".

Bit-0 irms Meter display


0: Display normal load meter 1: Display effective motor current

II Parameters

5. Spindle Parameters

【#13229】 SP229 SFNC9 Spindle function 9

Select the spindle functions.
Functions are allocated to each bit.
Set this in hexadecimal format.



Bit-F ssc Safety observation function

0: Stop 1: Start

Bit-E

Not used. Set to "0".

Bit-D rps Safety observation speed setting unit

0: %/min 1: 100%/min

Bit-C - 0

Not used. Set to "0".

【#13230】 SP230

Not used. Set to "0".

【#13231】 SP231

Not used. Set to "0".

【#13232】 SP232

Not used. Set to "0".

【#13233】 SP233 IVC Voltage non-sensitive band compensation

When "100%" is set, the voltage equivalent to the logical non-energized time will be compensated.

When "0" is set, 100% compensation will be performed.
Adjust in increments of 10% from the default value 100%.

If the value is too large, vibration or vibration noise may be generated.

---Setting range---
0 to 255 (%)

【#13234】 SP234

Not used. Set to "0".

【#13235】 SP235

Not used. Set to "0".

【#13236】 SP236

Not used. Set to "0".

【#13237(PR)】 SP237 TCF Torque command filter

Set the filter for the torque command. Set to "0" when not using this function.

The standard value is "500" when using the motor side detector TS5690 or TS5691.

---Setting range---
0 to 4500 (Hz)

【#13238】 SP238 SSCFEED Safety observation safety speed

Set to "0" when not using this function.

---Setting range---
0 to 18000 (°/min)

【#13239】 SP239 SSCRPM Safety observation safety motor speed

Set the motor's safety speed for the safety observation function.

Set to "0" when not using this function.

---Setting range---
0 to 32767 (r/min)

【#13240(PR)】 SP240

Not used. Set to "0".

【#13241(PR)】 SP241

This is automatically set by the NC system.

【#13242(PR)】 SP242

This is automatically set by the NC system.

【#13243(PR)】 SP243

This is automatically set by the NC system.

【#13244(PR)】 SP244

This is automatically set by the NC system.

II Parameters

5. Spindle Parameters

【#13245(PR)】 SP245

This is automatically set by the NC system.

【#13246(PR)】 SP246

This is automatically set by the NC system.

【#13247(PR)】 SP247

This is automatically set by the NC system.

【#13248(PR)】 SP248

This is automatically set by the NC system.

【#13249(PR)】 SP249

This is automatically set by the NC system.

【#13250(PR)】 SP250

This is automatically set by the NC system.

【#13251(PR)】 SP251

This is automatically set by the NC system.

【#13252(PR)】 SP252

This is automatically set by the NC system.

【#13253(PR)】 SP253

This is automatically set by the NC system.

【#13254(PR)】 SP254

This is automatically set by the NC system.

【#13255(PR)】 SP255

This is automatically set by the NC system.

【#13256(PR)】 SP256

This is automatically set by the NC system.

6. Rotary Axis Configuration Parameters

【#7900(PR)】 RCDAX_I Orthogonal coordinate horizontal axis name

Set the name of the horizontal axis in the orthogonal coordinate system.

---Setting range---

A,B,C,U,V,W,X,Y,Z

【#7901(PR)】 RCDAX_J Orthogonal coordinate vertical axis name

Set the name of the vertical axis in the orthogonal coordinate system.

---Setting range---

A,B,C,U,V,W,X,Y,Z

【#7902(PR)】 RCDAX_K Orthogonal coordinate height axis name

Set the name of the height axis in the orthogonal coordinate system.

---Setting range---

A,B,C,U,V,W,X,Y,Z

【#7903】 G92_CRD Origin zero set coordinate selection

Select the coordinate to preset when issuing an origin zero command (G92X_Y_Z_).

0: Tool center coordinate

1: Holder center coordinate

【#7904】 NO_TIP Tool handle feed function selection

Select whether to enable the tool handle feed.

0: Enable (tool handle feed)

1: Disable (standard)

【#7905】 NO_ABS Selection of tool axis travel amount display at manual ABS switch ON/OFF

Select how to update the display of tool axis travel amount.

0: Update at ABS switch OFF

1: Update at every ON and OFF of ABS switch

【#7906】 PASSTYP Singular point passage type

Select the movement after passing a singular point.

0: Type 1

A/B axis rotation angle will be in the same sign direction as that when the tool center point control started.

1: Type 2

C axis rotation amount on the singular point will be smaller.

【#7907】 CHK_ANG Near singular judgment angle

Set the angle for judging a position near the singular point.

---Setting range---

0.000 to 5.000 (°)

【#7908】 SLCT_PRG_COORD Programming coordinate system selection

Select the coordinate system for the programming coordinate.

0: Table coordinate system

1: Workpiece coordinate system (coordinate system that rotates together with workpiece)

【#7909】 IJK_VEC_MR Posture vector mirror image selection

Select whether to enable the mirror image on the posture vector (IJK) when Type 2 is selected in "#7906 PASSTYP".

0: Disable

1: Enable

【#7910】 SLCT_INT_MODE Interpolation method selection

Select the interpolation method.

0: Joint interpolation method

1: Single axis rotation interpolation method

【#7911】 SLCT_STANDARD_POS Rotary axis basic position selection

Select the basic position of the rotary axis.

0: Workpiece coordinate zero point

1: The position when the tool center point is commanded.

(Note) Even if the position is changed, it is not changed during tool center point control. It is changed when next tool center point control will be commanded.

【#7913】 MCHN_SPEED_CTRL Machine speed fluctuation suppression

Select whether to suppress the machine speed fluctuation due to rotary axis movement.

0: Suppress

1: Do not suppress

II Parameters

6. Rotary Axis Configuration Parameters

【#7920(PR)】 SLCT_T1 Rotary axis selection

Select in which axis direction to rotate the tool rotating type base-side rotary axis.
If the tool axis is inclined, use the second digit to set the axis direction in which the tool axis is inclined.

- 0: Invalid
- 1: I axis rotation
- 2: J axis rotation
- 3: K axis rotation

(Note) 0 to 99 can be set from the screen, but if an invalid value is set, the operation error "M01 0127 Rot axis parameter error" will occur when the power supply is turned ON.

---Setting range---

- 0 to 3
- 12, 13, 21, 23, 31, 32

【#7921(PR)】 TIANGT1 Inclination angle

Set the inclination angle if the tool-rotation type base-side rotary axis is inclined. Set the angle regarding CCW direction of the inclined plane as plus direction.

---Setting range---

- 359.999 to 359.999 (°)
- (Follow as "#1003 iunit Input setup unit".)

【#7922(PR)】 ROTAXT1 Rotary axis name

Set the name of the tool rotating type base-side rotary axis.

Set "0" when the axis has the mechanical axis specifications. (The setting is, however, invalid in the tool center point control.)

---Setting range---

- 0, A, B, C, U, V, W, X, Y, Z

【#7923】 DIR_T1 Rotation direction

Select the rotation direction of the tool rotating type base-side rotary axis.

- 0: CW
- 1: CCW

【#7924】 COFST1H Horizontal axis rotation center offset

Set the distance in the horizontal axis direction between the rotation centers of the tool-side rotary axis and the base-side rotary axis.

---Setting range---

- 99999.999 to 99999.999 (mm)

【#7925】 COFST1V Vertical axis rotation center offset

Set the distance in the vertical axis direction between the rotation centers of the tool-side rotary axis and the base-side rotary axis.

---Setting range---

- 99999.999 to 99999.999 (mm)

【#7926】 COFST1T Height axis rotation center offset

Set the distance in the height axis direction between the rotation centers of the tool-side rotary axis and the base-side rotary axis.

---Setting range---

- 99999.999 to 99999.999 (mm)

【#7927】 CERRT1H Horizontal axis rotation center error compensation amount

Set the error compensation amount in the horizontal axis direction of the tool rotating type base-side rotary axis rotation center.

---Setting range---

- 99999.999 to 99999.999 (mm)
- (Follow as "#1006 mcmpunit Machine error compensation unit".)

【#7928】 CERRT1V Vertical axis rotation center error compensation amount

Set the error compensation amount in the vertical axis direction of the tool rotating type base-side rotary axis rotation center.

---Setting range---

- 99999.999 to 99999.999 (mm)
- (Follow as "#1006 mcmpunit Machine error compensation unit".)

【#7930(PR)】 SLCT_T2 Rotary axis center

Select in which axis direction to rotate the tool rotating type tool-side rotary axis.

If the tool axis is inclined, use the second digit to set the axis direction in which the tool axis is inclined.

- 0: Invalid
- 1: I axis rotation
- 2: J axis rotation
- 3: K axis rotation

(Note) 0 to 99 can be set from the screen, but if an invalid value is set, the operation error "M01 0127 Rot axis parameter error" will occur when the power supply is turned ON.

---Setting range---

- 0 to 3
- 12, 13, 21, 23, 31, 32

II Parameters

6. Rotary Axis Configuration Parameters

【#7931(PR)】 TIANGT2 Inclination angle

Set the inclination angle if the tool-rotation type tool-side rotary axis is inclined. Set the angle regarding CCW direction of the inclined plane as plus direction.

---Setting range---

-359.999 to 359.999 (°)

(Follow as "#1003 iunit Input setup unit".)

【#7932(PR)】 ROTAXT2 Rotary axis name

Set the name of the tool rotating type tool-side rotary axis.

Set "0" when the axis has the mechanical axis specifications. (The setting is, however, invalid in the tool center point control.)

---Setting range---

0, A, B, C, U, V, W, X, Y, Z

【#7933】 DIR_T2 Rotation direction

Set the rotation direction of the tool rotating type tool-side rotary axis.

0: CW

1: CCW

【#7934】 COFST2H Horizontal axis rotation center offset

Set the distance in the horizontal axis direction between the spindle holder center and the rotation center of the tool-side rotary axis.

---Setting range---

-99999.999 to 99999.999 (mm)

【#7935】 COFST2V Vertical axis rotation center offset

Set the distance in the vertical axis direction between the spindle holder center and the rotation center of the tool-side rotary axis.

---Setting range---

-99999.999 to 99999.999 (mm)

【#7936】 COFST2T Height axis rotation center offset

Set the distance in the height axis direction between the spindle holder center and the rotation center of the tool-side rotary axis.

---Setting range---

-99999.999 to 99999.999 (mm)

【#7937】 CERRT2H Horizontal axis rotation center error compensation amount

Set the error compensation amount in the horizontal axis direction of the tool rotating type tool-side rotary axis rotation center.

---Setting range---

-99999.999 to 99999.999 (mm)

(Follow as "#1006 mcmpunit Machine error compensation unit".)

【#7938】 CERRT2V Vertical axis rotation center error compensation amount

Set the error compensation amount in the vertical axis direction of the tool rotating type tool-side rotary axis rotation center.

---Setting range---

-99999.999 to 99999.999 (mm)

(Follow as "#1006 mcmpunit Machine error compensation unit".)

【#7940(PR)】 SLCT_W1 Rotary axis selection

Select in which axis direction to rotate the table rotating type base-side rotary axis.

If the tool axis is inclined, use the second digit to set the axis direction in which the tool axis is inclined.

0: Invalid

1: I axis rotation

2: J axis rotation

3: K axis rotation

(Note) 0 to 99 can be set from the screen, but if an invalid value is set, the operation error "M01 0127 Rot axis parameter error" will occur when the power supply is turned ON.

---Setting range---

0 to 3

12, 13, 21, 23, 31, 32

【#7941(PR)】 TIANGW1 Inclination angle

Set the inclination angle if the table-rotation type base-side rotary axis is inclined. Set the angle regarding CCW direction of the inclined plane as plus direction.

---Setting range---

-359.999 to 359.999 (°)

(Follow as "#1003 iunit Input setup unit".)

【#7942(PR)】 ROTAXW1 Rotary axis name

Set the name of the table rotating type base-side rotary axis.

Set "0" when the axis has the mechanical axis specifications. (The setting is, however, invalid in the tool center point control.)

---Setting range---

0, A, B, C, U, V, W, X, Y, Z

II Parameters

6. Rotary Axis Configuration Parameters

【#7943】 DIR_W1 Rotation direction

Set the rotation direction for the table rotating type base-side rotary axis.
0: CW
1: CCW

【#7944】 COFSW1H Horizontal axis rotation center offset

When all axes are at the machine basic point, set the distance in the horizontal axis direction from the machine basic point to the rotation center of the base-side rotary axis.
---Setting range---
-99999.999 to 99999.999 (mm)

【#7945】 COFSW1V Vertical axis rotation center offset

When all axes are at the machine basic point, set the distance in the vertical axis direction from the machine basic point to the rotation center of the base-side rotary axis.
---Setting range---
-99999.999 to 99999.999 (mm)

【#7946】 COFSW1T Height axis rotation center offset

When all axes are at the machine basic point, set the distance in the height axis direction from the machine basic point to the rotation center of the base-side rotary axis.
---Setting range---
-99999.999 to 99999.999 (mm)

【#7947】 CERRW1H Horizontal axis rotation center error compensation amount

Set the error compensation amount in the horizontal axis direction of the table rotating type base-side rotary axis rotation center.
---Setting range---
-99999.999 to 99999.999 (mm)
(Follow as "#1006 mcmpunit Machine error compensation unit".)

【#7948】 CERRW1V Vertical axis rotation center error compensation amount

Set the error compensation amount in the vertical axis direction of the table rotating type base-side rotary axis rotation center.
---Setting range---
-99999.999 to 99999.999 (mm)
(Follow as "#1006 mcmpunit Machine error compensation unit".)

【#7950(PR)】 SLCT_W2 Rotary axis selection

Set in which direction to rotate the table rotating type workpiece-side rotary axis.
If the tool axis is inclined, use the second digit to set the axis direction in which the tool axis is inclined.
0: Invalid
1: I axis rotation
2: J axis rotation
3: K axis rotation
(Note) 0 to 99 can be set from the screen, but if an invalid value is set, the operation error "M01 0127 Rot axis parameter error" will occur when the power supply is turned ON.
---Setting range---
0 to 3
12, 13, 21, 23, 31, 32

【#7951(PR)】 TIANGW2 Inclination angle

Set the inclination angle if the table rotating type workpiece-side rotary axis is inclined. Set the angle regarding CCW direction of the inclined plane as minus direction.
---Setting range---
-359.999 to 359.999 (°)
(Follow as "#1003 iunit Input setup unit".)

【#7952(PR)】 ROTAXW2 Rotary axis name

Set the name of the table rotating type workpiece-side rotary axis.
Set "0" when the axis has the mechanical axis specifications. (The setting is, however, invalid in the tool center point control.)
---Setting range---
0, A, B, C, U, V, W, X, Y, Z

【#7953】 DIR_W2 Rotation direction

Set the rotation direction for the table rotating type workpiece-side rotary axis.
0: CW
1: CCW

【#7954】 COFSW2H Horizontal axis rotation center offset

When all axes are at the machine basic point, set the distance in the horizontal axis direction between rotation centers of the base-side rotary axis and the workpiece-side rotary axis.
---Setting range---
-99999.999 to 99999.999 (mm)

【#7955】 COFSW2V Vertical axis rotation center offset

When all axes are at the machine basic point, set the distance in the vertical axis direction between rotation centers of the base-side rotary axis and the workpiece-side rotary axis.
---Setting range---
-99999.999 to 99999.999 (mm)

II Parameters

6. Rotary Axis Configuration Parameters

【#7956】 COFSW2T Height axis rotation center offset

When all axes are at the machine basic point, set the distance in the height axis direction between rotation centers of the base-side rotary axis and the workpiece-side rotary axis.

---Setting range---

-99999.999 to 99999.999 (mm)

【#7957】 CERRW2H Horizontal axis rotation center error compensation amount

Set the error compensation amount in the horizontal axis direction of the table rotating type workpiece-side rotary axis rotation center.

---Setting range---

-99999.999 to 99999.999 (mm)

(Follow as "#1006 mcmpunit Machine error compensation unit".)

【#7958】 CERRW2V Vertical axis rotation center error compensation amount

Set the error compensation amount in the vertical axis direction of the table rotating type workpiece-side rotary axis rotation center.

---Setting range---

-99999.999 to 99999.999 (mm)

(Follow as "#1006 mcmpunit Machine error compensation unit".)

7. Machine Error Compensation

【#4000(PR)】 Pinc Machine error compensation increment method

Select the method to set the machine error compensation data.

- 0: Absolute amount method
- 1: Incremental amount method

【#4001】 cmpax Basic axis

Set a name of the basic axis for machine error compensation.

- (1) For pitch error compensation, set the name of the axis to be compensated.
- (2) For relative position compensation, set the name of the axis to be the basic axis.

Set "system No. + axis name" when using the multi-part system.

(Example) Z axis for 2nd part system: 2Z

---Setting range---

Axis name such as X, Y, Z, U, V, W, A, B, or C

【#4002】 drcax Compensation axis

Set a name of the compensation axis for machine error compensation.

- (1) For pitch error compensation, set the same axis name as in "#4001 cmpax".

- (2) For relative position compensation, set the name of the axis to be actually compensated.

Set "system No. + axis name" when using the multi-part system.

(Example) Z axis for 2nd part system: 2Z

---Setting range---

Axis name such as X, Y, Z, U, V, W, A, B, or C

【#4003】 rdvno Division point number at reference position

Set the compensation data No. corresponding to the reference position. As the reference position is actually the base position, there is no compensation No. Therefore set the number that is decremented by 1.

---Setting range---

4101 to 5124

【#4004】 mdvno Division point number at the most negative side

Set the compensation data No. at the farthest end on the negative side.

---Setting range---

4101 to 5124

【#4005】 pdvno Division point number at the most positive side

Set the compensation data No. at the farthest end on the positive side.

---Setting range---

4101 to 5124

【#4006】 sc Compensation scale factor

Set the scale factor for the compensation amount.

---Setting range---

0 to 99

【#4007】 spcdv Division interval

Set the interval to divide the basic axis.

Each compensation data will be the compensation amount for each of these intervals.

---Setting range---

1 to 9999999 (control unit applied)

8. PLC Constants

【#6401,6402 - 6495,6496】 R7800-Low,R7800-High - R7847-Low,R7847-High Bit selection

This is the bit type parameter used in the PLC program (ladder).
Even if the data is set in the R register that corresponds to the PLC side when this parameter is displayed, the screen will not change. Enter a different screen once, and then select this screen again.
Some of the parameters following #6449 may be fixed according to the usage purpose. Refer to the PLC Program Development On-board Instruction Manual.
0 : OFF
1 : ON

【#6497,6498 - 6595,6596】 R7848-Low,R7848-High - R7897-Low,R7897-High Bit selection expansion

This is the bit type parameter (expansion) used in the PLC program (ladder).
Even if the data is set in the R register that corresponds to the PLC side when this parameter is displayed, the screen will not change. Enter a different screen once, and then select this screen again.
0 : OFF
1 : ON

【#16000 - 16703】 T0 - T703 PLC timer <10ms/100ms>

Set the time for the timer used in the PLC program (ladder).
The 10ms timer and 100ms timer are identified by the command used.
(Note) This setting value is valid when parameter "#6449 bit0" in the following "[BIT SELECT]" is set to "0".
---Setting range---
0 to 32767(x 10ms or x 100ms)

【#17000 - 17063】 ST0 - ST63 PLC integrated timer <100ms INC.>

Set the time for the integrated timer used with the PLC program (ladder).
(Note) This setting value is valid when parameter "#6449 bit0" in the following "[BIT SELECT]" is set to "0".
---Setting range---
0 to 32767(x 100ms)

【#17200 - 17455】 C000 - C255 Counter

Set the time for the counter used with the PLC program (ladder).
(Note) This setting value is valid when parameter "#6449/bit1" in the following "[BIT SELECT]" is set to "0".
---Setting range---
0 to 32767

【#18001 - 18150】 R7500,7501 - R7798,7799 PLC constant

Set the value to be set in the data type R register used in the PLC program (ladder).
Even if the data is set in the R register that corresponds to the PLC side when this parameter is displayed, the screen will not change. Enter a different screen once, and then select this screen again.
---Setting range---
-99999999 to 99999999

9. Macro List

【#7001】 M [01] Code

Set the M code used for calling out the macro with the M command.
This is valid when "#1195 Mmac" is set to "1".

---Setting range---
1 to 9999

【#7002】 M [01] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7003】 M [01] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---
Program name or file name (up to 32 characters)

【#7011】 M [02] Code

Set the M code used for calling out the macro with the M command.
This is valid when "#1195 Mmac" is set to "1".

---Setting range---
1 to 9999

【#7012】 M [02] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7013】 M [02] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---
Program name or file name (up to 32 characters)

【#7021】 M [03] Code

Set the M code used for calling out the macro with the M command.
This is valid when "#1195 Mmac" is set to "1".

---Setting range---
1 to 9999

【#7022】 M [03] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7023】 M [03] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---
Program name or file name (up to 32 characters)

【#7031】 M [04] Code

Set the M code used for calling out the macro with the M command.
This is valid when "#1195 Mmac" is set to "1".

---Setting range---
1 to 9999

【#7032】 M [04] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

II Parameters

9. Macro List

【#7033】 M [04] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7041】 M [05] Code

Set the M code used for calling out the macro with the M command. This is valid when "#1195 Mmac" is set to "1".

---Setting range---

1 to 9999

【#7042】 M [05] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7043】 M [05] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7051】 M [06] Code

Set the M code used for calling out the macro with the M command. This is valid when "#1195 Mmac" is set to "1".

---Setting range---

1 to 9999

【#7052】 M [06] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7053】 M [06] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7061】 M [07] Code

Set the M code used for calling out the macro with the M command. This is valid when "#1195 Mmac" is set to "1".

---Setting range---

1 to 9999

【#7062】 M [07] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7063】 M [07] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7071】 M [08] Code

Set the M code used for calling out the macro with the M command. This is valid when "#1195 Mmac" is set to "1".

---Setting range---

1 to 9999

II Parameters

9. Macro List

【#7072】 M [08] Type

Set the macro call out type.

- 0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7073】 M [08] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7081】 M [09] Code

Set the M code used for calling out the macro with the M command.
This is valid when "#1195 Mmac" is set to "1".

---Setting range---

1 to 9999

【#7082】 M [09] Type

Set the macro call out type.

- 0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7083】 M [09] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7091】 M [10] Code

Set the M code used for calling out the macro with the M command.
This is valid when "#1195 Mmac" is set to "1".

---Setting range---

1 to 9999

【#7092】 M [10] Type

Set the macro call out type.

- 0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7093】 M [10] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7102】 M2mac Type

Set the type for when calling out the macro with the 2nd miscellaneous command.
The macro will be called out with the "#1170 M2name" address command when "#1198 M2mac" is set to "1".

- 0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7103】 M2mac Program No.

Set the program No. for when calling out the macro with the 2nd miscellaneous command.
The macro will be called out with the "#1170 M2name" address command when "#1198 M2mac" is set to "1".

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7201】 G [01] Code

Set the G code to be used when calling the macro with a G command.
Do not set a G code used in the system.

---Setting range---

1 to 255

II Parameters

9. Macro List

【#7202】 G [01] Type

Set the macro call out type.

- 0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7203】 G [01] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7211】 G [02] Code

Set the G code to be used when calling the macro with a G command.
Do not set a G code used in the system.

---Setting range---

1 to 255

【#7212】 G [02] Type

Set the macro call out type.

- 0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7213】 G [02] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7221】 G [03] Code

Set the G code to be used when calling the macro with a G command.
Do not set a G code used in the system.

---Setting range---

1 to 255

【#7222】 G [03] Type

Set the macro call out type.

- 0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7223】 G [03] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7231】 G [04] Code

Set the G code to be used when calling the macro with a G command.
Do not set a G code used in the system.

---Setting range---

1 to 255

【#7232】 G [04] Type

Set the macro call out type.

- 0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- 3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
- others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7233】 G [04] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

II Parameters

9. Macro List

【#7241】 G [05] Code

Set the G code to be used when calling the macro with a G command.
Do not set a G code used in the system.

---Setting range---
1 to 255

【#7242】 G [05] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7243】 G [05] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---
Program name or file name (up to 32 characters)

【#7251】 G [06] Code

Set the G code to be used when calling the macro with a G command.
Do not set a G code used in the system.

---Setting range---
1 to 255

【#7252】 G [06] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7253】 G [06] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---
Program name or file name (up to 32 characters)

【#7261】 G [07] Code

Set the G code to be used when calling the macro with a G command.
Do not set a G code used in the system.

---Setting range---
1 to 255

【#7262】 G [07] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7263】 G [07] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---
Program name or file name (up to 32 characters)

【#7271】 G [08] Code

Set the G code to be used when calling the macro with a G command.
Do not set a G code used in the system.

---Setting range---
1 to 255

【#7272】 G [08] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

II Parameters

9. Macro List

【#7273】 G [08] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7281】 G [09] Code

Set the G code to be used when calling the macro with a G command. Do not set a G code used in the system.

---Setting range---

1 to 255

【#7282】 G [09] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7283】 G [09] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7291】 G [10] Code

Set the G code to be used when calling the macro with a G command. Do not set a G code used in the system.

---Setting range---

1 to 255

【#7292】 G [10] Type

Set the macro call out type.

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7293】 G [10] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7302】 Smac Type

Set the type for when calling the macro with an S command. This is valid when "#1196 Smac" is set to "1".

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

【#7303】 Smac Program No.

Set the program No. for when calling the macro with an S command.

This is valid when "#1196 Smac" is set to "1".

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

【#7312】 Tmac Type

Set the type for when calling the macro with a T command.

This is valid when "#1197 Tmac" is set to "1".

0: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call
1: G65 P $\Delta\Delta\Delta\Delta$; and equivalent value call
2: G66 P $\Delta\Delta\Delta\Delta$; and equivalent value call
3: G66.1 P $\Delta\Delta\Delta\Delta$; and equivalent value call
others: M98 P $\Delta\Delta\Delta\Delta$; and equivalent value call

II Parameters

9. Macro List

【#7313】 Tmac Program No.

Set the program No. for when calling the macro with a T command.
This is valid when "#1197 Tmac" is set to "1".
Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.
---Setting range---
Program name or file name (up to 32 characters)

【#7401】 ASCII[01] Valid

The ASCII code macro parameters (#7402 to 7405) are validated.
0: Invalid
1: Valid

【#7402】 ASCII[01] Code

Set the ASCII code used to call macros with the ASCII code.
L system: A,B,D,F,H,I,J,K,M,Q,R,S,T
M system: A,B,F,H,I,K,M,Q,R,S,T

【#7403】 ASCII[01] Type

Set the macro call type.
0: M98
1: G65
2: G66
3: G66.1

【#7404】 ASCII[01] Program No.

Set the program No. called with macro call.
---Setting range---
0 to 99999999

【#7405】 ASCII[01] Variable

When the call type is "0", set the variable No. set after the ASCII code.
---Setting range---
100 to 149

【#7411】 ASCII[02] Valid

The ASCII code macro parameters (#7412 to 7415) are validated.
0: Invalid
1: Valid

【#7412】 ASCII[02] Code

Set the ASCII code used to call macros with the ASCII code.
L system: A,B,D,F,H,I,J,K,M,Q,R,S,T
M system: A,B,F,H,I,K,M,Q,R,S,T

【#7413】 ASCII[02] Type

Set the macro call type.
0: M98
1: G65
2: G66
3: G66.1

【#7414】 ASCII[02] Program No.

Set the program No. called with macro call.
---Setting range---
0 to 99999999

【#7415】 ASCII[02] Variable

When the call type is "0", set the variable No. set after the ASCII code.
---Setting range---
100 to 149

10. Position Switch

【#7500】 Pcheck High-speed switching of position switch

Specify whether to perform position switch area checking at high speeds.
0: Do not perform position switch area checking at high speed (do it the same as before).
1: Perform position switch area checking at high speed.

【#7501】 <axis> Axis name PSW1

Specify the name of the axis for which a position switch is provided.
---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

【#7502】 <dog1> Imaginary dog position 1 PSW1

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.
1st part system device: X1D00
2nd part system device: X1D20
---Setting range---
-99999.999 to 99999.999 (mm)

【#7503】 <dog2> Imaginary dog position 2 PSW1

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.
1st part system device: X1D00
2nd part system device: X1D20
---Setting range---
-99999.999 to 99999.999 (mm)

【#7504】 <check> Selection of area check method PSW1

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.
0: Use the command type machine position as the machine position for position switch area checking.
1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7511】 <axis> Axis name PSW2

Specify the name of the axis for which a position switch is provided.
---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

【#7512】 <dog1> Imaginary dog position 1 PSW2

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.
1st part system device: X1D00
2nd part system device: X1D20
---Setting range---
-99999.999 to 99999.999 (mm)

【#7513】 <dog2> Imaginary dog position 2 PSW2

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.
1st part system device: X1D00
2nd part system device: X1D20
---Setting range---
-99999.999 to 99999.999 (mm)

【#7514】 <check> Selection of area check method PSW2

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.
0: Use the command type machine position as the machine position for position switch area checking.
1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7521】 <axis> Axis name PSW3

Specify the name of the axis for which a position switch is provided.
---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

II Parameters

10. Position Switch

【#7522】 <dog1> Imaginary dog position 1 PSW3

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7523】 <dog2> Imaginary dog position 2 PSW3

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7524】 <check> Selection of area check method PSW3

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7531】 <axis> Axis name PSW4

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

【#7532】 <dog1> Imaginary dog position 1 PSW4

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7533】 <dog2> Imaginary dog position 2 PSW4

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7534】 <check> Selection of area check method PSW4

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7541】 <axis> Axis name PSW5

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

【#7542】 <dog1> Imaginary dog position 1 PSW5

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7543】 <dog2> Imaginary dog position 2 PSW5

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

II Parameters

10. Position Switch

【#7544】 <check> Selection of area check method PSW5

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7551】 <axis> Axis name PSW6

Specify the name of the axis for which a position switch is provided.

---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

【#7552】 <dog1> Imaginary dog position 1 PSW6

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7553】 <dog2> Imaginary dog position 2 PSW6

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7554】 <check> Selection of area check method PSW6

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7561】 <axis> Axis name PSW7

Specify the name of the axis for which a position switch is provided.

---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

【#7562】 <dog1> Imaginary dog position 1 PSW7

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7563】 <dog2> Imaginary dog position 2 PSW7

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7564】 <check> Selection of area check method PSW7

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7571】 <axis> Axis name PSW8

Specify the name of the axis for which a position switch is provided.

---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

II Parameters

10. Position Switch

【#7572】 <dog1> Imaginary dog position 1 PSW8

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7573】 <dog2> Imaginary dog position 2 PSW8

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7574】 <check> Selection of area check method PSW8

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7581】 <axis> Axis name PSW9

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

【#7582】 <dog1> Imaginary dog position 1 PSW9

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7583】 <dog2> Imaginary dog position 2 PSW9

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7584】 <check> Selection of area check method PSW9

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7591】 <axis> Axis name PSW10

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

【#7592】 <dog1> Imaginary dog position 1 PSW10

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7593】 <dog2> Imaginary dog position 2 PSW10

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

II Parameters

10. Position Switch

【#7594】 <check> Selection of area check method PSW10

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7601】 <axis> Axis name PSW11

Specify the name of the axis for which a position switch is provided.

---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

【#7602】 <dog1> Imaginary dog position 1 PSW11

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7603】 <dog2> Imaginary dog position 2 PSW11

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7604】 <check> Selection of area check method PSW11

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7611】 <axis> Axis name PSW12

Specify the name of the axis for which a position switch is provided.

---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

【#7612】 <dog1> Imaginary dog position 1 PSW12

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7613】 <dog2> Imaginary dog position 2 PSW12

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7614】 <check> Selection of area check method PSW12

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7621】 <axis> Axis name PSW13

Specify the name of the axis for which a position switch is provided.

---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

II Parameters

10. Position Switch

【#7622】 <dog1> Imaginary dog position 1 PSW13

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7623】 <dog2> Imaginary dog position 2 PSW13

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7624】 <check> Selection of area check method PSW13

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7631】 <axis> Axis name PSW14

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

【#7632】 <dog1> Imaginary dog position 1 PSW14

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7633】 <dog2> Imaginary dog position 2 PSW14

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7634】 <check> Selection of area check method PSW14

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7641】 <axis> Axis name PSW15

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

【#7642】 <dog1> Imaginary dog position 1 PSW15

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7643】 <dog2> Imaginary dog position 2 PSW15

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

II Parameters

10. Position Switch

【#7644】 <check> Selection of area check method PSW15

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7651】 <axis> Axis name PSW16

Specify the name of the axis for which a position switch is provided.

---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

【#7652】 <dog1> Imaginary dog position 1 PSW16

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7653】 <dog2> Imaginary dog position 2 PSW16

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7654】 <check> Selection of area check method PSW16

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7661】 <axis> Axis name PSW17

Specify the name of the axis for which a position switch is provided.

---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

【#7662】 <dog1> Imaginary dog position 1 PSW17

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7663】 <dog2> Imaginary dog position 2 PSW17

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7664】 <check> Selection of area check method PSW17

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7671】 <axis> Axis name PSW18

Specify the name of the axis for which a position switch is provided.

---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

II Parameters

10. Position Switch

【#7672】 <dog1> Imaginary dog position 1 PSW18

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7673】 <dog2> Imaginary dog position 2 PSW18

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7674】 <check> Selection of area check method PSW18

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7681】 <axis> Axis name PSW19

Specify the name of the axis for which a position switch is provided.

---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

【#7682】 <dog1> Imaginary dog position 1 PSW19

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7683】 <dog2> Imaginary dog position 2 PSW19

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7684】 <check> Selection of area check method PSW19

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7691】 <axis> Axis name PSW20

Specify the name of the axis for which a position switch is provided.

---Setting range---
X, Y, Z, U, V, W, A, B, or C axis address

【#7692】 <dog1> Imaginary dog position 1 PSW20

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

【#7693】 <dog2> Imaginary dog position 2 PSW20

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---
-99999.999 to 99999.999 (mm)

II Parameters

10. Position Switch

【#7694】 <check> Selection of area check method PSW20

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7701】 <axis> Axis name PSW21

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

【#7702】 <dog1> Imaginary dog position 1 PSW21

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7703】 <dog2> Imaginary dog position 2 PSW21

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7704】 <check> Selection of area check method PSW21

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7711】 <axis> Axis name PSW22

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

【#7712】 <dog1> Imaginary dog position 1 PSW22

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7713】 <dog2> Imaginary dog position 2 PSW22

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00
2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7714】 <check> Selection of area check method PSW22

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7721】 <axis> Axis name PSW23

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

II Parameters

10. Position Switch

【#7722】 <dog1> Imaginary dog position 1 PSW23

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7723】 <dog2> Imaginary dog position 2 PSW23

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7724】 <check> Selection of area check method PSW23

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

【#7731】 <axis> Axis name PSW24

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

【#7732】 <dog1> Imaginary dog position 1 PSW24

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7733】 <dog2> Imaginary dog position 2 PSW24

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

【#7734】 <check> Selection of area check method PSW24

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

11. Auxiliary Axis Parameter

【#50001(PR)】 MSR Motor series

Set the motor series. When set to the default value ("0000"), the system will automatically judge the series.

---Setting range---
0000 to FFFF (hexadecimal)

【#50002(PR)】 RTY Regeneration option type

Set the regenerative resistor type.
Default value: 0000

Setting value of the third digit from the left
0: Drive unit standard built-in resistor (10CT has no built-in resistor)
1: Setting prohibited
2: MR-RB032 (30W)
3: MR-RB12 (100W)
4: MR-RB32 (300W)
5: MR-RB30 (300W)
6: MR-RB50 (500W)
7 to F: Setting prohibited

Do not set values that are not written here.

【#50003(PR)】 PC1 Motor side gear ratio (machine rotation ratio)

Set the number of gear teeth on the motor side and the number of gear teeth on the machine side as an integer reduced to its lowest terms.
Set the total gear ratio if there are multiple gear levels.

For rotary axes, set the motor rotation speed per machine rotation.
Default value: 1

---Setting range---
1 to 32767

【#50004(PR)】 PC2 Machine side gear ratio (motor rotation ratio)

Set the number of gear teeth on the motor side and the number of gear teeth on the machine side as an integer reduced to its lowest terms.
Set the total gear ratio if there are multiple gear levels.

For rotary axes, set the motor rotation speed per machine rotation.
Default value: 1

---Setting range---
1 to 32767

【#50005(PR)】 PIT Feed pitch

Set the feed pitch.
Set "360" (default value) for rotary axes.
Set the feed lead for linear axes.

---Setting range---
1 to 32767(° or mm)

【#50006】 INP In-position detection width

Set the position droop for the in-position detection.
In-position will be detected when the position droop reaches the setting value or less.
Default value: 50

---Setting range---
1 to 32767 (1/1000° or μm)

【#50007】 ATU Auto-tuning

Set the adjustment of the auto-tuning.
Default value: 0102

***1: Low response (low-rigidity loads, loads which easily vibrate)
***2: Standard setting value
***3:
***4:
***5: High response (high-rigidity loads, loads which do not easily vibrate)

**0*: Standard friction amount
**1*: Large friction amount (set the position loop gain slightly lower)

*0**: Only auto-tuning PG2, VG2, VIC, and GD2
*1**: Only auto-tuning PG1, PG2, VG1, VG2, VIC, and GD2 (total gain). (Standard setting)
*2**: No auto-tuning

Do not set values that are not explained here.

【#50008】 PG1 Position loop gain 1

Set the position loop gain of the model loop. This parameter determines the trackability to a position command.
Default value: 70

---Setting range---
4 to 1000 (1/s)

【#50009】

Not used. Set to "0".

II Parameters

11. Auxiliary Axis Parameter

【#50010】 EMGt Deceleration control time constant

Set the deceleration time from the clamp speed (Aspeed1). Set the same value as the acceleration/deceleration time constant used for the normal rapid traverse.
Default value: 500

---Setting range---
0 to 32768 (ms)

【#50011】

Not used. Set to "0".

【#50012】

Not used. Set to "0".

【#50013】 MBR Vertical axis drop prevention time

Set the time to delay the servo OFF during servo OFF command. Increase the setting by 100ms at a time and set the minimum value where the axis does not drop.
Default value: 100

---Setting range---
0 to 1000 (ms)

【#50014】 NCH Notch filter No.

Set the frequency of the machine resonance suppression filter.

0: Not used
1: 1125 (Hz)
2: 563
3: 375
4: 282
5: 225
6: 188
7: 161

【#50015】

Not used. Set to "0".

【#50016】 JIT Jitter compensation

Set the number of pulses that ignore the jitter compensation.

0: The function is not used.
1 to 3: 1 to 3 pulses ignore.

【#50017】

Not used. Set to "0".

【#50018】

Not used. Set to "0".

【#50019】 PG2 Position loop gain 2

Set the position loop gain of the actual loop.
Determine the position responsiveness to external disturbance.
Default value: 25

---Setting range---
1 to 500 (1/s)

【#50020】 VG1 Speed loop gain 1

Set the speed loop gain of the model loop.
This parameter determines the tracking ability to a speed command.
Default value: 1200

---Setting range---
20 to 5000 (1/s)

【#50021】 VG2 Speed loop gain 2

Set the speed loop gain of the actual loop.
This parameter determines the speed responsiveness to external disturbance.
Default value: 600

---Setting range---
20 to 8000 (1/s)

【#50022】 VIC Speed integral compensation

Set the characteristics of the speed low-frequency region.
Default value: 20

---Setting range---
1 to 1000 (ms)

【#50023】 VDC Speed differential compensation

Set the speed differential compensation to reduce overshoot.
When the default value "1000" is set, the normal PI control will start.
Adjust the overshoot amount by lowering in increments of 20.

---Setting range---
0 to 1000

II Parameters

11. Auxiliary Axis Parameter

【#50024】 DG2 Load inertia ratio

Set the ratio of load inertia to motor inertia.

Default value: 2.0

---Setting range---

0.0 to 50.0 (fold)

【#50025】

Not used. Set to "0".

【#50030(PR)】 MTY Motor type

Set the motor type. When set to the default value ("0000"), the system will automatically judge the type.

---Setting range---

0000 to FFFF (hexadecimal)

【#50050】 MD1 D/A output channel 1 data No.

Set the Nos. of the data to output on D/A output channel 1.

Default value: 0000

Setting value of the rightmost digit

0: Speed feedback (with sign) Maximum speed = 8V

1: Current feedback (with sign) Maximum current (torque) = 8V

2: Speed feedback (without sign) Maximum speed = 8V

3: Current feedback (without sign) Maximum current (torque) = 8V

4: Current command Maximum current (torque) = 8V

5: Command FDT 100000 [degrees/min] = 10V

6: Position droop 1 (1/1) 2048 [pulse] = 10V

7: Position droop 2 (1/4) 8192 [pulse] = 10V

8: Position droop 3 (1/16) 32768 [pulse] = 10V

9: Position droop 4 (1/32) 65536 [pulse] = 10V

A: Position droop 5 (1/64) 131072 [pulse] = 10V

【#50051】 MO1 D/A output channel 1 output offset

Set this parameter when the zero level of D/A output channel 1 is not equal to zero.

---Setting range---

-999 to 999 (mV)

【#50052】

Not used. Set to "0".

【#50053】 MD2 D/A output channel 2 data No.

Set the Nos. of the data to output on D/A output channel 2.

Descriptions are the same as in "#50050 MD1".

Default value: 0000

---Setting range---

0000 to FFFF (hexadecimal)

【#50054】 MO2 D/A output channel 2 output offset

Set this parameter when the zero level of D/A output channel 2 is not equal to zero.

Default value: 0

---Setting range---

-999 to 999 (mV)

【#50055】

Not used. Set to "0".

【#50100(PR)】 station Number of indexing stations

Set the number of stations.

For linear axes, this value is expressed by: number of divisions = number of stations - 1.

Default value: 2

---Setting range---

2 to 360

II Parameters

11. Auxiliary Axis Parameter

【#50101(PR)】 Cont1 Control parameter 1

The bits that are not explained here must be set to the default value.
Default value : bit9 = "1", Other bits = "0"

bit1:

- 0: High-speed zero point return after the establishment of zero point
- 1: Dog-type return for each reference position return

bit8:

- 0: Reference position return direction (+)
- 1: Reference position return direction (-)

bit9:

- 0: Rotation direction determined by operation control signal (DIR)
- 1: Rotation direction in the shortcut direction

bitA

- 0: Machine basic position becomes the basic point.
- 1: Electrical basic position becomes the basic point.

bitD

- 0: Creation of coordinate zero point is valid.
- 1: Zero point is established at power supply ON position.

bitE

- 0: Rotation direction in operation control signal (DIR) or in the shortcut direction
- 1: Rotation direction in the arbitrary position command sign direction

bitF

- 0: Stopper direction is in the positioning direction.
- 1: Stopper direction is in the sign direction of the stopper amount.

【#50102(PR)】 Cont2 Control parameter 2

The bits that are not explained here must be set to the default value.
Default value : bit1,2,7 = "1", Other bits = "0"

bit1:

- 0: Error not corrected at servo OFF
- 1: Error corrected at servo OFF

bit2:

- 0: Linear axis
- 1: Rotary axis

bit3:

- 0: Station assignment direction CW
- 1: Station assignment direction CCW

bit4:

- 0: Uniform assignment
- 1: Non-uniform assignment

bit5:

- 0: DO channel standard assignment
- 1: DO channel reverse assignment

bit6:

- 0: 2-wire detector communication
- 1: 4-wire detector communication

bit7:

- 0: Incremental detection
- 1: Absolute position detection

II Parameters

11. Auxiliary Axis Parameter

【#50103(PR)】 EmgCont Emergency stop control

The bits that are not explained here must be set to the default value.
Default value : bit0 = "1", Other bits = "0"

bit0:

0: Enable external emergency stop
1: Disable external emergency stop

bit1:

0: Dynamic brake stop at emergency stop
1: Deceleration control stop at emergency stop

bit2:

0: Enable NC bus emergency stop input
1: Disable NC bus emergency stop input

bit3:

0: Enable NC bus emergency stop output
1: Disable NC bus emergency stop output

【#50104(PR)】 tleng Linear axis stroke length

Set the travel stroke length for linear axis.
The set value for this parameter will be ignored when non-uniform assignments are set or random positions are commanded.

Default value: 100.000

---Setting range---

0.001 to 99999.999 (mm)

【#50110】 ZRNspeed Reference position return speed

Set the clamp value of the feedrate when a reference position return is carried out.
The feedrate applies the manual operation speed in the parameter group selected at the time, which is clamped by this parameter set value.

Default value: 1000

---Setting range---

1 to 100000 (°/min or mm/min)

【#50111】 ZRNcreep Reference position return creep speed

Set the approach speed to the reference position after dog detection during a reference position return.

Default value: 200

---Setting range---

1 to 65535 (°/min or mm/min)

【#50112】 grid mask Grid mask

Set the amount that the dog is artificially extended. Normally set the half amount of the grid spacing.

Default value: 0

---Setting range---

0 to 65536 (1/1000° or μm)

【#50113(PR)】 grspc Grid spacing

Select the number of divisions in the grid spacing that is the conventional motor rotation travel amount.

The setting values "1", "2", "3" and "4" divide into 2, 4, 8 and 16 divisions respectively.

Default value: 0

---Setting range---

0 to 4 ("1 / (n-th power of 2)" divisions)

【#50114】 ZRNshift Reference position shift amount

Set the shift amount in a dog-type reference position return from the electrical basic position, which is determined on the grid, to the reference position.

Default value: 0.000

---Setting range---

0 to 65536 (1/1000° or μm)

【#50115】 ST.ofset Station offset

Set the distance (offset) from the reference position to station 1.

Default value: 0

---Setting range---

-99999.999 to 99999.999 (° or mm)

【#50116(PR)】 ABS base Absolute position zero point

Set the travel distance in shifting the machine coordinate basic point from the standard point during absolute position initializing.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

II Parameters

11. Auxiliary Axis Parameter

【#50117】 Limit(+) Soft limit (+)

Set the upper limit for commands in the plus direction.
Commands in the plus direction beyond this set value are not possible.
If the machine is in a position exceeding the setting value, commands in the minus direction will be possible.
If "#50117 Limit(+)" and "#50118 Limit(-)" are set to the same value, the soft limit function will not operate.

Default value: 1.000

---Setting range---

-99999.999 to 99999.999 (mm)

【#50118】 Limit(-) Soft limit (-)

Set the lower limit for commands in the minus direction.
Commands in the minus direction beyond this set value are not possible.
If the machine is in a position exceeding the setting value, commands in the plus direction will be possible.

Default value: 1.000

---Setting range---

-99999.999 to 99999.999 (mm)

【#50120】 ABS Type Absolute position detection parameter

The bits that are not explained here must be set to the default value.

Default value : bit2 = "1", Other bits = "0"

bit1:

0: Dogless-type method initializing
1: Dog-type method initializing

bit2:

0: Machine end stopper method initializing
1: Marked point alignment method initializing

bit3:

0: Electrical basic position direction (+)
1: Electrical basic position direction (-)

【#50123(PR)】 ABS check Absolute position power OFF tolerable movement value

Set the tolerable amount of travel for a machine that travels during power OFF in an absolute position detection system.
The "Absolute position power OFF movement exceeded (ABS)" signal will turn ON if the machine travels more than this setting value during power OFF.

The travel amount will not be checked when this parameter is set to "0.000".

Default value: 0.000

---Setting range---

0.000 to 99999.999 (° or mm)

【#50130】 backlash Backlash compensation amount

Set the backlash compensation amount.

Default value: 0

---Setting range---

0 to 9999 (1/1000° or μm)

【#50132】

Not used. Set to "0".

【#50133】

Not used. Set to "0".

【#50134】

Not used. Set to "0".

【#50135】

Not used. Set to "0".

【#50150】 Aspeed1 Operation parameter group 1 Automatic operation speed

Set the feedrate during automatic operation when operation parameter group 1 is selected.
This parameter is regarded as the clamp value for the automatic operation speeds and manual operation speeds of all operation groups.

A speed exceeding Aspeed1 cannot be commanded, even if it is set in a parameter.

Default value: 5000

---Setting range---

1 to 100000 (°/min or mm/min)

【#50151】 Mspeed1 Operation parameter group 1 Manual operation speed

Set the feedrate during manual operation or JOG operation when operation parameter group 1 is selected.

Default value: 2000

---Setting range---

1 to 100000 (°/min or mm/min)

II Parameters

11. Auxiliary Axis Parameter

【#50152】 time1.1 Operation parameter group 1 Acceleration/deceleration time constant 1

Set the linear acceleration/deceleration time for "Operation parameter group 1 automatic operation speed" (clamp speed) when operation parameter group 1 is selected.
When operating at a lower speed than the clamp speed, the axis will linearly accelerate/decelerate at the inclination determined above.
When this is set with "Acceleration/deceleration time constant 2", S-pattern acceleration/deceleration will be carried out. In this case, this parameter determines the acceleration/deceleration time of the linear part.
Default value: 100

---Setting range---
1 to 9999 (ms)

【#50153】 time1.2 Operation parameter group 1 Acceleration/deceleration time constant 2

Set this parameter when carrying out S-pattern acceleration/deceleration. Set the total time of the non-linear parts in the S-pattern acceleration/deceleration. When "1" is set, linear acceleration/deceleration will be carried out.
In the handle feed operation mode, this setting value is regarded as time constant for the linear acceleration/deceleration.
Default value: 1

---Setting range---
1 to 999 (ms)

【#50154】 TL1 Operation parameter group 1 Torque limit value

Set the motor output torque limit value when operation parameter group 1 is selected.
At the default value, the torque is limited at the maximum torque of the motor specifications.
Set the default value when torque limit is not especially required.
In the stopper positioning operation mode, this will be regarded as torque limit value when positioning to the stopper starting coordinates.
Default value: 500

---Setting range---
1 to 500 (%)

【#50155】 OD1 Operation parameter group 1 Excessive error detection width

Set the excessive error detection width when operation parameter group 1 is selected.
The excessive error alarm (S03 0052) will be detected when the position droop becomes larger than this setting value.
In the stopper positioning operation mode, this will be regarded as excessive error detection width when positioning to the stopper starting coordinates.
Default value: 100

---Setting range---
0 to 32767 (° or mm)

【#50156】 just1 Operation parameter group 1 Set position output width

Set the tolerable value at which "set position reached" (JST) or "automatic set position reached" (JSTA) signal is output when operation parameter group 1 is selected.
"Set position reached" (JST) indicates that the machine position is at any station. During automatic operation, "automatic set position reached" (JSTA) is also output under the same condition. These signals will turn OFF when the machine position moves away from the station over this value.
Default value: 0.500

---Setting range---
0.000 to 99999.999 (° or mm)

【#50157】 near1 Operation parameter group 1 Near set position output width

Set the tolerable value at which "near set position" (NEAR) signal is output when operation parameter group 1 is selected.
"Near set position" (NEAR) indicates that the machine position is near any station position. This value is generally set wider than the set position output width. During operations, this is related to the special commands when the station selection is set to "0".
Default value: 1.000

---Setting range---
0.000 to 99999.999 (° or mm)

【#50158】 Aspeed2 Operation parameter group 2 Automatic operation speed

Set the feedrate during automatic operation when operation parameter group 2 is selected.
Default value: 5000

---Setting range---
1 to 100000 (°/min or mm/min)

【#50159】 Mspeed2 Operation parameter group 2 Manual operation speed

Set the feedrate during manual operation or JOG operation when operation parameter group 2 is selected.
Default value: 2000

---Setting range---
1 to 100000 (°/min or mm/min)

II Parameters

11. Auxiliary Axis Parameter

【#50160】 time2.1 Operation parameter group 2 Acceleration/deceleration time constant 1

Set the linear acceleration/deceleration time for "Operation parameter group 1 automatic operation speed" (clamp speed) when operation parameter group 2 is selected. When operating at a lower speed than the clamp speed, the axis will linearly accelerate/decelerate at the inclination determined above. When this is set with "Acceleration/deceleration time constant 2", S-pattern acceleration/deceleration will be carried out. In this case, this parameter determines the acceleration/deceleration time of the linear part.

Default value: 100

---Setting range---
1 to 9999 (ms)

【#50161】 time2.2 Operation parameter group 2 Acceleration/deceleration time constant 2

Set this parameter when carrying out S-pattern acceleration/deceleration. Set the total time of the non-linear parts in the S-pattern acceleration/deceleration. When "1" is set, linear acceleration/deceleration will be carried out. In the handle feed operation mode, this setting value is regarded as time constant for the linear acceleration/deceleration.

Default value: 1

---Setting range---
1 to 999 (ms)

【#50162】 TL2 Operation parameter group 2 Torque limit value

Set the motor output torque limit value when operation parameter group 2 is selected. At the default value, the torque is limited at the maximum torque of the motor specifications. Set the default value when torque limit is not especially required. In the stopper positioning operation mode, this will be regarded as torque limit value during the stopper operation.

Default value: 500

---Setting range---
1 to 500 (%)

【#50163】 OD2 Operation parameter group 2 Excessive error detection width

Set the excessive error detection width when operation parameter group 2 is selected. The excessive error alarm (S03 0052) will be detected when the position droop becomes larger than this setting value. In the stopper positioning operation mode, this will be regarded as excessive error detection width during the stopper operation.

Default value: 100

---Setting range---
0 to 32767 (° or mm)

【#50164】 just2 Operation parameter group 2 Set position output width

Set the tolerable value at which "set position reached" (JST) or "automatic set position reached" (JSTA) signal is output when operation parameter group 2 is selected. "Set position reached" (JST) indicates that the machine position is at any station. During automatic operation, "automatic set position reached" (JSTA) is also output under the same condition. These signals will turn OFF when the machine position moves away from the station over this value.

Default value: 0.500

---Setting range---
0.000 to 99999.999 (° or mm)

【#50165】 near2 Operation parameter group 2 Near set position output width

Set the tolerable value at which "near set position" (NEAR) signal is output when operation parameter group 2 is selected. "Near set position" (NEAR) indicates that the machine position is near any station position. This value is generally set wider than the set position output width. During operations, this is related to the special commands when the station selection is set to "0".

Default value: 1.000

---Setting range---
0.000 to 99999.999 (° or mm)

【#50166】 Aspeed3 Operation parameter group 3 Automatic operation speed

Set the feedrate during automatic operation when operation parameter group 3 is selected. Default value: 5000

---Setting range---
1 to 100000 (°/min or mm/min)

【#50167】 Mspeed3 Operation parameter group 3 Manual operation speed

Set the feedrate during manual operation or JOG operation when operation parameter group 3 is selected. Default value: 2000

---Setting range---
1 to 100000 (°/min or mm/min)

II Parameters

11. Auxiliary Axis Parameter

【#50168】 time3.1 Operation parameter group 3 Acceleration/deceleration time constant 1

Set the linear acceleration/deceleration time for "Operation parameter group 3 automatic operation speed" (clamp speed) when operation parameter group 1 is selected. When operating at a lower speed than the clamp speed, the axis will linearly accelerate/decelerate at the inclination determined above. When this is set with "Acceleration/deceleration time constant 2", S-pattern acceleration/deceleration will be carried out. In this case, this parameter determines the acceleration/deceleration time of the linear part.

Default value: 100

---Setting range---
1 to 9999 (ms)

【#50169】 time3.2 Operation parameter group 3 Acceleration/deceleration time constant 2

Set this parameter when carrying out S-pattern acceleration/deceleration. Set the total time of the non-linear parts in the S-pattern acceleration/deceleration. When "1" is set, linear acceleration/deceleration will be carried out. In the handle feed operation mode, this setting value is regarded as time constant for the linear acceleration/deceleration.

Default value: 1

---Setting range---
1 to 999 (ms)

【#50170】 TL3 Operation parameter group 3 Torque limit value

Set the motor output torque limit value when operation parameter group 3 is selected. At the default value, the torque is limited at the maximum torque of the motor specifications. Set the default value when torque limit is not especially required. In the stopper positioning operation mode, this will be regarded as pressing torque limit value after completion of the positioning.

Default value: 500

---Setting range---
1 to 500 (%)

【#50171】 OD3 Operation parameter group 3 Excessive error detection width

Set the excessive error detection width when operation parameter group 3 is selected. The excessive error alarm (S03 0052) will be detected when the position droop becomes larger than this setting value. In the stopper positioning operation mode, this will be regarded as excessive error detection width during pressing after completion of the positioning.

Default value: 100

---Setting range---
0 to 32767 (° or mm)

【#50172】 just3 Operation parameter group 3 Set position output width

Set the tolerable value at which "set position reached" (JST) or "automatic set position reached" (JSTA) signal is output when operation parameter group 3 is selected. "Set position reached" (JST) indicates that the machine position is at any station. During automatic operation, "automatic set position reached" (JSTA) is also output under the same condition. These signals will turn OFF when the machine position moves away from the station over this value.

Default value: 0.500

---Setting range---
0.000 to 99999.999 (° or mm)

【#50173】 near3 Operation parameter group 3 Near set position output width

Set the tolerable value at which "near set position" (NEAR) signal is output when operation parameter group 3 is selected. "Near set position" (NEAR) indicates that the machine position is near any station position. This value is generally set wider than the set position output width. During operations, this is related to the special commands when the station selection is set to "0".

Default value: 1.000

---Setting range---
0.000 to 99999.999 (° or mm)

【#50174】 Aspeed4 Operation parameter group 4 Automatic operation speed

Set the feedrate during automatic operation when operation parameter group 4 is selected.

Default value: 5000

---Setting range---
1 to 100000 (°/min or mm/min)

【#50175】 Mspeed4 Operation parameter group 4 Manual operation speed

Set the feedrate during manual operation or JOG operation when operation parameter group 4 is selected.

Default value: 2000

---Setting range---
1 to 100000 (°/min or mm/min)

II Parameters

11. Auxiliary Axis Parameter

【#50176】 time4.1 Operation parameter group 4 Acceleration/deceleration time constant 1

Set the linear acceleration/deceleration time for "Operation parameter group 1 automatic operation speed" (clamp speed) when operation parameter group 4 is selected. When operating at a lower speed than the clamp speed, the axis will linearly accelerate/decelerate at the inclination determined above. When this is set with "Acceleration/deceleration time constant 2", S-pattern acceleration/deceleration will be carried out. In this case, this parameter determines the acceleration/deceleration time of the linear part.

Default value: 100

---Setting range---
1 to 9999 (ms)

【#50177】 time4.2 Operation parameter group 4 Acceleration/deceleration time constant 2

Set this parameter when carrying out S-pattern acceleration/deceleration. Set the total time of the non-linear parts in the S-pattern acceleration/deceleration. When "1" is set, linear acceleration/deceleration will be carried out. In the handle feed operation mode, this setting value is regarded as time constant for the linear acceleration/deceleration.

Default value: 1

---Setting range---
1 to 999 (ms)

【#50178】 TL4 Operation parameter group 4 Torque limit value

Set the motor output torque limit value when operation parameter group 4 is selected. At the default value, the torque is limited at the maximum torque of the motor specifications. Set the default value when torque limit is not especially required. In the stopper method initializing mode in absolute position detection system, this is regarded as torque limit value during stopper operation.

Default value: 500

---Setting range---
1 to 500 (%)

【#50179】 OD4 Operation parameter group 4 Excessive error detection width

Set the excessive error detection width when operation parameter group 4 is selected. The excessive error alarm (S03 0052) will be detected when the position droop becomes larger than this setting value.

In the stopper method initializing mode in absolute position detection system, this is regarded as excessive error detection width during stopper operation.

Default value: 100

---Setting range---
0 to 32767 (° or mm)

【#50180】 just4 Operation parameter group 4 Set position output width

Set the tolerable value at which "set position reached" (JST) or "automatic set position reached" (JSTA) signal is output when operation parameter group 4 is selected. "Set position reached" (JST) indicates that the machine position is at any station. During automatic operation, "automatic set position reached" (JSTA) is also output under the same condition. These signals will turn OFF when the machine position moves away from the station over this value.

Default value: 0.500

---Setting range---
0.000 to 99999.999 (° or mm)

【#50181】 near4 Operation parameter group 4 Near set position output width

Set the tolerable value at which "near set position" (NEAR) signal is output when operation parameter group 4 is selected.

"Near set position" (NEAR) indicates that the machine position is near any station position. This value is generally set wider than the set position output width. During operations, this is related to the special commands when the station selection is set to "0".

Default value: 1.000

---Setting range---
0.000 to 99999.999 (° or mm)

【#50190】 stpos2 Station 2 coordinate

Set the station 2 coordinate value when non-uniform assignment is selected.

The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

Default value: 0.000

---Setting range---
-99999.999 to 99999.999 (° or mm)

【#50191】 stpos3 Station 3 coordinate

Set the station 3 coordinate value when non-uniform assignment is selected.

The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

Default value: 0.000

---Setting range---
-99999.999 to 99999.999 (° or mm)

【#50192】 stpos4 Station 4 coordinate

Set the station 4 coordinate value when non-uniform assignment is selected.

The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

Default value: 0.000

---Setting range---
-99999.999 to 99999.999 (° or mm)

II Parameters

11. Auxiliary Axis Parameter

【#50193】 stpos5 Station 5 coordinate

Set the station 5 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).
Default value: 0.000

---Setting range---
-99999.999 to 99999.999 (° or mm)

【#50194】 stpos6 Station 6 coordinate

Set the station 6 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).
Default value: 0.000

---Setting range---
-99999.999 to 99999.999 (° or mm)

【#50195】 stpos7 Station 7 coordinate

Set the station 7 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).
Default value: 0.000

---Setting range---
-99999.999 to 99999.999 (° or mm)

【#50196】 stpos8 Station 8 coordinate

Set the station 8 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).
Default value: 0.000

---Setting range---
-99999.999 to 99999.999 (° or mm)

【#50197】 stpos9 Station 9 coordinate

Set the coordinate of each station when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).
Default value: 0.000

---Setting range---
-99999.999 to 99999.999 (° or mm)

【#50200】 PSWcheck PSW detection method

Select the criterion for the output of position switches 1 to 8.
bit0 to 7 correspond to position switches 1 to 8.
0: Judged by the machine position of the command system.
1: Judged by the machine FB position (actual position).
The bits that are not written here must be set to "0".

【#50201】 PSW1 dog1 PSW1 area setting 1

Set "PSW1 area setting" 1 and 2 to specify the area where the position switch 1 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000
---Setting range---
-99999.999 to 99999.999 (° or mm)

【#50202】 PSW1 dog2 PSW1 area setting 2

Set "PSW1 area setting" 1 and 2 to specify the area where the position switch 1 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000
---Setting range---
-99999.999 to 99999.999 (° or mm)

【#50203】 PSW2 dog1 PSW2 area setting 1

Set "PSW2 area setting" 1 and 2 to specify the area where the position switch 2 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000
---Setting range---
-99999.999 to 99999.999 (° or mm)

【#50204】 PSW2 dog2 PSW2 area setting 2

Set "PSW2 area setting" 1 and 2 to specify the area where the position switch 2 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000
---Setting range---
-99999.999 to 99999.999 (° or mm)

II Parameters

11. Auxiliary Axis Parameter

【#50205】 PSW3 dog1 PSW3 area setting 1

Set "PSW3 area setting" 1 and 2 to specify the area where the position switch 3 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

【#50206】 PSW3 dog2 PSW3 area setting 2

Set "PSW3 area setting" 1 and 2 to specify the area where the position switch 3 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

【#50207】 PSW4 dog1 PSW4 area setting 1

Set "PSW4 area setting" 1 and 2 to specify the area where the position switch 4 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

【#50208】 PSW4 dog2 PSW4 area setting 2

Set "PSW4 area setting" 1 and 2 to specify the area where the position switch 4 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

【#50209】 PSW5 dog1 PSW5 area setting 1

Set "PSW5 area setting" 1 and 2 to specify the area where the position switch 5 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

【#50210】 PSW5 dog2 PSW5 area setting 2

Set "PSW5 area setting" 1 and 2 to specify the area where the position switch 5 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

【#50211】 PSW6 dog1 PSW6 area setting 1

Set "PSW6 area setting" 1 and 2 to specify the area where the position switch 6 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

【#50212】 PSW6 dog2 PSW6 area setting 2

Set "PSW6 area setting" 1 and 2 to specify the area where the position switch 6 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

II Parameters

11. Auxiliary Axis Parameter

【#50213】 PSW7 dog1 PSW7 area setting 1

Set "PSW7 area setting" 1 and 2 to specify the area where the position switch 7 will turn ON when the machine is positioned.

Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

【#50214】 PSW7 dog2 PSW7 area setting 2

Set "PSW7 area setting" 1 and 2 to specify the area where the position switch 7 will turn ON when the machine is positioned.

Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

【#50215】 PSW8 dog1 PSW8 area setting 1

Set "PSW8 area setting" 1 and 2 to specify the area where the position switch 8 will turn ON when the machine is positioned.

Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

【#50216】 PSW8 dog2 PSW8 area setting 2

Set "PSW8 area setting" 1 and 2 to specify the area where the position switch 8 will turn ON when the machine is positioned.

Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation. For rotary axes, the output turns ON in the area excluding 0.000 degree.

Default value: 0.000

---Setting range---

-99999.999 to 99999.999 (° or mm)

【#50220】 push.1 Stopper amount

Set the command stroke of the stopper operation in the stopper positioning.

Default value: 0.000

---Setting range---

0.000 to 359.999 (° or mm)

【#50221】 push.t1 Stopper standby time

Set the standby time from the stopper starting coordinate positioning to the stopper operation start in the stopper positioning.

Default value: 0

---Setting range---

0 to 9999 (ms)

【#50222】 push.t2 Stopper torque release time

Set the time from the completion of the stopper operation to the changeover of the stopper torque in the stopper positioning.

Default value: 0

---Setting range---

0 to 9999 (ms)

【#50223】 push.t3 Set position signal output delay time

Set the time from the completion of the stopper operation to the output of the "automatic set position reached" (JSTA), "set position reached" (JST) or "near set position" (NEAR) signal in the stopper positioning.

Default setting: 0

---Setting range---

0 to 9999 (ms)

12. Open Parameter

【#29001】 Open param 1

Set LONG data.
#29001 to #29896 are used as parameter range where C language modules can be used arbitrarily.
---Setting range---
-

【#29901】 Open param 2

Set DOUBLE data.
#29901 to #29996 are used as parameter range where C language modules can be used arbitrarily.
---Setting range---
-

13. CC-Link Parameter

【#24001+40(n-1)(PR)】 SLn station No. CC-Link station No.

Set the station No. of the CC-Link I/F unit.
"n" represents the expansion slot No.(n=1 to 3)
-1: Invalid
0: Master station
1 to 64: Slave station

---Master station---
Set a value within the setting range.

---Local/standby master station---
Set a value within the setting range.

---Setting range---
-1 to 64

【#24002+40(n-1)(PR)】 SLn line spd&Mode CC-Link transmission rate and mode

Select the transmission rate and operation mode of the CC-Link I/F unit.
"n" represents the expansion slot No.(n=1 to 3)

<Online mode>
0 : 156Kbps
1 : 625Kbps
2 : 2.5Mbps
3 : 5Mbps
4 : 10M

<Circuit test mode>
5 : 156Kbps
6 : 625Kbps
7 : 2.5Mbps
8 : 5Mbps
9 : 10Mbps

<Hardware test mode>
10 : 156Kbps
11 : 625Kbps
12 : 2.5Mbps
13 : 5Mbps
14 : 10Mbps

(Note) Perform hardware test after removing the CC-Link cable.

---Master station---
Set a value within the setting range.

---Local/standby master station---
Set a value within the setting range.

---Setting range---
0 to 14

【#24003+40(n-1)(PR)】 SLn set fault sta Setting of data link faulty station

Select whether to clear or hold the data input from the data link faulty station.
"n" represents the expansion slot No.(n=1 to 3)
0: Clear
1: Hold

(Note) Refer to "CC-Link System Master/Local Module User's Manual (SH(NA)-080394E-E)" for the details of the functions.

---Master station---
Set to "0" or "1".

---Local/standby master station---
Set to "0" or "1".

【#24004+40(n-1)】 SLn PLC stop set Setting at PLC STOP

Set whether to refresh or compulsorily clear the slave stations at PLC STOP.
"n" represents the expansion slot No.(n=1 to 3)
0: Refresh
1: Compulsorily clear

(Note) Refer to "CC-Link System Master/Local Module User's Manual (SH(NA)-080394E-E)" for the details of the functions.

---Master station---
Set to "0" or "1".

---Local/standby master station---
Set to "0" or "1".

【#24005+40(n-1)(PR)】 SLn occ stations Number of occupied stations

Set the number of occupied local and standby master stations.
"n" represents the expansion slot No.(n=1 to 3)

---Master station---
Set to "0".

---Local/standby master station---
Set to either of "1" to "4".

---Setting range---
0 to 4

II Parameters

13. CC-Link Parameter

【#24006+40(n-1)(PR)】 SLn extended cyc Extended cyclic setting

Set the magnification for the extended cyclic operation of the local station whose type corresponds to Ver.2.

"n" represents the expansion slot No.(n=1 to 3)

Set "1" for the local station whose type corresponds to Ver.1.

This function is out of specifications when the protocol version is Ver.1. The setting for the local station is fixed to "1".

---Master station---

Set to "0".

---Local/standby master station---

Set to either of "1", "2", "4" or "8".

---Setting range---

0,1,2,4,8 (fold)

【#24007+40(n-1)】 SLn conn modules Number of connected modules

Set the total number of remote stations, local stations, intelligent device stations, standby master station and reserved stations connected to the master station.

"n" represents the expansion slot No.(n=1 to 3)

---Master station---

Set to either of "1" to "64".

---Local/standby master station---

Set to "0".

---Setting range---

0 to 64 (modules)

【#24008+40(n-1)】 SLn num of retries Number of retries

Set the number of retries for when a communication error occurs.

"n" represents the expansion slot No.(n=1 to 3)

---Master station---

Set to either of "1" or "7".

---Local/standby master station---

Set to "0".

---Setting range---

0 to 7 (times)

【#24009+40(n-1)】 SLn auto ret mdl's Number of automatic return modules

Set the total number of remote stations, local stations, intelligent device stations and standby master station that can be returned to system operation by a single link scan.

"n" represents the expansion slot No.(n=1 to 3)

(Note) Refer to "CC-Link System Master/Local Module User's Manual (SH(NA)-080394E-E)" for the details of the functions.

---Master station---

Set to either of "1" or "10".

---Local/standby master station---

Set to "0".

---Setting range---

0 to 10 (modules)

【#24010+40(n-1)(PR)】 SLn STBY master st Standby master station

Set the station No. of the standby master station.

"n" represents the expansion slot No.(n=1 to 3)

Set "0" when no standby master station is provided.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set "0" (fixed) for the local station.

Set "1" (fixed) for the standby station.

---Setting range---

0 to 64

【#24011+40(n-1)】 SLn ope at NC down Operation at NC down

Set the data link status for when the master station failure occurs.

"n" represents the expansion slot No.(n=1 to 3)

0: Fixed to stop

(Note) Refer to "CC-Link System Master/Local Module User's Manual (SH(NA)-080394E-E)" for the details of the functions.

---Master station---

Set to "0" (fixed).

---Local/standby master station---

Set to "0".

II Parameters

13. CC-Link Parameter

【#24012+40(n-1)】 SLn scan mode Scan mode

Select whether to synchronize the link scan with one ladder scan.
"n" represents the expansion slot No.(n=1 to 3)
0: Fixed to synchronize
---Master station---
Set to "0" (fixed).
---Local/standby master station---
Set to "0".

【#24013+40(n-1)】 SLn delay time Delay time

Set the delay time.
"n" represents the expansion slot No.(n=1 to 3)
0: (Fixed value)
---Master station---
Set to "0" (fixed).
---Local/standby master station---
Set to "0".

【#24014+40(n-1)】 SLn RX dev name Remote input (RX) refresh device name

Set the refresh device name of the remote input (RX) to be automatically refreshed.
(Example) X
"n" represents the expansion slot No.(n=1 to 3)
Set "0" when no setting is required.
---Master station---
Set a value within the setting range.
---Local/standby master station---
Set a value within the setting range.
---Setting range---
0,X,M,L,B,D,W,R

【#24015+40(n-1)】 SLn RX dev No. Remote input (RX) refresh device No.

Set the refresh device No. of the remote input (RX) to be automatically refreshed.
"n" represents the expansion slot No.(n=1 to 3)

(Note 1) When setting parameters in ALL.PRM with using the parameter input/output function, input the device No. of decimal digit.

(Example) When setting "X400" for the remote input (RX) refresh device No., input as follows; #24014+40(n-1): "X"
#24015+40(n-1): "1024"

(Note 2) When the refresh device name has been set, the refresh device No. will be "0". Confirm the refresh device No. after changing the refresh device name.

When specifying a bit device, set the address in increments of 16 points.
The operation will not be guaranteed unless the address is set in increments of 16 points.
(Example) 1000

---Master station---
Set a value within the setting range.
---Local/standby master station---
Set a value within the setting range.
---Setting range---
X: 0 to 5FF
M: 0 to 10239
L: 0 to 511
B: 0 to 1FFF
D: 0 to 2047
W: 0 to 1FFF
R: 8300 to 9799, 9800 to 9899

【#24016+40(n-1)(PR)】 SLn RY dev name Remote output (RY) refresh device name

Set the refresh device name of the remote output (RY) to be automatically refreshed.
(Example) Y
"n" represents the expansion slot No.(n=1 to 3)
Set "0" when no setting is required.
---Master station---
Set a value within the setting range.
---Local/standby master station---
Set a value within the setting range.
---Setting range---
0,Y,M,L,B,D,W,R

II Parameters

13. CC-Link Parameter

【#24017+40(n-1)】 SLn RY dev No. Remote output (RY) refresh device No.

Set the refresh device No. of the remote output (RY) to be automatically refreshed.
"n" represents the expansion slot No.(n=1 to 3)

(Note 1) When setting parameters in ALL.PRM with using the parameter input/output function, input the device No. of decimal digit.

(Example) When setting "X400" for the remote input (RX) refresh device No., input as follows; #24014+40(n-1): "X" #24015+40(n-1): "1024"

(Note 2) When the refresh device name has been set, the refresh device No. will be "0". Confirm the refresh device No. after changing the refresh device name.

When specifying a bit device, set the address in increments of 16 points.
The operation will not be guaranteed unless the address is set in increments of 16 points.
(Example) 1000

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

---Setting range---

Y: 0 to 5FF

M: 0 to 10239

L: 0 to 511

B: 0 to 1FFF

D: 0 to 2047

W: 0 to 1FFF

R: 8300 to 9799, 9800 to 9899

【#24018+40(n-1)】 SLn RWr dev name Remote register (RWr) refresh device name

Set the refresh device name of the remote register (RWr) to be automatically refreshed.
(Example) W

"n" represents the expansion slot No.(n=1 to 3)

Set "0" when no setting is required.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

---Setting range---

0,M,L,B,D,W,R

【#24019+40(n-1)】 SLn RWr dev No. Remote register (RWr) refresh device No.

Set the refresh device No. of the remote register (RWr) to be automatically refreshed.
"n" represents the expansion slot No.(n=1 to 3)

(Note 1) When setting parameters in ALL.PRM with using the parameter input/output function, input the device No. of decimal digit.

(Example) When setting "X400" for the remote input (RX) refresh device No., input as follows; #24014+40(n-1): "X" #24015+40(n-1): "1024"

(Note 2) When the refresh device name has been set, the refresh device No. will be "0". Confirm the refresh device No. after changing the refresh device name.

When specifying a bit device, set the address in increments of 16 points.
The operation will not be guaranteed unless the address is set in increments of 16 points.
(Example) 1FF0

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

---Setting range---

M: 0 to 10239

L: 0 to 511

B: 0 to 1FFF

D: 0 to 2047

W: 0 to 1FFF

R: 8300 to 9799, 9800 to 9899

【#24020+40(n-1)】 SLn RWw dev name Remote register (RWw) refresh device name

Set the refresh device name of the remote register (RWw) to be automatically refreshed.
(Example) W

"n" represents the expansion slot No.(n=1 to 3)

Set "0" when no setting is required.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

---Setting range---

0,M,L,B,D,W,R

II Parameters

13. CC-Link Parameter

【#24021+40(n-1)】 SLn RWw dev No. Remote register (RWw) refresh device No.

Set the refresh device No. of the remote register (RWw) to be automatically refreshed.
"n" represents the expansion slot No.(n=1 to 3)

(Note 1) When setting parameters in ALL.PRM with using the parameter input/output function, input the device No. of decimal digit.

(Example) When setting "X400" for the remote input (RX) refresh device No., input as follows; #24014+40(n-1): "X" #24015+40(n-1): "1024"

(Note 2) When the refresh device name has been set, the refresh device No. will be "0". Confirm the refresh device No. after changing the refresh device name.

When specifying a bit device, set the address in increments of 16 points.
The operation will not be guaranteed unless the address is set in increments of 16 points.
(Example) 1FF0

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

---Setting range---

M: 0 to 10239

L: 0 to 511

B: 0 to 1FFF

D: 0 to 2047

W: 0 to 1FFF

R: 8300 to 9799, 9800 to 9899

【#24022+40(n-1)】 SLn SB dev name Special relay (SB) refresh device name

Set the refresh device name of the special relay (SB) to be automatically refreshed.
(Example) SB

"n" represents the expansion slot No.(n=1 to 3)

Set "0" when no setting is required.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

---Setting range---

0,M,L,B,D,W,R,SB

【#24023+40(n-1)】 SLn SB dev No. Special relay (SB) refresh device No.

Set the refresh device No. of the special relay (SB) to be automatically refreshed.
"n" represents the expansion slot No.(n=1 to 3)

(Note 1) When setting parameters in ALL.PRM with using the parameter input/output function, input the device No. of decimal digit.

(Example) When setting "X400" for the remote input (RX) refresh device No., input as follows; #24014+40(n-1): "X" #24015+40(n-1): "1024"

(Note 2) When the refresh device name has been set, the refresh device No. will be "0". Confirm the refresh device No. after changing the refresh device name.

When specifying a bit device, set the address in increments of 16 points.
The operation will not be guaranteed unless the address is set in increments of 16 points.
(Example) 1F0

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

---Setting range---

M: 0 to 10239

L: 0 to 511

B: 0 to 1FFF

D: 0 to 2047

W: 0 to 1FFF

SB: 0 to 1FF

R: 8300 to 9799, 9800 to 9899

【#24024+40(n-1)】 SLn SW dev name Special relay (SW) refresh device name

Set the refresh device name of the special relay (SW) to be automatically refreshed.
"n" represents the expansion slot No.(n=1 to 3)

(Example) SW

Set "0" when no setting is required.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

---Setting range---

0,M,L,B,D,W,R,SW

II Parameters

13. CC-Link Parameter

【#24025+40(n-1)】 SLn SW dev No. Special relay (SW) refresh device No.

Set the refresh device No. of the special relay (SW) to be automatically refreshed.
"n" represents the expansion slot No.(n=1 to 3)

(Note 1) When setting parameters in ALL.PRM with using the parameter input/output function, input the device No. of decimal digit.
(Example) When setting "X400" for the remote input (RX) refresh device No., input as follows;
#24014+40(n-1): "X"
#24015+40(n-1): "1024"

(Note 2) When the refresh device name has been set, the refresh device No. will be "0". Confirm the refresh device No. after changing the refresh device name.

When specifying a bit device, set the address in increments of 16 points.
(Example) 1F0

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

---Setting range---

M: 0 to 10239

L: 0 to 511

B: 0 to 1FFF

D: 0 to 2047

W: 0 to 1FFF

SW: 0 to 1FF

R: 8300 to 9799, 9800 to 9899

【#24026+40(n-1)(PR)】 SLn Protocol Ver Protocol version

Select the CC-Link version mode that has been set to the slide switch SW1-2 on the CC-Link unit (HN566/HN567).

"n" represents the expansion slot No.(n=1 to 3)

0: Ver.2

1: Ver.1

Ver.2 mode has been set to SW1-2 as default.

---Master station---

Set to "0" or "1".

---Local/standby master station---

Set to "0" or "1".

【#24121+15(m-1)】 CNm station type Station type

Set the type of the connected remote station, local station, intelligent device station and standby master station.

0: No setting

1: Ver.1 remote I/O station

2: Ver.1 remote device station

3: Ver.1 intelligent device station

4: Ver.2 remote device station

5: Ver.2 intelligent device station

"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)

---Master station---

Set to either of "0" to "5".

---Local/standby master station---

Set to "0".

【#24122+15(m-1)】 CNm extended cyc Extended cyclic setting

Select the magnification for the extended cycling operation of the connected remote, local and intelligent stations.

Set "1" when the protocol version is Ver.1.

Set "0" when no setting is required.

"m" means the m-th connected station in ascending order of station No. (m=1 to 64)

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set to "0".

---Setting range---

0,1,2,4,8 (times)

【#24123+15(m-1)】 CNm occ stations Number of occupied stations

Set the number of the occupied stations by the connected remote, local and intelligent stations.

Set 1 for 8 points I/O and 16 points I/O.

Set "0" when no setting is required.

"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set to "0".

---Setting range---

0 to 4 (stations occupied)

II Parameters

13. CC-Link Parameter

【#24124+15(m-1)】 CNm station No. Station No.

- Set the station No. of the connected remote, local and intelligent stations.
Set "0" when no setting is required.
"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)
- Master station---
Set a value within the setting range.
 - Local/standby master station---
Set to "0".
 - Setting range---
0 to 64

【#24125+15(m-1)】 CNm remote sta pt Remote station points

- Select the number of points of the connected remote station.
"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)
The details of setting values differ with each protocol version and station type.
- Protocol: Ver.2 (station type: Ver.1, remote I/O station)
- 0: 0 point (reserved station)
 - 1: 8 points
 - 2: 8 points + 8 points reserved
 - 3: 16 points
 - 4: 32 points
- Setting 0 is valid only for the reserved station. When 0 is set for the other stations, the number of points will be 32.
 - Set the value so that the total number of points of remote I/O stations connected in series will be multiple of 16.
- (Example 1) 2 units of 8 points I/O: Set "1" for each
(Example 2) 3 units of 8 points I/O: Set "1" for the first and the second I/O, "2" for the third.
- Protocol: Ver.2 (station type: Ver.1 except remote I/O station)
- 0: 0 point (reserved station)
 - 1 to 4: Automatically calculated
- 0 point is valid only for the reserved station. When 0 is set for the other stations, the number of points will be automatically calculated.
 - Unless 0 is set, the number of points will be automatically calculated with the number of occupied stations and the setting value of the extended cycling.
- Protocol: Ver.1 (for all station types)
- 0 to 4: Automatically calculated
- 0 cannot be set even for the reserved station.
 - Automatically calculated with the setting value of the number of occupied stations.
- Master station---
Set a value corresponding to the protocol version and the station type.
 - Local/standby master station---
Set to "0".

【#24126+15(m-1)】 CNm set rsvd sta Reserved station

- Set the reserved/error invalid station.
"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)
- 0: No setting
 - 1: Reserved station
 - 2: Error invalid station
- (Note) Refer to "CC-Link System Master/Local Module User's Manual (SH(NA)-080394E-E)" for the details of the functions.
- Master station---
Set either of "0" to "2".
 - Local/standby master station---
Set to "0".

【#24131+15(m-1)】 CNm send size Send buffer size

- Set the allocation of the buffer memory size to the local station, standby master station and intelligent device station when in transient transmission.
"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)
Set "0" when no setting is required.
- (Note) The total size of the send/receive buffers must be 4096 (words) or less.
- Master station---
Set a value within the setting range.
 - Local/standby master station---
Set to "0".
 - Setting range---
0, 64 to 4096 (words)

II Parameters

13. CC-Link Parameter

【#24132+15(m-1)】 CNm receive size Receive buffer size

Set the allocation of the buffer memory size to the local station, standby master station and intelligent device station when in transient transmission.

"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)

Set "0" when no setting is required.

(Note) The total size of the send/receive buffers must be 4096 (words) or less.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set to "0".

---Setting range---

0, 64 to 4096 (words)

【#24133+15(m-1)】 CNm auto bfr size Automatic update buffer size

Set the allocation of the buffer memory size to the local station, standby master station and intelligent device station when in transient transmission.

"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)

Set "0" when no setting is required.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set to "0".

---Setting range---

0, 128 to 4096 (words)

14. Anshin-net Parameter 2 / MTB-net Parameter 2

【#10901(PR) Modem tel num

Set the PHS modem's registered No. (telephone No.).
 This is used for the authentication by the host.
 A hyphen "-" can be used as a delimiting character.
 This parameter is used as both Anshin-net parameter 2 and MTB-net parameter 2.
 ---Setting range---
 Within 28 characters

【#10902(PR) Num dispatch call

Set a call No. to Call Center.
 Enter from the area code for domestic calls.
 Enter from the communication company No. for international calls.
 A hyphen "-" can be used as a delimiting character.
 ---Setting range---
 Within 28 characters

【#10903(PR) Num arrival call 1

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.
 Enter from the area code for domestic calls.
 Enter from the communication company No. for international calls.
 This is used to distinguish between received calls from Call Center and those from machine tool builder.
 A hyphen "-" can be used as a delimiting character.
 ---Setting range---
 Within 28 characters

【#10904(PR) Num arrival call 2

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.
 Enter from the area code for domestic calls.
 Enter from the communication company No. for international calls.
 This is used to distinguish between received calls from Call Center and those from machine tool builder.
 A hyphen "-" can be used as a delimiting character.
 ---Setting range---
 Within 28 characters

【#10905(PR) Num arrival call 3

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.
 Enter from the area code for domestic calls.
 Enter from the communication company No. for international calls.
 This is used to distinguish between received calls from Call Center and those from machine tool builder.
 A hyphen "-" can be used as a delimiting character.
 ---Setting range---
 Within 28 characters

【#10906(PR) Num arrival call 4

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.
 Enter from the area code for domestic calls.
 Enter from the communication company No. for international calls.
 This is used to distinguish between received calls from Call Center and those from machine tool builder.
 A hyphen "-" can be used as a delimiting character.
 ---Setting range---
 Within 28 characters

【#10907(PR) Num arrival call 5

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.
 Enter from the area code for domestic calls.
 Enter from the communication company No. for international calls.
 This is used to distinguish between received calls from Call Center and those from machine tool builder.
 A hyphen "-" can be used as a delimiting character.
 ---Setting range---
 Within 28 characters

【#10908(PR) Num dispatch call

Set a call No. to a machine tool builder.
 Enter from the area code for domestic calls.
 Enter from the communication company No. for international calls.
 A hyphen "-" can be used as a delimiting character.
 ---Setting range---
 Within 28 characters

II Parameters

14. Anshin-net Parameter 2 / MTB-net Parameter 2

【#10909(PR)】 Num arrival call 1

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.
Enter from the area code for domestic calls.
Enter from the communication company No. for international calls.
This is used to distinguish between received calls from Call Center and those from machine tool builder.
A hyphen "-" can be used as a delimiting character.

---Setting range---
Within 28 characters

【#10910(PR)】 Num arrival call 2

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.
Enter from the area code for domestic calls.
Enter from the communication company No. for international calls.
This is used to distinguish between received calls from Call Center and those from machine tool builder.
A hyphen "-" can be used as a delimiting character.

---Setting range---
Within 28 characters

【#10911(PR)】 Num arrival call 3

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.
Enter from the area code for domestic calls.
Enter from the communication company No. for international calls.
This is used to distinguish between received calls from Call Center and those from machine tool builder.
A hyphen "-" can be used as a delimiting character.

---Setting range---
Within 28 characters

【#10912(PR)】 Num arrival call 4

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.
Enter from the area code for domestic calls.
Enter from the communication company No. for international calls.
This is used to distinguish between received calls from Call Center and those from machine tool builder.
A hyphen "-" can be used as a delimiting character.

---Setting range---
Within 28 characters

【#10913(PR)】 Num arrival call 5

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.
Enter from the area code for domestic calls.
Enter from the communication company No. for international calls.
This is used to distinguish between received calls from Call Center and those from machine tool builder.
A hyphen "-" can be used as a delimiting character.

---Setting range---
Within 28 characters

【#10914】 Auto select anet

Set whether to change to the Anshin-net screen when a call is automatically dispatched from the NC.
(Currently not used.)
0: Not change
1: Change

【#10915】 Num retry

Set the number of times to retry when a control command transmission error occurs.
Standard setting: 3

---Setting range---
0 to 255

【#10916】 Command time out

Set the timeout time for reception command standby.
Standard setting: 30 (s)

---Setting range---
0 to 65535 (s)

【#10917】 Frequ of redial

Set the number of times to redial.
Standard setting: 3
This parameter is used as both Anshin-net parameter 2 and MTB-net parameter 2.

---Setting range---
0 to 255

【#10918】 Interval of redial

Set the redial interval.
Standard setting: 100 (s)
This parameter is used as both Anshin-net parameter 2 and MTB-net parameter 2.

---Setting range---
0 to 65535 (s)

II Parameters

14. Anshin-net Parameter 2 / MTB-net Parameter 2

【#10919(PR)】 Modem connect port

Select the modem connection port.

- 1: Port 1
- 2: Port 2

This parameter is used as both Anshin-net parameter 2 and MTB-net parameter 2.

【#10920】 Dial mode select

Select the dialing method.

- 0: Fixed by modem (default)
- 1: Dial with tone (push) method
- 2: Dial with pulse (dial) method

This parameter is used as both Anshin-net parameter 2 and MTB-net parameter 2.

【#10921】 Call wait time

Set the call back waiting time.

Default value: 0

This parameter is used as both Anshin-net parameter 2 and MTB-net parameter 2.

---Setting range---

0 to 90 (s)

【#10922】 Machine Num

Set the machine's serial number as information for the machine tool builder to recognize the machine. This parameter is supposed to be input by the machine tool builder (when shipping or when starting the machine tool builder network). If this is set to blank, the system cannot connect with remote diagnosis tool kit.

---Setting range---

Within 15 characters (one-byte alphanumeric characters)

【#10951(PR)】 Condition kind 1

Set the condition (alarm or PLC signal) for the automatic notification of alarms.

Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>

- Operation alarm (Mxx)
- Stop code (Txx)
- Servo alarm (Sxx)
- Spindle servo alarm (Sxx)
- System alarm (Zxx)
- Absolute position detection alarm (Zxx)
- Emergency stop (EMG)
- Auxiliary axis servo alarm (Sxx)
- Auxiliary axis absolute position detection alarm (Zxx)
- Auxiliary axis OP error (Mxx)
- Auxiliary axis MCP alarm (Yxx)
- Computer link error (Lxx)
- Operation error (Exx)
- User PLC alarm (PLxx)

<Device (resister)>

- 1-bit data ... X,Y,U,W
- 16-bit data ... R

(Note 1) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" when setting "0" for "Condition num". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 5 characters

【#10952(PR)】 Condition num 1

Set the condition (alarm or PLC signal) for the automatic notification of alarms.

Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 4 characters

II Parameters

14. Anshin-net Parameter 2 / MTB-net Parameter 2

【#10953(PR)】 Condition kind 2

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>
Operation alarm (Mxx)
Stop code (Txx)
Servo alarm (Sxx)
Spindle servo alarm (Sxx)
System alarm (Zxx)
Absolute position detection alarm (Zxx)
Emergency stop (EMG)
Auxiliary axis servo alarm (Sxx)
Auxiliary axis absolute position detection alarm (Zxx)
Auxiliary axis OP error (Mxx)
Auxiliary axis MCP alarm (Yxx)
Computer link error (Lxx)
Operation error (Exx)
User PLC alarm (PLxx)

<Device (resister)>
1-bit data ... X,Y,U,W
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---
Within 5 characters

【#10954(PR)】 Condition num 2

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---
Within 4 characters

【#10955(PR)】 Condition kind 3

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>
Operation alarm (Mxx)
Stop code (Txx)
Servo alarm (Sxx)
Spindle servo alarm (Sxx)
System alarm (Zxx)
Absolute position detection alarm (Zxx)
Emergency stop (EMG)
Auxiliary axis servo alarm (Sxx)
Auxiliary axis absolute position detection alarm (Zxx)
Auxiliary axis OP error (Mxx)
Auxiliary axis MCP alarm (Yxx)
Computer link error (Lxx)
Operation error (Exx)
User PLC alarm (PLxx)

<Device (resister)>
1-bit data ... X,Y,U,W
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---
Within 5 characters

【#10956(PR)】 Condition num 3

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---
Within 4 characters

【#10957(PR)】 Condition kind 4

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>
Operation alarm (Mxx)
Stop code (Txx)
Servo alarm (Sxx)
Spindle servo alarm (Sxx)
System alarm (Zxx)
Absolute position detection alarm (Zxx)
Emergency stop (EMG)
Auxiliary axis servo alarm (Sxx)
Auxiliary axis absolute position detection alarm (Zxx)
Auxiliary axis OP error (Mxx)
Auxiliary axis MCP alarm (Yxx)
Computer link error (Lxx)
Operation error (Exx)
User PLC alarm (PLxx)

<Device (resister)>
1-bit data ... X,Y,U,W
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---
Within 5 characters

【#10958(PR)】 Condition num 4

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---
Within 4 characters

【#10959(PR)】 Condition kind 5

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>
Operation alarm (Mxx)
Stop code (Txx)
Servo alarm (Sxx)
Spindle servo alarm (Sxx)
System alarm (Zxx)
Absolute position detection alarm (Zxx)
Emergency stop (EMG)
Auxiliary axis servo alarm (Sxx)
Auxiliary axis absolute position detection alarm (Zxx)
Auxiliary axis OP error (Mxx)
Auxiliary axis MCP alarm (Yxx)
Computer link error (Lxx)
Operation error (Exx)
User PLC alarm (PLxx)

<Device (resister)>
1-bit data ... X,Y,U,W
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---
Within 5 characters

【#10960(PR)】 Condition num 5

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---
Within 4 characters

【#10961(PR)】 Condition kind 6

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>

Operation alarm (Mxx)
Stop code (Txx)
Servo alarm (Sxx)
Spindle servo alarm (Sxx)
System alarm (Zxx)
Absolute position detection alarm (Zxx)
Emergency stop (EMG)
Auxiliary axis servo alarm (Sxx)
Auxiliary axis absolute position detection alarm (Zxx)
Auxiliary axis OP error (Mxx)
Auxiliary axis MCP alarm (Yxx)
Computer link error (Lxx)
Operation error (Exx)
User PLC alarm (PLxx)

<Device (register)>

1-bit data ... X,Y,U,W
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 5 characters

【#10962(PR)】 Condition num 6

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 4 characters

【#10963(PR)】 Condition kind 7

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>

Operation alarm (Mxx)
Stop code (Txx)
Servo alarm (Sxx)
Spindle servo alarm (Sxx)
System alarm (Zxx)
Absolute position detection alarm (Zxx)
Emergency stop (EMG)
Auxiliary axis servo alarm (Sxx)
Auxiliary axis absolute position detection alarm (Zxx)
Auxiliary axis OP error (Mxx)
Auxiliary axis MCP alarm (Yxx)
Computer link error (Lxx)
Operation error (Exx)
User PLC alarm (PLxx)

<Device (register)>

1-bit data ... X,Y,U,W
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 5 characters

【#10964(PR)】 Condition num 7

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 4 characters

【#10965(PR)】 Condition kind 8

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>

Operation alarm (Mxx)
Stop code (Txx)
Servo alarm (Sxx)
Spindle servo alarm (Sxx)
System alarm (Zxx)
Absolute position detection alarm (Zxx)
Emergency stop (EMG)
Auxiliary axis servo alarm (Sxx)
Auxiliary axis absolute position detection alarm (Zxx)
Auxiliary axis OP error (Mxx)
Auxiliary axis MCP alarm (Yxx)
Computer link error (Lxx)
Operation error (Exx)
User PLC alarm (PLxx)

<Device (register)>

1-bit data ... X,Y,U,W
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 5 characters

【#10966(PR)】 Condition num 8

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 4 characters

【#10967(PR)】 Condition kind 9

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>

Operation alarm (Mxx)
Stop code (Txx)
Servo alarm (Sxx)
Spindle servo alarm (Sxx)
System alarm (Zxx)
Absolute position detection alarm (Zxx)
Emergency stop (EMG)
Auxiliary axis servo alarm (Sxx)
Auxiliary axis absolute position detection alarm (Zxx)
Auxiliary axis OP error (Mxx)
Auxiliary axis MCP alarm (Yxx)
Computer link error (Lxx)
Operation error (Exx)
User PLC alarm (PLxx)

<Device (register)>

1-bit data ... X,Y,U,W
16-bit data ... R

(Note 1) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" when setting "0" for "Condition num". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 5 characters

【#10968(PR)】 Condition num 9

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 4 characters

II Parameters

14. Anshin-net Parameter 2 / MTB-net Parameter 2

【#10969(PR)】 Condition kind 10

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>

- Operation alarm (Mxx)
- Stop code (Txx)
- Servo alarm (Sxx)
- Spindle servo alarm (Sxx)
- System alarm (Zxx)
- Absolute position detection alarm (Zxx)
- Emergency stop (EMG)
- Auxiliary axis servo alarm (Sxx)
- Auxiliary axis absolute position detection alarm (Zxx)
- Auxiliary axis OP error (Mxx)
- Auxiliary axis MCP alarm (Yxx)
- Computer link error (Lxx)
- Operation error (Exx)
- User PLC alarm (PLxx)

<Device (register)>

- 1-bit data ... X,Y,U,W
- 16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 5 characters

【#10970(PR)】 Condition num 10

Set the condition (alarm or PLC signal) for the automatic notification of alarms.
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 4 characters

15. PLC Axis Parameters

【#12800(PR)】 chgauxno Auxiliary axis number

Set the axis No. to be controlled as auxiliary axis using auxiliary axis interface.

---Setting range---
0 to 16

【#12801(PR)】 aux_station Number of indexing stations

Set the number of stations. For linear axis, this value is expressed by: number of divisions = number of stations -1.

---Setting range---
2 to 360

【#12802(PR)】 aux_Cont1 Control parameter 1

The bits that are not explained here must be set to "0".

Bit3:

0: Automatic reach signal isn't interlocked with the start signal.
1: Automatic reach signal is interlocked with the start signal.

Bit4:

0: Automatic reach signal is turned ON again.
1: Automatic reach signal isn't turned ON again.

Bit5:

0: Station No. Output within fixed position.
1: Station No. Constantly output.

bit9:

0: Rotation direction determined by operation control signal (DIR)
1: Rotation direction in the shortcut direction

bitE:

0: Rotation direction in operation control signal (DIR) or in the shortcut direction
1: Rotation direction in the arbitrary position command sign direction

bitF:

0: Stopper direction is in the positioning direction.
1: Stopper direction is in the sign direction of the stopper amount.

【#12803(PR)】 aux_Cont2 Control parameter 2

The bits that are not explained here must be set to "0".

bit4:

0: Uniform index
1: Non-uniform index

【#12804(PR)】 aux_tleng Linear axis stroke length

Set the movement stroke length for linear axes. This parameter is meaningless at the non-uniform index or random position command.

---Setting range---
0.001 to 99999.999 (mm)

【#12805】 aux_ST.offset Station offset

Set the distance (offset) from the reference position to station 1.

---Setting range---
-99999.999 to 99999.999 (° or mm)

【#12810+10(n-1)】 aux_Aspeedn Operation parameter group n Automatic operation speed

Set the feedrate during automatic operation when "operation parameter group n" is selected.

"#12810 aux_Aspeed1" is regarded as the clamp value for the automatic operation speeds and manual operation speeds of all operation groups.

A speed exceeding "aux_Aspeed1" cannot be commanded, even if it is set in a parameter.

---Setting range---
1 to 100000 (°/min or mm/min)

【#12811+10(n-1)】 aux_Mspeedn Operation parameter group n Manual operation speed

Set the feedrate during manual operation or JOG operation when "operation parameter group n" is selected.

---Setting range---
1 to 100000 (°/min or mm/min)

II Parameters

15. PLC Axis Parameters

【#12812+10(n-1)】 aux_timen.1 Operation parameter group n Acceleration/deceleration time

Set the linear acceleration/deceleration time for "Operation parameter group 1 automatic operation speed" (clamp speed) when "operation parameter group n" is selected. When this is set with "Acceleration/deceleration time constant 2", S-pattern acceleration/deceleration will be carried out. In this case, this parameter determines the acceleration/deceleration time of the linear part. When operating at a speed less than the clamp speed, if "#1361 aux_acc" is set to "0", the axis will accelerate/decelerate with the time constant set in this parameter. If "#1361 aux_acc" is set to "1", the axis will accelerate/decelerate at the constant inclination determined by this parameter and "aux_Aspeed1".

---Setting range---
1 to 4000 (ms)

【#12813+10(n-1)】 aux_timen.2 Operation parameter group n Acceleration/deceleration time

Set the total time of the non-linear parts in the S-pattern acceleration/deceleration. When "1" is set, linear acceleration/deceleration will be carried out. In the handle feed operation mode, this setting value is regarded as time constant for the linear acceleration/deceleration.

---Setting range---
1 to 4000 (ms)

【#12814+10(n-1)】 aux_TLn Operation parameter group n Torque limit value

Set the motor output torque limit value when "operation parameter group n" is selected. At the default value, the torque is limited at the maximum torque of the motor specifications. Set the default value when torque limit is not especially required. In the stopper positioning operation mode, this will be regarded as torque limit value when positioning to the stopper starting coordinates.

---Setting range---
1 to 500(%)

【#12815+10(n-1)】 aux_ODn Operation parameter group n Excessive error detection width

Set the excessive error detection width when "operation parameter group n" is selected. The excessive error alarm (S03 0052) will be detected when the position droop becomes larger than this setting value. In the stopper positioning operation mode, this will be regarded as excessive error detection width when positioning to the stopper starting coordinates. .

---Setting range---
0 to 32767(° or mm)

【#12816+10(n-1)】 aux_justn Operation parameter group n Set position output width

Set the tolerable value at which "set position reached" (JST) or "automatic set position reached" (JSTA) signal is output when "operation parameter group n" is selected. "Set position reached" (JST) indicates that the machine position is at any station. During automatic operation, "automatic set position reached" (JSTA) is also output under the same condition. These signals will turn OFF when the machine position moves away from the station over this value.

---Setting range---
0.000 to 99999.999(° or mm)

【#12817+10(n-1)】 aux_nearn Operation parameter group n Near set position output width

Set the tolerable value at which "near set position" (NEAR) signal is output when "operation parameter group n" is selected. "Near set position" (NEAR) indicates that the machine position is near any station position. This value is generally set wider than the set position output width. During operations, this is related to the special commands when the station selection is set to "0".

---Setting range---
0.000 to 99999.999(° or mm)

【#12818+10(n-1)(PR)】 aux_smgstn Operation parameter group n Acceleration/Deceleration type

Select the acceleration/deceleration type when "operation parameter group n" is selected.
1: Linear acceleration/deceleration
F: S-pattern acceleration/deceleration

【#12850】 aux_stpos2 Station 2 coordinate

Set the station 2 coordinate value when non-uniform assignment is selected. The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12851】 aux_stpos3 Station 3 coordinate

Set the station 3 coordinate value when non-uniform assignment is selected. The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

II Parameters

15. PLC Axis Parameters

【#12852】 aux_stpos4 Station 4 coordinate

Set the station 4 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12853】 aux_stpos5 Station 5 coordinate

Set the station 5 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12854】 aux_stpos6 Station 6 coordinate

Set the station 6 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12855】 aux_stpos7 Station 7 coordinate

Set the station 7 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12856】 aux_stpos8 Station 8 coordinate

Set the station 8 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12857】 aux_stpos9 Station 9 coordinate

Set the coordinate of each station when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12858】 aux_stpos10 Station 10 coordinate

Set the station 10 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12859】 aux_stpos11 Station 11 coordinate

Set the station 11 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12860】 aux_stpos12 Station 12 coordinate

Set the station 12 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12861】 aux_stpos13 Station 13 coordinate

Set the station 13 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12862】 aux_stpos14 Station 14 coordinate

Set the station 14 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12863】 aux_stpos15 Station 15 coordinate

Set the station 15 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12864】 aux_stpos16 Station 16 coordinate

Set the station 16 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

II Parameters

15. PLC Axis Parameters

【#12865】 aux_stpos17 Station 17 coordinate

Set the station 17 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12866】 aux_stpos18 Station 18 coordinate

Set the station 18 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12867】 aux_stpos19 Station 19 coordinate

Set the station 19 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12868】 aux_stpos20 Station 20 coordinate

Set the station 20 coordinate value when non-uniform assignment is selected.
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12870】 aux_PSWcheck PSW detection method

Select the criterion for the output of position switches 1 to 15.
bit0 to E correspond to position switches 1 to 15.
0: Judged by the machine position of the command system.
1: Judged by the machine FB position (actual position).

(Note) The bits that are not explained here must be set to "0".

【#12871】 aux_PSW1dog1 PSW1 area setting 1

Set "PSW1 area setting" 1 and 2 to specify the area where the position switch 1 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12872】 aux_PSW1dog2 PSW1 area setting 2

Set "PSW1 area setting" 1 and 2 to specify the area where the position switch 1 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12873】 aux_PSW2dog1 PSW2 area setting 1

Set "PSW2 area setting" 1 and 2 to specify the area where the position switch 2 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12874】 aux_PSW2dog2 PSW2 area setting 2

Set "PSW2 area setting" 1 and 2 to specify the area where the position switch 2 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12875】 aux_PSW3dog1 PSW3 area setting 1

Set "PSW3 area setting" 1 and 2 to specify the area where the position switch 3 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

II Parameters

15. PLC Axis Parameters

【#12876】 aux_PSW3dog2 PSW3 area setting 2

Set "PSW3 area setting" 1 and 2 to specify the area where the position switch 3 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12877】 aux_PSW4dog1 PSW4 area setting 1

Set "PSW4 area setting" 1 and 2 to specify the area where the position switch 4 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12878】 aux_PSW4dog2 PSW4 area setting 2

Set "PSW4 area setting" 1 and 2 to specify the area where the position switch 4 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12879】 aux_PSW5dog1 PSW5 area setting 1

Set "PSW5 area setting" 1 and 2 to specify the area where the position switch 5 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12880】 aux_PSW5dog2 PSW5 area setting 2

Set "PSW5 area setting" 1 and 2 to specify the area where the position switch 5 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12881】 aux_PSW6dog1 PSW6 area setting 1

Set "PSW6 area setting" 1 and 2 to specify the area where the position switch 6 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12882】 aux_PSW6dog2 PSW6 area setting 2

Set "PSW6 area setting" 1 and 2 to specify the area where the position switch 6 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12883】 aux_PSW7dog1 PSW7 area setting 1

Set "PSW7 area setting" 1 and 2 to specify the area where the position switch 7 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12884】 aux_PSW7dog2 PSW7 area setting 2

Set "PSW7 area setting" 1 and 2 to specify the area where the position switch 7 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

II Parameters

15. PLC Axis Parameters

【#12885】 aux_PSW8dog1 PSW8 area setting 1

Set "PSW8 area setting" 1 and 2 to specify the area where the position switch 8 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12886】 aux_PSW8dog2 PSW8 area setting 2

Set "PSW8 area setting" 1 and 2 to specify the area where the position switch 8 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12887】 aux_PSW9dog1 PSW9 area setting 1

Set "PSW9 area setting" 1 and 2 to specify the area where the position switch 9 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12888】 aux_PSW9dog2 PSW9 area setting 2

Set "PSW9 area setting" 1 and 2 to specify the area where the position switch 9 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12889】 aux_PSW10dog1 PSW10 area setting 1

Set "PSW10 area setting" 1 and 2 to specify the area where the position switch 10 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12890】 aux_PSW10dog2 PSW10 area setting 2

Set "PSW10 area setting" 1 and 2 to specify the area where the position switch 10 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12891】 aux_PSW11dog1 PSW11 area setting 1

Set "PSW11 area setting" 1 and 2 to specify the area where the position switch 11 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12892】 aux_PSW11dog2 PSW11 area setting 2

Set "PSW11 area setting" 1 and 2 to specify the area where the position switch 11 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12893】 aux_PSW12dog1 PSW12 area setting 1

Set "PSW12 area setting" 1 and 2 to specify the area where the position switch 12 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

II Parameters

15. PLC Axis Parameters

【#12894】 aux_PSW12dog2 PSW12 area setting 2

Set "PSW12 area setting" 1 and 2 to specify the area where the position switch 12 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12895】 aux_PSW13dog1 PSW13 area setting 1

Set "PSW13 area setting" 1 and 2 to specify the area where the position switch 13 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12896】 aux_PSW13dog2 PSW13 area setting 2

Set "PSW13 area setting" 1 and 2 to specify the area where the position switch 13 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12897】 aux_PSW14dog1 PSW14 area setting 1

Set "PSW14 area setting" 1 and 2 to specify the area where the position switch 14 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12898】 aux_PSW14dog2 PSW14 area setting 2

Set "PSW14 area setting" 1 and 2 to specify the area where the position switch 14 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12899】 aux_PSW15dog1 PSW15 area setting 1

Set "PSW15 area setting" 1 and 2 to specify the area where the position switch 15 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12900】 aux_PSW15dog2 PSW15 area setting 2

Set "PSW15 area setting" 1 and 2 to specify the area where the position switch 15 will turn ON when the machine is positioned.
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.
For rotary axes, the output turns ON in the area excluding 0.000 degree.

---Setting range---
-99999.999 to 99999.999(° or mm)

【#12910】 aux_push Stopper amount

Set the command stroke of the stopper operation in the stopper positioning.

---Setting range---
0.000 to 359.999(° or mm)

【#12911】 aux_pusht1 Stopper standby time

Set the standby time from the stopper starting coordinate positioning to the stopper operation start in the stopper positioning.

---Setting range---
0 to 9999(ms)

【#12912】 aux_pusht2 Stopper torque release time

Set the time from the completion of the stopper operation to the changeover of the stopper torque in the stopper positioning.

---Setting range---
0 to 9999(ms)

II Parameters

15. PLC Axis Parameters

【#12913】 aux_pusht3 Set position signal output delay time

Set the time from the completion of the stopper operation to the output of the "automatic set position reached" (JSTA), "set position reached" (JST) or "near set position" (NEAR) signal in the stopper positioning.

---Setting range---
0 to 9999(ms)

III PLC Devices

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X2F0	BRST	Board reset
X707		Power OFF processing
X70E	BATWR	Battery warning
X70F	BATAL	Battery alarm
X722		Diagnosis data output completion
X723		Collecting diagnosis data
X724		In remote program input
X725		Remote program input completion
X726		Remote program input error
X727		In tool ID communication
X72F		Power OFF required after parameter change
X752	CNOP	24 hours continuous operation
X758		Pallet program registration Ext. workpiece coordinate transfer completion
X780	RDY11	Servo ready 1st-axis 1st-phase
X781	RDY21	Servo ready 2nd-axis 1st-phase
X782	RDY31	Servo ready 3rd-axis 1st-phase
X783	RDY41	Servo ready 4th-axis 1st-phase
X784	RDY51	Servo ready 5th-axis 1st-phase
X785	RDY61	Servo ready 6th-axis 1st-phase
X786	RDY71	Servo ready 7th-axis 1st-phase
X787	RDY81	Servo ready 8th-axis 1st-phase
X788	RDY12	Servo ready 1st-axis 2nd-phase
X789	RDY22	Servo ready 2nd-axis 2nd-phase
X78A	RDY32	Servo ready 3rd-axis 2nd-phase
X78B	RDY42	Servo ready 4th-axis 2nd-phase
X78C	RDY52	Servo ready 5th-axis 2nd-phase
X78D	RDY62	Servo ready 6th-axis 2nd-phase
X78E	RDY72	Servo ready 7th-axis 2nd-phase
X78F	RDY82	Servo ready 8th-axis 2nd-phase
X790	RDY13	Servo ready 1st-axis 3rd-phase
X791	RDY23	Servo ready 2nd-axis 3rd-phase
X792	RDY33	Servo ready 3rd-axis 3rd-phase
X793	RDY43	Servo ready 4th-axis 3rd-phase
X794	RDY53	Servo ready 5th-axis 3rd-phase
X795	RDY63	Servo ready 6th-axis 3rd-phase
X796	RDY73	Servo ready 7th-axis 3rd-phase
X797	RDY83	Servo ready 8th-axis 3rd-phase
X798	RDY14	Servo ready 1st-axis 4th-phase
X799	RDY24	Servo ready 2nd-axis 4th-phase
X79A	RDY34	Servo ready 3rd-axis 4th-phase
X79B	RDY44	Servo ready 4th-axis 4th-phase
X79C	RDY54	Servo ready 5th-axis 4th-phase
X79D	RDY64	Servo ready 6th-axis 4th-phase
X79E	RDY74	Servo ready 7th-axis 4th-phase
X79F	RDY84	Servo ready 8th-axis 4th-phase
X7A0	AX11	Axis selection 1st-axis 1st-phase
X7A1	AX21	Axis selection 2nd-axis 1st-phase
X7A2	AX31	Axis selection 3rd-axis 1st-phase
X7A3	AX41	Axis selection 4th-axis 1st-phase
X7A4	AX51	Axis selection 5th-axis 1st-phase
X7A5	AX61	Axis selection 6th-axis 1st-phase
X7A6	AX71	Axis selection 7th-axis 1st-phase
X7A7	AX81	Axis selection 8th-axis 1st-phase
X7A8	AX12	Axis selection 1st-axis 2nd-phase
X7A9	AX22	Axis selection 2nd-axis 2nd-phase
X7AA	AX32	Axis selection 3rd-axis 2nd-phase
X7AB	AX42	Axis selection 4th-axis 2nd-phase
X7AC	AX52	Axis selection 5th-axis 2nd-phase
X7AD	AX62	Axis selection 6th-axis 2nd-phase
X7AE	AX72	Axis selection 7th-axis 2nd-phase
X7AF	AX82	Axis selection 8th-axis 2nd-phase
X7B0	AX13	Axis selection 1st-axis 3rd-phase
X7B1	AX23	Axis selection 2nd-axis 3rd-phase
X7B2	AX33	Axis selection 3rd-axis 3rd-phase
X7B3	AX43	Axis selection 4th-axis 3rd-phase
X7B4	AX53	Axis selection 5th-axis 3rd-phase
X7B5	AX63	Axis selection 6th-axis 3rd-phase
X7B6	AX73	Axis selection 7th-axis 3rd-phase
X7B7	AX83	Axis selection 8th-axis 3rd-phase
X7B8	AX14	Axis selection 1st-axis 4th-phase
X7B9	AX24	Axis selection 2nd-axis 4th-phase
X7BA	AX34	Axis selection 3rd-axis 4th-phase
X7BB	AX44	Axis selection 4th-axis 4th-phase
X7BC	AX54	Axis selection 5th-axis 4th-phase
X7BD	AX64	Axis selection 6th-axis 4th-phase
X7BE	AX74	Axis selection 7th-axis 4th-phase
X7BF	AX84	Axis selection 8th-axis 4th-phase
X7C0	MVP11	In axis plus motion 1st-axis 1st-phase
X7C1	MVP21	In axis plus motion 2nd-axis 1st-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X7C2	MVP31	In axis plus motion 3nd-axis 1st-phase
X7C3	MVP41	In axis plus motion 4th-axis 1st-phase
X7C4	MVP51	In axis plus motion 5th-axis 1st-phase
X7C5	MVP61	In axis plus motion 6th-axis 1st-phase
X7C6	MVP71	In axis plus motion 7th-axis 1st-phase
X7C7	MVP81	In axis plus motion 8th-axis 1st-phase
X7C8	MVP12	In axis plus motion 1st-axis 2nd-phase
X7C9	MVP22	In axis plus motion 2nd-axis 2nd-phase
X7CA	MVP32	In axis plus motion 3nd-axis 2nd-phase
X7CB	MVP42	In axis plus motion 4th-axis 2nd-phase
X7CC	MVP52	In axis plus motion 5th-axis 2nd-phase
X7CD	MVP62	In axis plus motion 6th-axis 2nd-phase
X7CE	MVP72	In axis plus motion 7th-axis 2nd-phase
X7CF	MVP82	In axis plus motion 8th-axis 2nd-phase
X7D0	MVP13	In axis plus motion 1st-axis 3rd-phase
X7D1	MVP23	In axis plus motion 2nd-axis 3rd-phase
X7D2	MVP33	In axis plus motion 3nd-axis 3rd-phase
X7D3	MVP43	In axis plus motion 4th-axis 3rd-phase
X7D4	MVP53	In axis plus motion 5th-axis 3rd-phase
X7D5	MVP63	In axis plus motion 6th-axis 3rd-phase
X7D6	MVP73	In axis plus motion 7th-axis 3rd-phase
X7D7	MVP83	In axis plus motion 8th-axis 3rd-phase
X7D8	MVP14	In axis plus motion 1st-axis 4th-phase
X7D9	MVP24	In axis plus motion 2nd-axis 4th-phase
X7DA	MVP34	In axis plus motion 3nd-axis 4th-phase
X7DB	MVP44	In axis plus motion 4th-axis 4th-phase
X7DC	MVP54	In axis plus motion 5th-axis 4th-phase
X7DD	MVP64	In axis plus motion 6th-axis 4th-phase
X7DE	MVP74	In axis plus motion 7th-axis 4th-phase
X7DF	MVP84	In axis plus motion 8th-axis 4th-phase
X7E0	MVM11	In axis minus motion 1st-axis 1st-phase
X7E1	MVM21	In axis minus motion 2nd-axis 1st-phase
X7E2	MVM31	In axis minus motion 3nd-axis 1st-phase
X7E3	MVM41	In axis minus motion 4th-axis 1st-phase
X7E4	MVM51	In axis minus motion 5th-axis 1st-phase
X7E5	MVM61	In axis minus motion 6th-axis 1st-phase
X7E6	MVM71	In axis minus motion 7th-axis 1st-phase
X7E7	MVM81	In axis minus motion 8th-axis 1st-phase
X7E8	MVM12	In axis minus motion 1st-axis 2nd-phase
X7E9	MVM22	In axis minus motion 2nd-axis 2nd-phase
X7EA	MVM32	In axis minus motion 3nd-axis 2nd-phase
X7EB	MVM42	In axis minus motion 4th-axis 2nd-phase
X7EC	MVM52	In axis minus motion 5th-axis 2nd-phase
X7ED	MVM62	In axis minus motion 6th-axis 2nd-phase
X7EE	MVM72	In axis minus motion 7th-axis 2nd-phase
X7EF	MVM82	In axis minus motion 8th-axis 2nd-phase
X7F0	MVM13	In axis minus motion 1st-axis 3rd-phase
X7F1	MVM23	In axis minus motion 2nd-axis 3rd-phase
X7F2	MVM33	In axis minus motion 3nd-axis 3rd-phase
X7F3	MVM43	In axis minus motion 4th-axis 3rd-phase
X7F4	MVM53	In axis minus motion 5th-axis 3rd-phase
X7F5	MVM63	In axis minus motion 6th-axis 3rd-phase
X7F6	MVM73	In axis minus motion 7th-axis 3rd-phase
X7F7	MVM83	In axis minus motion 8th-axis 3rd-phase
X7F8	MVM14	In axis minus motion 1st-axis 4th-phase
X7F9	MVM24	In axis minus motion 2nd-axis 4th-phase
X7FA	MVM34	In axis minus motion 3nd-axis 4th-phase
X7FB	MVM44	In axis minus motion 4th-axis 4th-phase
X7FC	MVM54	In axis minus motion 5th-axis 4th-phase
X7FD	MVM64	In axis minus motion 6th-axis 4th-phase
X7FE	MVM74	In axis minus motion 7th-axis 4th-phase
X7FF	MVM84	In axis minus motion 8th-axis 4th-phase
X800	ZP111	1st reference position reached 1st-axis 1st-phase
X801	ZP121	1st reference position reached 2nd-axis 1st-phase
X802	ZP131	1st reference position reached 3nd-axis 1st-phase
X803	ZP141	1st reference position reached 4th-axis 1st-phase
X804	ZP151	1st reference position reached 5th-axis 1st-phase
X805	ZP161	1st reference position reached 6th-axis 1st-phase
X806	ZP171	1st reference position reached 7th-axis 1st-phase
X807	ZP181	1st reference position reached 8th-axis 1st-phase
X808	ZP112	1st reference position reached 1st-axis 2nd-phase
X809	ZP122	1st reference position reached 2nd-axis 2nd-phase
X80A	ZP132	1st reference position reached 3nd-axis 2nd-phase
X80B	ZP142	1st reference position reached 4th-axis 2nd-phase
X80C	ZP152	1st reference position reached 5th-axis 2nd-phase
X80D	ZP162	1st reference position reached 6th-axis 2nd-phase
X80E	ZP172	1st reference position reached 7th-axis 2nd-phase
X80F	ZP182	1st reference position reached 8th-axis 2nd-phase
X810	ZP113	1st reference position reached 1st-axis 3rd-phase
X811	ZP123	1st reference position reached 2nd-axis 3rd-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X812	ZP133	1st reference position reached 3rd-axis 3rd-phase
X813	ZP143	1st reference position reached 4th-axis 3rd-phase
X814	ZP153	1st reference position reached 5th-axis 3rd-phase
X815	ZP163	1st reference position reached 6th-axis 3rd-phase
X816	ZP173	1st reference position reached 7th-axis 3rd-phase
X817	ZP183	1st reference position reached 8th-axis 3rd-phase
X818	ZP114	1st reference position reached 1st-axis 4th-phase
X819	ZP124	1st reference position reached 2nd-axis 4th-phase
X81A	ZP134	1st reference position reached 3rd-axis 4th-phase
X81B	ZP144	1st reference position reached 4th-axis 4th-phase
X81C	ZP154	1st reference position reached 5th-axis 4th-phase
X81D	ZP164	1st reference position reached 6th-axis 4th-phase
X81E	ZP174	1st reference position reached 7th-axis 4th-phase
X81F	ZP184	1st reference position reached 8th-axis 4th-phase
X820	ZP211	2nd reference position reached 1st-axis 1st-phase
X821	ZP221	2nd reference position reached 2nd-axis 1st-phase
X822	ZP231	2nd reference position reached 3rd-axis 1st-phase
X823	ZP241	2nd reference position reached 4th-axis 1st-phase
X824	ZP251	2nd reference position reached 5th-axis 1st-phase
X825	ZP261	2nd reference position reached 6th-axis 1st-phase
X826	ZP271	2nd reference position reached 7th-axis 1st-phase
X827	ZP281	2nd reference position reached 8th-axis 1st-phase
X828	ZP212	2nd reference position reached 1st-axis 2nd-phase
X829	ZP222	2nd reference position reached 2nd-axis 2nd-phase
X82A	ZP232	2nd reference position reached 3rd-axis 2nd-phase
X82B	ZP242	2nd reference position reached 4th-axis 2nd-phase
X82C	ZP252	2nd reference position reached 5th-axis 2nd-phase
X82D	ZP262	2nd reference position reached 6th-axis 2nd-phase
X82E	ZP272	2nd reference position reached 7th-axis 2nd-phase
X82F	ZP282	2nd reference position reached 8th-axis 2nd-phase
X830	ZP213	2nd reference position reached 1st-axis 3rd-phase
X831	ZP223	2nd reference position reached 2nd-axis 3rd-phase
X832	ZP233	2nd reference position reached 3rd-axis 3rd-phase
X833	ZP243	2nd reference position reached 4th-axis 3rd-phase
X834	ZP253	2nd reference position reached 5th-axis 3rd-phase
X835	ZP263	2nd reference position reached 6th-axis 3rd-phase
X836	ZP273	2nd reference position reached 7th-axis 3rd-phase
X837	ZP283	2nd reference position reached 8th-axis 3rd-phase
X838	ZP214	2nd reference position reached 1st-axis 4th-phase
X839	ZP224	2nd reference position reached 2nd-axis 4th-phase
X83A	ZP234	2nd reference position reached 3rd-axis 4th-phase
X83B	ZP244	2nd reference position reached 4th-axis 4th-phase
X83C	ZP254	2nd reference position reached 5th-axis 4th-phase
X83D	ZP264	2nd reference position reached 6th-axis 4th-phase
X83E	ZP274	2nd reference position reached 7th-axis 4th-phase
X83F	ZP284	2nd reference position reached 8th-axis 4th-phase
X840	ZP311	3rd reference position reached 1st-axis 1st-phase
X841	ZP321	3rd reference position reached 2nd-axis 1st-phase
X842	ZP331	3rd reference position reached 3rd-axis 1st-phase
X843	ZP341	3rd reference position reached 4th-axis 1st-phase
X844	ZP351	3rd reference position reached 5th-axis 1st-phase
X845	ZP361	3rd reference position reached 6th-axis 1st-phase
X846	ZP371	3rd reference position reached 7th-axis 1st-phase
X847	ZP381	3rd reference position reached 8th-axis 1st-phase
X848	ZP312	3rd reference position reached 1st-axis 2nd-phase
X849	ZP322	3rd reference position reached 2nd-axis 2nd-phase
X84A	ZP332	3rd reference position reached 3rd-axis 2nd-phase
X84B	ZP342	3rd reference position reached 4th-axis 2nd-phase
X84C	ZP352	3rd reference position reached 5th-axis 2nd-phase
X84D	ZP362	3rd reference position reached 6th-axis 2nd-phase
X84E	ZP372	3rd reference position reached 7th-axis 2nd-phase
X84F	ZP382	3rd reference position reached 8th-axis 2nd-phase
X850	ZP313	3rd reference position reached 1st-axis 3rd-phase
X851	ZP323	3rd reference position reached 2nd-axis 3rd-phase
X852	ZP333	3rd reference position reached 3rd-axis 3rd-phase
X853	ZP343	3rd reference position reached 4th-axis 3rd-phase
X854	ZP353	3rd reference position reached 5th-axis 3rd-phase
X855	ZP363	3rd reference position reached 6th-axis 3rd-phase
X856	ZP373	3rd reference position reached 7th-axis 3rd-phase
X857	ZP383	3rd reference position reached 8th-axis 3rd-phase
X858	ZP314	3rd reference position reached 1st-axis 4th-phase
X859	ZP324	3rd reference position reached 2nd-axis 4th-phase
X85A	ZP334	3rd reference position reached 3rd-axis 4th-phase
X85B	ZP344	3rd reference position reached 4th-axis 4th-phase
X85C	ZP354	3rd reference position reached 5th-axis 4th-phase
X85D	ZP364	3rd reference position reached 6th-axis 4th-phase
X85E	ZP374	3rd reference position reached 7th-axis 4th-phase
X85F	ZP384	3rd reference position reached 8th-axis 4th-phase
X860	ZP411	4th reference position reached 1st-axis 1st-phase
X861	ZP421	4th reference position reached 2nd-axis 1st-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X862	ZP431	4th reference position reached 3rd-axis 1st-phase
X863	ZP441	4th reference position reached 4th-axis 1st-phase
X864	ZP451	4th reference position reached 5th-axis 1st-phase
X865	ZP461	4th reference position reached 6th-axis 1st-phase
X866	ZP471	4th reference position reached 7th-axis 1st-phase
X867	ZP481	4th reference position reached 8th-axis 1st-phase
X868	ZP412	4th reference position reached 1st-axis 2nd-phase
X869	ZP422	4th reference position reached 2nd-axis 2nd-phase
X86A	ZP432	4th reference position reached 3rd-axis 2nd-phase
X86B	ZP442	4th reference position reached 4th-axis 2nd-phase
X86C	ZP452	4th reference position reached 5th-axis 2nd-phase
X86D	ZP462	4th reference position reached 6th-axis 2nd-phase
X86E	ZP472	4th reference position reached 7th-axis 2nd-phase
X86F	ZP482	4th reference position reached 8th-axis 2nd-phase
X870	ZP413	4th reference position reached 1st-axis 3rd-phase
X871	ZP423	4th reference position reached 2nd-axis 3rd-phase
X872	ZP433	4th reference position reached 3rd-axis 3rd-phase
X873	ZP443	4th reference position reached 4th-axis 3rd-phase
X874	ZP453	4th reference position reached 5th-axis 3rd-phase
X875	ZP463	4th reference position reached 6th-axis 3rd-phase
X876	ZP473	4th reference position reached 7th-axis 3rd-phase
X877	ZP483	4th reference position reached 8th-axis 3rd-phase
X878	ZP414	4th reference position reached 1st-axis 4th-phase
X879	ZP424	4th reference position reached 2nd-axis 4th-phase
X87A	ZP434	4th reference position reached 3rd-axis 4th-phase
X87B	ZP444	4th reference position reached 4th-axis 4th-phase
X87C	ZP454	4th reference position reached 5th-axis 4th-phase
X87D	ZP464	4th reference position reached 6th-axis 4th-phase
X87E	ZP474	4th reference position reached 7th-axis 4th-phase
X87F	ZP484	4th reference position reached 8th-axis 4th-phase
X880	NRF11	Near reference position 1st-axis 1st-phase
X881	NRF21	Near reference position 2nd-axis 1st-phase
X882	NRF31	Near reference position 3rd-axis 1st-phase
X883	NRF41	Near reference position 4th-axis 1st-phase
X884	NRF51	Near reference position 5th-axis 1st-phase
X885	NRF61	Near reference position 6th-axis 1st-phase
X886	NRF71	Near reference position 7th-axis 1st-phase
X887	NRF81	Near reference position 8th-axis 1st-phase
X888	NRF12	Near reference position 1st-axis 2nd-phase
X889	NRF22	Near reference position 2nd-axis 2nd-phase
X88A	NRF32	Near reference position 3rd-axis 2nd-phase
X88B	NRF42	Near reference position 4th-axis 2nd-phase
X88C	NRF52	Near reference position 5th-axis 2nd-phase
X88D	NRF62	Near reference position 6th-axis 2nd-phase
X88E	NRF72	Near reference position 7th-axis 2nd-phase
X88F	NRF82	Near reference position 8th-axis 2nd-phase
X890	NRF13	Near reference position 1st-axis 3rd-phase
X891	NRF23	Near reference position 2nd-axis 3rd-phase
X892	NRF33	Near reference position 3rd-axis 3rd-phase
X893	NRF43	Near reference position 4th-axis 3rd-phase
X894	NRF53	Near reference position 5th-axis 3rd-phase
X895	NRF63	Near reference position 6th-axis 3rd-phase
X896	NRF73	Near reference position 7th-axis 3rd-phase
X897	NRF83	Near reference position 8th-axis 3rd-phase
X898	NRF14	Near reference position 1st-axis 4th-phase
X899	NRF24	Near reference position 2nd-axis 4th-phase
X89A	NRF34	Near reference position 3rd-axis 4th-phase
X89B	NRF44	Near reference position 4th-axis 4th-phase
X89C	NRF54	Near reference position 5th-axis 4th-phase
X89D	NRF64	Near reference position 6th-axis 4th-phase
X89E	NRF74	Near reference position 7th-axis 4th-phase
X89F	NRF84	Near reference position 8th-axis 4th-phase
X8C0	ZSF11	Zero point initialization set completed 1st-axis 1st-phase
X8C1	ZSF21	Zero point initialization set completed 2nd-axis 1st-phase
X8C2	ZSF31	Zero point initialization set completed 3rd-axis 1st-phase
X8C3	ZSF41	Zero point initialization set completed 4th-axis 1st-phase
X8C4	ZSF51	Zero point initialization set completed 5th-axis 1st-phase
X8C5	ZSF61	Zero point initialization set completed 6th-axis 1st-phase
X8C6	ZSF71	Zero point initialization set completed 7th-axis 1st-phase
X8C7	ZSF81	Zero point initialization set completed 8th-axis 1st-phase
X8C8	ZSF12	Zero point initialization set completed 1st-axis 2nd-phase
X8C9	ZSF22	Zero point initialization set completed 2nd-axis 2nd-phase
X8CA	ZSF32	Zero point initialization set completed 3rd-axis 2nd-phase
X8CB	ZSF42	Zero point initialization set completed 4th-axis 2nd-phase
X8CC	ZSF52	Zero point initialization set completed 5th-axis 2nd-phase
X8CD	ZSF62	Zero point initialization set completed 6th-axis 2nd-phase
X8CE	ZSF72	Zero point initialization set completed 7th-axis 2nd-phase
X8CF	ZSF82	Zero point initialization set completed 8th-axis 2nd-phase
X8D0	ZSF13	Zero point initialization set completed 1st-axis 3rd-phase
X8D1	ZSF23	Zero point initialization set completed 2nd-axis 3rd-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X8D2	ZSF33	Zero point initialization set completed 3nd-axis 3rd-phase
X8D3	ZSF43	Zero point initialization set completed 4th-axis 3rd-phase
X8D4	ZSF53	Zero point initialization set completed 5th-axis 3rd-phase
X8D5	ZSF63	Zero point initialization set completed 6th-axis 3rd-phase
X8D6	ZSF73	Zero point initialization set completed 7th-axis 3rd-phase
X8D7	ZSF83	Zero point initialization set completed 8th-axis 3rd-phase
X8D8	ZSF14	Zero point initialization set completed 1st-axis 4th-phase
X8D9	ZSF24	Zero point initialization set completed 2nd-axis 4th-phase
X8DA	ZSF34	Zero point initialization set completed 3nd-axis 4th-phase
X8DB	ZSF44	Zero point initialization set completed 4th-axis 4th-phase
X8DC	ZSF54	Zero point initialization set completed 5th-axis 4th-phase
X8DD	ZSF64	Zero point initialization set completed 6th-axis 4th-phase
X8DE	ZSF74	Zero point initialization set completed 7th-axis 4th-phase
X8DF	ZSF84	Zero point initialization set completed 8th-axis 4th-phase
X8E0	ZSE11	Zero point initialization set error completed 1st-axis 1st-phase
X8E1	ZSE21	Zero point initialization set error completed 2nd-axis 1st-phase
X8E2	ZSE31	Zero point initialization set error completed 3nd-axis 1st-phase
X8E3	ZSE41	Zero point initialization set error completed 4th-axis 1st-phase
X8E4	ZSE51	Zero point initialization set error completed 5th-axis 1st-phase
X8E5	ZSE61	Zero point initialization set error completed 6th-axis 1st-phase
X8E6	ZSE71	Zero point initialization set error completed 7th-axis 1st-phase
X8E7	ZSE81	Zero point initialization set error completed 8th-axis 1st-phase
X8E8	ZSE12	Zero point initialization set error completed 1st-axis 2nd-phase
X8E9	ZSE22	Zero point initialization set error completed 2nd-axis 2nd-phase
X8EA	ZSE32	Zero point initialization set error completed 3nd-axis 2nd-phase
X8EB	ZSE42	Zero point initialization set error completed 4th-axis 2nd-phase
X8EC	ZSE52	Zero point initialization set error completed 5th-axis 2nd-phase
X8ED	ZSE62	Zero point initialization set error completed 6th-axis 2nd-phase
X8EE	ZSE72	Zero point initialization set error completed 7th-axis 2nd-phase
X8EF	ZSE82	Zero point initialization set error completed 8th-axis 2nd-phase
X8F0	ZSE13	Zero point initialization set error completed 1st-axis 3rd-phase
X8F1	ZSE23	Zero point initialization set error completed 2nd-axis 3rd-phase
X8F2	ZSE33	Zero point initialization set error completed 3nd-axis 3rd-phase
X8F3	ZSE43	Zero point initialization set error completed 4th-axis 3rd-phase
X8F4	ZSE53	Zero point initialization set error completed 5th-axis 3rd-phase
X8F5	ZSE63	Zero point initialization set error completed 6th-axis 3rd-phase
X8F6	ZSE73	Zero point initialization set error completed 7th-axis 3rd-phase
X8F7	ZSE83	Zero point initialization set error completed 8th-axis 3rd-phase
X8F8	ZSE14	Zero point initialization set error completed 1st-axis 4th-phase
X8F9	ZSE24	Zero point initialization set error completed 2nd-axis 4th-phase
X8FA	ZSE34	Zero point initialization set error completed 3nd-axis 4th-phase
X8FB	ZSE44	Zero point initialization set error completed 4th-axis 4th-phase
X8FC	ZSE54	Zero point initialization set error completed 5th-axis 4th-phase
X8FD	ZSE64	Zero point initialization set error completed 6th-axis 4th-phase
X8FE	ZSE74	Zero point initialization set error completed 7th-axis 4th-phase
X8FF	ZSE84	Zero point initialization set error completed 8th-axis 4th-phase
X900	ILI11	In current limit 1st-axis 1st-phase
X901	ILI21	In current limit 2nd-axis 1st-phase
X902	ILI31	In current limit 3nd-axis 1st-phase
X903	ILI41	In current limit 4th-axis 1st-phase
X904	ILI51	In current limit 5th-axis 1st-phase
X905	ILI61	In current limit 6th-axis 1st-phase
X906	ILI71	In current limit 7th-axis 1st-phase
X907	ILI81	In current limit 8th-axis 1st-phase
X908	ILI12	In current limit 1st-axis 2nd-phase
X909	ILI22	In current limit 2nd-axis 2nd-phase
X90A	ILI32	In current limit 3nd-axis 2nd-phase
X90B	ILI42	In current limit 4th-axis 2nd-phase
X90C	ILI52	In current limit 5th-axis 2nd-phase
X90D	ILI62	In current limit 6th-axis 2nd-phase
X90E	ILI72	In current limit 7th-axis 2nd-phase
X90F	ILI82	In current limit 8th-axis 2nd-phase
X910	ILI13	In current limit 1st-axis 3rd-phase
X911	ILI23	In current limit 2nd-axis 3rd-phase
X912	ILI33	In current limit 3nd-axis 3rd-phase
X913	ILI43	In current limit 4th-axis 3rd-phase
X914	ILI53	In current limit 5th-axis 3rd-phase
X915	ILI63	In current limit 6th-axis 3rd-phase
X916	ILI73	In current limit 7th-axis 3rd-phase
X917	ILI83	In current limit 8th-axis 3rd-phase
X918	ILI14	In current limit 1st-axis 4th-phase
X919	ILI24	In current limit 2nd-axis 4th-phase
X91A	ILI34	In current limit 3nd-axis 4th-phase
X91B	ILI44	In current limit 4th-axis 4th-phase
X91C	ILI54	In current limit 5th-axis 4th-phase
X91D	ILI64	In current limit 6th-axis 4th-phase
X91E	ILI74	In current limit 7th-axis 4th-phase
X91F	ILI84	In current limit 8th-axis 4th-phase
X920	ILA11	Current limit reached 1st-axis 1st-phase
X921	ILA21	Current limit reached 2nd-axis 1st-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X922	ILA31	Current limit reached 3rd-axis 1st-phase
X923	ILA41	Current limit reached 4th-axis 1st-phase
X924	ILA51	Current limit reached 5th-axis 1st-phase
X925	ILA61	Current limit reached 6th-axis 1st-phase
X926	ILA71	Current limit reached 7th-axis 1st-phase
X927	ILA81	Current limit reached 8th-axis 1st-phase
X928	ILA12	Current limit reached 1st-axis 2nd-phase
X929	ILA22	Current limit reached 2nd-axis 2nd-phase
X92A	ILA32	Current limit reached 3rd-axis 2nd-phase
X92B	ILA42	Current limit reached 4th-axis 2nd-phase
X92C	ILA52	Current limit reached 5th-axis 2nd-phase
X92D	ILA62	Current limit reached 6th-axis 2nd-phase
X92E	ILA72	Current limit reached 7th-axis 2nd-phase
X92F	ILA82	Current limit reached 8th-axis 2nd-phase
X930	ILA13	Current limit reached 1st-axis 3rd-phase
X931	ILA23	Current limit reached 2nd-axis 3rd-phase
X932	ILA33	Current limit reached 3rd-axis 3rd-phase
X933	ILA43	Current limit reached 4th-axis 3rd-phase
X934	ILA53	Current limit reached 5th-axis 3rd-phase
X935	ILA63	Current limit reached 6th-axis 3rd-phase
X936	ILA73	Current limit reached 7th-axis 3rd-phase
X937	ILA83	Current limit reached 8th-axis 3rd-phase
X938	ILA14	Current limit reached 1st-axis 4th-phase
X939	ILA24	Current limit reached 2nd-axis 4th-phase
X93A	ILA34	Current limit reached 3rd-axis 4th-phase
X93B	ILA44	Current limit reached 4th-axis 4th-phase
X93C	ILA54	Current limit reached 5th-axis 4th-phase
X93D	ILA64	Current limit reached 6th-axis 4th-phase
X93E	ILA74	Current limit reached 7th-axis 4th-phase
X93F	ILA84	Current limit reached 8th-axis 4th-phase
X940	ARRF11	NC axis up-to-speed 1st-axis 1st-phase
X941	ARRF21	NC axis up-to-speed 2nd-axis 1st-phase
X942	ARRF31	NC axis up-to-speed 3rd-axis 1st-phase
X943	ARRF41	NC axis up-to-speed 4th-axis 1st-phase
X944	ARRF51	NC axis up-to-speed 5th-axis 1st-phase
X945	ARRF61	NC axis up-to-speed 6th-axis 1st-phase
X946	ARRF71	NC axis up-to-speed 7th-axis 1st-phase
X947	ARRF81	NC axis up-to-speed 8th-axis 1st-phase
X948	ARRF12	NC axis up-to-speed 1st-axis 2nd-phase
X949	ARRF22	NC axis up-to-speed 2nd-axis 2nd-phase
X94A	ARRF32	NC axis up-to-speed 3rd-axis 2nd-phase
X94B	ARRF42	NC axis up-to-speed 4th-axis 2nd-phase
X94C	ARRF52	NC axis up-to-speed 5th-axis 2nd-phase
X94D	ARRF62	NC axis up-to-speed 6th-axis 2nd-phase
X94E	ARRF72	NC axis up-to-speed 7th-axis 2nd-phase
X94F	ARRF82	NC axis up-to-speed 8th-axis 2nd-phase
X950	ARRF13	NC axis up-to-speed 1st-axis 3rd-phase
X951	ARRF23	NC axis up-to-speed 2nd-axis 3rd-phase
X952	ARRF33	NC axis up-to-speed 3rd-axis 3rd-phase
X953	ARRF43	NC axis up-to-speed 4th-axis 3rd-phase
X954	ARRF53	NC axis up-to-speed 5th-axis 3rd-phase
X955	ARRF63	NC axis up-to-speed 6th-axis 3rd-phase
X956	ARRF73	NC axis up-to-speed 7th-axis 3rd-phase
X957	ARRF83	NC axis up-to-speed 8th-axis 3rd-phase
X958	ARRF14	NC axis up-to-speed 1st-axis 4th-phase
X959	ARRF24	NC axis up-to-speed 2nd-axis 4th-phase
X95A	ARRF34	NC axis up-to-speed 3rd-axis 4th-phase
X95B	ARRF44	NC axis up-to-speed 4th-axis 4th-phase
X95C	ARRF54	NC axis up-to-speed 5th-axis 4th-phase
X95D	ARRF64	NC axis up-to-speed 6th-axis 4th-phase
X95E	ARRF74	NC axis up-to-speed 7th-axis 4th-phase
X95F	ARRF84	NC axis up-to-speed 8th-axis 4th-phase
X960	UCLP11	Unclamp command 1st-axis 1st-phase
X961	UCLP21	Unclamp command 2nd-axis 1st-phase
X962	UCLP31	Unclamp command 3rd-axis 1st-phase
X963	UCLP41	Unclamp command 4th-axis 1st-phase
X964	UCLP51	Unclamp command 5th-axis 1st-phase
X965	UCLP61	Unclamp command 6th-axis 1st-phase
X966	UCLP71	Unclamp command 7th-axis 1st-phase
X967	UCLP81	Unclamp command 8th-axis 1st-phase
X968	UCLP12	Unclamp command 1st-axis 2nd-phase
X969	UCLP22	Unclamp command 2nd-axis 2nd-phase
X96A	UCLP32	Unclamp command 3rd-axis 2nd-phase
X96B	UCLP42	Unclamp command 4th-axis 2nd-phase
X96C	UCLP52	Unclamp command 5th-axis 2nd-phase
X96D	UCLP62	Unclamp command 6th-axis 2nd-phase
X96E	UCLP72	Unclamp command 7th-axis 2nd-phase
X96F	UCLP82	Unclamp command 8th-axis 2nd-phase
X970	UCLP13	Unclamp command 1st-axis 3rd-phase
X971	UCLP23	Unclamp command 2nd-axis 3rd-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X972	UCLP33	Unclamp command 3rd-axis 3rd-phase
X973	UCLP43	Unclamp command 4th-axis 3rd-phase
X974	UCLP53	Unclamp command 5th-axis 3rd-phase
X975	UCLP63	Unclamp command 6th-axis 3rd-phase
X976	UCLP73	Unclamp command 7th-axis 3rd-phase
X977	UCLP83	Unclamp command 8th-axis 3rd-phase
X978	UCLP14	Unclamp command 1st-axis 4th-phase
X979	UCLP24	Unclamp command 2nd-axis 4th-phase
X97A	UCLP34	Unclamp command 3rd-axis 4th-phase
X97B	UCLP44	Unclamp command 4th-axis 4th-phase
X97C	UCLP54	Unclamp command 5th-axis 4th-phase
X97D	UCLP64	Unclamp command 6th-axis 4th-phase
X97E	UCLP74	Unclamp command 7th-axis 4th-phase
X97F	UCLP84	Unclamp command 8th-axis 4th-phase
X980		In mixed synchronization control 1st axis 1st-phase
X981		In mixed synchronization control 2nd axis 1st-phase
X982		In mixed synchronization control 3rd axis 1st-phase
X983		In mixed synchronization control 4th axis 1st-phase
X984		In mixed synchronization control 5th axis 1st-phase
X985		In mixed synchronization control 6th axis 1st-phase
X986		In mixed synchronization control 7th axis 1st-phase
X987		In mixed synchronization control 8th axis 1st-phase
X988		In mixed synchronization control 1st axis 2nd-phase
X989		In mixed synchronization control 2nd axis 2nd-phase
X98A		In mixed synchronization control 3rd axis 2nd-phase
X98B		In mixed synchronization control 4th axis 2nd-phase
X98C		In mixed synchronization control 5th axis 2nd-phase
X98D		In mixed synchronization control 6th axis 2nd-phase
X98E		In mixed synchronization control 7th axis 2nd-phase
X98F		In mixed synchronization control 8th axis 2nd-phase
X990		In mixed synchronization control 1st axis 3rd-phase
X991		In mixed synchronization control 2nd axis 3rd-phase
X992		In mixed synchronization control 3rd axis 3rd-phase
X993		In mixed synchronization control 4th axis 3rd-phase
X994		In mixed synchronization control 5th axis 3rd-phase
X995		In mixed synchronization control 6th axis 3rd-phase
X996		In mixed synchronization control 7th axis 3rd-phase
X997		In mixed synchronization control 8th axis 3rd-phase
X998		In mixed synchronization control 1st axis 4th-phase
X999		In mixed synchronization control 2nd axis 4th-phase
X99A		In mixed synchronization control 3rd axis 4th-phase
X99B		In mixed synchronization control 4th axis 4th-phase
X99C		In mixed synchronization control 5th axis 4th-phase
X99D		In mixed synchronization control 6th axis 4th-phase
X99E		In mixed synchronization control 7th axis 4th-phase
X99F		In mixed synchronization control 8th axis 4th-phase
X9A0		In synchronous/superimposition control 1st axis 1st-phase
X9A1		In synchronous/superimposition control 2nd axis 1st-phase
X9A2		In synchronous/superimposition control 3rd axis 1st-phase
X9A3		In synchronous/superimposition control 4th axis 1st-phase
X9A4		In synchronous/superimposition control 5th axis 1st-phase
X9A5		In synchronous/superimposition control 6th axis 1st-phase
X9A6		In synchronous/superimposition control 7th axis 1st-phase
X9A7		In synchronous/superimposition control 8th axis 1st-phase
X9A8		In synchronous/superimposition control 1st axis 2nd-phase
X9A9		In synchronous/superimposition control 2nd axis 2nd-phase
X9AA		In synchronous/superimposition control 3rd axis 2nd-phase
X9AB		In synchronous/superimposition control 4th axis 2nd-phase
X9AC		In synchronous/superimposition control 5th axis 2nd-phase
X9AD		In synchronous/superimposition control 6th axis 2nd-phase
X9AE		In synchronous/superimposition control 7th axis 2nd-phase
X9AF		In synchronous/superimposition control 8th axis 2nd-phase
X9B0		In synchronous/superimposition control 1st axis 3rd-phase
X9B1		In synchronous/superimposition control 2nd axis 3rd-phase
X9B2		In synchronous/superimposition control 3rd axis 3rd-phase
X9B3		In synchronous/superimposition control 4th axis 3rd-phase
X9B4		In synchronous/superimposition control 5th axis 3rd-phase
X9B5		In synchronous/superimposition control 6th axis 3rd-phase
X9B6		In synchronous/superimposition control 7th axis 3rd-phase
X9B7		In synchronous/superimposition control 8th axis 3rd-phase
X9B8		In synchronous/superimposition control 1st axis 4th-phase
X9B9		In synchronous/superimposition control 2nd axis 4th-phase
X9BA		In synchronous/superimposition control 3rd axis 4th-phase
X9BB		In synchronous/superimposition control 4th axis 4th-phase
X9BC		In synchronous/superimposition control 5th axis 4th-phase
X9BD		In synchronous/superimposition control 6th axis 4th-phase
X9BE		In synchronous/superimposition control 7th axis 4th-phase
X9BF		In synchronous/superimposition control 8th axis 4th-phase
X9C0	MIR11	In mirror image 1st axis 1st-phase
X9C1	MIR21	In mirror image 2nd axis 1st-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X9C2	MIR31	In mirror image 3rd axis 1st-phase
X9C3	MIR41	In mirror image 4th axis 1st-phase
X9C4	MIR51	In mirror image 5th axis 1st-phase
X9C5	MIR61	In mirror image 6th axis 1st-phase
X9C6	MIR71	In mirror image 7th axis 1st-phase
X9C7	MIR81	In mirror image 8th axis 1st-phase
X9C8	MIR12	In mirror image 1st axis 2nd-phase
X9C9	MIR22	In mirror image 2nd axis 2nd-phase
X9CA	MIR32	In mirror image 3rd axis 2nd-phase
X9CB	MIR42	In mirror image 4th axis 2nd-phase
X9CC	MIR52	In mirror image 5th axis 2nd-phase
X9CD	MIR62	In mirror image 6th axis 2nd-phase
X9CE	MIR72	In mirror image 7th axis 2nd-phase
X9CF	MIR82	In mirror image 8th axis 2nd-phase
X9D0	MIR13	In mirror image 1st axis 3rd-phase
X9D1	MIR23	In mirror image 2nd axis 3rd-phase
X9D2	MIR33	In mirror image 3rd axis 3rd-phase
X9D3	MIR43	In mirror image 4th axis 3rd-phase
X9D4	MIR53	In mirror image 5th axis 3rd-phase
X9D5	MIR63	In mirror image 6th axis 3rd-phase
X9D6	MIR73	In mirror image 7th axis 3rd-phase
X9D7	MIR83	In mirror image 8th axis 3rd-phase
X9D8	MIR14	In mirror image 1st axis 4th-phase
X9D9	MIR24	In mirror image 2nd axis 4th-phase
X9DA	MIR34	In mirror image 3rd axis 4th-phase
X9DB	MIR44	In mirror image 4th axis 4th-phase
X9DC	MIR54	In mirror image 5th axis 4th-phase
X9DD	MIR64	In mirror image 6th axis 4th-phase
X9DE	MIR74	In mirror image 7th axis 4th-phase
X9DF	MIR84	In mirror image 8th axis 4th-phase
X9E0		Reference position establishment 1st axis 1st-phase
X9E1		Reference position establishment 2nd axis 1st-phase
X9E2		Reference position establishment 3rd axis 1st-phase
X9E3		Reference position establishment 4th axis 1st-phase
X9E4		Reference position establishment 5th axis 1st-phase
X9E5		Reference position establishment 6th axis 1st-phase
X9E6		Reference position establishment 7th axis 1st-phase
X9E7		Reference position establishment 8th axis 1st-phase
X9E8		Reference position establishment 1st axis 2nd-phase
X9E9		Reference position establishment 2nd axis 2nd-phase
X9EA		Reference position establishment 3rd axis 2nd-phase
X9EB		Reference position establishment 4th axis 2nd-phase
X9EC		Reference position establishment 5th axis 2nd-phase
X9ED		Reference position establishment 6th axis 2nd-phase
X9EE		Reference position establishment 7th axis 2nd-phase
X9EF		Reference position establishment 8th axis 2nd-phase
X9F0		Reference position establishment 1st axis 3rd-phase
X9F1		Reference position establishment 2nd axis 3rd-phase
X9F2		Reference position establishment 3rd axis 3rd-phase
X9F3		Reference position establishment 4th axis 3rd-phase
X9F4		Reference position establishment 5th axis 3rd-phase
X9F5		Reference position establishment 6th axis 3rd-phase
X9F6		Reference position establishment 7th axis 3rd-phase
X9F7		Reference position establishment 8th axis 3rd-phase
X9F8		Reference position establishment 1st axis 4th-phase
X9F9		Reference position establishment 2nd axis 4th-phase
X9FA		Reference position establishment 3rd axis 4th-phase
X9FB		Reference position establishment 4th axis 4th-phase
X9FC		Reference position establishment 5th axis 4th-phase
X9FD		Reference position establishment 6th axis 4th-phase
X9FE		Reference position establishment 7th axis 4th-phase
X9FF		Reference position establishment 8th axis 4th-phase
XA00		Reference position return direction 1st axis 1st-phase
XA01		Reference position return direction 2nd axis 1st-phase
XA02		Reference position return direction 3rd axis 1st-phase
XA03		Reference position return direction 4th axis 1st-phase
XA04		Reference position return direction 5th axis 1st-phase
XA05		Reference position return direction 6th axis 1st-phase
XA06		Reference position return direction 7th axis 1st-phase
XA07		Reference position return direction 8th axis 1st-phase
XA08		Reference position return direction 1st axis 2nd-phase
XA09		Reference position return direction 2nd axis 2nd-phase
XA0A		Reference position return direction 3rd axis 2nd-phase
XA0B		Reference position return direction 4th axis 2nd-phase
XA0C		Reference position return direction 5th axis 2nd-phase
XA0D		Reference position return direction 6th axis 2nd-phase
XA0E		Reference position return direction 7th axis 2nd-phase
XA0F		Reference position return direction 8th axis 2nd-phase
XA10		Reference position return direction 1st axis 3rd-phase
XA11		Reference position return direction 2nd axis 3rd-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
XA12		Reference position return direction 3rd axis 3rd-phase
XA13		Reference position return direction 4th axis 3rd-phase
XA14		Reference position return direction 5th axis 3rd-phase
XA15		Reference position return direction 6th axis 3rd-phase
XA16		Reference position return direction 7th axis 3rd-phase
XA17		Reference position return direction 8th axis 3rd-phase
XA18		Reference position return direction 1st axis 4th-phase
XA19		Reference position return direction 2nd axis 4th-phase
XA1A		Reference position return direction 3rd axis 4th-phase
XA1B		Reference position return direction 4th axis 4th-phase
XA1C		Reference position return direction 5th axis 4th-phase
XA1D		Reference position return direction 6th axis 4th-phase
XA1E		Reference position return direction 7th axis 4th-phase
XA1F		Reference position return direction 8th axis 4th-phase
XA20		In NC axis control 1st axis 1st-phase
XA21		In NC axis control 2nd axis 1st-phase
XA22		In NC axis control 3rd axis 1st-phase
XA23		In NC axis control 4th axis 1st-phase
XA24		In NC axis control 5th axis 1st-phase
XA25		In NC axis control 6th axis 1st-phase
XA26		In NC axis control 7th axis 1st-phase
XA27		In NC axis control 8th axis 1st-phase
XA28		In NC axis control 1st axis 2nd-phase
XA29		In NC axis control 2nd axis 2nd-phase
XA2A		In NC axis control 3rd axis 2nd-phase
XA2B		In NC axis control 4th axis 2nd-phase
XA2C		In NC axis control 5th axis 2nd-phase
XA2D		In NC axis control 6th axis 2nd-phase
XA2E		In NC axis control 7th axis 2nd-phase
XA2F		In NC axis control 8th axis 2nd-phase
XA30		In NC axis control 1st axis 3rd-phase
XA31		In NC axis control 2nd axis 3rd-phase
XA32		In NC axis control 3rd axis 3rd-phase
XA33		In NC axis control 4th axis 3rd-phase
XA34		In NC axis control 5th axis 3rd-phase
XA35		In NC axis control 6th axis 3rd-phase
XA36		In NC axis control 7th axis 3rd-phase
XA37		In NC axis control 8th axis 3rd-phase
XA38		In NC axis control 1st axis 4th-phase
XA39		In NC axis control 2nd axis 4th-phase
XA3A		In NC axis control 3rd axis 4th-phase
XA3B		In NC axis control 4th axis 4th-phase
XA3C		In NC axis control 5th axis 4th-phase
XA3D		In NC axis control 6th axis 4th-phase
XA3E		In NC axis control 7th axis 4th-phase
XA3F		In NC axis control 8th axis 4th-phase
XA40	ECIL1	Ext. machine coordinate system offset data illegal 1st axis 1st-phase
XA41	ECIL2	Ext. machine coordinate system offset data illegal 2nd axis 1st-phase
XA42	ECIL3	Ext. machine coordinate system offset data illegal 3rd axis 1st-phase
XA43	ECIL4	Ext. machine coordinate system offset data illegal 4th axis 1st-phase
XA44	ECIL5	Ext. machine coordinate system offset data illegal 5th axis 1st-phase
XA45	ECIL6	Ext. machine coordinate system offset data illegal 6th axis 1st-phase
XA46	ECIL7	Ext. machine coordinate system offset data illegal 7th axis 1st-phase
XA47	ECIL8	Ext. machine coordinate system offset data illegal 8th axis 1st-phase
XA48	ECIL1	Ext. machine coordinate system offset data illegal 1st axis 2nd-phase
XA49	ECIL2	Ext. machine coordinate system offset data illegal 2nd axis 2nd-phase
XA4A	ECIL3	Ext. machine coordinate system offset data illegal 3rd axis 2nd-phase
XA4B	ECIL4	Ext. machine coordinate system offset data illegal 4th axis 2nd-phase
XA4C	ECIL5	Ext. machine coordinate system offset data illegal 5th axis 2nd-phase
XA4D	ECIL6	Ext. machine coordinate system offset data illegal 6th axis 2nd-phase
XA4E	ECIL7	Ext. machine coordinate system offset data illegal 7th axis 2nd-phase
XA4F	ECIL8	Ext. machine coordinate system offset data illegal 8th axis 2nd-phase
XA50	ECIL1	Ext. machine coordinate system offset data illegal 1st axis 3rd-phase
XA51	ECIL2	Ext. machine coordinate system offset data illegal 2nd axis 3rd-phase
XA52	ECIL3	Ext. machine coordinate system offset data illegal 3rd axis 3rd-phase
XA53	ECIL4	Ext. machine coordinate system offset data illegal 4th axis 3rd-phase
XA54	ECIL5	Ext. machine coordinate system offset data illegal 5th axis 3rd-phase
XA55	ECIL6	Ext. machine coordinate system offset data illegal 6th axis 3rd-phase
XA56	ECIL7	Ext. machine coordinate system offset data illegal 7th axis 3rd-phase
XA57	ECIL8	Ext. machine coordinate system offset data illegal 8th axis 3rd-phase
XA58	ECIL1	Ext. machine coordinate system offset data illegal 1st axis 4th-phase
XA59	ECIL2	Ext. machine coordinate system offset data illegal 2nd axis 4th-phase
XA5A	ECIL3	Ext. machine coordinate system offset data illegal 3rd axis 4th-phase
XA5B	ECIL4	Ext. machine coordinate system offset data illegal 4th axis 4th-phase
XA5C	ECIL5	Ext. machine coordinate system offset data illegal 5th axis 4th-phase
XA5D	ECIL6	Ext. machine coordinate system offset data illegal 6th axis 4th-phase
XA5E	ECIL7	Ext. machine coordinate system offset data illegal 7th axis 4th-phase
XA5F	ECIL8	Ext. machine coordinate system offset data illegal 8th axis 4th-phase
XC00	JO1	In jog mode 1st-phase
XC01	HO1	In handle mode 1st-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
XC02	SO1	In incremental mode 1st-phase
XC03	PTPO1	In manual arbitrary feed mode 1st-phase
XC04	ZRNO1	In reference position return mode 1st-phase
XC05	ASTO1	In automatic initial set mode 1st-phase
XC06		In jog-handle simultaneous mode 1st-phase
XC08	MEMO1	In memory mode 1st-phase
XC09	TO1	In tape mode 1st-phase
XC0A		In online operation mode 1st-phase
XC0B	DO1	In MDI mode 1st-phase
XC10	MA1	Controller ready completion 1st-phase
XC11	SA1	Servo ready completion 1st-phase
XC12	OP1	In automatic operation "run" 1st-phase
XC13	STL1	In automatic operation "start" 1st-phase
XC14	SPL1	In automatic operation "pause" 1st-phase
XC15	RST1	In "reset" 1st-phase
XC16	CXN1	In manual arbitrary feed 1st-phase
XC17	RWD1	In rewind 1st-phase
XC18	DEN1	Motion command completion 1st-phase
XC19	TIMP1	All axes in-position 1st-phase
XC1A	TSMZ1	All axes smoothing zero 1st-phase
XC1C	CXFIN1	Manual arbitrary feed completion 1st-phase
XC1D	ETSE1	External search finished 1st-phase
XC1F		In high-speed machining mode (G05) 1st-phase
XC20	RPN1	In rapid traverse 1st-phase
XC21	CUT1	In cutting feed 1st-phase
XC22	TAP1	In tapping 1st-phase
XC23	THRD1	In thread cutting 1st-phase
XC24	SYN1	In synchronous feed 1st-phase
XC25	CSS1	In constant surface speed 1st-phase
XC26	SKIP1	In skip 1st-phase
XC27	ZRNN1	In reference position return 1st-phase
XC28	INCH1	In inch unit selection 1st-phase
XC29	DLKN1	In display lock 1st-phase
XC2A	F1DN1	F 1-digit commanded 1st-phase
XC2B	TLFO1	In tool life management 1st-phase
XC2E	TLOV1	Tool life over 1st-phase
XC2F		Tool group life over 1st-phase
XC30	F111	F 1-digit No. code 1 1st-phase
XC31	F121	F 1-digit No. code 2 1st-phase
XC32	F141	F 1-digit No. code 4 1st-phase
XC33	F181	F 1-digit No. code 8 1st-phase
XC34		Waiting between part systems 1st-phase
XC35	PCINO	In PLC interrupt 1st-phase
XC37	ASLE1	Illegal axis selected 1st-phase
XC40	DM001	M code independent output M00 1st-phase
XC41	DM011	M code independent output M01 1st-phase
XC42	DM021	M code independent output M02 1st-phase
XC43	DM301	M code independent output M30 1st-phase
XC49	MMS1	Manual numerical command 1st-phase
XC4A		In tool escape and return mode 1st-phase
XC4F		In circular feed in manual mode 1st-phase
XC60	MF11	M function strobe 1 1st-phase
XC61	MF21	M function strobe 2 1st-phase
XC62	MF31	M function strobe 3 1st-phase
XC63	MF41	M function strobe 4 1st-phase
XC64	SF11	S function strobe 1 1st-phase
XC65	SF21	S function strobe 2 1st-phase
XC66	SF31	S function strobe 3 1st-phase
XC67	SF41	S function strobe 4 1st-phase
XC68	TF11	T function strobe 1 1st-phase
XC69	TF21	T function strobe 2 1st-phase
XC6A	TF31	T function strobe 3 1st-phase
XC6B	TF41	T function strobe 4 1st-phase
XC6C	BF11	2nd M function strobe 1 1st-phase
XC6D	BF21	2nd M function strobe 2 1st-phase
XC6E	BF31	2nd M function strobe 3 1st-phase
XC6F	BF41	2nd M function strobe 4 1st-phase
XC80	CHOP1	In chopping start 1st-phase
XC81	CHP11	Basic position -> upper dead point path flag 1st-phase
XC82	CHP21	Upper dead point -> bottom dead point path flag 1st-phase
XC83	CHP31	Bottom dead point -> upper dead point path flag 1st-phase
XC84	CHP41	Upper dead point -> basic position path flag 1st-phase
XC85	CHPMD1	In chopping mode 1st-phase
XC86		Stroke compensation completion 1st-phase
XC87		Tool escape and return transit point recognition completed 1st-phase
XC8A	SSE1	Search & start (error) 1st-phase
XC8B	SSG1	Search & start (search) 1st-phase
XC93	TCP1	Tool change position return completion 1st-phase
XC94	TCRQ1	New tool change 1st-phase
XC95		All spindles simultaneous control (G47.1) 1st-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
XC96		Life prediction 1st-phase
XC98	AL11	NC alarm 1 1st-phase
XC99	AL21	NC alarm 2 (Servo alarm) 1st-phase
XC9A	AL31	NC alarm 3 (Program error) 1st-phase
XC9B	AL41	NC alarm 4 (Operation error) 1st-phase
XCA0		Load monitor in execution 1st-phase
XCA1		Load monitor teaching mode valid 1st-phase
XCA2		Load monitor monitor mode valid 1st-phase
XCA3		Adaptive control in execution 1st-phase
XCA5	TRVE1	Tap retract possible 1st-phase
XCA6	PCNT1	No. of work machining over 1st-phase
XCA7	ABSW1	Absolute position warning 1st-phase
XCB0		In Spindle-NC axis polygon mode 1st-phase
XCB1	AL51	NC alarm 5 1st-phase
XCB2		In Spindle-Spindle polygon mode 1st-phase
XCB3		Spindle-spindle polygon synchronization completion 1st-phase
XCB9		In 3-dimensional coordinate conversion 1st-phase
XCC0	RTAP1	In synchronized tapping selection (M command) 1st-phase
XCC1		In small diameter deep hole cycle 1st-phase
XCC2		High-speed retract function valid state 1st-phase
XCC3		In high-speed retract function operation 1st-phase
XCC8		In barrier valid (left) 1st-phase
XCC9		In barrier valid (right) 1st-phase
XCD8	DROPNS1	Door open enable 1st-phase
XCE8		Door open enable (2 channels per 1 part system) 1st-phase
XCE9		Door open enable (3 channels per 1 part system) spare 1st-phase
XD40	JO2	In jog mode 2nd-phase
XD41	HO2	In handle mode 2nd-phase
XD42	SO2	In incremental mode 2nd-phase
XD43	PTPO2	In manual arbitrary feed mode 2nd-phase
XD44	ZRNO2	In reference position return mode 2nd-phase
XD45	ASTO2	In automatic initial set mode 2nd-phase
XD46		In jog-handle simultaneous mode 2nd-phase
XD48	MEMO2	In memory mode 2nd-phase
XD49	TO2	In tape mode 2nd-phase
XD4A		In online operation mode 2nd-phase
XD4B	DO2	In MDI mode 2nd-phase
XD50	MA2	Controller ready completion 2nd-phase
XD51	SA2	Servo ready completion 2nd-phase
XD52	OP2	In automatic operation "run" 2nd-phase
XD53	STL2	In automatic operation "start" 2nd-phase
XD54	SPL2	In automatic operation "pause" 2nd-phase
XD55	RST2	In "reset" 2nd-phase
XD56	CXN2	In manual arbitrary feed 2nd-phase
XD57	RWD2	In rewind 2nd-phase
XD58	DEN2	Motion command completion 2nd-phase
XD59	TIMP2	All axes in-position 2nd-phase
XD5A	TSMZ2	All axes smoothing zero 2nd-phase
XD5C	CXFIN2	Manual arbitrary feed completion 2nd-phase
XD5D	ETSE2	External search finished 2nd-phase
XD5F		In high-speed machining mode (G05) 2nd-phase
XD60	RPN2	In rapid traverse 2nd-phase
XD61	CUT2	In cutting feed 2nd-phase
XD62	TAP2	In tapping 2nd-phase
XD63	THRD2	In thread cutting 2nd-phase
XD64	SYN2	In synchronous feed 2nd-phase
XD65	CSS2	In constant surface speed 2nd-phase
XD66	SKIP2	In skip 2nd-phase
XD67	ZRNN2	In reference position return 2nd-phase
XD68	INCH2	In inch unit selection 2nd-phase
XD69	DLKN2	In display lock 2nd-phase
XD6A	F1DN2	F 1-digit commanded 2nd-phase
XD6B	TLFO2	In tool life management 2nd-phase
XD6E	TLOV2	Tool life over 2nd-phase
XD6F		Tool group life over 2nd-phase
XD70	F112	F 1-digit No. code 1 2nd-phase
XD71	F122	F 1-digit No. code 2 2nd-phase
XD72	F142	F 1-digit No. code 4 2nd-phase
XD73	F182	F 1-digit No. code 8 2nd-phase
XD74		Waiting between part systems 2nd-phase
XD75	PCINO	In PLC interrupt 2nd-phase
XD77	ASLE2	Illegal axis selected 2nd-phase
XD80	DM002	M code independent output M00 2nd-phase
XD81	DM012	M code independent output M01 2nd-phase
XD82	DM022	M code independent output M02 2nd-phase
XD83	DM302	M code independent output M30 2nd-phase
XD89	MMS2	Manual numerical command 2nd-phase
XD8A		In tool escape and return mode 2nd-phase
XD8F		In circular feed in manual mode 2nd-phase
XDA0	MF12	M function strobe 1 2nd-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
XDA1	MF22	M function strobe 2 2nd-phase
XDA2	MF32	M function strobe 3 2nd-phase
XDA3	MF42	M function strobe 4 2nd-phase
XDA4	SF12	S function strobe 1 2nd-phase
XDA5	SF22	S function strobe 2 2nd-phase
XDA6	SF32	S function strobe 3 2nd-phase
XDA7	SF42	S function strobe 4 2nd-phase
XDA8	TF12	T function strobe 1 2nd-phase
XDA9	TF22	T function strobe 2 2nd-phase
XDAA	TF32	T function strobe 3 2nd-phase
XDAB	TF42	T function strobe 4 2nd-phase
XDAC	BF12	2nd M function strobe 1 2nd-phase
XDAD	BF22	2nd M function strobe 2 2nd-phase
XDAE	BF32	2nd M function strobe 3 2nd-phase
XDAF	BF42	2nd M function strobe 4 2nd-phase
XDC0	CHOP2	In chopping start 2nd-phase
XDC1	CHP12	Basic position -> upper dead point path flag 2nd-phase
XDC2	CHP22	Upper dead point -> bottom dead point path flag 2nd-phase
XDC3	CHP32	Bottom dead point -> upper dead point path flag 2nd-phase
XDC4	CHP42	Upper dead point -> basic position path flag 2nd-phase
XDC5	CHPMD2	In chopping mode 2nd-phase
XDC6		Stroke compensation completion 2nd-phase
XDC7		Tool escape and return transit point recognition completed 2nd-phase
XDCA	SSE2	Search & start (error) 2nd-phase
XDCB	SSG2	Search & start (search) 2nd-phase
XDD3	TCP2	Tool change position return completion 2nd-phase
XDD4	TCRQ2	New tool change 2nd-phase
XDD5		All spindles simultaneous control (G47.1) 2nd-phase
XDD6		Life prediction 2nd-phase
XDD8	AL12	NC alarm 1 2nd-phase
XDD9	AL22	NC alarm 2 (Servo alarm) 2nd-phase
XDDA	AL32	NC alarm 3 (Program error) 2nd-phase
Xddb	AL42	NC alarm 4 (Operation error) 2nd-phase
XDE0		Load monitor in execution 2nd-phase
XDE1		Load monitor teaching mode valid 2nd-phase
XDE2		Load monitor monitor mode valid 2nd-phase
XDE3		Adaptive control in execution 2nd-phase
XDE5	TRVE2	Tap retract possible 2nd-phase
XDE6	PCNT2	No. of work machining over 2nd-phase
XDE7	ABSW2	Absolute position warning 2nd-phase
XDF0		In Spindle-NC axis polygon mode 2nd-phase
XDF1	AL52	NC alarm 5 2nd-phase
XDF2		In Spindle-Spindle polygon mode 2nd-phase
XDF3		Spindle-spindle polygon synchronization completion 2nd-phase
XDF9		In 3-dimensional coordinate conversion 2nd-phase
XE00	RTAP2	In synchronized tapping selection (M command) 2nd-phase
XE01		In small diameter deep hole cycle 2nd-phase
XE02		High-speed retract function valid state 2nd-phase
XE03		In high-speed retract function operation 2nd-phase
XE08		In barrier valid (left) 2nd-phase
XE09		In barrier valid (right) 2nd-phase
XE18	DROPNS2	Door open enable 2nd-phase
XE28		Door open enable (2 channels per 1 part system) 2nd-phase
XE29		Door open enable (3 channels per 1 part system) spare 2nd-phase
XE80	JO3	In jog mode 3rd-phase
XE81	HO3	In handle mode 3rd-phase
XE82	SO3	In incremental mode 3rd-phase
XE83	PTPO3	In manual arbitrary feed mode 3rd-phase
XE84	ZRNO3	In reference position return mode 3rd-phase
XE85	ASTO3	In automatic initial set mode 3rd-phase
XE86		In jog-handle simultaneous mode 3rd-phase
XE88	MEMO3	In memory mode 3rd-phase
XE89	TO3	In tape mode 3rd-phase
XE8A		In online operation mode 3rd-phase
XE8B	DO3	In MDI mode 3rd-phase
XE90	MA3	Controller ready completion 3rd-phase
XE91	SA3	Servo ready completion 3rd-phase
XE92	OP3	In automatic operation "run" 3rd-phase
XE93	STL3	In automatic operation "start" 3rd-phase
XE94	SPL3	In automatic operation "pause" 3rd-phase
XE95	RST3	In "reset" 3rd-phase
XE96	CXN3	In manual arbitrary feed 3rd-phase
XE97	RWD3	In rewind 3rd-phase
XE98	DEN3	Motion command completion 3rd-phase
XE99	TIMP3	All axes in-position 3rd-phase
XE9A	TSMZ3	All axes smoothing zero 3rd-phase
XE9C	CXFIN3	Manual arbitrary feed completion 3rd-phase
XE9D	ETSE3	External search finished 3rd-phase
XE9F		In high-speed machining mode (G05) 3rd-phase
XEA0	RPN3	In rapid traverse 3rd-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
XEA1	CUT3	In cutting feed 3rd-phase
XEA2	TAP3	In tapping 3rd-phase
XEA3	THRD3	In thread cutting 3rd-phase
XEA4	SYN3	In synchronous feed 3rd-phase
XEA5	CSS3	In constant surface speed 3rd-phase
XEA6	SKIP3	In skip 3rd-phase
XEA7	ZRNN3	In reference position return 3rd-phase
XEA8	INCH3	In inch unit selection 3rd-phase
XEA9	DLKN3	In display lock 3rd-phase
XEAA	F1DN3	F 1-digit commanded 3rd-phase
XEAB	TLFO3	In tool life management 3rd-phase
XEAE	TLOV3	Tool life over 3rd-phase
XEAF		Tool group life over 3rd-phase
XEB0	F113	F 1-digit No. code 1 3rd-phase
XEB1	F123	F 1-digit No. code 2 3rd-phase
XEB2	F143	F 1-digit No. code 4 3rd-phase
XEB3	F183	F 1-digit No. code 8 3rd-phase
XEB4		Waiting between part systems 3rd-phase
XEB5	PCINO	In PLC interrupt 3rd-phase
XEB7	ASLE3	Illegal axis selected 3rd-phase
XEC0	DM003	M code independent output M00 3rd-phase
XEC1	DM013	M code independent output M01 3rd-phase
XEC2	DM023	M code independent output M02 3rd-phase
XEC3	DM303	M code independent output M30 3rd-phase
XEC9	MMS3	Manual numerical command 3rd-phase
XECA		In tool escape and return mode 3rd-phase
XECF		In circular feed in manual mode 3rd-phase
XEE0	MF13	M function strobe 1 3rd-phase
XEE1	MF23	M function strobe 2 3rd-phase
XEE2	MF33	M function strobe 3 3rd-phase
XEE3	MF43	M function strobe 4 3rd-phase
XEE4	SF13	S function strobe 1 3rd-phase
XEE5	SF23	S function strobe 2 3rd-phase
XEE6	SF33	S function strobe 3 3rd-phase
XEE7	SF43	S function strobe 4 3rd-phase
XEE8	TF13	T function strobe 1 3rd-phase
XEE9	TF23	T function strobe 2 3rd-phase
XEEA	TF33	T function strobe 3 3rd-phase
XEEB	TF43	T function strobe 4 3rd-phase
XEEC	BF13	2nd M function strobe 1 3rd-phase
XEED	BF23	2nd M function strobe 2 3rd-phase
XEEE	BF33	2nd M function strobe 3 3rd-phase
XEEF	BF43	2nd M function strobe 4 3rd-phase
XF00	CHOP3	In chopping start 3rd-phase
XF01	CHP13	Basic position -> upper dead point path flag 3rd-phase
XF02	CHP23	Upper dead point -> bottom dead point path flag 3rd-phase
XF03	CHP33	Bottom dead point -> upper dead point path flag 3rd-phase
XF04	CHP43	Upper dead point -> basic position path flag 3rd-phase
XF05	CHPMD3	In chopping mode 3rd-phase
XF06		Stroke compensation completion 3rd-phase
XF07		Tool escape and return transit point recognition completed 3rd-phase
XF0A	SSE3	Search & start (error) 3rd-phase
XF0B	SSG3	Search & start (search) 3rd-phase
XF13	TCP3	Tool change position return completion 3rd-phase
XF14	TCRQ3	New tool change 3rd-phase
XF15		All spindles simultaneous control (G47.1) 3rd-phase
XF16		Life prediction 3rd-phase
XF18	AL13	NC alarm 1 3rd-phase
XF19	AL23	NC alarm 2 (Servo alarm) 3rd-phase
XF1A	AL33	NC alarm 3 (Program error) 3rd-phase
XF1B	AL43	NC alarm 4 (Operation error) 3rd-phase
XF20		Load monitor in execution 3rd-phase
XF21		Load monitor teaching mode valid 3rd-phase
XF22		Load monitor monitor mode valid 3rd-phase
XF23		Adaptive control in execution 3rd-phase
XF25	TRVE3	Tap retract possible 3rd-phase
XF26	PCNT3	No. of work machining over 3rd-phase
XF27	ABSW3	Absolute position warning 3rd-phase
XF30		In Spindle-NC axis polygon mode 3rd-phase
XF31	AL53	NC alarm 5 3rd-phase
XF32		In Spindle-Spindle polygon mode 3rd-phase
XF33		Spindle-spindle polygon synchronization completion 3rd-phase
XF39		In 3-dimensional coordinate conversion 3rd-phase
XF40	RTAP3	In synchronized tapping selection (M command) 3rd-phase
XF41		In small diameter deep hole cycle 3rd-phase
XF42		High-speed retract function valid state 3rd-phase
XF43		In high-speed retract function operation 3rd-phase
XF48		In barrier valid (left) 3rd-phase
XF49		In barrier valid (right) 3rd-phase
XF58	DROPNS3	Door open enable 3rd-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
XF68		Door open enable (2 channels per 1 part system) 3rd-phase
XF69		Door open enable (3 channels per 1 part system) spare 3rd-phase
XFC0	JO4	In jog mode 4th-phase
XFC1	HO4	In handle mode 4th-phase
XFC2	SO4	In incremental mode 4th-phase
XFC3	PTPO4	In manual arbitrary feed mode 4th-phase
XFC4	ZRNO4	In reference position return mode 4th-phase
XFC5	ASTO4	In automatic initial set mode 4th-phase
XFC6		In jog-handle simultaneous mode 4th-phase
XFC8	MEMO4	In memory mode 4th-phase
XFC9	TO4	In tape mode 4th-phase
XFCA		In online operation mode 4th-phase
XFCB	DO4	In MDI mode 4th-phase
XFD0	MA4	Controller ready completion 4th-phase
XFD1	SA4	Servo ready completion 4th-phase
XFD2	OP4	In automatic operation "run" 4th-phase
XFD3	STL4	In automatic operation "start" 4th-phase
XFD4	SPL4	In automatic operation "pause" 4th-phase
XFD5	RST4	In "reset" 4th-phase
XFD6	CXN4	In manual arbitrary feed 4th-phase
XFD7	RWD4	In rewind 4th-phase
XFD8	DEN4	Motion command completion 4th-phase
XFD9	TIMP4	All axes in-position 4th-phase
XFDA	TSMZ4	All axes smoothing zero 4th-phase
XFDC	CXFIN4	Manual arbitrary feed completion 4th-phase
XFDD	ETSE4	External search finished 4th-phase
XFDF		In high-speed machining mode (G05) 4th-phase
XFE0	RPN4	In rapid traverse 4th-phase
XFE1	CUT4	In cutting feed 4th-phase
XFE2	TAP4	In tapping 4th-phase
XFE3	THR4	In thread cutting 4th-phase
XFE4	SYN4	In synchronous feed 4th-phase
XFE5	CSS4	In constant surface speed 4th-phase
XFE6	SKIP4	In skip 4th-phase
XFE7	ZRNN4	In reference position return 4th-phase
XFE8	INCH4	In inch unit selection 4th-phase
XFE9	DLKN4	In display lock 4th-phase
XFEA	F1DN4	F 1-digit commanded 4th-phase
XFEB	TLFO4	In tool life management 4th-phase
XFEE	TLOV4	Tool life over 4th-phase
XFEF		Tool group life over 4th-phase
XFF0	F114	F 1-digit No. code 1 4th-phase
XFF1	F124	F 1-digit No. code 2 4th-phase
XFF2	F144	F 1-digit No. code 4 4th-phase
XFF3	F184	F 1-digit No. code 8 4th-phase
XFF4		Waiting between part systems 4th-phase
XFF5	PCINO	In PLC interrupt 4th-phase
XFF7	ASLE4	Illegal axis selected 4th-phase
X1000	DM004	M code independent output M00 4th-phase
X1001	DM014	M code independent output M01 4th-phase
X1002	DM024	M code independent output M02 4th-phase
X1003	DM304	M code independent output M30 4th-phase
X1009	MMS4	Manual numerical command 4th-phase
X100A		In tool escape and return mode 4th-phase
X100F		In circular feed in manual mode 4th-phase
X1020	MF14	M function strobe 1 4th-phase
X1021	MF24	M function strobe 2 4th-phase
X1022	MF34	M function strobe 3 4th-phase
X1023	MF44	M function strobe 4 4th-phase
X1024	SF14	S function strobe 1 4th-phase
X1025	SF24	S function strobe 2 4th-phase
X1026	SF34	S function strobe 3 4th-phase
X1027	SF44	S function strobe 4 4th-phase
X1028	TF14	T function strobe 1 4th-phase
X1029	TF24	T function strobe 2 4th-phase
X102A	TF34	T function strobe 3 4th-phase
X102B	TF44	T function strobe 4 4th-phase
X102C	BF14	2nd M function strobe 1 4th-phase
X102D	BF24	2nd M function strobe 2 4th-phase
X102E	BF34	2nd M function strobe 3 4th-phase
X102F	BF44	2nd M function strobe 4 4th-phase
X1040	CHOP4	In chopping start 4th-phase
X1041	CHP14	Basic position -> upper dead point path flag 4th-phase
X1042	CHP24	Upper dead point -> bottom dead point path flag 4th-phase
X1043	CHP34	Bottom dead point -> upper dead point path flag 4th-phase
X1044	CHP44	Upper dead point -> basic position path flag 4th-phase
X1045	CHPMD4	In chopping mode 4th-phase
X1046		Stroke compensation completion 4th-phase
X1047		Tool escape and return transit point recognition completed 4th-phase
X104A	SSE4	Search & start (error) 4th-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X104B	SSG4	Search & start (search) 4th-phase
X1053	TCP4	Tool change position return completion 4th-phase
X1054	TCRQ4	New tool change 4th-phase
X1055		All spindles simultaneous control (G47.1) 4th-phase
X1056		Life prediction 4th-phase
X1058	AL14	NC alarm 1 4th-phase
X1059	AL24	NC alarm 2 (Servo alarm) 4th-phase
X105A	AL34	NC alarm 3 (Program error) 4th-phase
X105B	AL44	NC alarm 4 (Operation error) 4th-phase
X1060		Load monitor in execution 4th-phase
X1061		Load monitor teaching mode valid 4th-phase
X1062		Load monitor monitor mode valid 4th-phase
X1063		Adaptive control in execution 4th-phase
X1065	TRVE4	Tap retract possible 4th-phase
X1066	PCNT4	No. of work machining over 4th-phase
X1067	ABSW4	Absolute position warning 4th-phase
X1070		In Spindle-NC axis polygon mode 4th-phase
X1071	AL54	NC alarm 5 4th-phase
X1072		In Spindle-Spindle polygon mode 4th-phase
X1073		Spindle-spindle polygon synchronization completion 4th-phase
X1079		In 3-dimensional coordinate conversion 4th-phase
X1080	RTAP4	In synchronized tapping selection (M command) 4th-phase
X1081		In small diameter deep hole cycle 4th-phase
X1082		High-speed retract function valid state 4th-phase
X1083		In high-speed retract function operation 4th-phase
X1088		In barrier valid (left) 4th-phase
X1089		In barrier valid (right) 4th-phase
X1098	DROPNS4	Door open enable 4th-phase
X10A8		Door open enable (2 channels per 1 part system) 4th-phase
X10A9		Door open enable (3 channels per 1 part system) spare 4th-phase
X1880	SUPP1	Spindle speed upper limit over 1st-Spindle
X1881	SLOW1	Spindle speed lower limit over 1st-Spindle
X1882	SIGE1	S command gear No. illegal 1st-Spindle
X1883	SOVE1	S command max./min. command value over 1st-Spindle
X1884	SNGE1	S command no gear selected 1st-Spindle
X1885	GR11	Spindle gear shift command 1 1st-Spindle
X1886	GR21	Spindle gear shift command 2 1st-Spindle
X1887		(Always "0") 1st-Spindle
X1888	ORA2O1	Spindle 2nd in-position 1st-Spindle
X1889	CDO1	Current detection 1st-Spindle
X188A	VRO1	Speed detection 1st-Spindle
X188B	FLO1	In spindle alarm 1st-Spindle
X188C	ZSO1	Zero speed 1st-Spindle
X188D	USO1	Spindle up-to-speed 1st-Spindle
X188E	ORAO1	Spindle in-position 1st-Spindle
X188F	LCSA1	In L coil selection 1st-Spindle
X1890	SMA1	Spindle ready-ON 1st-Spindle
X1891	SSA1	Spindle servo-ON 1st-Spindle
X1892	SENG1	In spindle emergency stop 1st-Spindle
X1893	SSRN1	In spindle forward run 1st-Spindle
X1894	SSRI1	In spindle reverse run 1st-Spindle
X1895	SZPH1	Z-phase passed 1st-Spindle
X1896	SIMP1	Position loop in-position 1st-Spindle
X1897	STLQ1	In spindle Spindle torque limit 1st-Spindle
X1898	M1SEL1	In motor 1 selection 1st-Spindle
X1899	M2SEL1	In motor 2 selection 1st-Spindle
X189D	SD21	Speed detection 2 1st-Spindle
X189E	MCSA1	In M coil selection 1st-Spindle
X189F		Index positioning completion 1st-Spindle
X18A0	ENB1	Spindle enable 1st-spindle
X18A8	SPSYN11	In spindle synchronization 1st-Spindle
X18A9	FSPRV1	Spindle rotation speed synchronization completion 1st-Spindle
X18AA	FSPPH1	Spindle phase synchronization completion 1st-Spindle
X18AB	SPSYN21	In spindle synchronization 2 1st-Spindle
X18AE	SPSYN3	In tool spindle synchronization II 1st-spindle
X18B3	PHOVR	Hob axis delay excess 1st-spindle
X18B5	EXOFN	In spindle holding force up 1st-spindle
X18E0	SUPP2	Spindle speed upper limit over 2nd-Spindle
X18E1	SLOW2	Spindle speed lower limit over 2nd-Spindle
X18E2	SIGE2	S command gear No. illegal 2nd-Spindle
X18E3	SOVE2	S command max./min. command value over 2nd-Spindle
X18E4	SNGE2	S command no gear selected 2nd-Spindle
X18E5	GR12	Spindle gear shift command 1 2nd-Spindle
X18E6	GR22	Spindle gear shift command 2 2nd-Spindle
X18E7		(Always "0") 2nd-Spindle
X18E8	ORA2O2	Spindle 2nd in-position 2nd-Spindle
X18E9	CDO2	Current detection 2nd-Spindle
X18EA	VRO2	Speed detection 2nd-Spindle
X18EB	FLO2	In spindle alarm 2nd-Spindle
X18EC	ZSO2	Zero speed 2nd-Spindle

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X18ED	USO2	Spindle up-to-speed 2nd-Spindle
X18EE	ORAO2	Spindle in-position 2nd-Spindle
X18EF	LCSA2	In L coil selection 2nd-Spindle
X18F0	SMA2	Spindle ready-ON 2nd-Spindle
X18F1	SSA2	Spindle servo-ON 2nd-Spindle
X18F2	SENG2	In spindle emergency stop 2nd-Spindle
X18F3	SSRN2	In spindle forward run 2nd-Spindle
X18F4	SSRI2	In spindle reverse run 2nd-Spindle
X18F5	SZPH2	Z-phase passed 2nd-Spindle
X18F6	SIMP2	Position loop in-position 2nd-Spindle
X18F7	STLQ2	In spindle torque limit 2nd-Spindle
X18F8	M1SEL2	In motor 1 selection 2nd-Spindle
X18F9	M2SEL2	In motor 2 selection 2nd-Spindle
X18FD	SD22	Speed detection 2 2nd-Spindle
X18FE	MCSA1	In M coil selection 2nd-Spindle
X18FF		Index positioning completion 2nd-Spindle
X1900	ENB2	Spindle enable 2nd-spindle
X1908	SPSYN12	In spindle synchronization 2nd-Spindle
X1909	FSPRV2	Spindle rotation speed synchronization completion 2nd-Spindle
X190A	FSPPH2	Spindle phase synchronization completion 2nd-Spindle
X190B	SPSYN22	In spindle synchronization 2 2nd-Spindle
X190E	SPSYN3	In tool spindle synchronization II 2nd-spindle
X1913	PHOVR	Hob axis delay excess 2nd-spindle
X1915	EXOFN	In spindle holding force up 2nd-spindle
X1940	SUPP3	Spindle speed upper limit over 3rd-Spindle
X1941	SLOW3	Spindle speed lower limit over 3rd-Spindle
X1942	SIGE3	S command gear No. illegal 3rd-Spindle
X1943	SOVE3	S command max./min. command value over 3rd-Spindle
X1944	SNGE3	S command no gear selected 3rd-Spindle
X1945	GR13	Spindle gear shift command 1 3rd-Spindle
X1946	GR23	Spindle gear shift command 2 3rd-Spindle
X1947		(Always "0") 3rd-Spindle
X1948	ORA2O3	Spindle 2nd in-position 3rd-Spindle
X1949	CDO3	Current detection 3rd-Spindle
X194A	VRO3	Speed detection 3rd-Spindle
X194B	FLO3	In spindle alarm 3rd-Spindle
X194C	ZSO3	Zero speed 3rd-Spindle
X194D	USO3	Spindle up-to-speed 3rd-Spindle
X194E	ORAO3	Spindle in-position 3rd-Spindle
X194F	LCSA3	In L coil selection 3rd-Spindle
X1950	SMA3	Spindle ready-ON 3rd-Spindle
X1951	SSA3	Spindle servo-ON 3rd-Spindle
X1952	SENG3	In spindle emergency stop 3rd-Spindle
X1953	SSRN3	In spindle forward run 3rd-Spindle
X1954	SSRI3	In spindle reverse run 3rd-Spindle
X1955	SZPH3	Z-phase passed 3rd-Spindle
X1956	SIMP3	Position loop in-position 3rd-Spindle
X1957	STLQ3	In spindle torque limit 3rd-Spindle
X1958	M1SEL3	In motor 1 selection 3rd-Spindle
X1959	M2SEL3	In motor 2 selection 3rd-Spindle
X195D	SD23	Speed detection 2 3rd-Spindle
X195E	MCSA1	In M coil selection 3rd-Spindle
X195F		Index positioning completion 3rd-Spindle
X1960	ENB3	Spindle enable 3rd-spindle
X1968	SPSYN13	In spindle synchronization 3rd-Spindle
X1969	FSPRV3	Spindle rotation speed synchronization completion 3rd-Spindle
X196A	FSPPH3	Spindle phase synchronization completion 3rd-Spindle
X196B	SPSYN23	In spindle synchronization 2 3rd-Spindle
X196E	SPSYN3	In tool spindle synchronization II 3rd-spindle
X1973	PHOVR	Hob axis delay excess 3rd-spindle
X1975	EXOFN	In spindle holding force up 3rd-spindle
X19A0	SUPP4	Spindle speed upper limit over 4th-Spindle
X19A1	SLOW4	Spindle speed lower limit over 4th-Spindle
X19A2	SIGE4	S command gear No. illegal 4th-Spindle
X19A3	SOVE4	S command max./min. command value over 4th-Spindle
X19A4	SNGE4	S command no gear selected 4th-Spindle
X19A5	GR14	Spindle gear shift command 1 4th-Spindle
X19A6	GR24	Spindle gear shift command 2 4th-Spindle
X19A7		(Always "0") 4th-Spindle
X19A8	ORA2O4	Spindle 2nd in-position 4th-Spindle
X19A9	CDO4	Current detection 4th-Spindle
X19AA	VRO4	Speed detection 4th-Spindle
X19AB	FLO4	In spindle alarm 4th-Spindle
X19AC	ZSO4	Zero speed 4th-Spindle
X19AD	USO4	Spindle up-to-speed 4th-Spindle
X19AE	ORAO4	Spindle in-position 4th-Spindle
X19AF	LCSA4	In L coil selection 4th-Spindle
X19B0	SMA4	Spindle ready-ON 4th-Spindle
X19B1	SSA4	Spindle servo-ON 4th-Spindle
X19B2	SENG4	In spindle emergency stop 4th-Spindle

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X19B3	SSRN4	In spindle forward run 4th-Spindle
X19B4	SSRI4	In spindle reverse run 4th-Spindle
X19B5	SZPH4	Z-phase passed 4th-Spindle
X19B6	SIMP4	Position loop in-position 4th-Spindle
X19B7	STLQ4	In spindle torque limit 4th-Spindle
X19B8	M1SEL4	In motor 1 selection 4th-Spindle
X19B9	M2SEL4	In motor 2 selection 4th-Spindle
X19BD	SD24	Speed detection 2 4th-Spindle
X19BE	MCSA1	In M coil selection 4th-Spindle
X19BF		Index positioning completion 4th-Spindle
X19C0	ENB4	Spindle enable 4th-spindle
X19C8	SPSYN14	In spindle synchronization 4th-Spindle
X19C9	FSPRV4	Spindle rotation speed synchronization completion 4th-Spindle
X19CA	FSPPH4	Spindle phase synchronization completion 4th-Spindle
X19CB	SPSYN24	In spindle synchronization 2 4th-Spindle
X19CE	SPSYN3	In tool spindle synchronization II 4th-spindle
X19D3	PHOVR	Hob axis delay excess 4th-spindle
X19D5	EXOFN	In spindle holding force up 4th-spindle
X1A00	SUPP5	Spindle speed upper limit over 5th-Spindle
X1A01	SLOW5	Spindle speed lower limit over 5th-Spindle
X1A02	SIGE5	S command gear No. illegal 5th-Spindle
X1A03	SOVE5	S command max./min. command value over 5th-Spindle
X1A04	SNGE5	S command no gear selected 5th-Spindle
X1A05	GR15	Spindle gear shift command 1 5th-Spindle
X1A06	GR25	Spindle gear shift command 2 5th-Spindle
X1A08	ORA2O5	Spindle 2nd in-position 5th-Spindle
X1A09	CDO5	Current detection 5th-Spindle
X1A0A	VRO5	Speed detection 5th-Spindle
X1A0B	FLO5	In spindle alarm 5th-Spindle
X1A0C	ZSO5	Zero speed 5th-Spindle
X1A0D	USO5	Spindle up-to-speed 5th-Spindle
X1A0E	ORA05	Spindle in-position 5th-Spindle
X1A0F	LCSA5	In L coil selection 5th-Spindle
X1A10	SMA5	Spindle ready-ON 5th-Spindle
X1A12	SENG5	In spindle emergency stop 5th-Spindle
X1A13	SSRN5	In spindle forward run 5th-Spindle
X1A14	SSRI5	In spindle reverse run 5th-Spindle
X1A15	SZPH5	Z-phase passed 5th-Spindle
X1A16	SIMP5	Position loop in-position 5th-Spindle
X1A17	STLQ5	In spindle torque limit 5th-Spindle
X1A18	M1SEL5	In motor 1 selection 5th-Spindle
X1A19	M2SEL5	In motor 2 selection 5th-Spindle
X1A1D	SD2n	Speed detection 2 5th-Spindle
X1A1E	MCSA1	In M coil selection 5th-Spindle
X1A1F		Index positioning completion 5th-Spindle
X1A20	ENB1	Spindle enable 5th-spindle
X1A28	SPSYN11	In spindle synchronization 5th-Spindle
X1A29	FSPRV1	Spindle rotation speed synchronization completion 5th-Spindle
X1A2A	FSPPH1	Spindle phase synchronization completion 5th-Spindle
X1A2B	SPSYN21	In spindle synchronization 2 5th-Spindle
X1A2C	SPCMP1	Chuck close confirmation 5th-spindle
X1A2E	SPSYN3	In tool spindle synchronization II 5th-spindle
X1A33	PHOVR	Hob axis delay excess 5th-spindle
X1A35	EXOFN	In spindle holding force up 5th-spindle
X1A60	SUPP6	Spindle speed upper limit over 6th-Spindle
X1A61	SLOW6	Spindle speed lower limit over 6th-Spindle
X1A62	SIGE6	S command gear No. illegal 6th-Spindle
X1A63	SOVE6	S command max./min. command value over 6th-Spindle
X1A64	SNGE6	S command no gear selected 6th-Spindle
X1A65	GR16	Spindle gear shift command 1 6th-Spindle
X1A66	GR26	Spindle gear shift command 2 6th-Spindle
X1A68	ORA2O6	Spindle 2nd in-position 6th-Spindle
X1A69	CDO6	Current detection 6th-Spindle
X1A6A	VRO6	Speed detection 6th-Spindle
X1A6B	FLO6	In spindle alarm 6th-Spindle
X1A6C	ZSO6	Zero speed 6th-Spindle
X1A6D	USO6	Spindle up-to-speed 6th-Spindle
X1A6E	ORA06	Spindle in-position 6th-Spindle
X1A6F	LCSA6	In L coil selection 6th-Spindle
X1A70	SMA6	Spindle ready-ON 6th-Spindle
X1A72	SENG6	In spindle emergency stop 6th-Spindle
X1A73	SSRN6	In spindle forward run 6th-Spindle
X1A74	SSRI6	In spindle reverse run 6th-Spindle
X1A75	SZPH6	Z-phase passed 6th-Spindle
X1A76	SIMP6	Position loop in-position 6th-Spindle
X1A77	STLQ6	In spindle torque limit 6th-Spindle
X1A78	M1SEL6	In motor 1 selection 6th-Spindle
X1A79	M2SEL6	In motor 2 selection 6th-Spindle
X1A7D	SD2n	Speed detection 2 6th-Spindle
X1A7E	MCSA1	In M coil selection 6th-Spindle

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X1A7F		Index positioning completion 6th-Spindle
X1A80	ENB1	Spindle enable 6th-spindle
X1A88	SPSYN11	In spindle synchronization 6th-Spindle
X1A89	FSPRV1	Spindle rotation speed synchronization completion 6th-Spindle
X1A8A	FSPPH1	Spindle phase synchronization completion 6th-Spindle
X1A8B	SPSYN21	In spindle synchronization 2 6th-Spindle
X1A8C	SPCMP1	Chuck close confirmation 6th-spindle
X1A8E	SPSYN3	In tool spindle synchronization II 5th-spindle
X1A93	PHOVR	Hob axis delay excess 6th-spindle
X1A95	EXOFN	In spindle holding force up 6th-spindle
X1CD0		Handy terminal key 1
X1CD1		Handy terminal key 2
X1CD2		Handy terminal key 3
X1CD3		Handy terminal key 4
X1CD4		Handy terminal key 5
X1CD5		Handy terminal key 6
X1CD6		Handy terminal key 7
X1CD7		Handy terminal key 8
X1CD8		Handy terminal key 9
X1CD9		Handy terminal key 10
X1CDA		Handy terminal key 11
X1CDB		Handy terminal key 12
X1CDC		Handy terminal key 13
X1CDD		Handy terminal key 14
X1CDE		Handy terminal key 15
X1CDF		Handy terminal key 16
X1CE0		Handy terminal key 17
X1CE1		Handy terminal key 18
X1CE2		Handy terminal key 19
X1CE3		Handy terminal key 20
X1CE4		Handy terminal key 21
X1CE5		Handy terminal key 22
X1CE6		Handy terminal key 23
X1CE7		Handy terminal key 24
X1CE8		Handy terminal key 25
X1CE9		Handy terminal key 26
X1CEA		Handy terminal key 27
X1CEB		Handy terminal key 28
X1CEC		Handy terminal key 29
X1CED		Handy terminal key 30
X1CEE		Handy terminal key 31
X1CEF		Handy terminal key 32
X1CF0		Handy terminal key 33
X1CF1		Handy terminal key 34
X1CF2		Handy terminal key 35
X1CF3		Handy terminal key 36
X1CF4		Handy terminal key 37
X1CF5		Handy terminal key 38
X1CF6		Handy terminal key 39
X1CF7		Handy terminal key 40
X1CF8		Handy terminal key 41
X1CF9		Handy terminal key 42
X1CFA		Handy terminal key 43
X1CFB		Handy terminal key 44
X1CFC		Handy terminal key 45
X1D00	PSW11	Position switch 1 1st-phase
X1D01	PSW21	Position switch 2 1st-phase
X1D02	PSW31	Position switch 3 1st-phase
X1D03	PSW41	Position switch 4 1st-phase
X1D04	PSW51	Position switch 5 1st-phase
X1D05	PSW61	Position switch 6 1st-phase
X1D06	PSW71	Position switch 7 1st-phase
X1D07	PSW81	Position switch 8 1st-phase
X1D08	PSW91	Position switch 9 1st-phase
X1D09	PSW101	Position switch 10 1st-phase
X1D0A	PSW111	Position switch 11 1st-phase
X1D0B	PSW121	Position switch 12 1st-phase
X1D0C	PSW131	Position switch 13 1st-phase
X1D0D	PSW141	Position switch 14 1st-phase
X1D0E	PSW151	Position switch 15 1st-phase
X1D0F	PSW161	Position switch 16 1st-phase
X1D10	PSW171	Position switch 17 1st-phase
X1D11	PSW181	Position switch 18 1st-phase
X1D12	PSW191	Position switch 19 1st-phase
X1D13	PSW201	Position switch 20 1st-phase
X1D14	PSW211	Position switch 21 1st-phase
X1D15	PSW221	Position switch 22 1st-phase
X1D16	PSW231	Position switch 23 1st-phase
X1D17	PSW241	Position switch 24 1st-phase
X1D20	PSW12	Position switch 1 2nd-phase

III PLC Devices
1. Bit Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
X1D21	PSW22	Position switch 2 2nd-phase
X1D22	PSW32	Position switch 3 2nd-phase
X1D23	PSW42	Position switch 4 2nd-phase
X1D24	PSW52	Position switch 5 2nd-phase
X1D25	PSW62	Position switch 6 2nd-phase
X1D26	PSW72	Position switch 7 2nd-phase
X1D27	PSW82	Position switch 8 2nd-phase
X1D28	PSW92	Position switch 9 2nd-phase
X1D29	PSW102	Position switch 10 2nd-phase
X1D2A	PSW112	Position switch 11 2nd-phase
X1D2B	PSW122	Position switch 12 2nd-phase
X1D2C	PSW132	Position switch 13 2nd-phase
X1D2D	PSW142	Position switch 14 2nd-phase
X1D2E	PSW152	Position switch 15 2nd-phase
X1D2F	PSW162	Position switch 16 2nd-phase
X1D30	PSW172	Position switch 17 2nd-phase
X1D31	PSW182	Position switch 18 2nd-phase
X1D32	PSW192	Position switch 19 2nd-phase
X1D33	PSW202	Position switch 20 2nd-phase
X1D34	PSW212	Position switch 21 2nd-phase
X1D35	PSW222	Position switch 22 2nd-phase
X1D36	PSW232	Position switch 23 2nd-phase
X1D37	PSW242	Position switch 24 2nd-phase
X1D40	PSW13	Position switch 1 3rd-phase
X1D41	PSW23	Position switch 2 3rd-phase
X1D42	PSW33	Position switch 3 3rd-phase
X1D43	PSW43	Position switch 4 3rd-phase
X1D44	PSW53	Position switch 5 3rd-phase
X1D45	PSW63	Position switch 6 3rd-phase
X1D46	PSW73	Position switch 7 3rd-phase
X1D47	PSW83	Position switch 8 3rd-phase
X1D48	PSW93	Position switch 9 3rd-phase
X1D49	PSW103	Position switch 10 3rd-phase
X1D4A	PSW113	Position switch 11 3rd-phase
X1D4B	PSW123	Position switch 12 3rd-phase
X1D4C	PSW133	Position switch 13 3rd-phase
X1D4D	PSW143	Position switch 14 3rd-phase
X1D4E	PSW153	Position switch 15 3rd-phase
X1D4F	PSW163	Position switch 16 3rd-phase
X1D50	PSW173	Position switch 17 3rd-phase
X1D51	PSW183	Position switch 18 3rd-phase
X1D52	PSW193	Position switch 19 3rd-phase
X1D53	PSW203	Position switch 20 3rd-phase
X1D54	PSW213	Position switch 21 3rd-phase
X1D55	PSW223	Position switch 22 3rd-phase
X1D56	PSW233	Position switch 23 3rd-phase
X1D57	PSW243	Position switch 24 3rd-phase
X1D60	PSW14	Position switch 1 4th-phase
X1D61	PSW24	Position switch 2 4th-phase
X1D62	PSW34	Position switch 3 4th-phase
X1D63	PSW44	Position switch 4 4th-phase
X1D64	PSW54	Position switch 5 4th-phase
X1D65	PSW64	Position switch 6 4th-phase
X1D66	PSW74	Position switch 7 4th-phase
X1D67	PSW84	Position switch 8 4th-phase
X1D68	PSW94	Position switch 9 4th-phase
X1D69	PSW104	Position switch 10 4th-phase
X1D6A	PSW114	Position switch 11 4th-phase
X1D6B	PSW124	Position switch 12 4th-phase
X1D6C	PSW134	Position switch 13 4th-phase
X1D6D	PSW144	Position switch 14 4th-phase
X1D6E	PSW154	Position switch 15 4th-phase
X1D6F	PSW164	Position switch 16 4th-phase
X1D70	PSW174	Position switch 17 4th-phase
X1D71	PSW184	Position switch 18 4th-phase
X1D72	PSW194	Position switch 19 4th-phase
X1D73	PSW204	Position switch 20 4th-phase
X1D74	PSW214	Position switch 21 4th-phase
X1D75	PSW224	Position switch 22 4th-phase
X1D76	PSW234	Position switch 23 4th-phase
X1D77	PSW244	Position switch 24 4th-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R0	AI1	Analog input 1
R1	AI2	Analog input 2
R2	AI3	Analog input 3
R3	AI4	Analog input 4
R4	AI5	Analog input 5
R5	AI6	Analog input 6
R6	AI7	Analog input 7
R7	AI8	Analog input 8
R8		KEY IN 1
R9		(Full key)
R11		Clock data Month/Year
R12		Clock data Hour/Date
R13		Clock data Second/Minute
R16		CNC software version code
R17		CNC software version code
R18		CNC software version code
R19		CNC software version code
R25		PLC high-speed process time
R26		Turret interference check status
R27		Interference object alarm information
R30		Remote program input error information
R31		MELDAS-NET output
R37		PLC window parameter status
R56		Battery drop cause
R57		Temperature warning cause
R58		5V/24V error cause
R60		Control unit temperature
R62		Tool ID communication error information
R68		PLC main scan time
R69		Emergency stop cause
R70		DIO card information
R72		Ball screw thermal displacement compensation Compensation amount 1st axis
R73		Ball screw thermal displacement compensation Compensation amount 2nd axis
R74		Ball screw thermal displacement compensation Compensation amount 3rd axis
R75		Ball screw thermal displacement compensation Compensation amount 4th axis
R85		Modal task data update cycle
R96	SMODEN	Speed monitor door open possible
R97	SODIO	Safety observation I/O signal status
R210		Displayed screen No.
R500		External search status 1st-phase
R504		M code data 1 1st-phase
R505		M code data 1 1st-phase
R506		M code data 2 1st-phase
R507		M code data 2 1st-phase
R508		M code data 3 1st-phase
R509		M code data 3 1st-phase
R510		M code data 4 1st-phase
R511		M code data 4 1st-phase
R512		S code data 1 1st-phase
R513		S code data 1 1st-phase
R514		S code data 2 1st-phase
R515		S code data 2 1st-phase
R516		S code data 3 1st-phase
R517		S code data 3 1st-phase
R518		S code data 4 1st-phase
R519		S code data 4 1st-phase
R536		T code data 1 1st-phase
R537		T code data 1 1st-phase
R538		T code data 2 1st-phase
R539		T code data 2 1st-phase
R540		T code data 3 1st-phase
R541		T code data 3 1st-phase
R542		T code data 4 1st-phase
R543		T code data 4 1st-phase
R544		2nd M function data 1 1st-phase
R545		2nd M function data 1 1st-phase
R546		2nd M function data 2 1st-phase
R547		2nd M function data 2 1st-phase
R548		2nd M function data 3 1st-phase
R549		2nd M function data 3 1st-phase
R550		2nd M function data 4 1st-phase
R551		2nd M function data 4 1st-phase
R554		Chopping error No. 1st-phase
R555		Manual measurement status 1st-phase
R564		Load monitor warning axis 1st-phase
R565		Load monitor alarm axis 1st-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R566		Load monitor data alarm information 1st-phase
R567		Group in tool life management 1st-phase
R571		Adaptive control override 1st-phase
R572		CNC completion standby status 1st-phase
R573		(Blank) 1st-phase
R574		In initialization 1st-phase
R575		Initialization incompleteness 1st-phase
R576		Reference position adjustment value parameter setting completed 1st-phase
R580		Near reference position (per reference position) 1st-phase
R581		Near reference position (per reference position) 1st-phase
R582		Presetter contact 1st-phase
R583		Presetter interlock 1st-phase
R584		Area signal X axis on/off 1st-phase
R585		Area signal Z axis on/off 1st-phase
R586		Area signal X axis (-) on/off 1st-phase
R587		Area signal Z axis (-) on/off 1st-phase
R588		Takt time (ms) (L) 1st-phase
R589		Takt time (ms) (H) 1st-phase
R590		Takt time (min) (L) 1st-phase
R591		Takt time (min) (H) 1st-phase
R596		Load monitor status (1) 1st-phase
R597		Load monitor status (2) 1st-phase
R598		Load monitor status (3) 1st-phase
R599		Load monitor status (4) 1st-phase
R600		Load monitor status (5) 1st-phase
R601		Load monitor status (6) 1st-phase
R602		Load monitor status (7) 1st-phase
R603		Load monitor status (8) 1st-phase
R604		Load monitor status (9) 1st-phase
R605		Load monitor status (10) 1st-phase
R606		No. of work machining (current value) 1st-phase
R607		No. of work machining (current value) 1st-phase
R628		Tool life usage data 1st-phase
R629		Tool life usage data 1st-phase
R630		Number of registered tool life control tools 1st-phase
R636		Circular feed in manual mode current position X 1st-phase
R637		Circular feed in manual mode current position X 1st-phase
R638		Circular feed in manual mode current position X 1st-phase
R639		Circular feed in manual mode current position X 1st-phase
R640		Circular feed in manual mode current position Y 1st-phase
R641		Circular feed in manual mode current position Y 1st-phase
R642		Circular feed in manual mode current position Y 1st-phase
R643		Circular feed in manual mode current position Y 1st-phase
R700		External search status 2nd-phase
R704		M code data 1 2nd-phase
R705		M code data 1 2nd-phase
R706		M code data 2 2nd-phase
R707		M code data 2 2nd-phase
R708		M code data 3 2nd-phase
R709		M code data 3 2nd-phase
R710		M code data 4 2nd-phase
R711		M code data 4 2nd-phase
R712		S code data 1 2nd-phase
R713		S code data 1 2nd-phase
R714		S code data 2 2nd-phase
R715		S code data 2 2nd-phase
R716		S code data 3 2nd-phase
R717		S code data 3 2nd-phase
R718		S code data 4 2nd-phase
R719		S code data 4 2nd-phase
R736		T code data 1 2nd-phase
R737		T code data 1 2nd-phase
R738		T code data 2 2nd-phase
R739		T code data 2 2nd-phase
R740		T code data 3 2nd-phase
R741		T code data 3 2nd-phase
R742		T code data 4 2nd-phase
R743		T code data 4 2nd-phase
R744		2nd M function data 1 2nd-phase
R745		2nd M function data 1 2nd-phase
R746		2nd M function data 2 2nd-phase
R747		2nd M function data 2 2nd-phase
R748		2nd M function data 3 2nd-phase
R749		2nd M function data 3 2nd-phase
R750		2nd M function data 4 2nd-phase
R751		2nd M function data 4 2nd-phase
R754		Chopping error No. 2nd-phase
R755		Manual measurement status 2nd-phase
R764		Load monitor warning axis 2nd-phase
R765		Load monitor alarm axis 2nd-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R766		Load monitor data alarm information 2nd-phase
R767		Group in tool life management 2nd-phase
R771		Adaptive control override 2nd-phase
R772		CNC completion standby status 2nd-phase
R773		(Blank) 2nd-phase
R774		In initialization 2nd-phase
R775		Initialization incompleteness 2nd-phase
R776		Reference position adjustment value parameter setting completed 2nd-phase
R780		Near reference position (per reference position) 2nd-phase
R781		Near reference position (per reference position) 2nd-phase
R782		Presetter contact 2nd-phase
R783		Presetter interlock 2nd-phase
R784		Area signal X axis on/off 2nd-phase
R785		Area signal Z axis on/off 2nd-phase
R786		Area signal X axis (-) on/off 2nd-phase
R787		Area signal Z axis (-) on/off 2nd-phase
R788		Takt time (ms) (L) 2nd-phase
R789		Takt time (ms) (H) 2nd-phase
R790		Takt time (min) (L) 2nd-phase
R791		Takt time (min) (H) 2nd-phase
R796		Load monitor status (1) 2nd-phase
R797		Load monitor status (2) 2nd-phase
R798		Load monitor status (3) 2nd-phase
R799		Load monitor status (4) 2nd-phase
R800		Load monitor status (5) 2nd-phase
R801		Load monitor status (6) 2nd-phase
R802		Load monitor status (7) 2nd-phase
R803		Load monitor status (8) 2nd-phase
R804		Load monitor status (9) 2nd-phase
R805		Load monitor status (10) 2nd-phase
R806		No. of work machining (current value) 2nd-phase
R807		No. of work machining (current value) 2nd-phase
R828		Tool life usage data 2nd-phase
R829		Tool life usage data 2nd-phase
R830		Number of registered tool life control tools 2nd-phase
R836		Circular feed in manual mode current position X 2nd-phase
R837		Circular feed in manual mode current position X 2nd-phase
R838		Circular feed in manual mode current position X 2nd-phase
R839		Circular feed in manual mode current position X 2nd-phase
R840		Circular feed in manual mode current position Y 2nd-phase
R841		Circular feed in manual mode current position Y 2nd-phase
R842		Circular feed in manual mode current position Y 2nd-phase
R843		Circular feed in manual mode current position Y 2nd-phase
R900		External search status 3rd-phase
R904		M code data 1 3rd-phase
R905		M code data 1 3rd-phase
R906		M code data 2 3rd-phase
R907		M code data 2 3rd-phase
R908		M code data 3 3rd-phase
R909		M code data 3 3rd-phase
R910		M code data 4 3rd-phase
R911		M code data 4 3rd-phase
R912		S code data 1 3rd-phase
R913		S code data 1 3rd-phase
R914		S code data 2 3rd-phase
R915		S code data 2 3rd-phase
R916		S code data 3 3rd-phase
R917		S code data 3 3rd-phase
R918		S code data 4 3rd-phase
R919		S code data 4 3rd-phase
R936		T code data 1 3rd-phase
R937		T code data 1 3rd-phase
R938		T code data 2 3rd-phase
R939		T code data 2 3rd-phase
R940		T code data 3 3rd-phase
R941		T code data 3 3rd-phase
R942		T code data 4 3rd-phase
R943		T code data 4 3rd-phase
R944		2nd M function data 1 3rd-phase
R945		2nd M function data 1 3rd-phase
R946		2nd M function data 2 3rd-phase
R947		2nd M function data 2 3rd-phase
R948		2nd M function data 3 3rd-phase
R949		2nd M function data 3 3rd-phase
R950		2nd M function data 4 3rd-phase
R951		2nd M function data 4 3rd-phase
R954		Chopping error No. 3rd-phase
R955		Manual measurement status 3rd-phase
R964		Load monitor warning axis 3rd-phase
R965		Load monitor alarm axis 3rd-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R966		Load monitor data alarm information 3rd-phase
R967		Group in tool life management 3rd-phase
R971		Adaptive control override 3rd-phase
R972		CNC completion standby status 3rd-phase
R973		(Blank) 3rd-phase
R974		In initialization 3rd-phase
R975		Initialization incompleteness 3rd-phase
R976		Reference position adjustment value parameter setting completed 3rd-phase
R980		Near reference position (per reference position) 3rd-phase
R981		Near reference position (per reference position) 3rd-phase
R982		Presetter contact 3rd-phase
R983		Presetter interlock 3rd-phase
R984		Area signal X axis on/off 3rd-phase
R985		Area signal Z axis on/off 3rd-phase
R986		Area signal X axis (-) on/off 3rd-phase
R987		Area signal Z axis (-) on/off 3rd-phase
R988		Takt time (ms) (L) 3rd-phase
R989		Takt time (ms) (H) 3rd-phase
R990		Takt time (min) (L) 3rd-phase
R991		Takt time (min) (H) 3rd-phase
R996		Load monitor status (1) 3rd-phase
R997		Load monitor status (2) 3rd-phase
R998		Load monitor status (3) 3rd-phase
R999		Load monitor status (4) 3rd-phase
R1000		Load monitor status (5) 3rd-phase
R1001		Load monitor status (6) 3rd-phase
R1002		Load monitor status (7) 3rd-phase
R1003		Load monitor status (8) 3rd-phase
R1004		Load monitor status (9) 3rd-phase
R1005		Load monitor status (10) 3rd-phase
R1006		No. of work machining (current value) 3rd-phase
R1007		No. of work machining (current value) 3rd-phase
R1028		Tool life usage data 3rd-phase
R1029		Tool life usage data 3rd-phase
R1030		Number of registered tool life control tools 3rd-phase
R1036		Circular feed in manual mode current position X 3rd-phase
R1037		Circular feed in manual mode current position X 3rd-phase
R1038		Circular feed in manual mode current position X 3rd-phase
R1039		Circular feed in manual mode current position X 3rd-phase
R1040		Circular feed in manual mode current position Y 3rd-phase
R1041		Circular feed in manual mode current position Y 3rd-phase
R1042		Circular feed in manual mode current position Y 3rd-phase
R1043		Circular feed in manual mode current position Y 3rd-phase
R1100		External search status 4th-phase
R1104		M code data 1 4th-phase
R1105		M code data 1 4th-phase
R1106		M code data 2 4th-phase
R1107		M code data 2 4th-phase
R1108		M code data 3 4th-phase
R1109		M code data 3 4th-phase
R1110		M code data 4 4th-phase
R1111		M code data 4 4th-phase
R1112		S code data 1 4th-phase
R1113		S code data 1 4th-phase
R1114		S code data 2 4th-phase
R1115		S code data 2 4th-phase
R1116		S code data 3 4th-phase
R1117		S code data 3 4th-phase
R1118		S code data 4 4th-phase
R1119		S code data 4 4th-phase
R1136		T code data 1 4th-phase
R1137		T code data 1 4th-phase
R1138		T code data 2 4th-phase
R1139		T code data 2 4th-phase
R1140		T code data 3 4th-phase
R1141		T code data 3 4th-phase
R1142		T code data 4 4th-phase
R1143		T code data 4 4th-phase
R1144		2nd M function data 1 4th-phase
R1145		2nd M function data 1 4th-phase
R1146		2nd M function data 2 4th-phase
R1147		2nd M function data 2 4th-phase
R1148		2nd M function data 3 4th-phase
R1149		2nd M function data 3 4th-phase
R1150		2nd M function data 4 4th-phase
R1151		2nd M function data 4 4th-phase
R1154		Chopping error No. 4th-phase
R1155		Manual measurement status 4th-phase
R1164		Load monitor warning axis 4th-phase
R1165		Load monitor alarm axis 4th-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R1166		Load monitor data alarm information 4th-phase
R1167		Group in tool life management 4th-phase
R1171		Adaptive control override 4th-phase
R1172		CNC completion standby status 4th-phase
R1173		(Blank) 4th-phase
R1174		In initialization 4th-phase
R1175		Initialization incompleteness 4th-phase
R1176		Reference position adjustment value parameter setting completed 4th-phase
R1180		Near reference position (per reference position) 4th-phase
R1181		Near reference position (per reference position) 4th-phase
R1182		Presetter contact 4th-phase
R1183		Presetter interlock 4th-phase
R1184		Area signal X axis on/off 4th-phase
R1185		Area signal Z axis on/off 4th-phase
R1186		Area signal X axis (-) on/off 4th-phase
R1187		Area signal Z axis (-) on/off 4th-phase
R1188		Takt time (ms) (L) 4th-phase
R1189		Takt time (ms) (H) 4th-phase
R1190		Takt time (min) (L) 4th-phase
R1191		Takt time (min) (H) 4th-phase
R1196		Load monitor status (1) 4th-phase
R1197		Load monitor status (2) 4th-phase
R1198		Load monitor status (3) 4th-phase
R1199		Load monitor status (4) 4th-phase
R1200		Load monitor status (5) 4th-phase
R1201		Load monitor status (6) 4th-phase
R1202		Load monitor status (7) 4th-phase
R1203		Load monitor status (8) 4th-phase
R1204		Load monitor status (9) 4th-phase
R1205		Load monitor status (10) 4th-phase
R1206		No. of work machining (current value) 4th-phase
R1207		No. of work machining (current value) 4th-phase
R1228		Tool life usage data 4th-phase
R1229		Tool life usage data 4th-phase
R1230		Number of registered tool life control tools 4th-phase
R1236		Circular feed in manual mode current position X 4th-phase
R1237		Circular feed in manual mode current position X 4th-phase
R1238		Circular feed in manual mode current position X 4th-phase
R1239		Circular feed in manual mode current position X 4th-phase
R1240		Circular feed in manual mode current position Y 4th-phase
R1241		Circular feed in manual mode current position Y 4th-phase
R1242		Circular feed in manual mode current position Y 4th-phase
R1243		Circular feed in manual mode current position Y 4th-phase
R2592		Reference position adjustment completion 1st-phase
R2618		Tool length measurement 2 Tool No. 1st-phase
R2619		Tool length measurement 2 Tool No. 1st-phase
R2625		Servo ready completion output designation 1st-phase
R2636		Circular feed in manual mode Operation mode data (L) 1st-phase
R2637		Circular feed in manual mode Operation mode data (H) 1st-phase
R2638		Circular feed in manual mode Part system designation 1st-phase
R2640		Circular feed in manual mode Horizontal axis designation 1st-phase
R2641		Circular feed in manual mode Vertical axis designation 1st-phase
R2644		Circular feed in manual mode Basic point X data (L) 1st-phase
R2645		Circular feed in manual mode Basic point X data (H) 1st-phase
R2648		Circular feed in manual mode Basic point Y data (L) 1st-phase
R2649		Circular feed in manual mode Basic point Y data (H) 1st-phase
R2652		Circular feed in manual mode Travel range X+ data (L) 1st-phase
R2653		Circular feed in manual mode Travel range X+ data (H) 1st-phase
R2656		Circular feed in manual mode Travel range X-data (L) 1st-phase
R2657		Circular feed in manual mode Travel range X-data (L) 1st-phase
R2660		Circular feed in manual mode Travel range Y+ data (L) 1st-phase
R2661		Circular feed in manual mode Travel range Y+ data (H) 1st-phase
R2664		Circular feed in manual mode Travel range Y- data (L) 1st-phase
R2665		Circular feed in manual mode Travel range Y- data (H) 1st-phase
R2668		Circular feed in manual mode Gradient/arc center X data (L) 1st-phase
R2669		Circular feed in manual mode Gradient/arc center X data (H) 1st-phase
R2672		Circular feed in manual mode Gradient/arc center Y data (L) 1st-phase
R2673		Circular feed in manual mode Gradient/arc center Y data (H) 1st-phase
R2792		Reference position adjustment completion 2nd-phase
R2818		Tool length measurement 2 tool No. 2nd-phase
R2819		Tool length measurement 2 tool No. 2nd-phase
R2825		Servo ready completion output designation 2nd-phase
R2836		Circular feed in manual mode Operation mode data (L) 2nd-phase
R2837		Circular feed in manual mode Operation mode data (H) 2nd-phase
R2838		Circular feed in manual mode Part system designation 2nd-phase
R2840		Circular feed in manual mode Horizontal axis designation 2nd-phase
R2841		Circular feed in manual mode Vertical axis designation 2nd-phase
R2844		Circular feed in manual mode Basic point X data (L) 2nd-phase
R2845		Circular feed in manual mode Basic point X data (H) 2nd-phase
R2848		Circular feed in manual mode Basic point Y data (L) 2nd-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R2849		Circular feed in manual mode Basic point Y data (H) 2nd-phase
R2852		Circular feed in manual mode Travel range X+ data (L) 2nd-phase
R2853		Circular feed in manual mode Travel range X+ data (H) 2nd-phase
R2856		Circular feed in manual mode Travel range X-data (L) 2nd-phase
R2857		Circular feed in manual mode Travel range X-data (L) 2nd-phase
R2860		Circular feed in manual mode Travel range Y+ data (L) 2nd-phase
R2861		Circular feed in manual mode Travel range Y+ data (H) 2nd-phase
R2864		Circular feed in manual mode Travel range Y- data (L) 2nd-phase
R2865		Circular feed in manual mode Travel range Y- data (H) 2nd-phase
R2868		Circular feed in manual mode Gradient/arc center X data (L) 2nd-phase
R2869		Circular feed in manual mode Gradient/arc center X data (H) 2nd-phase
R2872		Circular feed in manual mode Gradient/arc center Y data (L) 2nd-phase
R2873		Circular feed in manual mode Gradient/arc center Y data (H) 2nd-phase
R2992		Reference position adjustment completion 3rd-phase
R3018		Tool length measurement 2 Tool No. 3rd-phase
R3019		Tool length measurement 2 Tool No. 3rd-phase
R3025		Servo ready completion output designation 3rd-phase
R3036		Circular feed in manual mode Operation mode data (L) 3rd-phase
R3037		Circular feed in manual mode Operation mode data (H) 3rd-phase
R3038		Circular feed in manual mode Part system designation 3rd-phase
R3040		Circular feed in manual mode Horizontal axis designation 3rd-phase
R3041		Circular feed in manual mode Vertical axis designation 3rd-phase
R3044		Circular feed in manual mode Basic point X data (L) 3rd-phase
R3045		Circular feed in manual mode Basic point X data (H) 3rd-phase
R3048		Circular feed in manual mode Basic point Y data (L) 3rd-phase
R3049		Circular feed in manual mode Basic point Y data (H) 3rd-phase
R3052		Circular feed in manual mode Travel range X+ data (L) 3rd-phase
R3053		Circular feed in manual mode Travel range X+ data (H) 3rd-phase
R3056		Circular feed in manual mode Travel range X-data (L) 3rd-phase
R3057		Circular feed in manual mode Travel range X-data (L) 3rd-phase
R3060		Circular feed in manual mode Travel range Y+ data (L) 3rd-phase
R3061		Circular feed in manual mode Travel range Y+ data (H) 3rd-phase
R3064		Circular feed in manual mode Travel range Y- data (L) 3rd-phase
R3065		Circular feed in manual mode Travel range Y- data (H) 3rd-phase
R3068		Circular feed in manual mode Gradient/arc center X data (L) 3rd-phase
R3069		Circular feed in manual mode Gradient/arc center X data (H) 3rd-phase
R3072		Circular feed in manual mode Gradient/arc center Y data (L) 3rd-phase
R3073		Circular feed in manual mode Gradient/arc center Y data (H) 3rd-phase
R3192		Reference position adjustment completion 4th-phase
R3218		Tool length measurement 2 Tool No. 4th-phase
R3219		Tool length measurement 2 Tool No. 4th-phase
R3225		Servo ready completion output designation 4th-phase
R3236		Circular feed in manual mode Operation mode data (L) 4th-phase
R3237		Circular feed in manual mode Operation mode data (H) 4th-phase
R3238		Circular feed in manual mode Part system designation 4th-phase
R3240		Circular feed in manual mode Horizontal axis designation 4th-phase
R3241		Circular feed in manual mode Vertical axis designation 4th-phase
R3244		Circular feed in manual mode Basic point X data (L) 4th-phase
R3245		Circular feed in manual mode Basic point X data (H) 4th-phase
R3248		Circular feed in manual mode Basic point Y data (L) 4th-phase
R3249		Circular feed in manual mode Basic point Y data (H) 4th-phase
R3252		Circular feed in manual mode Travel range X+ data (L) 4th-phase
R3253		Circular feed in manual mode Travel range X+ data (H) 4th-phase
R3256		Circular feed in manual mode Travel range X-data (L) 4th-phase
R3257		Circular feed in manual mode Travel range X-data (L) 4th-phase
R3260		Circular feed in manual mode Travel range Y+ data (L) 4th-phase
R3261		Circular feed in manual mode Travel range Y+ data (H) 4th-phase
R3264		Circular feed in manual mode Travel range Y- data (L) 4th-phase
R3265		Circular feed in manual mode Travel range Y- data (H) 4th-phase
R3268		Circular feed in manual mode Gradient/arc center X data (L) 4th-phase
R3269		Circular feed in manual mode Gradient/arc center X data (H) 4th-phase
R3272		Circular feed in manual mode Gradient/arc center Y data (L) 4th-phase
R3273		Circular feed in manual mode Gradient/arc center Y data (H) 4th-phase
R4500		Machine position 1st axis 1st-phase
R4501		Machine position 1st axis 1st-phase
R4504		Machine position 2nd axis 1st-phase
R4505		Machine position 2nd axis 1st-phase
R4508		Machine position 3rd axis 1st-phase
R4509		Machine position 3rd axis 1st-phase
R4512		Machine position 4th axis 1st-phase
R4513		Machine position 4th axis 1st-phase
R4516		Machine position 5th axis 1st-phase
R4517		Machine position 5th axis 1st-phase
R4520		Machine position 6th axis 1st-phase
R4521		Machine position 6th axis 1st-phase
R4524		Machine position 7th axis 1st-phase
R4525		Machine position 7th axis 1st-phase
R4528		Machine position 8th axis 1st-phase
R4529		Machine position 8th axis 1st-phase
R4532		Machine position 1st axis 2nd-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R4533		Machine position 1st axis 2nd-phase
R4536		Machine position 2nd axis 2nd-phase
R4537		Machine position 2nd axis 2nd-phase
R4540		Machine position 3rd axis 2nd-phase
R4541		Machine position 3rd axis 2nd-phase
R4544		Machine position 4th axis 2nd-phase
R4545		Machine position 4th axis 2nd-phase
R4548		Machine position 5th axis 2nd-phase
R4549		Machine position 5th axis 2nd-phase
R4552		Machine position 6th axis 2nd-phase
R4553		Machine position 6th axis 2nd-phase
R4556		Machine position 7th axis 2nd-phase
R4557		Machine position 7th axis 2nd-phase
R4560		Machine position 8th axis 2nd-phase
R4561		Machine position 8th axis 2nd-phase
R4564		Machine position 1st axis 3rd-phase
R4565		Machine position 1st axis 3rd-phase
R4568		Machine position 2nd axis 3rd-phase
R4569		Machine position 2nd axis 3rd-phase
R4572		Machine position 3rd axis 3rd-phase
R4573		Machine position 3rd axis 3rd-phase
R4576		Machine position 4th axis 3rd-phase
R4577		Machine position 4th axis 3rd-phase
R4580		Machine position 5th axis 3rd-phase
R4581		Machine position 5th axis 3rd-phase
R4584		Machine position 6th axis 3rd-phase
R4585		Machine position 6th axis 3rd-phase
R4588		Machine position 7th axis 3rd-phase
R4589		Machine position 7th axis 3rd-phase
R4592		Machine position 8th axis 3rd-phase
R4593		Machine position 8th axis 3rd-phase
R4596		Machine position 1st axis 4th-phase
R4597		Machine position 1st axis 4th-phase
R4600		Machine position 2nd axis 4th-phase
R4601		Machine position 2nd axis 4th-phase
R4604		Machine position 3rd axis 4th-phase
R4605		Machine position 3rd axis 4th-phase
R4608		Machine position 4th axis 4th-phase
R4609		Machine position 4th axis 4th-phase
R4612		Machine position 5th axis 4th-phase
R4613		Machine position 5th axis 4th-phase
R4616		Machine position 6th axis 4th-phase
R4617		Machine position 6th axis 4th-phase
R4620		Machine position 7th axis 4th-phase
R4621		Machine position 7th axis 4th-phase
R4624		Machine position 8th axis 4th-phase
R4625		Machine position 8th axis 4th-phase
R4628		Feedback machine position 1st axis 1st-phase
R4629		Feedback machine position 1st axis 1st-phase
R4632		Feedback machine position 2nd axis 1st-phase
R4633		Feedback machine position 2nd axis 1st-phase
R4636		Feedback machine position 3rd axis 1st-phase
R4637		Feedback machine position 3rd axis 1st-phase
R4640		Feedback machine position 4th axis 1st-phase
R4641		Feedback machine position 4th axis 1st-phase
R4644		Feedback machine position 5th axis 1st-phase
R4645		Feedback machine position 5th axis 1st-phase
R4648		Feedback machine position 6th axis 1st-phase
R4649		Feedback machine position 6th axis 1st-phase
R4652		Feedback machine position 7th axis 1st-phase
R4653		Feedback machine position 7th axis 1st-phase
R4656		Feedback machine position 8th axis 1st-phase
R4657		Feedback machine position 8th axis 1st-phase
R4660		Feedback machine position 1st axis 2nd-phase
R4661		Feedback machine position 1st axis 2nd-phase
R4664		Feedback machine position 2nd axis 2nd-phase
R4665		Feedback machine position 2nd axis 2nd-phase
R4668		Feedback machine position 3rd axis 2nd-phase
R4669		Feedback machine position 3rd axis 2nd-phase
R4672		Feedback machine position 4th axis 2nd-phase
R4673		Feedback machine position 4th axis 2nd-phase
R4676		Feedback machine position 5th axis 2nd-phase
R4677		Feedback machine position 5th axis 2nd-phase
R4680		Feedback machine position 6th axis 2nd-phase
R4681		Feedback machine position 6th axis 2nd-phase
R4684		Feedback machine position 7th axis 2nd-phase
R4685		Feedback machine position 7th axis 2nd-phase
R4688		Feedback machine position 8th axis 2nd-phase
R4689		Feedback machine position 8th axis 2nd-phase
R4692		Feedback machine position 1st axis 3rd-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R4693		Feedback machine position 1st axis 3rd-phase
R4696		Feedback machine position 2nd axis 3rd-phase
R4697		Feedback machine position 2nd axis 3rd-phase
R4700		Feedback machine position 3rd axis 3rd-phase
R4701		Feedback machine position 3rd axis 3rd-phase
R4704		Feedback machine position 4th axis 3rd-phase
R4705		Feedback machine position 4th axis 3rd-phase
R4708		Feedback machine position 5th axis 3rd-phase
R4709		Feedback machine position 5th axis 3rd-phase
R4712		Feedback machine position 6th axis 3rd-phase
R4713		Feedback machine position 6th axis 3rd-phase
R4716		Feedback machine position 7th axis 3rd-phase
R4717		Feedback machine position 7th axis 3rd-phase
R4720		Feedback machine position 8th axis 3rd-phase
R4721		Feedback machine position 8th axis 3rd-phase
R4724		Feedback machine position 1st axis 4th-phase
R4725		Feedback machine position 1st axis 4th-phase
R4728		Feedback machine position 2nd axis 4th-phase
R4729		Feedback machine position 2nd axis 4th-phase
R4732		Feedback machine position 3rd axis 4th-phase
R4733		Feedback machine position 3rd axis 4th-phase
R4736		Feedback machine position 4th axis 4th-phase
R4737		Feedback machine position 4th axis 4th-phase
R4740		Feedback machine position 5th axis 4th-phase
R4741		Feedback machine position 5th axis 4th-phase
R4744		Feedback machine position 6th axis 4th-phase
R4745		Feedback machine position 6th axis 4th-phase
R4748		Feedback machine position 7th axis 4th-phase
R4749		Feedback machine position 7th axis 4th-phase
R4752		Feedback machine position 8th axis 4th-phase
R4753		Feedback machine position 8th axis 4th-phase
R4756		Servo deflection amount 1st axis 1st-phase
R4757		Servo deflection amount 1st axis 1st-phase
R4758		Servo deflection amount 2nd axis 1st-phase
R4759		Servo deflection amount 2nd axis 1st-phase
R4760		Servo deflection amount 3rd axis 1st-phase
R4761		Servo deflection amount 3rd axis 1st-phase
R4762		Servo deflection amount 4th axis 1st-phase
R4763		Servo deflection amount 4th axis 1st-phase
R4764		Servo deflection amount 5th axis 1st-phase
R4765		Servo deflection amount 5th axis 1st-phase
R4766		Servo deflection amount 6th axis 1st-phase
R4767		Servo deflection amount 6th axis 1st-phase
R4768		Servo deflection amount 7th axis 1st-phase
R4769		Servo deflection amount 7th axis 1st-phase
R4770		Servo deflection amount 8th axis 1st-phase
R4771		Servo deflection amount 8th axis 1st-phase
R4772		Servo deflection amount 1st axis 2nd-phase
R4773		Servo deflection amount 1st axis 2nd-phase
R4774		Servo deflection amount 2nd axis 2nd-phase
R4775		Servo deflection amount 2nd axis 2nd-phase
R4776		Servo deflection amount 3rd axis 2nd-phase
R4777		Servo deflection amount 3rd axis 2nd-phase
R4778		Servo deflection amount 4th axis 2nd-phase
R4779		Servo deflection amount 4th axis 2nd-phase
R4780		Servo deflection amount 5th axis 2nd-phase
R4781		Servo deflection amount 5th axis 2nd-phase
R4782		Servo deflection amount 6th axis 2nd-phase
R4783		Servo deflection amount 6th axis 2nd-phase
R4784		Servo deflection amount 7th axis 2nd-phase
R4785		Servo deflection amount 7th axis 2nd-phase
R4786		Servo deflection amount 8th axis 2nd-phase
R4787		Servo deflection amount 8th axis 2nd-phase
R4788		Servo deflection amount 1st axis 3rd-phase
R4789		Servo deflection amount 1st axis 3rd-phase
R4790		Servo deflection amount 2nd axis 3rd-phase
R4791		Servo deflection amount 2nd axis 3rd-phase
R4792		Servo deflection amount 3rd axis 3rd-phase
R4793		Servo deflection amount 3rd axis 3rd-phase
R4794		Servo deflection amount 4th axis 3rd-phase
R4795		Servo deflection amount 4th axis 3rd-phase
R4796		Servo deflection amount 5th axis 3rd-phase
R4797		Servo deflection amount 5th axis 3rd-phase
R4798		Servo deflection amount 6th axis 3rd-phase
R4799		Servo deflection amount 6th axis 3rd-phase
R4800		Servo deflection amount 7th axis 3rd-phase
R4801		Servo deflection amount 7th axis 3rd-phase
R4802		Servo deflection amount 8th axis 3rd-phase
R4803		Servo deflection amount 8th axis 3rd-phase
R4804		Servo deflection amount 1st axis 4th-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R4805		Servo deflection amount 1st axis 4th-phase
R4806		Servo deflection amount 2nd axis 4th-phase
R4807		Servo deflection amount 2nd axis 4th-phase
R4808		Servo deflection amount 3rd axis 4th-phase
R4809		Servo deflection amount 3rd axis 4th-phase
R4810		Servo deflection amount 4th axis 4th-phase
R4811		Servo deflection amount 4th axis 4th-phase
R4812		Servo deflection amount 5th axis 4th-phase
R4813		Servo deflection amount 5th axis 4th-phase
R4814		Servo deflection amount 6th axis 4th-phase
R4815		Servo deflection amount 6th axis 4th-phase
R4816		Servo deflection amount 7th axis 4th-phase
R4817		Servo deflection amount 7th axis 4th-phase
R4818		Servo deflection amount 8th axis 4th-phase
R4819		Servo deflection amount 8th axis 4th-phase
R4820		Motor rotation speed 1st axis 1st-phase
R4821		Motor rotation speed 1st axis 1st-phase
R4822		Motor rotation speed 2nd axis 1st-phase
R4823		Motor rotation speed 2nd axis 1st-phase
R4824		Motor rotation speed 3rd axis 1st-phase
R4825		Motor rotation speed 3rd axis 1st-phase
R4826		Motor rotation speed 4th axis 1st-phase
R4827		Motor rotation speed 4th axis 1st-phase
R4828		Motor rotation speed 5th axis 1st-phase
R4829		Motor rotation speed 5th axis 1st-phase
R4830		Motor rotation speed 6th axis 1st-phase
R4831		Motor rotation speed 6th axis 1st-phase
R4832		Motor rotation speed 7th axis 1st-phase
R4833		Motor rotation speed 7th axis 1st-phase
R4834		Motor rotation speed 8th axis 1st-phase
R4835		Motor rotation speed 8th axis 1st-phase
R4836		Motor rotation speed 1st axis 2nd-phase
R4837		Motor rotation speed 1st axis 2nd-phase
R4838		Motor rotation speed 2nd axis 2nd-phase
R4839		Motor rotation speed 2nd axis 2nd-phase
R4840		Motor rotation speed 3rd axis 2nd-phase
R4841		Motor rotation speed 3rd axis 2nd-phase
R4842		Motor rotation speed 4th axis 2nd-phase
R4843		Motor rotation speed 4th axis 2nd-phase
R4844		Motor rotation speed 5th axis 2nd-phase
R4845		Motor rotation speed 5th axis 2nd-phase
R4846		Motor rotation speed 6th axis 2nd-phase
R4847		Motor rotation speed 6th axis 2nd-phase
R4848		Motor rotation speed 7th axis 2nd-phase
R4849		Motor rotation speed 7th axis 2nd-phase
R4850		Motor rotation speed 8th axis 2nd-phase
R4851		Motor rotation speed 8th axis 2nd-phase
R4852		Motor rotation speed 1st axis 3rd-phase
R4853		Motor rotation speed 1st axis 3rd-phase
R4854		Motor rotation speed 2nd axis 3rd-phase
R4855		Motor rotation speed 2nd axis 3rd-phase
R4856		Motor rotation speed 3rd axis 3rd-phase
R4857		Motor rotation speed 3rd axis 3rd-phase
R4858		Motor rotation speed 4th axis 3rd-phase
R4859		Motor rotation speed 4th axis 3rd-phase
R4860		Motor rotation speed 5th axis 3rd-phase
R4861		Motor rotation speed 5th axis 3rd-phase
R4862		Motor rotation speed 6th axis 3rd-phase
R4863		Motor rotation speed 6th axis 3rd-phase
R4864		Motor rotation speed 7th axis 3rd-phase
R4865		Motor rotation speed 7th axis 3rd-phase
R4866		Motor rotation speed 8th axis 3rd-phase
R4867		Motor rotation speed 8th axis 3rd-phase
R4868		Motor rotation speed 1st axis 4th-phase
R4869		Motor rotation speed 1st axis 4th-phase
R4870		Motor rotation speed 2nd axis 4th-phase
R4871		Motor rotation speed 2nd axis 4th-phase
R4872		Motor rotation speed 3rd axis 4th-phase
R4873		Motor rotation speed 3rd axis 4th-phase
R4874		Motor rotation speed 4th axis 4th-phase
R4875		Motor rotation speed 4th axis 4th-phase
R4876		Motor rotation speed 5th axis 4th-phase
R4877		Motor rotation speed 5th axis 4th-phase
R4878		Motor rotation speed 6th axis 4th-phase
R4879		Motor rotation speed 6th axis 4th-phase
R4880		Motor rotation speed 7th axis 4th-phase
R4881		Motor rotation speed 7th axis 4th-phase
R4882		Motor rotation speed 8th axis 4th-phase
R4883		Motor rotation speed 8th axis 4th-phase
R4884		Motor load current 1st axis 1st-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R4885		Motor load current 1st axis 1st-phase
R4886		Motor load current 2nd axis 1st-phase
R4887		Motor load current 2nd axis 1st-phase
R4888		Motor load current 3rd axis 1st-phase
R4889		Motor load current 3rd axis 1st-phase
R4890		Motor load current 4th axis 1st-phase
R4891		Motor load current 4th axis 1st-phase
R4892		Motor load current 5th axis 1st-phase
R4893		Motor load current 5th axis 1st-phase
R4894		Motor load current 6th axis 1st-phase
R4895		Motor load current 6th axis 1st-phase
R4896		Motor load current 7th axis 1st-phase
R4897		Motor load current 7th axis 1st-phase
R4898		Motor load current 8th axis 1st-phase
R4899		Motor load current 8th axis 1st-phase
R4900		Motor load current 1st axis 2nd-phase
R4901		Motor load current 1st axis 2nd-phase
R4902		Motor load current 2nd axis 2nd-phase
R4903		Motor load current 2nd axis 2nd-phase
R4904		Motor load current 3rd axis 2nd-phase
R4905		Motor load current 3rd axis 2nd-phase
R4906		Motor load current 4th axis 2nd-phase
R4907		Motor load current 4th axis 2nd-phase
R4908		Motor load current 5th axis 2nd-phase
R4909		Motor load current 5th axis 2nd-phase
R4910		Motor load current 6th axis 2nd-phase
R4911		Motor load current 6th axis 2nd-phase
R4912		Motor load current 7th axis 2nd-phase
R4913		Motor load current 7th axis 2nd-phase
R4914		Motor load current 8th axis 2nd-phase
R4915		Motor load current 8th axis 2nd-phase
R4916		Motor load current 1st axis 3rd-phase
R4917		Motor load current 1st axis 3rd-phase
R4918		Motor load current 2nd axis 3rd-phase
R4919		Motor load current 2nd axis 3rd-phase
R4920		Motor load current 3rd axis 3rd-phase
R4921		Motor load current 3rd axis 3rd-phase
R4922		Motor load current 4th axis 3rd-phase
R4923		Motor load current 4th axis 3rd-phase
R4924		Motor load current 5th axis 3rd-phase
R4925		Motor load current 5th axis 3rd-phase
R4926		Motor load current 6th axis 3rd-phase
R4927		Motor load current 6th axis 3rd-phase
R4928		Motor load current 7th axis 3rd-phase
R4929		Motor load current 7th axis 3rd-phase
R4930		Motor load current 8th axis 3rd-phase
R4931		Motor load current 8th axis 3rd-phase
R4932		Motor load current 1st axis 4th-phase
R4933		Motor load current 1st axis 4th-phase
R4934		Motor load current 2nd axis 4th-phase
R4935		Motor load current 2nd axis 4th-phase
R4936		Motor load current 3rd axis 4th-phase
R4937		Motor load current 3rd axis 4th-phase
R4938		Motor load current 4th axis 4th-phase
R4939		Motor load current 4th axis 4th-phase
R4940		Motor load current 5th axis 4th-phase
R4941		Motor load current 5th axis 4th-phase
R4942		Motor load current 6th axis 4th-phase
R4943		Motor load current 6th axis 4th-phase
R4944		Motor load current 7th axis 4th-phase
R4945		Motor load current 7th axis 4th-phase
R4946		Motor load current 8th axis 4th-phase
R4947		Motor load current 8th axis 4th-phase
R4948		Skip coordinate position 1st axis 1st-phase
R4949		Skip coordinate position 1st axis 1st-phase
R4952		Skip coordinate position 2nd axis 1st-phase
R4953		Skip coordinate position 2nd axis 1st-phase
R4956		Skip coordinate position 3rd axis 1st-phase
R4957		Skip coordinate position 3rd axis 1st-phase
R4960		Skip coordinate position 4th axis 1st-phase
R4961		Skip coordinate position 4th axis 1st-phase
R4964		Skip coordinate position 5th axis 1st-phase
R4965		Skip coordinate position 5th axis 1st-phase
R4968		Skip coordinate position 6th axis 1st-phase
R4969		Skip coordinate position 6th axis 1st-phase
R4972		Skip coordinate position 7th axis 1st-phase
R4973		Skip coordinate position 7th axis 1st-phase
R4976		Skip coordinate position 8th axis 1st-phase
R4977		Skip coordinate position 8th axis 1st-phase
R4980		Skip coordinate position 1st axis 2nd-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R4981		Skip coordinate position 1st axis 2nd-phase
R4984		Skip coordinate position 2nd axis 2nd-phase
R4985		Skip coordinate position 2nd axis 2nd-phase
R4988		Skip coordinate position 3rd axis 2nd-phase
R4989		Skip coordinate position 3rd axis 2nd-phase
R4992		Skip coordinate position 4th axis 2nd-phase
R4993		Skip coordinate position 4th axis 2nd-phase
R4996		Skip coordinate position 5th axis 2nd-phase
R4997		Skip coordinate position 5th axis 2nd-phase
R5000		Skip coordinate position 6th axis 2nd-phase
R5001		Skip coordinate position 6th axis 2nd-phase
R5004		Skip coordinate position 7th axis 2nd-phase
R5005		Skip coordinate position 7th axis 2nd-phase
R5008		Skip coordinate position 8th axis 2nd-phase
R5009		Skip coordinate position 8th axis 2nd-phase
R5012		Skip coordinate position 1st axis 3rd-phase
R5013		Skip coordinate position 1st axis 3rd-phase
R5016		Skip coordinate position 2nd axis 3rd-phase
R5017		Skip coordinate position 2nd axis 3rd-phase
R5020		Skip coordinate position 3rd axis 3rd-phase
R5021		Skip coordinate position 3rd axis 3rd-phase
R5024		Skip coordinate position 4th axis 3rd-phase
R5025		Skip coordinate position 4th axis 3rd-phase
R5028		Skip coordinate position 5th axis 3rd-phase
R5029		Skip coordinate position 5th axis 3rd-phase
R5032		Skip coordinate position 6th axis 3rd-phase
R5033		Skip coordinate position 6th axis 3rd-phase
R5036		Skip coordinate position 7th axis 3rd-phase
R5037		Skip coordinate position 7th axis 3rd-phase
R5040		Skip coordinate position 8th axis 3rd-phase
R5041		Skip coordinate position 8th axis 3rd-phase
R5044		Skip coordinate position 1st axis 4th-phase
R5045		Skip coordinate position 1st axis 4th-phase
R5048		Skip coordinate position 2nd axis 4th-phase
R5049		Skip coordinate position 2nd axis 4th-phase
R5052		Skip coordinate position 3rd axis 4th-phase
R5053		Skip coordinate position 3rd axis 4th-phase
R5056		Skip coordinate position 4th axis 4th-phase
R5057		Skip coordinate position 4th axis 4th-phase
R5060		Skip coordinate position 5th axis 4th-phase
R5061		Skip coordinate position 5th axis 4th-phase
R5064		Skip coordinate position 6th axis 4th-phase
R5065		Skip coordinate position 6th axis 4th-phase
R5068		Skip coordinate position 7th axis 4th-phase
R5069		Skip coordinate position 7th axis 4th-phase
R5072		Skip coordinate position 8th axis 4th-phase
R5073		Skip coordinate position 8th axis 4th-phase
R5076		Synchronous error amount 1st, 9th, 17th, 25th axis 1st-phase
R5077		Synchronous error amount 1st, 9th, 17th, 25th axis 1st-phase
R5078		Synchronous error amount 2nd, 10th, 18th, 26th axis 1st-phase
R5079		Synchronous error amount 2nd, 10th, 18th, 26th axis 1st-phase
R5080		Synchronous error amount 3rd, 11th, 19th, 27th axis 1st-phase
R5081		Synchronous error amount 3rd, 11th, 19th, 27th axis 1st-phase
R5082		Synchronous error amount 4th, 12th, 20th, 28th axis 1st-phase
R5083		Synchronous error amount 4th, 12th, 20th, 28th axis 1st-phase
R5084		Synchronous error amount 5th, 13th, 21st, 29th axis 1st-phase
R5085		Synchronous error amount 5th, 13th, 21st, 29th axis 1st-phase
R5086		Synchronous error amount 6th, 14th, 22nd, 30th axis 1st-phase
R5087		Synchronous error amount 6th, 14th, 22nd, 30th axis 1st-phase
R5088		Synchronous error amount 7th, 15th, 23rd, 31st axis 1st-phase
R5089		Synchronous error amount 7th, 15th, 23rd, 31st axis 1st-phase
R5090		Synchronous error amount 8th, 16th, 24th, 32nd axis 1st-phase
R5091		Synchronous error amount 8th, 16th, 24th, 32nd axis 1st-phase
R5092		Synchronous error amount 1st, 9th, 17th, 25th axis 2nd-phase
R5093		Synchronous error amount 1st, 9th, 17th, 25th axis 2nd-phase
R5094		Synchronous error amount 2nd, 10th, 18th, 26th axis 2nd-phase
R5095		Synchronous error amount 2nd, 10th, 18th, 26th axis 2nd-phase
R5096		Synchronous error amount 3rd, 11th, 19th, 27th axis 2nd-phase
R5097		Synchronous error amount 3rd, 11th, 19th, 27th axis 2nd-phase
R5098		Synchronous error amount 4th, 12th, 20th, 28th axis 2nd-phase
R5099		Synchronous error amount 4th, 12th, 20th, 28th axis 2nd-phase
R5100		Synchronous error amount 5th, 13th, 21st, 29th axis 2nd-phase
R5101		Synchronous error amount 5th, 13th, 21st, 29th axis 2nd-phase
R5102		Synchronous error amount 6th, 14th, 22nd, 30th axis 2nd-phase
R5103		Synchronous error amount 6th, 14th, 22nd, 30th axis 2nd-phase
R5104		Synchronous error amount 7th, 15th, 23rd, 31st axis 2nd-phase
R5105		Synchronous error amount 7th, 15th, 23rd, 31st axis 2nd-phase
R5106		Synchronous error amount 8th, 16th, 24th, 32nd axis 2nd-phase
R5107		Synchronous error amount 8th, 16th, 24th, 32nd axis 2nd-phase
R5108		Synchronous error amount 1st, 9th, 17th, 25th axis 3rd-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R6373		User macro output #1132(Controller -> PLC) 1st-phase
R6374		User macro output #1133(Controller -> PLC) 1st-phase
R6375		User macro output #1133(Controller -> PLC) 1st-phase
R6376		User macro output #1134(Controller -> PLC) 1st-phase
R6377		User macro output #1134(Controller -> PLC) 1st-phase
R6378		User macro output #1135(Controller -> PLC) 1st-phase
R6379		User macro output #1135(Controller -> PLC) 1st-phase
R6380		User macro output #1132(Controller -> PLC) 2nd-phase
R6381		User macro output #1132(Controller -> PLC) 2nd-phase
R6382		User macro output #1133(Controller -> PLC) 2nd-phase
R6383		User macro output #1133(Controller -> PLC) 2nd-phase
R6384		User macro output #1134(Controller -> PLC) 2nd-phase
R6385		User macro output #1134(Controller -> PLC) 2nd-phase
R6386		User macro output #1135(Controller -> PLC) 2nd-phase
R6387		User macro output #1135(Controller -> PLC) 2nd-phase
R6388		User macro output #1132(Controller -> PLC) 3rd-phase
R6389		User macro output #1132(Controller -> PLC) 3rd-phase
R6390		User macro output #1133(Controller -> PLC) 3rd-phase
R6391		User macro output #1133(Controller -> PLC) 3rd-phase
R6392		User macro output #1134(Controller -> PLC) 3rd-phase
R6393		User macro output #1134(Controller -> PLC) 3rd-phase
R6394		User macro output #1135(Controller -> PLC) 3rd-phase
R6395		User macro output #1135(Controller -> PLC) 3rd-phase
R6396		User macro output #1132(Controller -> PLC) 4th-phase
R6397		User macro output #1132(Controller -> PLC) 4th-phase
R6398		User macro output #1133(Controller -> PLC) 4th-phase
R6399		User macro output #1133(Controller -> PLC) 4th-phase
R6400		User macro output #1134(Controller -> PLC) 4th-phase
R6401		User macro output #1134(Controller -> PLC) 4th-phase
R6402		User macro output #1135(Controller -> PLC) 4th-phase
R6403		User macro output #1135(Controller -> PLC) 4th-phase
R6500		Spindle command rotation speed input 1st-Spindle
R6501		Spindle command rotation speed input 1st-Spindle
R6502		Spindle command final data (Rotation speed) 1st-Spindle
R6503		Spindle command final data (Rotation speed) 1st-Spindle
R6504		Spindle command final data (12-bit binary) 1st-Spindle
R6505		Spindle command final data (12-bit binary) 1st-Spindle
R6506		Spindle actual speed 1st-Spindle
R6507		Spindle actual speed 1st-Spindle
R6508		Spindle load 1st-Spindle
R6516		Spindle synchronization phase error / Hob axis delay angle 1st-Spindle
R6517		Spindle synchronization Maximum phase error / Maximum hob axis delay angle 1st-spindle
R6518		Spindle synchronization Phase offset data 1st-Spindle
R6519		Spindle synchronization Phase error monitor 1st-Spindle
R6520		Spindle synchronization Phase error monitor (lower limit) 1st-Spindle
R6521		Spindle synchronization Phase error monitor (upper limit) 1st-Spindle
R6522		Spindle synchronization phase error 1 1st-Spindle
R6523		Spindle synchronization phase error 2 1st-Spindle
R6532		Synchronous tapping Current error width (L) 1st-spindle
R6533		Synchronous tapping Current error width (H) 1st-spindle
R6534		Synchronous tapping Maximum error width (L) 1st-spindle
R6535		Synchronous tapping Maximum error width (H) 1st-spindle
R6536		Synchronous tapping Current error angle (L) 1st-spindle
R6537		Synchronous tapping Current error angle (H) 1st-spindle
R6538		Synchronous tapping Maximum error angle (L) 1st-spindle
R6539		Synchronous tapping Maximum error angle (H) 1st-spindle
R6550		Spindle command rotation speed input 2nd-Spindle
R6551		Spindle command rotation speed input 2nd-Spindle
R6552		Spindle command final data (Rotation speed) 2nd-Spindle
R6553		Spindle command final data (Rotation speed) 2nd-Spindle
R6554		Spindle command final data (12-bit binary) 2nd-Spindle
R6555		Spindle command final data (12-bit binary) 2nd-Spindle
R6556		Spindle actual speed 2nd-Spindle
R6557		Spindle actual speed 2nd-Spindle
R6558		Spindle load 2nd-Spindle
R6566		Spindle synchronization phase error / Hob axis delay angle 2nd-Spindle
R6567		Spindle synchronization Maximum phase error / Maximum hob axis delay angle 2nd-spindle
R6568		Spindle synchronization Phase offset data 2nd-Spindle
R6569		Spindle synchronization Phase error monitor 2nd-Spindle
R6570		Spindle synchronization Phase error monitor (lower limit) 2nd-Spindle
R6571		Spindle synchronization Phase error monitor (upper limit) 2nd-Spindle
R6572		Spindle synchronization phase error 1 2nd-Spindle
R6573		Spindle synchronization phase error 2 2nd-Spindle
R6582		Synchronous tapping Current error width (L) 2nd-spindle
R6583		Synchronous tapping Current error width (H) 2nd-spindle
R6584		Synchronous tapping Maximum error width (L) 2nd-spindle

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R6585		Synchronous tapping Maximum error width (H) 2nd-spindle
R6586		Synchronous tapping Current error angle (L) 2nd-spindle
R6587		Synchronous tapping Current error angle (H) 2nd-spindle
R6588		Synchronous tapping Maximum error angle (L) 2nd-spindle
R6589		Synchronous tapping Maximum error angle (H) 2nd-spindle
R6600		Spindle command rotation speed input 3rd-Spindle
R6601		Spindle command rotation speed input 3rd-Spindle
R6602		Spindle command final data (Rotation speed) 3rd-Spindle
R6603		Spindle command final data (Rotation speed) 3rd-Spindle
R6604		Spindle command final data (12-bit binary) 3rd-Spindle
R6605		Spindle command final data (12-bit binary) 3rd-Spindle
R6606		Spindle actual speed 3rd-Spindle
R6607		Spindle actual speed 3rd-Spindle
R6608		Spindle load 3rd-Spindle
R6616		Spindle synchronization phase error / Hob axis delay angle 3rd-Spindle
R6617		Spindle synchronization Maximum phase error / Maximum hob axis delay angle 3rd-spindle
R6618		Spindle synchronization Phase offset data 3rd-Spindle
R6619		Spindle synchronization Phase error monitor 3rd-Spindle
R6620		Spindle synchronization Phase error monitor (lower limit) 3rd-Spindle
R6621		Spindle synchronization Phase error monitor (upper limit) 3rd-Spindle
R6622		Spindle synchronization phase error 1 3rd-Spindle
R6623		Spindle synchronization phase error 2 3rd-Spindle
R6632		Synchronous tapping Current error width (L) 3rd-spindle
R6633		Synchronous tapping Current error width (H) 3rd-spindle
R6634		Synchronous tapping Maximum error width (L) 3rd-spindle
R6635		Synchronous tapping Maximum error width (H) 3rd-spindle
R6636		Synchronous tapping Current error angle (L) 3rd-spindle
R6637		Synchronous tapping Current error angle (H) 3rd-spindle
R6638		Synchronous tapping Maximum error angle (L) 3rd-spindle
R6639		Synchronous tapping Maximum error angle (H) 3rd-spindle
R6650		Spindle command rotation speed input 4th-Spindle
R6651		Spindle command rotation speed input 4th-Spindle
R6652		Spindle command final data (Rotation speed) 4th-Spindle
R6653		Spindle command final data (Rotation speed) 4th-Spindle
R6654		Spindle command final data (12-bit binary) 4th-Spindle
R6655		Spindle command final data (12-bit binary) 4th-Spindle
R6656		Spindle actual speed 4th-Spindle
R6657		Spindle actual speed 4th-Spindle
R6658		Spindle load 4th-Spindle
R6666		Spindle synchronization phase error / Hob axis delay angle 4th-Spindle
R6667		Spindle synchronization Maximum phase error / Maximum hob axis delay angle 4th-spindle
R6668		Spindle synchronization Phase offset data 4th-Spindle
R6669		Spindle synchronization Phase error monitor 4th-Spindle
R6670		Spindle synchronization Phase error monitor (lower limit) 4th-Spindle
R6671		Spindle synchronization Phase error monitor (upper limit) 4th-Spindle
R6672		Spindle synchronization phase error 1 4th-Spindle
R6673		Spindle synchronization phase error 2 4th-Spindle
R6682		Synchronous tapping Current error width (L) 4th-spindle
R6683		Synchronous tapping Current error width (H) 4th-spindle
R6684		Synchronous tapping Maximum error width (L) 4th-spindle
R6685		Synchronous tapping Maximum error width (H) 4th-spindle
R6686		Synchronous tapping Current error angle (L) 4th-spindle
R6687		Synchronous tapping Current error angle (H) 4th-spindle
R6688		Synchronous tapping Maximum error angle (L) 4th-spindle
R6689		Synchronous tapping Maximum error angle (H) 4th-spindle
R6700		Spindle command rotation speed input 5th-Spindle
R6701		Spindle command rotation speed input 5th-Spindle
R6702		Spindle command final data (Rotation speed) 5th-Spindle
R6703		Spindle command final data (Rotation speed) 5th-Spindle
R6704		Spindle command final data (12-bit binary) 5th-Spindle
R6705		Spindle command final data (12-bit binary) 5th-Spindle
R6706		Spindle actual speed 5th-Spindle
R6707		Spindle actual speed 5th-Spindle
R6708		Spindle load 5th-Spindle
R6716		Spindle synchronization phase error / Hob axis delay angle 5th-spindle
R6717		Spindle synchronization Maximum phase error / Maximum hob axis delay angle 5th-spindle
R6718		Spindle synchronization Phase offset data 5th-Spindle
R6719		Spindle synchronization Phase error monitor 5th-Spindle
R6720		Spindle synchronization Phase error monitor (lower limit) 5th-Spindle
R6721		Spindle synchronization Phase error monitor (upper limit) 5th-Spindle
R6722		Spindle synchronization phase error 1 5th-Spindle
R6723		Spindle synchronization phase error 2 5th-Spindle
R6732		Synchronous tapping Current error width (L) 5th-spindle
R6733		Synchronous tapping Current error width (H) 5th-spindle

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R6734		Synchronous tapping Maximum error width (L) 5th-spindle
R6735		Synchronous tapping Maximum error width (H) 5th-spindle
R6736		Synchronous tapping Current error angle (L) 5th-spindle
R6737		Synchronous tapping Current error angle (H) 5th-spindle
R6738		Synchronous tapping Maximum error angle (L) 5th-spindle
R6739		Synchronous tapping Maximum error angle (H) 5th-spindle
R6750		Spindle command rotation speed input 6th-Spindle
R6751		Spindle command rotation speed input 6th-Spindle
R6752		Spindle command final data (Rotation speed) 6th-Spindle
R6753		Spindle command final data (Rotation speed) 6th-Spindle
R6754		Spindle command final data (12-bit binary) 6th-Spindle
R6755		Spindle command final data (12-bit binary) 6th-Spindle
R6756		Spindle actual speed 6th-Spindle
R6757		Spindle actual speed 6th-Spindle
R6758		Spindle load 6th-Spindle
R6766		Spindle synchronization phase error / Hob axis delay angle 6th-spindle
R6767		Spindle synchronization Maximum phase error / Maximum hob axis delay angle 6th-spindle
R6768		Spindle synchronization Phase offset data 6th-Spindle
R6769		Spindle synchronization Phase error monitor 6th-Spindle
R6770		Spindle synchronization Phase error monitor (lower limit) 6th-Spindle
R6771		Spindle synchronization Phase error monitor (upper limit) 6th-Spindle
R6772		Spindle synchronization phase error 1 6th-Spindle
R6773		Spindle synchronization phase error 2 6th-Spindle
R6782		Synchronous tapping Current error width (L) 6th-spindle
R6783		Synchronous tapping Current error width (H) 6th-spindle
R6784		Synchronous tapping Maximum error width (L) 6th-spindle
R6785		Synchronous tapping Maximum error width (H) 6th-spindle
R6786		Synchronous tapping Current error angle (L) 6th-spindle
R6787		Synchronous tapping Current error angle (H) 6th-spindle
R6788		Synchronous tapping Maximum error angle (L) 6th-spindle
R6789		Synchronous tapping Maximum error angle (H) 6th-spindle
R9900		J2CT control status 4
R9901		J2CT control status 3
R9902		J2CT control status 2
R9903		J2CT control status 1
R9904		J2CT control Machine position (L) 1st axis
R9905		J2CT control Machine position (H) 1st axis
R9906		J2CT control status 4
R9907		J2CT control status 3
R9908		J2CT control status 2
R9909		J2CT control status 1
R9910		J2CT control Machine position (L) 2nd axis
R9911		J2CT control Machine position (H) 2nd axis
R9912		J2CT control status 4
R9913		J2CT control status 3
R9914		J2CT control status 2
R9915		J2CT control status 1
R9916		J2CT control Machine position (L) 3rd axis
R9917		J2CT control Machine position (H) 3rd axis
R9918		J2CT control status 4
R9919		J2CT control status 3
R9920		J2CT control status 2
R9921		J2CT control status 1
R9922		J2CT control Machine position (L) 4th axis
R9923		J2CT control Machine position (H) 4th axis
R9924		J2CT control status 4
R9925		J2CT control status 3
R9926		J2CT control status 2
R9927		J2CT control status 1
R9928		J2CT control Machine position (L) 5th axis
R9929		J2CT control Machine position (H) 5th axis
R9930		J2CT control status 4
R9931		J2CT control status 3
R9932		J2CT control status 2
R9933		J2CT control status 1
R9934		J2CT control Machine position (L) 6th axis
R9935		J2CT control Machine position (H) 6th axis
R9940		J2CT control Machine position (L) 7th axis
R9941		J2CT control Machine position (H) 7th axis
R9946		J2CT control Machine position (L) 8th axis
R9947		J2CT control Machine position (H) 8th axis
R9948		J2CT in operation adjustment mode
R10000		RIO1 No. of error occurrences 1st ch
R10001		RIO1 No. of error occurrences 2nd ch
R10002		RIO1 No. of error occurrences 3rd ch
R10003		RIO1 No. of error occurrences 4th ch
R10004		RIO1 No. of error occurrences 5th ch
R10005		RIO1 No. of error occurrences 6th ch

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R10006		RIO1 No. of error occurrences 7th ch
R10007		RIO1 No. of error occurrences 8th ch
R10008		RIO2 No. of error occurrences 1st ch
R10009		RIO2 No. of error occurrences 2nd ch
R10010		RIO2 No. of error occurrences 3rd ch
R10011		RIO2 No. of error occurrences 4th ch
R10012		RIO2 No. of error occurrences 5th ch
R10013		RIO2 No. of error occurrences 6th ch
R10014		RIO2 No. of error occurrences 7th ch
R10015		RIO2 No. of error occurrences 8th ch
R10016		RIO3 No. of error occurrences 1st ch
R10017		RIO3 No. of error occurrences 2nd ch
R10018		RIO3 No. of error occurrences 3rd ch
R10019		RIO3 No. of error occurrences 4th ch
R10020		RIO3 No. of error occurrences 5th ch
R10021		RIO3 No. of error occurrences 6th ch
R10022		RIO3 No. of error occurrences 7th ch
R10023		RIO3 No. of error occurrences 8th ch
R10064		Connection status of each channel RIO1,2
R10065		Connection status of each channel RIO3
R10068		CRC warning channel RIO1,2
R10069		CRC warning channel RIO3
R10600		ATC control parameter
R11806		Standby tool: cumulative usage time 1st-phase
R11807		Standby tool: cumulative usage time 1st-phase
R11808		Standby tool: service lifetime 1st-phase
R11809		Standby tool: service lifetime 1st-phase
R11810		Standby tool: cumulative usage count 1st-phase
R11811		Standby tool: service life count 1st-phase
R11812		Standby tool: cumulative usage wear amount 1st-phase
R11813		Standby tool: cumulative usage wear amount 1st-phase
R11814		Standby tool: service life wear amount 1st-phase
R11815		Standby tool: service life wear amount 1st-phase
R11820		Standby tool: length wear amount 1st-phase
R11821		Standby tool: length wear amount 1st-phase
R11822		Standby tool: radius wear amount 1st-phase
R11823		Standby tool: radius wear amount 1st-phase
R11830		Active tool: Cumulative usage time 1st-phase
R11831		Active tool: Cumulative usage time 1st-phase
R11832		Active tool: Service lifetime 1st-phase
R11833		Active tool: Service lifetime 1st-phase
R11834		Active tool: Cumulative usage count 1st-phase
R11835		Active tool: Cumulative usage wear amount 1st-phase
R11836		Active tool: Service life wear amount 1st-phase
R11837		Active tool: Service life wear amount 1st-phase
R11838		Active tool: Length compensation amount 1st-phase
R11839		Active tool: Length compensation amount 1st-phase
R11844		Active tool: Length wear amount 1st-phase
R11845		Active tool: Length wear amount 1st-phase
R11846		Active tool: Radius wear amount 1st-phase
R11847		Active tool: Radius wear amount 1st-phase
R11856		Standby tool: cumulative usage time 2nd-phase
R11857		Standby tool: cumulative usage time 2nd-phase
R11858		Standby tool: service lifetime 2nd-phase
R11859		Standby tool: service lifetime 2nd-phase
R11860		Standby tool: cumulative usage count 2nd-phase
R11861		Standby tool: service life count 2nd-phase
R11862		Standby tool: cumulative usage wear amount 2nd-phase
R11863		Standby tool: cumulative usage wear amount 2nd-phase
R11864		Standby tool: service life wear amount 2nd-phase
R11865		Standby tool: service life wear amount 2nd-phase
R11870		Standby tool: length wear amount 2nd-phase
R11871		Standby tool: length wear amount 2nd-phase
R11872		Standby tool: radius wear amount 2nd-phase
R11873		Standby tool: radius wear amount 2nd-phase
R11880		Active tool: Cumulative usage time 2nd-phase
R11881		Active tool: Cumulative usage time 2nd-phase
R11882		Active tool: Service lifetime 2nd-phase
R11883		Active tool: Service lifetime 2nd-phase
R11884		Active tool: Cumulative usage count 2nd-phase
R11885		Active tool: Cumulative usage wear amount 2nd-phase
R11886		Active tool: Service life wear amount 2nd-phase
R11887		Active tool: Service life wear amount 2nd-phase
R11888		Active tool: Length compensation amount 2nd-phase
R11889		Active tool: Length compensation amount 2nd-phase
R11894		Active tool: Length wear amount 2nd-phase
R11895		Active tool: Length wear amount 2nd-phase
R11896		Active tool: Radius wear amount 2nd-phase
R11897		Active tool: Radius wear amount 2nd-phase
R11906		Standby tool: cumulative usage time 3rd-phase

III PLC Devices
2. Data Type Input Signals (CNC->PLC)

Device	Abbrev.	Signal name
R11907		Standby tool: cumulative usage time 3rd-phase
R11908		Standby tool: service lifetime 3rd-phase
R11909		Standby tool: service lifetime 3rd-phase
R11910		Standby tool: cumulative usage count 3rd-phase
R11911		Standby tool: service life count 3rd-phase
R11912		Standby tool: cumulative usage wear amount 3rd-phase
R11913		Standby tool: cumulative usage wear amount 3rd-phase
R11914		Standby tool: service life wear amount 3rd-phase
R11915		Standby tool: service life wear amount 3rd-phase
R11920		Standby tool: length wear amount 3rd-phase
R11921		Standby tool: length wear amount 3rd-phase
R11922		Standby tool: radius wear amount 3rd-phase
R11923		Standby tool: radius wear amount 3rd-phase
R11930		Active tool: Cumulative usage time 3rd-phase
R11931		Active tool: Cumulative usage time 3rd-phase
R11932		Active tool: Service lifetime 3rd-phase
R11933		Active tool: Service lifetime 3rd-phase
R11934		Active tool: Cumulative usage count 3rd-phase
R11935		Active tool: Cumulative usage wear amount 3rd-phase
R11936		Active tool: Service life wear amount 3rd-phase
R11937		Active tool: Service life wear amount 3rd-phase
R11938		Active tool: Length compensation amount 3rd-phase
R11939		Active tool: Length compensation amount 3rd-phase
R11944		Active tool: Length wear amount 3rd-phase
R11945		Active tool: Length wear amount 3rd-phase
R11946		Active tool: Radius wear amount 3rd-phase
R11947		Active tool: Radius wear amount 3rd-phase
R11956		Standby tool: cumulative usage time 4th-phase
R11957		Standby tool: cumulative usage time 4th-phase
R11958		Standby tool: service lifetime 4th-phase
R11959		Standby tool: service lifetime 4th-phase
R11960		Standby tool: cumulative usage count 4th-phase
R11961		Standby tool: service life count 4th-phase
R11962		Standby tool: cumulative usage wear amount 4th-phase
R11963		Standby tool: cumulative usage wear amount 4th-phase
R11964		Standby tool: service life wear amount 4th-phase
R11965		Standby tool: service life wear amount 4th-phase
R11970		Standby tool: length wear amount 4th-phase
R11971		Standby tool: length wear amount 4th-phase
R11972		Standby tool: radius wear amount 4th-phase
R11973		Standby tool: radius wear amount 4th-phase
R11980		Active tool: Cumulative usage time 4th-phase
R11981		Active tool: Cumulative usage time 4th-phase
R11982		Active tool: Service lifetime 4th-phase
R11983		Active tool: Service lifetime 4th-phase
R11984		Active tool: Cumulative usage count 4th-phase
R11985		Active tool: Cumulative usage wear amount 4th-phase
R11986		Active tool: Service life wear amount 4th-phase
R11987		Active tool: Service life wear amount 4th-phase
R11988		Active tool: Length compensation amount 4th-phase
R11989		Active tool: Length compensation amount 4th-phase
R11994		Active tool: Length wear amount 4th-phase
R11995		Active tool: Length wear amount 4th-phase
R11996		Active tool: Radius wear amount 4th-phase
R11997		Active tool: Radius wear amount 4th-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y704	RHD1	Integration time input 1
Y705	RHD2	Integration time input 2
Y708	*KEY1	Data protect key 1
Y709	*KEY2	Data protect key 2
Y70A	*KEY3	Data protect key 3
Y70C	PDISP1	Program display during operation 1st-phase
Y70D		Handle pulse encoder communication connector priority
Y718	*PCD1	PLC axis near point detection 1
Y719	*PCD2	PLC axis near point detection 2
Y71A	*PCD3	PLC axis near point detection 3
Y71B	*PCD4	PLC axis near point detection 4
Y71C	*PCD5	PLC axis near point detection 5th axis
Y71D	*PCD6	PLC axis near point detection 6th axis
Y720	PCH1	PLC axis 1st handle valid
Y721	PCH2	PLC axis 2st handle valid
Y722	PCH3	PLC axis 3st handle valid
Y723	PABMI	PLC axis control buffering mode valid
Y728	CRTFN	CRT changeover completion
Y729	CSRON	Screen display request
Y72B		Collecting diagnosis data stop
Y72C	SMPTRG	NC data sampling trigger
Y72E		Pallet program registration In APC execution
Y72F		Ext. workpiece coordinate transfer ready
Y730	DISP1	Display changeover \$1
Y731	DISP2	Display changeover \$2
Y732	DISP3	Display changeover \$3
Y733	DISP4	Display changeover \$4
Y73F	CCHK	Interference check valid
Y740		Tool IC new read
Y741		Tool IC exchange read
Y742	MCT	Contactorf shutoff test signal
Y747		Turret interference check valid
Y748		PLC skip 1
Y749		PLC skip 2
Y74A		PLC skip 3
Y74B		PLC skip 4
Y74C		PLC skip 5
Y74D		PLC skip 6
Y74E		PLC skip 7
Y74F		PLC skip 8
Y75D		Automatic power OFF request
Y764		Encoder 1 arbitrary pulse selection
Y765		Encoder 2 arbitrary pulse selection
Y766		Encoder 1 arbitrary pulse valid
Y767		Encoder 2 arbitrary pulse valid
Y768	DOOR1	Door open I
Y76C		Remote program input start
Y76D		Tool ID data read
Y76E		Tool ID data write
Y76F		Tool ID data erase
Y770	PLCAE1	PLC axis control valid 1st axis
Y771	PLCAE2	PLC axis control valid 2nd axis
Y772	PLCAE3	PLC axis control valid 3rd axis
Y773	PLCAE4	PLC axis control valid 4th axis
Y774	PLCAE5	PLC axis control valid 5th axis
Y775	PLCAE6	PLC axis control valid 6th axis
Y780	DTCH11	Control axis detach 1st-axis 1st-phase
Y781	DTCH21	Control axis detach 2nd-axis 1st-phase
Y782	DTCH31	Control axis detach 3rd-axis 1st-phase
Y783	DTCH41	Control axis detach 4th-axis 1st-phase
Y784	DTCH51	Control axis detach 5th-axis 1st-phase
Y785	DTCH61	Control axis detach 6th-axis 1st-phase
Y786	DTCH71	Control axis detach 7th-axis 1st-phase
Y787	DTCH81	Control axis detach 8th-axis 1st-phase
Y788	DTCH12	Control axis detach 1st-axis 2nd-phase
Y789	DTCH22	Control axis detach 2nd-axis 2nd-phase
Y78A	DTCH32	Control axis detach 3rd-axis 2nd-phase
Y78B	DTCH42	Control axis detach 4th-axis 2nd-phase
Y78C	DTCH52	Control axis detach 5th-axis 2nd-phase
Y78D	DTCH62	Control axis detach 6th-axis 2nd-phase
Y78E	DTCH72	Control axis detach 7th-axis 2nd-phase
Y78F	DTCH82	Control axis detach 8th-axis 2nd-phase
Y790	DTCH13	Control axis detach 1st-axis 3rd-phase
Y791	DTCH23	Control axis detach 2nd-axis 3rd-phase
Y792	DTCH33	Control axis detach 3rd-axis 3rd-phase
Y793	DTCH43	Control axis detach 4th-axis 3rd-phase
Y794	DTCH53	Control axis detach 5th-axis 3rd-phase
Y795	DTCH63	Control axis detach 6th-axis 3rd-phase
Y796	DTCH73	Control axis detach 7th-axis 3rd-phase
Y797	DTCH83	Control axis detach 8th-axis 3rd-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y798	DTCH14	Control axis detach 1st-axis 4th-phase
Y799	DTCH24	Control axis detach 2nd-axis 4th-phase
Y79A	DTCH34	Control axis detach 3rd-axis 4th-phase
Y79B	DTCH44	Control axis detach 4th-axis 4th-phase
Y79C	DTCH54	Control axis detach 5th-axis 4th-phase
Y79D	DTCH64	Control axis detach 6th-axis 4th-phase
Y79E	DTCH74	Control axis detach 7th-axis 4th-phase
Y79F	DTCH84	Control axis detach 8th-axis 4th-phase
Y7A0	*SVF11	Servo OFF 1st-axis 1st-phase
Y7A1	*SVF21	Servo OFF 2nd-axis 1st-phase
Y7A2	*SVF31	Servo OFF 3rd-axis 1st-phase
Y7A3	*SVF41	Servo OFF 4th-axis 1st-phase
Y7A4	*SVF51	Servo OFF 5th-axis 1st-phase
Y7A5	*SVF61	Servo OFF 6th-axis 1st-phase
Y7A6	*SVF71	Servo OFF 7th-axis 1st-phase
Y7A7	*SVF81	Servo OFF 8th-axis 1st-phase
Y7A8	*SVF12	Servo OFF 1st-axis 2nd-phase
Y7A9	*SVF22	Servo OFF 2nd-axis 2nd-phase
Y7AA	*SVF32	Servo OFF 3rd-axis 2nd-phase
Y7AB	*SVF42	Servo OFF 4th-axis 2nd-phase
Y7AC	*SVF52	Servo OFF 5th-axis 2nd-phase
Y7AD	*SVF62	Servo OFF 6th-axis 2nd-phase
Y7AE	*SVF72	Servo OFF 7th-axis 2nd-phase
Y7AF	*SVF82	Servo OFF 8th-axis 2nd-phase
Y7B0	*SVF13	Servo OFF 1st-axis 3rd-phase
Y7B1	*SVF23	Servo OFF 2nd-axis 3rd-phase
Y7B2	*SVF33	Servo OFF 3rd-axis 3rd-phase
Y7B3	*SVF43	Servo OFF 4th-axis 3rd-phase
Y7B4	*SVF53	Servo OFF 5th-axis 3rd-phase
Y7B5	*SVF63	Servo OFF 6th-axis 3rd-phase
Y7B6	*SVF73	Servo OFF 7th-axis 3rd-phase
Y7B7	*SVF83	Servo OFF 8th-axis 3rd-phase
Y7B8	*SVF14	Servo OFF 1st-axis 4th-phase
Y7B9	*SVF24	Servo OFF 2nd-axis 4th-phase
Y7BA	*SVF34	Servo OFF 3rd-axis 4th-phase
Y7BB	*SVF44	Servo OFF 4th-axis 4th-phase
Y7BC	*SVF54	Servo OFF 5th-axis 4th-phase
Y7BD	*SVF64	Servo OFF 6th-axis 4th-phase
Y7BE	*SVF74	Servo OFF 7th-axis 4th-phase
Y7BF	*SVF84	Servo OFF 8th-axis 4th-phase
Y7C0	MI11	Mirror image 1st-axis 1st-phase
Y7C1	MI21	Mirror image 2nd-axis 1st-phase
Y7C2	MI31	Mirror image 3rd-axis 1st-phase
Y7C3	MI41	Mirror image 4th-axis 1st-phase
Y7C4	MI51	Mirror image 5th-axis 1st-phase
Y7C5	MI61	Mirror image 6th-axis 1st-phase
Y7C6	MI71	Mirror image 7th-axis 1st-phase
Y7C7	MI81	Mirror image 8th-axis 1st-phase
Y7C8	MI12	Mirror image 1st-axis 2nd-phase
Y7C9	MI22	Mirror image 2nd-axis 2nd-phase
Y7CA	MI32	Mirror image 3rd-axis 2nd-phase
Y7CB	MI42	Mirror image 4th-axis 2nd-phase
Y7CC	MI52	Mirror image 5th-axis 2nd-phase
Y7CD	MI62	Mirror image 6th-axis 2nd-phase
Y7CE	MI72	Mirror image 7th-axis 2nd-phase
Y7CF	MI82	Mirror image 8th-axis 2nd-phase
Y7D0	MI13	Mirror image 1st-axis 3rd-phase
Y7D1	MI23	Mirror image 2nd-axis 3rd-phase
Y7D2	MI33	Mirror image 3rd-axis 3rd-phase
Y7D3	MI43	Mirror image 4th-axis 3rd-phase
Y7D4	MI53	Mirror image 5th-axis 3rd-phase
Y7D5	MI63	Mirror image 6th-axis 3rd-phase
Y7D6	MI73	Mirror image 7th-axis 3rd-phase
Y7D7	MI83	Mirror image 8th-axis 3rd-phase
Y7D8	MI14	Mirror image 1st-axis 4th-phase
Y7D9	MI24	Mirror image 2nd-axis 4th-phase
Y7DA	MI34	Mirror image 3rd-axis 4th-phase
Y7DB	MI44	Mirror image 4th-axis 4th-phase
Y7DC	MI54	Mirror image 5th-axis 4th-phase
Y7DD	MI64	Mirror image 6th-axis 4th-phase
Y7DE	MI74	Mirror image 7th-axis 4th-phase
Y7DF	MI84	Mirror image 8th-axis 4th-phase
Y7E0	*+EDT11	External deceleration + 1st-axis 1st-phase
Y7E1	*+EDT21	External deceleration + 2nd-axis 1st-phase
Y7E2	*+EDT31	External deceleration + 3rd-axis 1st-phase
Y7E3	*+EDT41	External deceleration + 4th-axis 1st-phase
Y7E4	*+EDT51	External deceleration + 5th-axis 1st-phase
Y7E5	*+EDT61	External deceleration + 6th-axis 1st-phase
Y7E6	*+EDT71	External deceleration + 7th-axis 1st-phase
Y7E7	*+EDT81	External deceleration + 8th-axis 1st-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y7E8	*+EDT12	External deceleration + 1st-axis 2nd-phase
Y7E9	*+EDT22	External deceleration + 2nd-axis 2nd-phase
Y7EA	*+EDT32	External deceleration + 3rd-axis 2nd-phase
Y7EB	*+EDT42	External deceleration + 4th-axis 2nd-phase
Y7EC	*+EDT52	External deceleration + 5th-axis 2nd-phase
Y7ED	*+EDT62	External deceleration + 6th-axis 2nd-phase
Y7EE	*+EDT72	External deceleration + 7th-axis 2nd-phase
Y7EF	*+EDT82	External deceleration + 8th-axis 2nd-phase
Y7F0	*+EDT13	External deceleration + 1st-axis 3rd-phase
Y7F1	*+EDT23	External deceleration + 2nd-axis 3rd-phase
Y7F2	*+EDT33	External deceleration + 3rd-axis 3rd-phase
Y7F3	*+EDT43	External deceleration + 4th-axis 3rd-phase
Y7F4	*+EDT53	External deceleration + 5th-axis 3rd-phase
Y7F5	*+EDT63	External deceleration + 6th-axis 3rd-phase
Y7F6	*+EDT73	External deceleration + 7th-axis 3rd-phase
Y7F7	*+EDT83	External deceleration + 8th-axis 3rd-phase
Y7F8	*+EDT14	External deceleration + 1st-axis 4th-phase
Y7F9	*+EDT24	External deceleration + 2nd-axis 4th-phase
Y7FA	*+EDT34	External deceleration + 3rd-axis 4th-phase
Y7FB	*+EDT44	External deceleration + 4th-axis 4th-phase
Y7FC	*+EDT54	External deceleration + 5th-axis 4th-phase
Y7FD	*+EDT64	External deceleration + 6th-axis 4th-phase
Y7FE	*+EDT74	External deceleration + 7th-axis 4th-phase
Y7FF	*+EDT84	External deceleration + 8th-axis 4th-phase
Y800	*-EDT11	External deceleration - 1st-axis 1st-phase
Y801	*-EDT21	External deceleration - 2nd-axis 1st-phase
Y802	*-EDT31	External deceleration - 3rd-axis 1st-phase
Y803	*-EDT41	External deceleration - 4th-axis 1st-phase
Y804	*-EDT51	External deceleration - 5th-axis 1st-phase
Y805	*-EDT61	External deceleration - 6th-axis 1st-phase
Y806	*-EDT71	External deceleration - 7th-axis 1st-phase
Y807	*-EDT81	External deceleration - 8th-axis 1st-phase
Y808	*-EDT12	External deceleration - 1st-axis 2nd-phase
Y809	*-EDT22	External deceleration - 2nd-axis 2nd-phase
Y80A	*-EDT32	External deceleration - 3rd-axis 2nd-phase
Y80B	*-EDT42	External deceleration - 4th-axis 2nd-phase
Y80C	*-EDT52	External deceleration - 5th-axis 2nd-phase
Y80D	*-EDT62	External deceleration - 6th-axis 2nd-phase
Y80E	*-EDT72	External deceleration - 7th-axis 2nd-phase
Y80F	*-EDT82	External deceleration - 8th-axis 2nd-phase
Y810	*-EDT13	External deceleration - 1st-axis 3rd-phase
Y811	*-EDT23	External deceleration - 2nd-axis 3rd-phase
Y812	*-EDT33	External deceleration - 3rd-axis 3rd-phase
Y813	*-EDT43	External deceleration - 4th-axis 3rd-phase
Y814	*-EDT53	External deceleration - 5th-axis 3rd-phase
Y815	*-EDT63	External deceleration - 6th-axis 3rd-phase
Y816	*-EDT73	External deceleration - 7th-axis 3rd-phase
Y817	*-EDT83	External deceleration - 8th-axis 3rd-phase
Y818	*-EDT14	External deceleration - 1st-axis 4th-phase
Y819	*-EDT24	External deceleration - 2nd-axis 4th-phase
Y81A	*-EDT34	External deceleration - 3rd-axis 4th-phase
Y81B	*-EDT44	External deceleration - 4th-axis 4th-phase
Y81C	*-EDT54	External deceleration - 5th-axis 4th-phase
Y81D	*-EDT64	External deceleration - 6th-axis 4th-phase
Y81E	*-EDT74	External deceleration - 7th-axis 4th-phase
Y81F	*-EDT84	External deceleration - 8th-axis 4th-phase
Y820	*+AIT11	Automatic interlock + 1st-axis 1st-phase
Y821	*+AIT21	Automatic interlock + 2nd-axis 1st-phase
Y822	*+AIT31	Automatic interlock + 3rd-axis 1st-phase
Y823	*+AIT41	Automatic interlock + 4th-axis 1st-phase
Y824	*+AIT51	Automatic interlock + 5th-axis 1st-phase
Y825	*+AIT61	Automatic interlock + 6th-axis 1st-phase
Y826	*+AIT71	Automatic interlock + 7th-axis 1st-phase
Y827	*+AIT81	Automatic interlock + 8th-axis 1st-phase
Y828	*+AIT12	Automatic interlock + 1st-axis 2nd-phase
Y829	*+AIT22	Automatic interlock + 2nd-axis 2nd-phase
Y82A	*+AIT32	Automatic interlock + 3rd-axis 2nd-phase
Y82B	*+AIT42	Automatic interlock + 4th-axis 2nd-phase
Y82C	*+AIT52	Automatic interlock + 5th-axis 2nd-phase
Y82D	*+AIT62	Automatic interlock + 6th-axis 2nd-phase
Y82E	*+AIT72	Automatic interlock + 7th-axis 2nd-phase
Y82F	*+AIT82	Automatic interlock + 8th-axis 2nd-phase
Y830	*+AIT13	Automatic interlock + 1st-axis 3rd-phase
Y831	*+AIT23	Automatic interlock + 2nd-axis 3rd-phase
Y832	*+AIT33	Automatic interlock + 3rd-axis 3rd-phase
Y833	*+AIT43	Automatic interlock + 4th-axis 3rd-phase
Y834	*+AIT53	Automatic interlock + 5th-axis 3rd-phase
Y835	*+AIT63	Automatic interlock + 6th-axis 3rd-phase
Y836	*+AIT73	Automatic interlock + 7th-axis 3rd-phase
Y837	*+AIT83	Automatic interlock + 8th-axis 3rd-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y838	*+AIT14	Automatic interlock + 1st-axis 4th-phase
Y839	*+AIT24	Automatic interlock + 2nd-axis 4th-phase
Y83A	*+AIT34	Automatic interlock + 3rd-axis 4th-phase
Y83B	*+AIT44	Automatic interlock + 4th-axis 4th-phase
Y83C	*+AIT54	Automatic interlock + 5th-axis 4th-phase
Y83D	*+AIT64	Automatic interlock + 6th-axis 4th-phase
Y83E	*+AIT74	Automatic interlock + 7th-axis 4th-phase
Y83F	*+AIT84	Automatic interlock + 8th-axis 4th-phase
Y840	*-AIT11	Automatic interlock - 1st-axis 1st-phase
Y841	*-AIT21	Automatic interlock - 2nd-axis 1st-phase
Y842	*-AIT31	Automatic interlock - 3rd-axis 1st-phase
Y843	*-AIT41	Automatic interlock - 4th-axis 1st-phase
Y844	*-AIT51	Automatic interlock - 5th-axis 1st-phase
Y845	*-AIT61	Automatic interlock - 6th-axis 1st-phase
Y846	*-AIT71	Automatic interlock - 7th-axis 1st-phase
Y847	*-AIT81	Automatic interlock - 8th-axis 1st-phase
Y848	*-AIT12	Automatic interlock - 1st-axis 2nd-phase
Y849	*-AIT22	Automatic interlock - 2nd-axis 2nd-phase
Y84A	*-AIT32	Automatic interlock - 3rd-axis 2nd-phase
Y84B	*-AIT42	Automatic interlock - 4th-axis 2nd-phase
Y84C	*-AIT52	Automatic interlock - 5th-axis 2nd-phase
Y84D	*-AIT62	Automatic interlock - 6th-axis 2nd-phase
Y84E	*-AIT72	Automatic interlock - 7th-axis 2nd-phase
Y84F	*-AIT82	Automatic interlock - 8th-axis 2nd-phase
Y850	*-AIT13	Automatic interlock - 1st-axis 3rd-phase
Y851	*-AIT23	Automatic interlock - 2nd-axis 3rd-phase
Y852	*-AIT33	Automatic interlock - 3rd-axis 3rd-phase
Y853	*-AIT43	Automatic interlock - 4th-axis 3rd-phase
Y854	*-AIT53	Automatic interlock - 5th-axis 3rd-phase
Y855	*-AIT63	Automatic interlock - 6th-axis 3rd-phase
Y856	*-AIT73	Automatic interlock - 7th-axis 3rd-phase
Y857	*-AIT83	Automatic interlock - 8th-axis 3rd-phase
Y858	*-AIT14	Automatic interlock - 1st-axis 4th-phase
Y859	*-AIT24	Automatic interlock - 2nd-axis 4th-phase
Y85A	*-AIT34	Automatic interlock - 3rd-axis 4th-phase
Y85B	*-AIT44	Automatic interlock - 4th-axis 4th-phase
Y85C	*-AIT54	Automatic interlock - 5th-axis 4th-phase
Y85D	*-AIT64	Automatic interlock - 6th-axis 4th-phase
Y85E	*-AIT74	Automatic interlock - 7th-axis 4th-phase
Y85F	*-AIT84	Automatic interlock - 8th-axis 4th-phase
Y860	*+MIT11	Manual interlock + 1st-axis 1st-phase
Y861	*+MIT21	Manual interlock + 2nd-axis 1st-phase
Y862	*+MIT31	Manual interlock + 3rd-axis 1st-phase
Y863	*+MIT41	Manual interlock + 4th-axis 1st-phase
Y864	*+MIT51	Manual interlock + 5th-axis 1st-phase
Y865	*+MIT61	Manual interlock + 6th-axis 1st-phase
Y866	*+MIT71	Manual interlock + 7th-axis 1st-phase
Y867	*+MIT81	Manual interlock + 8th-axis 1st-phase
Y868	*+MIT12	Manual interlock + 1st-axis 2nd-phase
Y869	*+MIT22	Manual interlock + 2nd-axis 2nd-phase
Y86A	*+MIT32	Manual interlock + 3rd-axis 2nd-phase
Y86B	*+MIT42	Manual interlock + 4th-axis 2nd-phase
Y86C	*+MIT52	Manual interlock + 5th-axis 2nd-phase
Y86D	*+MIT62	Manual interlock + 6th-axis 2nd-phase
Y86E	*+MIT72	Manual interlock + 7th-axis 2nd-phase
Y86F	*+MIT82	Manual interlock + 8th-axis 2nd-phase
Y870	*+MIT13	Manual interlock + 1st-axis 3rd-phase
Y871	*+MIT23	Manual interlock + 2nd-axis 3rd-phase
Y872	*+MIT33	Manual interlock + 3rd-axis 3rd-phase
Y873	*+MIT43	Manual interlock + 4th-axis 3rd-phase
Y874	*+MIT53	Manual interlock + 5th-axis 3rd-phase
Y875	*+MIT63	Manual interlock + 6th-axis 3rd-phase
Y876	*+MIT73	Manual interlock + 7th-axis 3rd-phase
Y877	*+MIT83	Manual interlock + 8th-axis 3rd-phase
Y878	*+MIT14	Manual interlock + 1st-axis 4th-phase
Y879	*+MIT24	Manual interlock + 2nd-axis 4th-phase
Y87A	*+MIT34	Manual interlock + 3rd-axis 4th-phase
Y87B	*+MIT44	Manual interlock + 4th-axis 4th-phase
Y87C	*+MIT54	Manual interlock + 5th-axis 4th-phase
Y87D	*+MIT64	Manual interlock + 6th-axis 4th-phase
Y87E	*+MIT74	Manual interlock + 7th-axis 4th-phase
Y87F	*+MIT84	Manual interlock + 8th-axis 4th-phase
Y880	*-MIT11	Manual interlock - 1st-axis 1st-phase
Y881	*-MIT21	Manual interlock - 2nd-axis 1st-phase
Y882	*-MIT31	Manual interlock - 3rd-axis 1st-phase
Y883	*-MIT41	Manual interlock - 4th-axis 1st-phase
Y884	*-MIT51	Manual interlock - 5th-axis 1st-phase
Y885	*-MIT61	Manual interlock - 6th-axis 1st-phase
Y886	*-MIT71	Manual interlock - 7th-axis 1st-phase
Y887	*-MIT81	Manual interlock - 8th-axis 1st-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y888	*-MIT12	Manual interlock - 1st-axis 2nd-phase
Y889	*-MIT22	Manual interlock - 2nd-axis 2nd-phase
Y88A	*-MIT32	Manual interlock - 3rd-axis 2nd-phase
Y88B	*-MIT42	Manual interlock - 4th-axis 2nd-phase
Y88C	*-MIT52	Manual interlock - 5th-axis 2nd-phase
Y88D	*-MIT62	Manual interlock - 6th-axis 2nd-phase
Y88E	*-MIT72	Manual interlock - 7th-axis 2nd-phase
Y88F	*-MIT82	Manual interlock - 8th-axis 2nd-phase
Y890	*-MIT13	Manual interlock - 1st-axis 3rd-phase
Y891	*-MIT23	Manual interlock - 2nd-axis 3rd-phase
Y892	*-MIT33	Manual interlock - 3rd-axis 3rd-phase
Y893	*-MIT43	Manual interlock - 4th-axis 3rd-phase
Y894	*-MIT53	Manual interlock - 5th-axis 3rd-phase
Y895	*-MIT63	Manual interlock - 6th-axis 3rd-phase
Y896	*-MIT73	Manual interlock - 7th-axis 3rd-phase
Y897	*-MIT83	Manual interlock - 8th-axis 3rd-phase
Y898	*-MIT14	Manual interlock - 1st-axis 4th-phase
Y899	*-MIT24	Manual interlock - 2nd-axis 4th-phase
Y89A	*-MIT34	Manual interlock - 3rd-axis 4th-phase
Y89B	*-MIT44	Manual interlock - 4th-axis 4th-phase
Y89C	*-MIT54	Manual interlock - 5th-axis 4th-phase
Y89D	*-MIT64	Manual interlock - 6th-axis 4th-phase
Y89E	*-MIT74	Manual interlock - 7th-axis 4th-phase
Y89F	*-MIT84	Manual interlock - 8th-axis 4th-phase
Y8A0	AMLK11	Automatic machine lock 1st-axis 1st-phase
Y8A1	AMLK21	Automatic machine lock 2nd-axis 1st-phase
Y8A2	AMLK31	Automatic machine lock 3rd-axis 1st-phase
Y8A3	AMLK41	Automatic machine lock 4th-axis 1st-phase
Y8A4	AMLK51	Automatic machine lock 5th-axis 1st-phase
Y8A5	AMLK61	Automatic machine lock 6th-axis 1st-phase
Y8A6	AMLK71	Automatic machine lock 7th-axis 1st-phase
Y8A7	AMLK81	Automatic machine lock 8th-axis 1st-phase
Y8A8	AMLK12	Automatic machine lock 1st-axis 2nd-phase
Y8A9	AMLK22	Automatic machine lock 2nd-axis 2nd-phase
Y8AA	AMLK32	Automatic machine lock 3rd-axis 2nd-phase
Y8AB	AMLK42	Automatic machine lock 4th-axis 2nd-phase
Y8AC	AMLK52	Automatic machine lock 5th-axis 2nd-phase
Y8AD	AMLK62	Automatic machine lock 6th-axis 2nd-phase
Y8AE	AMLK72	Automatic machine lock 7th-axis 2nd-phase
Y8AF	AMLK82	Automatic machine lock 8th-axis 2nd-phase
Y8B0	AMLK13	Automatic machine lock 1st-axis 3rd-phase
Y8B1	AMLK23	Automatic machine lock 2nd-axis 3rd-phase
Y8B2	AMLK33	Automatic machine lock 3rd-axis 3rd-phase
Y8B3	AMLK43	Automatic machine lock 4th-axis 3rd-phase
Y8B4	AMLK53	Automatic machine lock 5th-axis 3rd-phase
Y8B5	AMLK63	Automatic machine lock 6th-axis 3rd-phase
Y8B6	AMLK73	Automatic machine lock 7th-axis 3rd-phase
Y8B7	AMLK83	Automatic machine lock 8th-axis 3rd-phase
Y8B8	AMLK14	Automatic machine lock 1st-axis 4th-phase
Y8B9	AMLK24	Automatic machine lock 2nd-axis 4th-phase
Y8BA	AMLK34	Automatic machine lock 3rd-axis 4th-phase
Y8BB	AMLK44	Automatic machine lock 4th-axis 4th-phase
Y8BC	AMLK54	Automatic machine lock 5th-axis 4th-phase
Y8BD	AMLK64	Automatic machine lock 6th-axis 4th-phase
Y8BE	AMLK74	Automatic machine lock 7th-axis 4th-phase
Y8BF	AMLK84	Automatic machine lock 8th-axis 4th-phase
Y8C0	MMLK11	Manual machine lock 1st-axis 1st-phase
Y8C1	MMLK21	Manual machine lock 2nd-axis 1st-phase
Y8C2	MMLK31	Manual machine lock 3rd-axis 1st-phase
Y8C3	MMLK41	Manual machine lock 4th-axis 1st-phase
Y8C4	MMLK51	Manual machine lock 5th-axis 1st-phase
Y8C5	MMLK61	Manual machine lock 6th-axis 1st-phase
Y8C6	MMLK71	Manual machine lock 7th-axis 1st-phase
Y8C7	MMLK81	Manual machine lock 8th-axis 1st-phase
Y8C8	MMLK12	Manual machine lock 1st-axis 2nd-phase
Y8C9	MMLK22	Manual machine lock 2nd-axis 2nd-phase
Y8CA	MMLK32	Manual machine lock 3rd-axis 2nd-phase
Y8CB	MMLK42	Manual machine lock 4th-axis 2nd-phase
Y8CC	MMLK52	Manual machine lock 5th-axis 2nd-phase
Y8CD	MMLK62	Manual machine lock 6th-axis 2nd-phase
Y8CE	MMLK72	Manual machine lock 7th-axis 2nd-phase
Y8CF	MMLK82	Manual machine lock 8th-axis 2nd-phase
Y8D0	MMLK13	Manual machine lock 1st-axis 3rd-phase
Y8D1	MMLK23	Manual machine lock 2nd-axis 3rd-phase
Y8D2	MMLK33	Manual machine lock 3rd-axis 3rd-phase
Y8D3	MMLK43	Manual machine lock 4th-axis 3rd-phase
Y8D4	MMLK53	Manual machine lock 5th-axis 3rd-phase
Y8D5	MMLK63	Manual machine lock 6th-axis 3rd-phase
Y8D6	MMLK73	Manual machine lock 7th-axis 3rd-phase
Y8D7	MMLK83	Manual machine lock 8th-axis 3rd-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y8D8	MMLK14	Manual machine lock 1st-axis 4th-phase
Y8D9	MMLK24	Manual machine lock 2nd-axis 4th-phase
Y8DA	MMLK34	Manual machine lock 3rd-axis 4th-phase
Y8DB	MMLK44	Manual machine lock 4th-axis 4th-phase
Y8DC	MMLK54	Manual machine lock 5th-axis 4th-phase
Y8DD	MMLK64	Manual machine lock 6th-axis 4th-phase
Y8DE	MMLK74	Manual machine lock 7th-axis 4th-phase
Y8DF	MMLK84	Manual machine lock 8th-axis 4th-phase
Y8E0	+J11	Feed axis selection + 1st-axis 1st-phase
Y8E1	+J21	Feed axis selection + 2nd-axis 1st-phase
Y8E2	+J31	Feed axis selection + 3rd-axis 1st-phase
Y8E3	+J41	Feed axis selection + 4th-axis 1st-phase
Y8E4	+J51	Feed axis selection + 5th-axis 1st-phase
Y8E5	+J61	Feed axis selection + 6th-axis 1st-phase
Y8E6	+J71	Feed axis selection + 7th-axis 1st-phase
Y8E7	+J81	Feed axis selection + 8th-axis 1st-phase
Y8E8	+J12	Feed axis selection + 1st-axis 2nd-phase
Y8E9	+J22	Feed axis selection + 2nd-axis 2nd-phase
Y8EA	+J32	Feed axis selection + 3rd-axis 2nd-phase
Y8EB	+J42	Feed axis selection + 4th-axis 2nd-phase
Y8EC	+J52	Feed axis selection + 5th-axis 2nd-phase
Y8ED	+J62	Feed axis selection + 6th-axis 2nd-phase
Y8EE	+J72	Feed axis selection + 7th-axis 2nd-phase
Y8EF	+J82	Feed axis selection + 8th-axis 2nd-phase
Y8F0	+J13	Feed axis selection + 1st-axis 3rd-phase
Y8F1	+J23	Feed axis selection + 2nd-axis 3rd-phase
Y8F2	+J33	Feed axis selection + 3rd-axis 3rd-phase
Y8F3	+J43	Feed axis selection + 4th-axis 3rd-phase
Y8F4	+J53	Feed axis selection + 5th-axis 3rd-phase
Y8F5	+J63	Feed axis selection + 6th-axis 3rd-phase
Y8F6	+J73	Feed axis selection + 7th-axis 3rd-phase
Y8F7	+J83	Feed axis selection + 8th-axis 3rd-phase
Y8F8	+J14	Feed axis selection + 1st-axis 4th-phase
Y8F9	+J24	Feed axis selection + 2nd-axis 4th-phase
Y8FA	+J34	Feed axis selection + 3rd-axis 4th-phase
Y8FB	+J44	Feed axis selection + 4th-axis 4th-phase
Y8FC	+J54	Feed axis selection + 5th-axis 4th-phase
Y8FD	+J64	Feed axis selection + 6th-axis 4th-phase
Y8FE	+J74	Feed axis selection + 7th-axis 4th-phase
Y8FF	+J84	Feed axis selection + 8th-axis 4th-phase
Y900	-J11	Feed axis selection - 1st-axis 1st-phase
Y901	-J21	Feed axis selection - 2nd-axis 1st-phase
Y902	-J31	Feed axis selection - 3rd-axis 1st-phase
Y903	-J41	Feed axis selection - 4th-axis 1st-phase
Y904	-J51	Feed axis selection - 5th-axis 1st-phase
Y905	-J61	Feed axis selection - 6th-axis 1st-phase
Y906	-J71	Feed axis selection - 7th-axis 1st-phase
Y907	-J81	Feed axis selection - 8th-axis 1st-phase
Y908	-J12	Feed axis selection - 1st-axis 2nd-phase
Y909	-J22	Feed axis selection - 2nd-axis 2nd-phase
Y90A	-J32	Feed axis selection - 3rd-axis 2nd-phase
Y90B	-J42	Feed axis selection - 4th-axis 2nd-phase
Y90C	-J52	Feed axis selection - 5th-axis 2nd-phase
Y90D	-J62	Feed axis selection - 6th-axis 2nd-phase
Y90E	-J72	Feed axis selection - 7th-axis 2nd-phase
Y90F	-J82	Feed axis selection - 8th-axis 2nd-phase
Y910	-J13	Feed axis selection - 1st-axis 3rd-phase
Y911	-J23	Feed axis selection - 2nd-axis 3rd-phase
Y912	-J33	Feed axis selection - 3rd-axis 3rd-phase
Y913	-J43	Feed axis selection - 4th-axis 3rd-phase
Y914	-J53	Feed axis selection - 5th-axis 3rd-phase
Y915	-J63	Feed axis selection - 6th-axis 3rd-phase
Y916	-J73	Feed axis selection - 7th-axis 3rd-phase
Y917	-J83	Feed axis selection - 8th-axis 3rd-phase
Y918	-J14	Feed axis selection - 1st-axis 4th-phase
Y919	-J24	Feed axis selection - 2nd-axis 4th-phase
Y91A	-J34	Feed axis selection - 3rd-axis 4th-phase
Y91B	-J44	Feed axis selection - 4th-axis 4th-phase
Y91C	-J54	Feed axis selection - 5th-axis 4th-phase
Y91D	-J64	Feed axis selection - 6th-axis 4th-phase
Y91E	-J74	Feed axis selection - 7th-axis 4th-phase
Y91F	-J84	Feed axis selection - 8th-axis 4th-phase
Y920	MAE11	Manual/Automatic simultaneous valid 1st-axis 1st-phase
Y921	MAE21	Manual/Automatic simultaneous valid 2nd-axis 1st-phase
Y922	MAE31	Manual/Automatic simultaneous valid 3rd-axis 1st-phase
Y923	MAE41	Manual/Automatic simultaneous valid 4th-axis 1st-phase
Y924	MAE51	Manual/Automatic simultaneous valid 5th-axis 1st-phase
Y925	MAE61	Manual/Automatic simultaneous valid 6th-axis 1st-phase
Y926	MAE71	Manual/Automatic simultaneous valid 7th-axis 1st-phase
Y927	MAE81	Manual/Automatic simultaneous valid 8th-axis 1st-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y928	MAE12	Manual/Automatic simultaneous valid 1st-axis 2nd-phase
Y929	MAE22	Manual/Automatic simultaneous valid 2nd-axis 2nd-phase
Y92A	MAE32	Manual/Automatic simultaneous valid 3rd-axis 2nd-phase
Y92B	MAE42	Manual/Automatic simultaneous valid 4th-axis 2nd-phase
Y92C	MAE52	Manual/Automatic simultaneous valid 5th-axis 2nd-phase
Y92D	MAE62	Manual/Automatic simultaneous valid 6th-axis 2nd-phase
Y92E	MAE72	Manual/Automatic simultaneous valid 7th-axis 2nd-phase
Y92F	MAE82	Manual/Automatic simultaneous valid 8th-axis 2nd-phase
Y930	MAE13	Manual/Automatic simultaneous valid 1st-axis 3rd-phase
Y931	MAE23	Manual/Automatic simultaneous valid 2nd-axis 3rd-phase
Y932	MAE33	Manual/Automatic simultaneous valid 3rd-axis 3rd-phase
Y933	MAE43	Manual/Automatic simultaneous valid 4th-axis 3rd-phase
Y934	MAE53	Manual/Automatic simultaneous valid 5th-axis 3rd-phase
Y935	MAE63	Manual/Automatic simultaneous valid 6th-axis 3rd-phase
Y936	MAE73	Manual/Automatic simultaneous valid 7th-axis 3rd-phase
Y937	MAE83	Manual/Automatic simultaneous valid 8th-axis 3rd-phase
Y938	MAE14	Manual/Automatic simultaneous valid 1st-axis 4th-phase
Y939	MAE24	Manual/Automatic simultaneous valid 2nd-axis 4th-phase
Y93A	MAE34	Manual/Automatic simultaneous valid 3rd-axis 4th-phase
Y93B	MAE44	Manual/Automatic simultaneous valid 4th-axis 4th-phase
Y93C	MAE54	Manual/Automatic simultaneous valid 5th-axis 4th-phase
Y93D	MAE64	Manual/Automatic simultaneous valid 6th-axis 4th-phase
Y93E	MAE74	Manual/Automatic simultaneous valid 7th-axis 4th-phase
Y93F	MAE84	Manual/Automatic simultaneous valid 8th-axis 4th-phase
Y940	FBE11	Manual feedrate B valid 1st axis 1st-phase
Y941	FBE21	Manual feedrate B valid 2nd axis 1st-phase
Y942	FBE31	Manual feedrate B valid 3rd axis 1st-phase
Y943	FBE41	Manual feedrate B valid 4th axis 1st-phase
Y944	FBE51	Manual feedrate B valid 5th axis 1st-phase
Y945	FBE61	Manual feedrate B valid 6th axis 1st-phase
Y946	FBE71	Manual feedrate B valid 7th axis 1st-phase
Y947	FBE81	Manual feedrate B valid 8th axis 1st-phase
Y948	FBE12	Manual feedrate B valid 1st axis 2nd-phase
Y949	FBE22	Manual feedrate B valid 2nd axis 2nd-phase
Y94A	FBE32	Manual feedrate B valid 3rd axis 2nd-phase
Y94B	FBE42	Manual feedrate B valid 4th axis 2nd-phase
Y94C	FBE52	Manual feedrate B valid 5th axis 2nd-phase
Y94D	FBE62	Manual feedrate B valid 6th axis 2nd-phase
Y94E	FBE72	Manual feedrate B valid 7th axis 2nd-phase
Y94F	FBE82	Manual feedrate B valid 8th axis 2nd-phase
Y950	FBE13	Manual feedrate B valid 1st axis 3rd-phase
Y951	FBE23	Manual feedrate B valid 2nd axis 3rd-phase
Y952	FBE33	Manual feedrate B valid 3rd axis 3rd-phase
Y953	FBE43	Manual feedrate B valid 4th axis 3rd-phase
Y954	FBE53	Manual feedrate B valid 5th axis 3rd-phase
Y955	FBE63	Manual feedrate B valid 6th axis 3rd-phase
Y956	FBE73	Manual feedrate B valid 7th axis 3rd-phase
Y957	FBE83	Manual feedrate B valid 8th axis 3rd-phase
Y958	FBE14	Manual feedrate B valid 1st axis 4th-phase
Y959	FBE24	Manual feedrate B valid 2nd axis 4th-phase
Y95A	FBE34	Manual feedrate B valid 3rd axis 4th-phase
Y95B	FBE44	Manual feedrate B valid 4th axis 4th-phase
Y95C	FBE54	Manual feedrate B valid 5th axis 4th-phase
Y95D	FBE64	Manual feedrate B valid 6th axis 4th-phase
Y95E	FBE74	Manual feedrate B valid 7th axis 4th-phase
Y95F	FBE84	Manual feedrate B valid 8th axis 4th-phase
Y960	AZS11	Zero point initialization set mode 1st-axis 1st-phase
Y961	AZS21	Zero point initialization set mode 2nd-axis 1st-phase
Y962	AZS31	Zero point initialization set mode 3rd-axis 1st-phase
Y963	AZS41	Zero point initialization set mode 4th-axis 1st-phase
Y964	AZS51	Zero point initialization set mode 5th-axis 1st-phase
Y965	AZS61	Zero point initialization set mode 6th-axis 1st-phase
Y966	AZS71	Zero point initialization set mode 7th-axis 1st-phase
Y967	AZS81	Zero point initialization set mode 8th-axis 1st-phase
Y968	AZS12	Zero point initialization set mode 1st-axis 2nd-phase
Y969	AZS22	Zero point initialization set mode 2nd-axis 2nd-phase
Y96A	AZS32	Zero point initialization set mode 3rd-axis 2nd-phase
Y96B	AZS42	Zero point initialization set mode 4th-axis 2nd-phase
Y96C	AZS52	Zero point initialization set mode 5th-axis 2nd-phase
Y96D	AZS62	Zero point initialization set mode 6th-axis 2nd-phase
Y96E	AZS72	Zero point initialization set mode 7th-axis 2nd-phase
Y96F	AZS82	Zero point initialization set mode 8th-axis 2nd-phase
Y970	AZS13	Zero point initialization set mode 1st-axis 3rd-phase
Y971	AZS23	Zero point initialization set mode 2nd-axis 3rd-phase
Y972	AZS33	Zero point initialization set mode 3rd-axis 3rd-phase
Y973	AZS43	Zero point initialization set mode 4th-axis 3rd-phase
Y974	AZS53	Zero point initialization set mode 5th-axis 3rd-phase
Y975	AZS63	Zero point initialization set mode 6th-axis 3rd-phase
Y976	AZS73	Zero point initialization set mode 7th-axis 3rd-phase
Y977	AZS83	Zero point initialization set mode 8th-axis 3rd-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y978	AZS14	Zero point initialization set mode 1st-axis 4th-phase
Y979	AZS24	Zero point initialization set mode 2nd-axis 4th-phase
Y97A	AZS34	Zero point initialization set mode 3rd-axis 4th-phase
Y97B	AZS44	Zero point initialization set mode 4th-axis 4th-phase
Y97C	AZS54	Zero point initialization set mode 5th-axis 4th-phase
Y97D	AZS64	Zero point initialization set mode 6th-axis 4th-phase
Y97E	AZS74	Zero point initialization set mode 7th-axis 4th-phase
Y97F	AZS84	Zero point initialization set mode 8th-axis 4th-phase
Y980	ZST11	Zero point initialization set start 1st-axis 1st-phase
Y981	ZST21	Zero point initialization set start 2nd-axis 1st-phase
Y982	ZST31	Zero point initialization set start 3rd-axis 1st-phase
Y983	ZST41	Zero point initialization set start 4th-axis 1st-phase
Y984	ZST51	Zero point initialization set start 5th-axis 1st-phase
Y985	ZST61	Zero point initialization set start 6th-axis 1st-phase
Y986	ZST71	Zero point initialization set start 7th-axis 1st-phase
Y987	ZST81	Zero point initialization set start 8th-axis 1st-phase
Y988	ZST12	Zero point initialization set start 1st-axis 2nd-phase
Y989	ZST22	Zero point initialization set start 2nd-axis 2nd-phase
Y98A	ZST32	Zero point initialization set start 3rd-axis 2nd-phase
Y98B	ZST42	Zero point initialization set start 4th-axis 2nd-phase
Y98C	ZST52	Zero point initialization set start 5th-axis 2nd-phase
Y98D	ZST62	Zero point initialization set start 6th-axis 2nd-phase
Y98E	ZST72	Zero point initialization set start 7th-axis 2nd-phase
Y98F	ZST82	Zero point initialization set start 8th-axis 2nd-phase
Y990	ZST13	Zero point initialization set start 1st-axis 3rd-phase
Y991	ZST23	Zero point initialization set start 2nd-axis 3rd-phase
Y992	ZST33	Zero point initialization set start 3rd-axis 3rd-phase
Y993	ZST43	Zero point initialization set start 4th-axis 3rd-phase
Y994	ZST53	Zero point initialization set start 5th-axis 3rd-phase
Y995	ZST63	Zero point initialization set start 6th-axis 3rd-phase
Y996	ZST73	Zero point initialization set start 7th-axis 3rd-phase
Y997	ZST83	Zero point initialization set start 8th-axis 3rd-phase
Y998	ZST14	Zero point initialization set start 1st-axis 4th-phase
Y999	ZST24	Zero point initialization set start 2nd-axis 4th-phase
Y99A	ZST34	Zero point initialization set start 3rd-axis 4th-phase
Y99B	ZST44	Zero point initialization set start 4th-axis 4th-phase
Y99C	ZST54	Zero point initialization set start 5th-axis 4th-phase
Y99D	ZST64	Zero point initialization set start 6th-axis 4th-phase
Y99E	ZST74	Zero point initialization set start 7th-axis 4th-phase
Y99F	ZST84	Zero point initialization set start 8th-axis 4th-phase
Y9A0	ILC11	Current limit changeover 1st-axis 1st-phase
Y9A1	ILC21	Current limit changeover 2nd-axis 1st-phase
Y9A2	ILC31	Current limit changeover 3rd-axis 1st-phase
Y9A3	ILC41	Current limit changeover 4th-axis 1st-phase
Y9A4	ILC51	Current limit changeover 5th-axis 1st-phase
Y9A5	ILC61	Current limit changeover 6th-axis 1st-phase
Y9A6	ILC71	Current limit changeover 7th-axis 1st-phase
Y9A7	ILC81	Current limit changeover 8th-axis 1st-phase
Y9A8	ILC12	Current limit changeover 1st-axis 2nd-phase
Y9A9	ILC22	Current limit changeover 2nd-axis 2nd-phase
Y9AA	ILC32	Current limit changeover 3rd-axis 2nd-phase
Y9AB	ILC42	Current limit changeover 4th-axis 2nd-phase
Y9AC	ILC52	Current limit changeover 5th-axis 2nd-phase
Y9AD	ILC62	Current limit changeover 6th-axis 2nd-phase
Y9AE	ILC72	Current limit changeover 7th-axis 2nd-phase
Y9AF	ILC82	Current limit changeover 8th-axis 2nd-phase
Y9B0	ILC13	Current limit changeover 1st-axis 3rd-phase
Y9B1	ILC23	Current limit changeover 2nd-axis 3rd-phase
Y9B2	ILC33	Current limit changeover 3rd-axis 3rd-phase
Y9B3	ILC43	Current limit changeover 4th-axis 3rd-phase
Y9B4	ILC53	Current limit changeover 5th-axis 3rd-phase
Y9B5	ILC63	Current limit changeover 6th-axis 3rd-phase
Y9B6	ILC73	Current limit changeover 7th-axis 3rd-phase
Y9B7	ILC83	Current limit changeover 8th-axis 3rd-phase
Y9B8	ILC14	Current limit changeover 1st-axis 4th-phase
Y9B9	ILC24	Current limit changeover 2nd-axis 4th-phase
Y9BA	ILC34	Current limit changeover 3rd-axis 4th-phase
Y9BB	ILC44	Current limit changeover 4th-axis 4th-phase
Y9BC	ILC54	Current limit changeover 5th-axis 4th-phase
Y9BD	ILC64	Current limit changeover 6th-axis 4th-phase
Y9BE	ILC74	Current limit changeover 7th-axis 4th-phase
Y9BF	ILC84	Current limit changeover 8th-axis 4th-phase
Y9C0	DOR11	Droop release request 1st-axis 1st-phase
Y9C1	DOR21	Droop release request 2nd-axis 1st-phase
Y9C2	DOR31	Droop release request 3rd-axis 1st-phase
Y9C3	DOR41	Droop release request 4th-axis 1st-phase
Y9C4	DOR51	Droop release request 5th-axis 1st-phase
Y9C5	DOR61	Droop release request 6th-axis 1st-phase
Y9C6	DOR71	Droop release request 7th-axis 1st-phase
Y9C7	DOR81	Droop release request 8th-axis 1st-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y9C8	DOR12	Droop release request 1st-axis 2nd-phase
Y9C9	DOR22	Droop release request 2nd-axis 2nd-phase
Y9CA	DOR32	Droop release request 3rd-axis 2nd-phase
Y9CB	DOR42	Droop release request 4th-axis 2nd-phase
Y9CC	DOR52	Droop release request 5th-axis 2nd-phase
Y9CD	DOR62	Droop release request 6th-axis 2nd-phase
Y9CE	DOR72	Droop release request 7th-axis 2nd-phase
Y9CF	DOR82	Droop release request 8th-axis 2nd-phase
Y9D0	DOR13	Droop release request 1st-axis 3rd-phase
Y9D1	DOR23	Droop release request 2nd-axis 3rd-phase
Y9D2	DOR33	Droop release request 3rd-axis 3rd-phase
Y9D3	DOR43	Droop release request 4th-axis 3rd-phase
Y9D4	DOR53	Droop release request 5th-axis 3rd-phase
Y9D5	DOR63	Droop release request 6th-axis 3rd-phase
Y9D6	DOR73	Droop release request 7th-axis 3rd-phase
Y9D7	DOR83	Droop release request 8th-axis 3rd-phase
Y9D8	DOR14	Droop release request 1st-axis 4th-phase
Y9D9	DOR24	Droop release request 2nd-axis 4th-phase
Y9DA	DOR34	Droop release request 3rd-axis 4th-phase
Y9DB	DOR44	Droop release request 4th-axis 4th-phase
Y9DC	DOR54	Droop release request 5th-axis 4th-phase
Y9DD	DOR64	Droop release request 6th-axis 4th-phase
Y9DE	DOR74	Droop release request 7th-axis 4th-phase
Y9DF	DOR84	Droop release request 8th-axis 4th-phase
Y9E0		Workpiece coordinate Measurement 1st axis (Spare) 1st-phase
Y9E1		Workpiece coordinate Measurement 2nd axis 1st-phase
Y9E2		Workpiece coordinate Measurement 3rd axis (Spare) 1st-phase
Y9E3		Workpiece coordinate Measurement 4th axis (Spare) 1st-phase
Y9E4		Workpiece coordinate Measurement 5th axis (Spare) 1st-phase
Y9E5		Workpiece coordinate Measurement 6th axis (Spare) 1st-phase
Y9E6		Workpiece coordinate Measurement 7th axis (Spare) 1st-phase
Y9E7		Workpiece coordinate Measurement 8th axis (Spare) 1st-phase
Y9E8		Workpiece coordinate Measurement 1st axis (Spare) 2nd-phase
Y9E9		Workpiece coordinate Measurement 2nd axis 2nd-phase
Y9EA		Workpiece coordinate Measurement 3rd axis (Spare) 2nd-phase
Y9EB		Workpiece coordinate Measurement 4th axis (Spare) 2nd-phase
Y9EC		Workpiece coordinate Measurement 5th axis (Spare) 2nd-phase
Y9ED		Workpiece coordinate Measurement 6th axis (Spare) 2nd-phase
Y9EE		Workpiece coordinate Measurement 7th axis (Spare) 2nd-phase
Y9EF		Workpiece coordinate Measurement 8th axis (Spare) 2nd-phase
Y9F0		Workpiece coordinate Measurement 1st axis (Spare) 3rd-phase
Y9F1		Workpiece coordinate Measurement 2nd axis 3rd-phase
Y9F2		Workpiece coordinate Measurement 3rd axis (Spare) 3rd-phase
Y9F3		Workpiece coordinate Measurement 4th axis (Spare) 3rd-phase
Y9F4		Workpiece coordinate Measurement 5th axis (Spare) 3rd-phase
Y9F5		Workpiece coordinate Measurement 6th axis (Spare) 3rd-phase
Y9F6		Workpiece coordinate Measurement 7th axis (Spare) 3rd-phase
Y9F7		Workpiece coordinate Measurement 8th axis (Spare) 3rd-phase
Y9F8		Workpiece coordinate Measurement 1st axis (Spare) 4th-phase
Y9F9		Workpiece coordinate Measurement 2nd axis 4th-phase
Y9FA		Workpiece coordinate Measurement 3rd axis (Spare) 4th-phase
Y9FB		Workpiece coordinate Measurement 4th axis (Spare) 4th-phase
Y9FC		Workpiece coordinate Measurement 5th axis (Spare) 4th-phase
Y9FD		Workpiece coordinate Measurement 6th axis (Spare) 4th-phase
Y9FE		Workpiece coordinate Measurement 7th axis (Spare) 4th-phase
Y9FF		Workpiece coordinate Measurement 8th axis (Spare) 4th-phase
YA00	DTCH211	Control axis detach 2 1st-axis 1st-phase
YA01	DTCH221	Control axis detach 2 2nd-axis 1st-phase
YA02	DTCH231	Control axis detach 2 3rd-axis 1st-phase
YA03	DTCH241	Control axis detach 2 4th-axis 1st-phase
YA04	DTCH251	Control axis detach 2 5th-axis 1st-phase
YA05	DTCH261	Control axis detach 2 6th-axis 1st-phase
YA06	DTCH271	Control axis detach 2 7th-axis 1st-phase
YA07	DTCH281	Control axis detach 2 8th-axis 1st-phase
YA08	DTCH212	Control axis detach 2 1st-axis 2nd-phase
YA09	DTCH222	Control axis detach 2 2nd-axis 2nd-phase
YA0A	DTCH232	Control axis detach 2 3rd-axis 2nd-phase
YA0B	DTCH242	Control axis detach 2 4th-axis 2nd-phase
YA0C	DTCH252	Control axis detach 2 5th-axis 2nd-phase
YA0D	DTCH262	Control axis detach 2 6th-axis 2nd-phase
YA0E	DTCH272	Control axis detach 2 7th-axis 2nd-phase
YA0F	DTCH282	Control axis detach 2 8th-axis 2nd-phase
YA10	DTCH213	Control axis detach 2 1st-axis 3rd-phase
YA11	DTCH223	Control axis detach 2 2nd-axis 3rd-phase
YA12	DTCH233	Control axis detach 2 3rd-axis 3rd-phase
YA13	DTCH243	Control axis detach 2 4th-axis 3rd-phase
YA14	DTCH253	Control axis detach 2 5th-axis 3rd-phase
YA15	DTCH263	Control axis detach 2 6th-axis 3rd-phase
YA16	DTCH273	Control axis detach 2 7th-axis 3rd-phase
YA17	DTCH283	Control axis detach 2 8th-axis 3rd-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
YA18	DTCH214	Control axis detach 2 1st-axis 4th-phase
YA19	DTCH224	Control axis detach 2 2nd-axis 4th-phase
YA1A	DTCH234	Control axis detach 2 3rd-axis 4th-phase
YA1B	DTCH244	Control axis detach 2 4th-axis 4th-phase
YA1C	DTCH254	Control axis detach 2 5th-axis 4th-phase
YA1D	DTCH264	Control axis detach 2 6th-axis 4th-phase
YA1E	DTCH274	Control axis detach 2 7th-axis 4th-phase
YA1F	DTCH284	Control axis detach 2 8th-axis 4th-phase
YA20	UCLPF11	Unclamp completion 1st-axis 1st-phase
YA21	UCLPF21	Unclamp completion 2nd-axis 1st-phase
YA22	UCLPF31	Unclamp completion 3rd-axis 1st-phase
YA23	UCLPF41	Unclamp completion 4th-axis 1st-phase
YA24	UCLPF51	Unclamp completion 5th-axis 1st-phase
YA25	UCLPF61	Unclamp completion 6th-axis 1st-phase
YA26	UCLPF71	Unclamp completion 7th-axis 1st-phase
YA27	UCLPF81	Unclamp completion 8th-axis 1st-phase
YA28	UCLPF12	Unclamp completion 1st-axis 2nd-phase
YA29	UCLPF22	Unclamp completion 2nd-axis 2nd-phase
YA2A	UCLPF32	Unclamp completion 3rd-axis 2nd-phase
YA2B	UCLPF42	Unclamp completion 4th-axis 2nd-phase
YA2C	UCLPF52	Unclamp completion 5th-axis 2nd-phase
YA2D	UCLPF62	Unclamp completion 6th-axis 2nd-phase
YA2E	UCLPF72	Unclamp completion 7th-axis 2nd-phase
YA2F	UCLPF82	Unclamp completion 8th-axis 2nd-phase
YA30	UCLPF13	Unclamp completion 1st-axis 3rd-phase
YA31	UCLPF23	Unclamp completion 2nd-axis 3rd-phase
YA32	UCLPF33	Unclamp completion 3rd-axis 3rd-phase
YA33	UCLPF43	Unclamp completion 4th-axis 3rd-phase
YA34	UCLPF53	Unclamp completion 5th-axis 3rd-phase
YA35	UCLPF63	Unclamp completion 6th-axis 3rd-phase
YA36	UCLPF73	Unclamp completion 7th-axis 3rd-phase
YA37	UCLPF83	Unclamp completion 8th-axis 3rd-phase
YA38	UCLPF14	Unclamp completion 1st-axis 4th-phase
YA39	UCLPF24	Unclamp completion 2nd-axis 4th-phase
YA3A	UCLPF34	Unclamp completion 3rd-axis 4th-phase
YA3B	UCLPF44	Unclamp completion 4th-axis 4th-phase
YA3C	UCLPF54	Unclamp completion 5th-axis 4th-phase
YA3D	UCLPF64	Unclamp completion 6th-axis 4th-phase
YA3E	UCLPF74	Unclamp completion 7th-axis 4th-phase
YA3F	UCLPF84	Unclamp completion 8th-axis 4th-phase
YA40	ZR11	Each axis reference position return 1st-axis 1st-phase
YA41	ZR21	Each axis reference position return 2nd-axis 1st-phase
YA42	ZR31	Each axis reference position return 3rd-axis 1st-phase
YA43	ZR41	Each axis reference position return 4th-axis 1st-phase
YA44	ZR51	Each axis reference position return 5th-axis 1st-phase
YA45	ZR61	Each axis reference position return 6th-axis 1st-phase
YA46	ZR71	Each axis reference position return 7th-axis 1st-phase
YA47	ZR81	Each axis reference position return 8th-axis 1st-phase
YA48	ZR12	Each axis reference position return 1st-axis 2nd-phase
YA49	ZR22	Each axis reference position return 2nd-axis 2nd-phase
YA4A	ZR32	Each axis reference position return 3rd-axis 2nd-phase
YA4B	ZR42	Each axis reference position return 4th-axis 2nd-phase
YA4C	ZR52	Each axis reference position return 5th-axis 2nd-phase
YA4D	ZR62	Each axis reference position return 6th-axis 2nd-phase
YA4E	ZR72	Each axis reference position return 7th-axis 2nd-phase
YA4F	ZR82	Each axis reference position return 8th-axis 2nd-phase
YA50	ZR13	Each axis reference position return 1st-axis 3rd-phase
YA51	ZR23	Each axis reference position return 2nd-axis 3rd-phase
YA52	ZR33	Each axis reference position return 3rd-axis 3rd-phase
YA53	ZR43	Each axis reference position return 4th-axis 3rd-phase
YA54	ZR53	Each axis reference position return 5th-axis 3rd-phase
YA55	ZR63	Each axis reference position return 6th-axis 3rd-phase
YA56	ZR73	Each axis reference position return 7th-axis 3rd-phase
YA57	ZR83	Each axis reference position return 8th-axis 3rd-phase
YA58	ZR14	Each axis reference position return 1st-axis 4th-phase
YA59	ZR24	Each axis reference position return 2nd-axis 4th-phase
YA5A	ZR34	Each axis reference position return 3rd-axis 4th-phase
YA5B	ZR44	Each axis reference position return 4th-axis 4th-phase
YA5C	ZR54	Each axis reference position return 5th-axis 4th-phase
YA5D	ZR64	Each axis reference position return 6th-axis 4th-phase
YA5E	ZR74	Each axis reference position return 7th-axis 4th-phase
YA5F	ZR84	Each axis reference position return 8th-axis 4th-phase
YA60		Mixed synchronization control request 1st axis 1st-phase
YA61		Mixed synchronization control request 2nd axis 1st-phase
YA62		Mixed synchronization control request 3rd axis 1st-phase
YA63		Mixed synchronization control request 4th axis 1st-phase
YA64		Mixed synchronization control request 5th axis 1st-phase
YA65		Mixed synchronization control request 6th axis 1st-phase
YA66		Mixed synchronization control request 7th axis 1st-phase
YA67		Mixed synchronization control request 8th axis 1st-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
YA68		Mixed synchronization control request 1st axis 2nd-phase
YA69		Mixed synchronization control request 2nd axis 2nd-phase
YA6A		Mixed synchronization control request 3rd axis 2nd-phase
YA6B		Mixed synchronization control request 4th axis 2nd-phase
YA6C		Mixed synchronization control request 5th axis 2nd-phase
YA6D		Mixed synchronization control request 6th axis 2nd-phase
YA6E		Mixed synchronization control request 7th axis 2nd-phase
YA6F		Mixed synchronization control request 8th axis 2nd-phase
YA70		Mixed synchronization control request 1st axis 3rd-phase
YA71		Mixed synchronization control request 2nd axis 3rd-phase
YA72		Mixed synchronization control request 3rd axis 3rd-phase
YA73		Mixed synchronization control request 4th axis 3rd-phase
YA74		Mixed synchronization control request 5th axis 3rd-phase
YA75		Mixed synchronization control request 6th axis 3rd-phase
YA76		Mixed synchronization control request 7th axis 3rd-phase
YA77		Mixed synchronization control request 8th axis 3rd-phase
YA78		Mixed synchronization control request 1st axis 4th-phase
YA79		Mixed synchronization control request 2nd axis 4th-phase
YA7A		Mixed synchronization control request 3rd axis 4th-phase
YA7B		Mixed synchronization control request 4th axis 4th-phase
YA7C		Mixed synchronization control request 5th axis 4th-phase
YA7D		Mixed synchronization control request 6th axis 4th-phase
YA7E		Mixed synchronization control request 7th axis 4th-phase
YA7F		Mixed synchronization control request 8th axis 4th-phase
YA80	SYNC11	Synchronous control request 1st axis 1st-phase
YA81	SYNC21	Synchronous control request 2nd axis 1st-phase
YA82	SYNC31	Synchronous control request 3rd axis 1st-phase
YA83	SYNC41	Synchronous control request 4th axis 1st-phase
YA84	SYNC51	Synchronous control request 5th axis 1st-phase
YA85	SYNC61	Synchronous control request 6th axis 1st-phase
YA86	SYNC71	Synchronous control request 7th axis 1st-phase
YA87	SYNC81	Synchronous control request 8th axis 1st-phase
YA88	SYNC12	Synchronous control request 1st axis 2nd-phase
YA89	SYNC22	Synchronous control request 2nd axis 2nd-phase
YA8A	SYNC32	Synchronous control request 3rd axis 2nd-phase
YA8B	SYNC42	Synchronous control request 4th axis 2nd-phase
YA8C	SYNC52	Synchronous control request 5th axis 2nd-phase
YA8D	SYNC62	Synchronous control request 6th axis 2nd-phase
YA8E	SYNC72	Synchronous control request 7th axis 2nd-phase
YA8F	SYNC82	Synchronous control request 8th axis 2nd-phase
YA90	SYNC13	Synchronous control request 1st axis 3rd-phase
YA91	SYNC23	Synchronous control request 2nd axis 3rd-phase
YA92	SYNC33	Synchronous control request 3rd axis 3rd-phase
YA93	SYNC43	Synchronous control request 4th axis 3rd-phase
YA94	SYNC53	Synchronous control request 5th axis 3rd-phase
YA95	SYNC63	Synchronous control request 6th axis 3rd-phase
YA96	SYNC73	Synchronous control request 7th axis 3rd-phase
YA97	SYNC83	Synchronous control request 8th axis 3rd-phase
YA98	SYNC14	Synchronous control request 1st axis 4th-phase
YA99	SYNC24	Synchronous control request 2nd axis 4th-phase
YA9A	SYNC34	Synchronous control request 3rd axis 4th-phase
YA9B	SYNC44	Synchronous control request 4th axis 4th-phase
YA9C	SYNC54	Synchronous control request 5th axis 4th-phase
YA9D	SYNC64	Synchronous control request 6th axis 4th-phase
YA9E	SYNC74	Synchronous control request 7th axis 4th-phase
YA9F	SYNC84	Synchronous control request 8th axis 4th-phase
YAA0	PILE11	Superimposition control request 1st axis 1st-phase
YAA1	PILE21	Superimposition control request 2nd axis 1st-phase
YAA2	PILE31	Superimposition control request 3rd axis 1st-phase
YAA3	PILE41	Superimposition control request 4th axis 1st-phase
YAA4	PILE51	Superimposition control request 5th axis 1st-phase
YAA5	PILE61	Superimposition control request 6th axis 1st-phase
YAA6	PILE71	Superimposition control request 7th axis 1st-phase
YAA7	PILE81	Superimposition control request 8th axis 1st-phase
YAA8	PILE12	Superimposition control request 1st axis 2nd-phase
YAA9	PILE22	Superimposition control request 2nd axis 2nd-phase
YAAA	PILE32	Superimposition control request 3rd axis 2nd-phase
YAAB	PILE42	Superimposition control request 4th axis 2nd-phase
YAAC	PILE52	Superimposition control request 5th axis 2nd-phase
YAAD	PILE62	Superimposition control request 6th axis 2nd-phase
YAAE	PILE72	Superimposition control request 7th axis 2nd-phase
YAAF	PILE82	Superimposition control request 8th axis 2nd-phase
YAB0	PILE13	Superimposition control request 1st axis 3rd-phase
YAB1	PILE23	Superimposition control request 2nd axis 3rd-phase
YAB2	PILE33	Superimposition control request 3rd axis 3rd-phase
YAB3	PILE43	Superimposition control request 4th axis 3rd-phase
YAB4	PILE53	Superimposition control request 5th axis 3rd-phase
YAB5	PILE63	Superimposition control request 6th axis 3rd-phase
YAB6	PILE73	Superimposition control request 7th axis 3rd-phase
YAB7	PILE83	Superimposition control request 8th axis 3rd-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
YAB8	PILE14	Superimposition control request 1st axis 4th-phase
YAB9	PILE24	Superimposition control request 2nd axis 4th-phase
YABA	PILE34	Superimposition control request 3rd axis 4th-phase
YABB	PILE44	Superimposition control request 4th axis 4th-phase
YABC	PILE54	Superimposition control request 5th axis 4th-phase
YABD	PILE64	Superimposition control request 6th axis 4th-phase
YABE	PILE74	Superimposition control request 7th axis 4th-phase
YABF	PILE84	Superimposition control request 8th axis 4th-phase
YAC0		NC axis control selection 1st axis 1st-phase
YAC1		NC axis control selection 2nd axis 1st-phase
YAC2		NC axis control selection 3rd axis 1st-phase
YAC3		NC axis control selection 4th axis 1st-phase
YAC4		NC axis control selection 5th axis 1st-phase
YAC5		NC axis control selection 6th axis 1st-phase
YAC6		NC axis control selection 7th axis 1st-phase
YAC7		NC axis control selection 8th axis 1st-phase
YAC8		NC axis control selection 1st axis 2nd-phase
YAC9		NC axis control selection 2nd axis 2nd-phase
YACA		NC axis control selection 3rd axis 2nd-phase
YACB		NC axis control selection 4th axis 2nd-phase
YACC		NC axis control selection 5th axis 2nd-phase
YACD		NC axis control selection 6th axis 2nd-phase
YACE		NC axis control selection 7th axis 2nd-phase
YACF		NC axis control selection 8th axis 2nd-phase
YAD0		NC axis control selection 1st axis 3rd-phase
YAD1		NC axis control selection 2nd axis 3rd-phase
YAD2		NC axis control selection 3rd axis 3rd-phase
YAD3		NC axis control selection 4th axis 3rd-phase
YAD4		NC axis control selection 5th axis 3rd-phase
YAD5		NC axis control selection 6th axis 3rd-phase
YAD6		NC axis control selection 7th axis 3rd-phase
YAD7		NC axis control selection 8th axis 3rd-phase
YAD8		NC axis control selection 1st axis 4th-phase
YAD9		NC axis control selection 2nd axis 4th-phase
YADA		NC axis control selection 3rd axis 4th-phase
YADB		NC axis control selection 4th axis 4th-phase
YADC		NC axis control selection 5th axis 4th-phase
YADD		NC axis control selection 6th axis 4th-phase
YADE		NC axis control selection 7th axis 4th-phase
YADF		NC axis control selection 8th axis 4th-phase
YC00	J1	Jog mode 1st-phase
YC01	H1	Handle mode 1st-phase
YC02	S1	Incremental mode 1st-phase
YC03	PTP1	Manual arbitrary feed mode 1st-phase
YC04	ZRN1	Reference position return mode 1st-phase
YC05	AST1	Automatic initialization mode 1st-phase
YC08	MEM1	Memory mode 1st-phase
YC09	T1	Tape mode 1st-phase
YCOA		Online operation mode (Computer link B) 1st-phase
YCOB	D1	MDI mode 1st-phase
YC10	ST1	Automatic operation "start" command (Cycle start) 1st-phase
YC11	*SP1	Automatic operation "pause" command (Feed hold) 1st-phase
YC12	SBK1	Single block 1st-phase
YC13	*BSL1	Block start interlock 1st-phase
YC14	*CSL1	Cutting block start interlock 1st-phase
YC15	DRN1	Dry run 1st-phase
YC17	ERD1	Error detection 1st-phase
YC18	NRST11	NC reset 1 1st-phase
YC19	NRST21	NC reset 2 1st-phase
YC1A	RRW1	Reset & rewind 1st-phase
YC1B	*CDZ1	Chamfering 1st-phase
YC1C	ARST1	Automatic restart 1st-phase
YC1D	EXTSS1	External search strobe 1st-phase
YC1E	FIN11	M function finish 1 1st-phase
YC1F	FIN21	M function finish 2 1st-phase
YC20	TLM1	Tool length measurement 1 1st-phase
YC21	TLMS1	Tool length measurement 2 1st-phase
YC22	SYCM1	Synchronization correction mode 1st-phase
YC23	PRST1	Program restart 1st-phase
YC24	PB1	Playback 1st-phase
YC25	UIT1	Macro interrupt 1st-phase
YC26	RT1	Rapid traverse 1st-phase
YC27		Reverse run 1st-phase
YC28	ABS1	Manual absolute 1st-phase
YC29	DLK1	Display lock 1st-phase
YC2A	F1D1	F1-digit speed change valid 1st-phase
YC2B	CRQ1	Recalculation request 1st-phase
YC2C	QEMG1	PLC emergency stop 1st-phase
YC2D	RTN1	Reference position retract 1st-phase
YC2E	PIT1	PLC interrupt 1st-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
YC30	CHPS1	Chopping 1st-phase
YC31	RSST1	Search & start 1st-phase
YC32		Magazine index check valid (ATC high-speed) 1st-phase
YC34		Chopping parameter valid 1st-phase
YC35		Inclined axis control valid 1st-phase
YC36		Inclined axis control:no z axis compensation 1st-phase
YC37	BDT11	Optional block skip 1 1st-phase
YC38	BDT21	Optional block skip 2 1st-phase
YC39	BDT31	Optional block skip 3 1st-phase
YC3A	BDT41	Optional block skip 4 1st-phase
YC3B	BDT51	Optional block skip 5 1st-phase
YC3C	BDT61	Optional block skip 6 1st-phase
YC3D	BDT71	Optional block skip 7 1st-phase
YC3E	BDT81	Optional block skip 8 1st-phase
YC3F	BDT91	Optional block skip 9 1st-phase
YC40	HS111	1st handle axis selection code 1 1st-phase
YC41	HS121	1st handle axis selection code 2 1st-phase
YC42	HS141	1st handle axis selection code 4 1st-phase
YC43	HS181	1st handle axis selection code 8 1st-phase
YC44	HS1161	1st handle axis selection code 16 1st-phase
YC47	HS1S1	1st handle valid 1st-phase
YC48	HS211	2nd handle axis selection code 1 1st-phase
YC49	HS221	2nd handle axis selection code 2 1st-phase
YC4A	HS241	2nd handle axis selection code 4 1st-phase
YC4B	HS281	2nd handle axis selection code 8 1st-phase
YC4C	HS2161	2nd handle axis selection code 16 1st-phase
YC4F	HS2S1	2nd handle valid 1st-phase
YC50	HS311	3rd handle axis selection code 1 1st-phase
YC51	HS321	3rd handle axis selection code 2 1st-phase
YC52	HS341	3rd handle axis selection code 4 1st-phase
YC53	HS381	3rd handle axis selection code 8 1st-phase
YC54	HS3161	3rd handle axis selection code 16 1st-phase
YC57	HS3S1	3rd handle valid 1st-phase
YC58	OVC1	Override cancel 1st-phase
YC59	OVSL1	Manual override method selection 1st-phase
YC5A	AFL1	Miscellaneous function lock 1st-phase
YC5C	TRV1	Tap retract 1st-phase
YC5E		Tool handle feed mode 1st-phase
YC60	*FV111	Cutting feedrate override code 1 1st-phase
YC61	*FV121	Cutting feedrate override code 2 1st-phase
YC62	*FV141	Cutting feedrate override code 4 1st-phase
YC63	*FV181	Cutting feedrate override code 8 1st-phase
YC64	*FV1161	Cutting feedrate override code 16 1st-phase
YC66	FV2E1	2nd cutting feedrate override valid 1st-phase
YC67	FVS1	Cutting feedrate override method selection 1st-phase
YC68	ROV11	Rapid traverse override code 1 1st-phase
YC69	ROV21	Rapid traverse override code 2 1st-phase
YC6F	ROVS1	Rapid traverse override method selection 1st-phase
YC70	*JV11	Manual feedrate code 1 1st-phase
YC71	*JV21	Manual feedrate code 2 1st-phase
YC72	*JV41	Manual feedrate code 4 1st-phase
YC73	*JV81	Manual feedrate code 8 1st-phase
YC74	*JV161	Manual feedrate code 16 1st-phase
YC77	JVS1	Manual feedrate method selection 1st-phase
YC78	PCF11	Feedrate least increment code 1 1st-phase
YC79	PCF21	Feedrate least increment code 2 1st-phase
YC7A	JSYN1	Jog synchronous feed valid 1st-phase
YC7B	JHAN1	Jog handle synchronous 1st-phase
YC7C		Each axis manual feedrate B valid 1st-phase
YC7D		Manual feedrate B surface speed control valid 1st-phase
YC7E		Circular feed in manual mode valid 1st-phase
YC80	MP11	Handle/incremental feed multiplication code 1 1st-phase
YC81	MP21	Handle/incremental feed multiplication code 2 1st-phase
YC82	MP41	Handle/incremental feed multiplication code 4 1st-phase
YC86	MPP1	Magnification valid for each handle 1st-phase
YC87	MPS1	Handle/incremental feed magnification method selection 1st-phase
YC88	TAL11	Tool alarm 1/Tool skip 1 1st-phase
YC89	TAL21	Tool alarm 2 1st-phase
YC8A	TCEF1	Usage data count valid 1st-phase
YC8B	TLF11	Tool life management input 1st-phase
YC8C	TCRT1	Tool change reset 1st-phase
YC8D		Tool escape and return transit point designation 1st-phase
YC90	ZSL11	Reference position selection code 1 1st-phase
YC91	ZSL21	Reference position selection code 2 1st-phase
YC92		Tool length compensation along the tool axis compensation amount change mode 1st-phase
YC97	M1	Reference position selection method 1st-phase
YC9D		Manual speed command valid 1st-phase
YC9E		Manual speed command sign reversed 1st-phase
YC9F		Manual speed command reverse run valid 1st-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
YCA0	CX111	Manual arbitrary feed 1st axis selection code 1 1st-phase
YCA1	CX121	Manual arbitrary feed 1st axis selection code 2 1st-phase
YCA2	CX141	Manual arbitrary feed 1st axis selection code 4 1st-phase
YCA3	CX181	Manual arbitrary feed 1st axis selection code 8 1st-phase
YCA4	CX1161	Manual arbitrary feed 1st axis selection code 16 1st-phase
YCA7	CX1S1	Manual arbitrary feed 1st axis valid 1st-phase
YCA8	CX211	Manual arbitrary feed 2nd axis selection code 1 1st-phase
YCA9	CX221	Manual arbitrary feed 2nd axis selection code 2 1st-phase
YCAA	CX241	Manual arbitrary feed 2nd axis selection code 4 1st-phase
YCAC	CX281	Manual arbitrary feed 2nd axis selection code 8 1st-phase
YCAC	CX2161	Manual arbitrary feed 2nd axis selection code 16 1st-phase
YCAF	CX2S1	Manual arbitrary feed 2nd axis valid 1st-phase
YCB0	CX311	Manual arbitrary feed 3rd axis selection code 1 1st-phase
YCB1	CX321	Manual arbitrary feed 3rd axis selection code 2 1st-phase
YCB2	CX341	Manual arbitrary feed 3rd axis selection code 4 1st-phase
YCB3	CX381	Manual arbitrary feed 3rd axis selection code 8 1st-phase
YCB4	CX3161	Manual arbitrary feed 3rd axis selection code 16 1st-phase
YCB7	CX3S1	Manual arbitrary feed 3rd axis valid 1st-phase
YCB8	CXS11	Manual arbitrary feed smoothing off 1st-phase
YCB9	CXS21	Manual arbitrary feed axis independent 1st-phase
YCBA	CXS31	Manual arbitrary feed EX.F/MODAL.F 1st-phase
YCBB	CXS41	Manual arbitrary feed G0/G1 1st-phase
YCBC	CXS51	Manual arbitrary feed MC/WK 1st-phase
YCBD	CXS61	Manual arbitrary feed ABS/INC 1st-phase
YCBE	*CXS71	Manual arbitrary feed stop 1st-phase
YCBF	CXS81	Manual arbitrary feed strobe 1st-phase
YCC0	ILM11	Current limit mode 1 1st-phase
YCC1	ILM21	Current limit mode 2 1st-phase
YCC3	LDWT1	Load monitor execution 1st-phase
YCC4		Load monitor teaching mode 1st-phase
YCC5		Load monitor monitor mode 1st-phase
YCC6		Load monitor alarm reset 1st-phase
YCC7		Load monitor warning reset 1st-phase
YCC8	*ZRIT1	2nd reference position return interlock 1st-phase
YCC9		Adaptive control execution 1st-phase
YCCA		Small diameter deep hole drilling cycle 1st-phase
YCCB		Chuck barrier on 1st-phase
YCCC		High-speed retract function valid 1st-phase
YCD0		Waiting ignore 1st-phase
YCD1		Spindle-spindle polygon cancel 1st-phase
YCD2		Synchronous tapping command polarity reversal 1st-phase
YCD3		Spindle off mode 1st-phase
YCD4		Longitudinal hole drilling axis selection 1st-phase
YCD8		Barrier valid (left) 1st-phase
YCD9		Barrier valid (right) 1st-phase
YCDA		Tool presetter sub-side valid 1st-phase
YCDB		Movable area clamping 1st-phase
YCE1	DOOR21	Door open II 1st-phase
YCE2		Door open signal input(spindle speed monitor) 1st-phase
YCE3		Door interlock spindle speed clamp 1st-phase
YCE8		Door open II (2 channels per 1 part system) 1st-phase
YCE9		Door open II (3 channels per 1 part system) Spare 1st-phase
YCF4	BCHK1	Barrier check invalid 1st-phase
YCFA	DRNC1	Dry run invalid 1st-phase
YCFB	AUTED1	Automatic error detection 1st-phase
YD08	RVSP	Reverse run from block start 1st-phase
YD09	RVIT	Macro interrupt priority 1st-phase
YD0A	RVMD	Reverse run control mode 1st-phase
YD40	J2	Jog mode 2nd-phase
YD41	H2	Handle mode 2nd-phase
YD42	S2	Incremental mode 2nd-phase
YD43	PTP2	Manual arbitrary feed mode 2nd-phase
YD44	ZRN2	Reference position return mode 2nd-phase
YD45	AST2	Automatic initialization mode 2nd-phase
YD48	MEM2	Memory mode 2nd-phase
YD49	T2	Tape mode 2nd-phase
YD4A		Online operation mode (Computer link B) 2nd-phase
YD4B	D2	MDI mode 2nd-phase
YD50	ST2	Automatic operation "start" command (Cycle start) 2nd-phase
YD51	*SP2	Automatic operation "pause" command (Feed hold) 2nd-phase
YD52	SBK2	Single block 2nd-phase
YD53	*BSL2	Block start interlock 2nd-phase
YD54	*CSL2	Cutting block start interlock 2nd-phase
YD55	DRN2	Dry run 2nd-phase
YD57	ERD2	Error detection 2nd-phase
YD58	NRST12	NC reset 1 2nd-phase
YD59	NRST22	NC reset 2 2nd-phase
YD5A	RRW2	Reset & rewind 2nd-phase
YD5B	*CDZ2	Chamfering 2nd-phase
YD5C	ARST2	Automatic restart 2nd-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
YD5D	EXTSS2	External search strobe 2nd-phase
YD5E	FIN12	M function finish 1 2nd-phase
YD5F	FIN22	M function finish 2 2nd-phase
YD60	TLM2	Tool length measurement 1 2nd-phase
YD61	TLMS2	Tool length measurement 2 2nd-phase
YD62	SYCM2	Synchronization correction mode 2nd-phase
YD63	PRST2	Program restart 2nd-phase
YD64	PB2	Playback 2nd-phase
YD65	UIT2	Macro interrupt 2nd-phase
YD66	RT2	Rapid traverse 2nd-phase
YD67		Reverse run 2nd-phase
YD68	ABS2	Manual absolute 2nd-phase
YD69	DLK2	Display lock 2nd-phase
YD6A	F1D2	F1-digit speed change valid 2nd-phase
YD6B	CRQ2	Recalculation request 2nd-phase
YD6C	QEMG2	PLC emergency stop 2nd-phase
YD6D	RTN2	Reference position retract 2nd-phase
YD6E	PIT2	PLC interrupt 2nd-phase
YD70	CHPS2	Chopping 2nd-phase
YD71	RSST2	Search & start 2nd-phase
YD72		Magazine index check valid (ATC high-speed) 2nd-phase
YD74		Chopping parameter valid 2nd-phase
YD75		Inclined axis control valid 2nd-phase
YD76		Inclined axis control: no z axis compensation 2nd-phase
YD77	BDT12	Optional block skip 1 2nd-phase
YD78	BDT22	Optional block skip 2 2nd-phase
YD79	BDT32	Optional block skip 3 2nd-phase
YD7A	BDT42	Optional block skip 4 2nd-phase
YD7B	BDT52	Optional block skip 5 2nd-phase
YD7C	BDT62	Optional block skip 6 2nd-phase
YD7D	BDT72	Optional block skip 7 2nd-phase
YD7E	BDT82	Optional block skip 8 2nd-phase
YD7F	BDT92	Optional block skip 9 2nd-phase
YD80	HS112	1st handle axis selection code 1 2nd-phase
YD81	HS122	1st handle axis selection code 2 2nd-phase
YD82	HS142	1st handle axis selection code 4 2nd-phase
YD83	HS182	1st handle axis selection code 8 2nd-phase
YD84	HS1162	1st handle axis selection code 16 2nd-phase
YD87	HS1S2	1st handle valid 2nd-phase
YD88	HS212	2nd handle axis selection code 1 2nd-phase
YD89	HS222	2nd handle axis selection code 2 2nd-phase
YD8A	HS242	2nd handle axis selection code 4 2nd-phase
YD8B	HS282	2nd handle axis selection code 8 2nd-phase
YD8C	HS2162	2nd handle axis selection code 16 2nd-phase
YD8F	HS2S2	2nd handle valid 2nd-phase
YD90	HS312	3rd handle axis selection code 1 2nd-phase
YD91	HS322	3rd handle axis selection code 2 2nd-phase
YD92	HS342	3rd handle axis selection code 4 2nd-phase
YD93	HS382	3rd handle axis selection code 8 2nd-phase
YD94	HS3162	3rd handle axis selection code 16 2nd-phase
YD97	HS3S2	3rd handle valid 2nd-phase
YD98	OVC2	Override cancel 2nd-phase
YD99	OVSL2	Manual override method selection 2nd-phase
YD9A	AFL2	Miscellaneous function lock 2nd-phase
YD9C	TRV2	Tap retract 2nd-phase
YD9E		Tool handle feed mode 2nd-phase
YDA0	*FV112	Cutting feedrate override code 1 2nd-phase
YDA1	*FV122	Cutting feedrate override code 2 2nd-phase
YDA2	*FV142	Cutting feedrate override code 4 2nd-phase
YDA3	*FV182	Cutting feedrate override code 8 2nd-phase
YDA4	*FV1162	Cutting feedrate override code 16 2nd-phase
YDA6	FV2E2	2nd cutting feedrate override valid 2nd-phase
YDA7	FVS2	Cutting feedrate override method selection 2nd-phase
YDA8	ROV12	Rapid traverse override code 1 2nd-phase
YDA9	ROV22	Rapid traverse override code 2 2nd-phase
YDAF	ROVS2	Rapid traverse override method selection 2nd-phase
YDB0	*JV12	Manual feedrate code 1 2nd-phase
YDB1	*JV22	Manual feedrate code 2 2nd-phase
YDB2	*JV42	Manual feedrate code 4 2nd-phase
YDB3	*JV82	Manual feedrate code 8 2nd-phase
YDB4	*JV162	Manual feedrate code 16 2nd-phase
YDB7	JVS2	Manual feedrate method selection 2nd-phase
YDB8	PCF12	Feedrate least increment code 1 2nd-phase
YDB9	PCF22	Feedrate least increment code 2 2nd-phase
YDBA	JSYN2	Jog synchronous feed valid 2nd-phase
YDBB	JHAN2	Jog•handle synchronous 2nd-phase
YDBC		Each axis manual feedrate B valid 2nd-phase
YDBD		Manual feedrate B surface speed control valid 2nd-phase
YDBE		Circular feed in manual mode valid 2nd-phase
YDC0	MP12	Handle/incremental feed multiplication code 1 2nd-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
YDC1	MP22	Handle/incremental feed multiplication code 2 2nd-phase
YDC2	MP42	Handle/incremental feed multiplication code 4 2nd-phase
YDC6	MPP2	Magnification valid for each handle 2nd-phase
YDC7	MPS2	Handle/incremental feed magnification method selection 2nd-phase
YDC8	TAL12	Tool alarm 1/Tool skip 1 2nd-phase
YDC9	TAL22	Tool alarm 2 2nd-phase
YDCA	TCEF2	Usage data count valid 2nd-phase
YDCB	TLF12	Tool life management input 2nd-phase
YDCC	TCRT2	Tool change reset 2nd-phase
YDCD		Tool escape and return transit point designation 2nd-phase
YDD0	ZSL12	Reference position selection code 1 2nd-phase
YDD1	ZSL22	Reference position selection code 2 2nd-phase
YDD2		Tool length compensation along the tool axis compensation amount change mode 2nd-phase
YDD7	M2	Reference position selection method 2nd-phase
YDDD		Manual speed command valid 2nd-phase
YDDE		Manual speed command sign reversed 2nd-phase
YDDF		Manual speed command reverse run valid 2nd-phase
YDE0	CX112	Manual arbitrary feed 1st axis selection code 1 2nd-phase
YDE1	CX122	Manual arbitrary feed 1st axis selection code 2 2nd-phase
YDE2	CX142	Manual arbitrary feed 1st axis selection code 4 2nd-phase
YDE3	CX182	Manual arbitrary feed 1st axis selection code 8 2nd-phase
YDE4	CX1162	Manual arbitrary feed 1st axis selection code 16 2nd-phase
YDE7	CX1S2	Manual arbitrary feed 1st axis valid 2nd-phase
YDE8	CX212	Manual arbitrary feed 2nd axis selection code 1 2nd-phase
YDE9	CX222	Manual arbitrary feed 2nd axis selection code 2 2nd-phase
YDEA	CX242	Manual arbitrary feed 2nd axis selection code 4 2nd-phase
YDEB	CX282	Manual arbitrary feed 2nd axis selection code 8 2nd-phase
YDEC	CX2162	Manual arbitrary feed 2nd axis selection code 16 2nd-phase
YDEF	CX2S2	Manual arbitrary feed 2nd axis valid 2nd-phase
YDF0	CX312	Manual arbitrary feed 3rd axis selection code 1 2nd-phase
YDF1	CX322	Manual arbitrary feed 3rd axis selection code 2 2nd-phase
YDF2	CX342	Manual arbitrary feed 3rd axis selection code 4 2nd-phase
YDF3	CX382	Manual arbitrary feed 3rd axis selection code 8 2nd-phase
YDF4	CX3162	Manual arbitrary feed 3rd axis selection code 16 2nd-phase
YDF7	CX3S2	Manual arbitrary feed 3rd axis valid 2nd-phase
YDF8	CXS12	Manual arbitrary feed smoothing off 2nd-phase
YDF9	CXS22	Manual arbitrary feed axis independent 2nd-phase
YDFA	CXS32	Manual arbitrary feed EX.F/MODAL.F 2nd-phase
YDFB	CXS42	Manual arbitrary feed G0/G1 2nd-phase
YDFC	CXS52	Manual arbitrary feed MC/WK 2nd-phase
YDFD	CXS62	Manual arbitrary feed ABS/INC 2nd-phase
YDFE	*CXS72	Manual arbitrary feed stop 2nd-phase
YDFF	CXS82	Manual arbitrary feed strobe 2nd-phase
YE00	ILM12	Current limit mode 1 2nd-phase
YE01	ILM22	Current limit mode 2 2nd-phase
YE03	LDWT2	Load monitor execution 2nd-phase
YE04		Load monitor teaching mode 2nd-phase
YE05		Load monitor monitor mode 2nd-phase
YE06		Load monitor alarm reset 2nd-phase
YE07		Load monitor warning reset 2nd-phase
YE08	*ZRIT2	2nd reference position return interlock 2nd-phase
YE09		Adaptive control execution 2nd-phase
YE0A		Small diameter deep hole drilling cycle 2nd-phase
YE0B		Chuck barrier on 2nd-phase
YE0C		High-speed retract function valid 2nd-phase
YE10		Waiting ignore 2nd-phase
YE11		Spindle-spindle polygon cancel 2nd-phase
YE12		Synchronous tapping command polarity reversal 2nd-phase
YE13		Spindle off mode 2nd-phase
YE13		Longitudinal hole drilling axis selection 2nd-phase
YE18		Barrier valid (left) 2nd-phase
YE19		Barrier valid (right) 2nd-phase
YE1A		Tool presetter sub-side valid 2nd-phase
YE1B		Movable area clamping 2nd-phase
YE21	DOOR22	Door open II 2nd-phase
YE22		Door open signal input(spindle speed monitor) 2nd-phase
YE23		Door interlock spindle speed clamp 2nd-phase
YE28		Door open II (2 channels per 1 part system) 2nd-phase
YE29		Door open II (3 channels per 1 part system) Spare 2nd-phase
YE34	BCHK2	Barrier check invalid 2nd-phase
YE3A	DRNC2	Dry run invalid 2nd-phase
YE3B	AUTED2	Automatic error detection 2nd-phase
YE48	RVSP	Reverse run from block start 2nd-phase
YE49	RVIT	Macro interrupt priority 2nd-phase
YE4A	RVMD	Reverse run control mode 2nd-phase
YE80	J3	Jog mode 3rd-phase
YE81	H3	Handle mode 3rd-phase
YE82	S3	Incremental mode 3rd-phase
YE83	PTP3	Manual arbitrary feed mode 3rd-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
YE84	ZRN3	Reference position return mode 3rd-phase
YE85	AST3	Automatic initialization mode 3rd-phase
YE88	MEM3	Memory mode 3rd-phase
YE89	T3	Tape mode 3rd-phase
YE8A		Online operation mode (Computer link B) 3rd-phase
YE8B	D3	MDI mode 3rd-phase
YE90	ST3	Automatic operation "start" command (Cycle start) 3rd-phase
YE91	*SP3	Automatic operation "pause" command (Feed hold) 3rd-phase
YE92	SBK3	Single block 3rd-phase
YE93	*BSL3	Block start interlock 3rd-phase
YE94	*CSL3	Cutting block start interlock 3rd-phase
YE95	DRN3	Dry run 3rd-phase
YE97	ERD3	Error detection 3rd-phase
YE98	NRST13	NC reset 1 3rd-phase
YE99	NRST23	NC reset 2 3rd-phase
YE9A	RRW3	Reset & rewind 3rd-phase
YE9B	*CDZ3	Chamfering 3rd-phase
YE9C	ARST3	Automatic restart 3rd-phase
YE9D	EXTSS3	External search strobe 3rd-phase
YE9E	FIN13	M function finish 1 3rd-phase
YE9F	FIN23	M function finish 2 3rd-phase
YEAO	TLM3	Tool length measurement 1 3rd-phase
YEA1	TLMS3	Tool length measurement 2 3rd-phase
YEA2	SYCM3	Synchronization correction mode 3rd-phase
YEA3	PRST3	Program restart 3rd-phase
YEA4	PB3	Playback 3rd-phase
YEA5	UIT3	Macro interrupt 3rd-phase
YEA6	RT3	Rapid traverse 3rd-phase
YEA7		Reverse run 3rd-phase
YEA8	ABS3	Manual absolute 3rd-phase
YEA9	DLK3	Display lock 3rd-phase
YEA A	F1D3	F1-digit speed change valid 3rd-phase
YEA B	CRQ3	Recalculation request 3rd-phase
YEA C	QEMG3	PLC emergency stop 3rd-phase
YEA D	RTN3	Reference position retract 3rd-phase
YEA E	PIT3	PLC interrupt 3rd-phase
YEB0	CHPS3	Chopping 3rd-phase
YEB1	RSST3	Search & start 3rd-phase
YEB2		Magazine index check valid (ATC high-speed) 3rd-phase
YEB4		Chopping parameter valid 3rd-phase
YEB5		Inclined axis control valid 3rd-phase
YEB6		Inclined axis control:no z axis compensation 3rd-phase
YEB7	BDT13	Optional block skip 1 3rd-phase
YEB8	BDT23	Optional block skip 2 3rd-phase
YEB9	BDT33	Optional block skip 3 3rd-phase
YEB A	BDT43	Optional block skip 4 3rd-phase
YEB B	BDT53	Optional block skip 5 3rd-phase
YEB C	BDT63	Optional block skip 6 3rd-phase
YEB D	BDT73	Optional block skip 7 3rd-phase
YEB E	BDT83	Optional block skip 8 3rd-phase
YEB F	BDT93	Optional block skip 9 3rd-phase
YEC0	HS113	1st handle axis selection code 1 3rd-phase
YEC1	HS123	1st handle axis selection code 2 3rd-phase
YEC2	HS143	1st handle axis selection code 4 3rd-phase
YEC3	HS183	1st handle axis selection code 8 3rd-phase
YEC4	HS1163	1st handle axis selection code 16 3rd-phase
YEC7	HS1S3	1st handle valid 3rd-phase
YEC8	HS213	2nd handle axis selection code 1 3rd-phase
YEC9	HS223	2nd handle axis selection code 2 3rd-phase
YEC A	HS243	2nd handle axis selection code 4 3rd-phase
YEC B	HS283	2nd handle axis selection code 8 3rd-phase
YEC C	HS2163	2nd handle axis selection code 16 3rd-phase
YEC F	HS2S3	2nd handle valid 3rd-phase
YED0	HS313	3rd handle axis selection code 1 3rd-phase
YED1	HS323	3rd handle axis selection code 2 3rd-phase
YED2	HS343	3rd handle axis selection code 4 3rd-phase
YED3	HS383	3rd handle axis selection code 8 3rd-phase
YED4	HS3163	3rd handle axis selection code 16 3rd-phase
YED7	HS3S3	3rd handle valid 3rd-phase
YED8	OVC3	Override cancel 3rd-phase
YED9	OVSL3	Manual override method selection 3rd-phase
YEDA	AFL3	Miscellaneous function lock 3rd-phase
YEDC	TRV3	Tap retract 3rd-phase
YEDE		Tool handle feed mode 3rd-phase
YEE0	*FV113	Cutting feedrate override code 1 3rd-phase
YEE1	*FV123	Cutting feedrate override code 2 3rd-phase
YEE2	*FV143	Cutting feedrate override code 4 3rd-phase
YEE3	*FV183	Cutting feedrate override code 8 3rd-phase
YEE4	*FV1163	Cutting feedrate override code 16 3rd-phase
YEE6	FV2E3	2nd cutting feedrate override valid 3rd-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
YEE7	FVS3	Cutting feedrate override method selection 3rd-phase
YEE8	ROV13	Rapid traverse override code 1 3rd-phase
YEE9	ROV23	Rapid traverse override code 2 3rd-phase
YEEF	ROVS3	Rapid traverse override method selection 3rd-phase
YEF0	*JV13	Manual feedrate code 1 3rd-phase
YEF1	*JV23	Manual feedrate code 2 3rd-phase
YEF2	*JV43	Manual feedrate code 4 3rd-phase
YEF3	*JV83	Manual feedrate code 8 3rd-phase
YEF4	*JV163	Manual feedrate code 16 3rd-phase
YEF7	JVS3	Manual feedrate method selection 3rd-phase
YEF8	PCF13	Feedrate least increment code 1 3rd-phase
YEF9	PCF23	Feedrate least increment code 2 3rd-phase
YEFA	JSYN3	Jog synchronous feed valid 3rd-phase
YEFB	JHAN3	Jog*handle synchronous 3rd-phase
YEFC		Each axis manual feedrate B valid 3rd-phase
Yefd		Manual feedrate B surface speed control valid 3rd-phase
YEFE		Circular feed in manual mode valid 3rd-phase
YF00	MP13	Handle/incremental feed multiplication code 1 3rd-phase
YF01	MP23	Handle/incremental feed multiplication code 2 3rd-phase
YF02	MP43	Handle/incremental feed multiplication code 4 3rd-phase
YF06	MPP3	Magnification valid for each handle 3rd-phase
YF07	MPS3	Handle/incremental feed magnification method selection 3rd-phase
YF08	TAL13	Tool alarm 1/Tool skip 1 3rd-phase
YF09	TAL23	Tool alarm 2 3rd-phase
YF0A	TCEF3	Usage data count valid 3rd-phase
YF0B	TLF13	Tool life management input 3rd-phase
YF0C	TCRT3	Tool change reset 3rd-phase
YF0D		Tool escape and return transit point designation 3rd-phase
YF10	ZSL13	Reference position selection code 1 3rd-phase
YF11	ZSL23	Reference position selection code 2 3rd-phase
YF12		Tool length compensation along the tool axis compensation amount change mode 3rd-phase
YF17	M3	Reference position selection method 3rd-phase
YF1D		Manual speed command valid 3rd-phase
YF1E		Manual speed command sign reversed 3rd-phase
YF1F		Manual speed command reverse run valid 3rd-phase
YF20	CX113	Manual arbitrary feed 1st axis selection code 1 3rd-phase
YF21	CX123	Manual arbitrary feed 1st axis selection code 2 3rd-phase
YF22	CX143	Manual arbitrary feed 1st axis selection code 4 3rd-phase
YF23	CX183	Manual arbitrary feed 1st axis selection code 8 3rd-phase
YF24	CX1163	Manual arbitrary feed 1st axis selection code 16 3rd-phase
YF27	CX1S3	Manual arbitrary feed 1st axis valid 3rd-phase
YF28	CX213	Manual arbitrary feed 2nd axis selection code 1 3rd-phase
YF29	CX223	Manual arbitrary feed 2nd axis selection code 2 3rd-phase
YF2A	CX243	Manual arbitrary feed 2nd axis selection code 4 3rd-phase
YF2B	CX283	Manual arbitrary feed 2nd axis selection code 8 3rd-phase
YF2C	CX2163	Manual arbitrary feed 2nd axis selection code 16 3rd-phase
YF2F	CX2S3	Manual arbitrary feed 2nd axis valid 3rd-phase
YF30	CX313	Manual arbitrary feed 3rd axis selection code 1 3rd-phase
YF31	CX323	Manual arbitrary feed 3rd axis selection code 2 3rd-phase
YF32	CX343	Manual arbitrary feed 3rd axis selection code 4 3rd-phase
YF33	CX383	Manual arbitrary feed 3rd axis selection code 8 3rd-phase
YF34	CX3163	Manual arbitrary feed 3rd axis selection code 16 3rd-phase
YF37	CX3S3	Manual arbitrary feed 3rd axis valid 3rd-phase
YF38	CXS13	Manual arbitrary feed smoothing off 3rd-phase
YF39	CXS23	Manual arbitrary feed axis independent 3rd-phase
YF3A	CXS33	Manual arbitrary feed EX.F/MODAL.F 3rd-phase
YF3B	CXS43	Manual arbitrary feed G0/G1 3rd-phase
YF3C	CXS53	Manual arbitrary feed MC/WK 3rd-phase
YF3D	CXS63	Manual arbitrary feed ABS/INC 3rd-phase
YF3E	*CXS73	Manual arbitrary feed stop 3rd-phase
YF3F	CXS83	Manual arbitrary feed strobe 3rd-phase
YF40	ILM13	Current limit mode 1 3rd-phase
YF41	ILM23	Current limit mode 2 3rd-phase
YF43	LDWT3	Load monitor execution 3rd-phase
YF44		Load monitor teaching mode 3rd-phase
YF45		Load monitor monitor mode 3rd-phase
YF46		Load monitor alarm reset 3rd-phase
YF47		Load monitor warning reset 3rd-phase
YF48	*ZRIT3	2nd reference position return interlock 3rd-phase
YF49		Adaptive control execution 3rd-phase
YF4A		Small diameter deep hole drilling cycle 3rd-phase
YF4B		Chuck barrier on 3rd-phase
YF4C		High-speed retract function valid 3rd-phase
YF50		Waiting ignore 3rd-phase
YF51		Spindle-spindle polygon cancel 3rd-phase
YF52		Synchronous tapping command polarity reversal 3rd-phase
YF53		Spindle off mode 3rd-phase
YF53		Longitudinal hole drilling axis selection 3rd-phase
YF58		Barrier valid (left) 3rd-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
YF59		Barrier valid (right) 3rd-phase
YF5A		Tool presetter sub-side valid 3rd-phase
YF5B		Movable area clamping 3rd-phase
YF61	DOOR23	Door open II 3rd-phase
YF62		Door open signal input(spindle speed monitor) 3rd-phase
YF63		Door interlock spindle speed clamp 3rd-phase
YF68		Door open II (2 channels per 1 part system) 3rd-phase
YF69		Door open II (3 channels per 1 part system) Spare 3rd-phase
YF74	BCHK3	Barrier check invalid 3rd-phase
YF7A	DRNC3	Dry run invalid 3rd-phase
YF7B	AUTED3	Automatic error detection 3rd-phase
YF88	RVSP	Reverse run from block start 3rd-phase
YF89	RVIT	Macro interrupt priority 3rd-phase
YF8A	RVMD	Reverse run control mode 3rd-phase
YFC0	J4	Jog mode 4th-phase
YFC1	H4	Handle mode 4th-phase
YFC2	S4	Incremental mode 4th-phase
YFC3	PTP4	Manual arbitrary feed mode 4th-phase
YFC4	ZRN4	Reference position return mode 4th-phase
YFC5	AST4	Automatic initialization mode 4th-phase
YFC8	MEM4	Memory mode 4th-phase
YFC9	T4	Tape mode 4th-phase
YFCA		Online operation mode (Computer link B) 4th-phase
YFCB	D4	MDI mode 4th-phase
YFD0	ST4	Automatic operation "start" command (Cycle start) 4th-phase
YFD1	*SP4	Automatic operation "pause" command (Feed hold) 4th-phase
YFD2	SBK4	Single block 4th-phase
YFD3	*BSL4	Block start interlock 4th-phase
YFD4	*CSL4	Cutting block start interlock 4th-phase
YFD5	DRN4	Dry run 4th-phase
YFD7	ERD4	Error detection 4th-phase
YFD8	NRST14	NC reset 1 4th-phase
YFD9	NRST24	NC reset 2 4th-phase
YFDA	RRW4	Reset & rewind 4th-phase
YFDB	*CDZ4	Chamfering 4th-phase
YFDC	ARST4	Automatic restart 4th-phase
YFDD	EXTSS4	External search strobe 4th-phase
YFDE	FIN14	M function finish 1 4th-phase
YFDF	FIN24	M function finish 2 4th-phase
YFE0	TLM4	Tool length measurement 1 4th-phase
YFE1	TLMS4	Tool length measurement 2 4th-phase
YFE2	SYCM4	Synchronization correction mode 4th-phase
YFE3	PRST4	Program restart 4th-phase
YFE4	PB4	Playback 4th-phase
YFE5	UIT4	Macro interrupt 4th-phase
YFE6	RT4	Rapid traverse 4th-phase
YFE7		Reverse run 4th-phase
YFE8	ABS4	Manual absolute 4th-phase
YFE9	DLK4	Display lock 4th-phase
YFEA	F1D4	F1-digit speed change valid 4th-phase
YFEB	CRQ4	Recalculation request 4th-phase
YFEC	QEMG4	PLC emergency stop 4th-phase
YFED	RTN4	Reference position retract 4th-phase
YFEE	PIT4	PLC interrupt 4th-phase
YFF0	CHPS4	Chopping 4th-phase
YFF1	RSST4	Search & start 4th-phase
YFF2		Magazine index check valid (ATC high-speed) 3rd-phase
YFF4		Chopping parameter valid 4th-phase
YFF5		Inclined axis control valid 4th-phase
YFF6		Inclined axis control:no z axis compensation 4th-phase
YFF7	BDT14	Optional block skip 1 4th-phase
YFF8	BDT24	Optional block skip 2 4th-phase
YFF9	BDT34	Optional block skip 3 4th-phase
YFFA	BDT44	Optional block skip 4 4th-phase
YFFB	BDT54	Optional block skip 5 4th-phase
YFFC	BDT64	Optional block skip 6 4th-phase
YFFD	BDT74	Optional block skip 7 4th-phase
YFFE	BDT84	Optional block skip 8 4th-phase
YFFF	BDT94	Optional block skip 9 4th-phase
Y1000	HS114	1st handle axis selection code 1 4th-phase
Y1001	HS124	1st handle axis selection code 2 4th-phase
Y1002	HS144	1st handle axis selection code 4 4th-phase
Y1003	HS184	1st handle axis selection code 8 4th-phase
Y1004	HS1164	1st handle axis selection code 16 4th-phase
Y1007	HS1S4	1st handle valid 4th-phase
Y1008	HS214	2nd handle axis selection code 1 4th-phase
Y1009	HS224	2nd handle axis selection code 2 4th-phase
Y100A	HS244	2nd handle axis selection code 4 4th-phase
Y100B	HS284	2nd handle axis selection code 8 4th-phase
Y100C	HS2164	2nd handle axis selection code 16 4th-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y100F	HS2S4	2nd handle valid 4th-phase
Y1010	HS314	3rd handle axis selection code 1 4th-phase
Y1011	HS324	3rd handle axis selection code 2 4th-phase
Y1012	HS344	3rd handle axis selection code 4 4th-phase
Y1013	HS384	3rd handle axis selection code 8 4th-phase
Y1014	HS3164	3rd handle axis selection code 16 4th-phase
Y1017	HS3S4	3rd handle valid 4th-phase
Y1018	OVC4	Override cancel 4th-phase
Y1019	OVSL4	Manual override method selection 4th-phase
Y101A	AFL4	Miscellaneous function lock 4th-phase
Y101C	TRV4	Tap retract 4th-phase
Y101E		Tool handle feed mode 4th-phase
Y1020	*FV114	Cutting feedrate override code 1 4th-phase
Y1021	*FV124	Cutting feedrate override code 2 4th-phase
Y1022	*FV144	Cutting feedrate override code 4 4th-phase
Y1023	*FV184	Cutting feedrate override code 8 4th-phase
Y1024	*FV1164	Cutting feedrate override code 16 4th-phase
Y1026	FV2E4	2nd cutting feedrate override valid 4th-phase
Y1027	FVS4	Cutting feedrate override method selection 4th-phase
Y1028	ROV14	Rapid traverse override code 1 4th-phase
Y1029	ROV24	Rapid traverse override code 2 4th-phase
Y102F	ROVS4	Rapid traverse override method selection 4th-phase
Y1030	*JV14	Manual feedrate code 1 4th-phase
Y1031	*JV24	Manual feedrate code 2 4th-phase
Y1032	*JV44	Manual feedrate code 4 4th-phase
Y1033	*JV84	Manual feedrate code 8 4th-phase
Y1034	*JV164	Manual feedrate code 16 4th-phase
Y1037	JVS4	Manual feedrate method selection 4th-phase
Y1038	PCF14	Feedrate least increment code 1 4th-phase
Y1039	PCF24	Feedrate least increment code 2 4th-phase
Y103A	JSYN4	Jog synchronous feed valid 4th-phase
Y103B	JHAN4	Jog handle synchronous 4th-phase
Y103C		Each axis manual feedrate B valid 4th-phase
Y103D		Manual feedrate B surface speed control valid 4th-phase
Y103E		Circular feed in manual mode valid 4th-phase
Y1040	MP14	Handle/incremental feed multiplication code 1 4th-phase
Y1041	MP24	Handle/incremental feed multiplication code 2 4th-phase
Y1042	MP44	Handle/incremental feed multiplication code 4 4th-phase
Y1046	MPP4	Magnification valid for each handle 4th-phase
Y1047	MPS4	Handle/incremental feed magnification method selection 4th-phase
Y1048	TAL14	Tool alarm 1/Tool skip 1 4th-phase
Y1049	TAL24	Tool alarm 2 4th-phase
Y104A	TCEF4	Usage data count valid 4th-phase
Y104B	TLF14	Tool life management input 4th-phase
Y104C	TCRT4	Tool change reset 4th-phase
Y104D		Tool escape and return transit point designation 4th-phase
Y1050	ZSL14	Reference position selection code 1 4th-phase
Y1051	ZSL24	Reference position selection code 2 4th-phase
Y1052		Tool length compensation along the tool axis compensation amount change mode 4th-phase
Y1057	M4	Reference position selection method 4th-phase
Y105D		Manual speed command valid 4th-phase
Y105E		Manual speed command sign reversed 4th-phase
Y105F		Manual speed command reverse run valid 4th-phase
Y1060	CX114	Manual arbitrary feed 1st axis selection code 1 4th-phase
Y1061	CX124	Manual arbitrary feed 1st axis selection code 2 4th-phase
Y1062	CX144	Manual arbitrary feed 1st axis selection code 4 4th-phase
Y1063	CX184	Manual arbitrary feed 1st axis selection code 8 4th-phase
Y1064	CX1164	Manual arbitrary feed 1st axis selection code 16 4th-phase
Y1067	CX1S4	Manual arbitrary feed 1st axis valid 4th-phase
Y1068	CX214	Manual arbitrary feed 2nd axis selection code 1 4th-phase
Y1069	CX224	Manual arbitrary feed 2nd axis selection code 2 4th-phase
Y106A	CX244	Manual arbitrary feed 2nd axis selection code 4 4th-phase
Y106B	CX284	Manual arbitrary feed 2nd axis selection code 8 4th-phase
Y106C	CX2164	Manual arbitrary feed 2nd axis selection code 16 4th-phase
Y106F	CX2S4	Manual arbitrary feed 2nd axis valid 4th-phase
Y1070	CX314	Manual arbitrary feed 3rd axis selection code 1 4th-phase
Y1071	CX324	Manual arbitrary feed 3rd axis selection code 2 4th-phase
Y1072	CX344	Manual arbitrary feed 3rd axis selection code 4 4th-phase
Y1073	CX384	Manual arbitrary feed 3rd axis selection code 8 4th-phase
Y1074	CX3164	Manual arbitrary feed 3rd axis selection code 16 4th-phase
Y1077	CX3S4	Manual arbitrary feed 3rd axis valid 4th-phase
Y1078	CXS14	Manual arbitrary feed smoothing off 4th-phase
Y1079	CXS24	Manual arbitrary feed axis independent 4th-phase
Y107A	CXS34	Manual arbitrary feed EX.F/MODAL.F 4th-phase
Y107B	CXS44	Manual arbitrary feed G0/G1 4th-phase
Y107C	CXS54	Manual arbitrary feed MC/WK 4th-phase
Y107D	CXS64	Manual arbitrary feed ABS/INC 4th-phase
Y107E	*CXS74	Manual arbitrary feed stop 4th-phase
Y107F	CXS84	Manual arbitrary feed strobe 4th-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y1080	ILM14	Current limit mode 1 4th-phase
Y1081	ILM24	Current limit mode 2 4th-phase
Y1083	LDWT4	Load monitor execution 4th-phase
Y1084		Load monitor teaching mode 4th-phase
Y1085		Load monitor monitor mode 4th-phase
Y1086		Load monitor alarm reset 4th-phase
Y1087		Load monitor warning reset 4th-phase
Y1088	*ZRIT4	2nd reference position return interlock 4th-phase
Y1089		Adaptive control execution 4th-phase
Y108A		Small diameter deep hole drilling cycle 4th-phase
Y108B		Chuck barrier on 4th-phase
Y108C		High-speed retract function valid 4th-phase
Y1090		Waiting ignore 4th-phase
Y1091		Spindle-spindle polygon cancel 4th-phase
Y1092		Synchronous tapping command polarity reversal 4th-phase
Y1093		Spindle off mode 4th-phase
Y1093		Longitudinal hole drilling axis selection 4th-phase
Y1098		Barrier valid (left) 4th-phase
Y1099		Barrier valid (right) 4th-phase
Y109A		Tool presetter sub-side valid 4th-phase
Y109B		Movable area clamping 4th-phase
Y10A1	DOOR24	Door open II 4th-phase
Y10A2		Door open signal input(spindle speed monitor) 4th-phase
Y10A3		Door interlock spindle speed clamp 4th-phase
Y10A8		Door open II (2 channels per 1 part system) 4th-phase
Y10A9		Door open II (3 channels per 1 part system) Spare 4th-phase
Y10B4	BCHK4	Barrier check invalid 4th-phase
Y10BA	DRNC4	Dry run invalid 4th-phase
Y10BB	AUTED4	Automatic error detection 4th-phase
Y10C8	RVSP	Reverse run from block start 4th-phase
Y10C9	RVIT	Macro interrupt priority 4th-phase
Y10CA	RVMD	Reverse run control mode 4th-phase
Y1885	GFIN1	Gear shift completion 1st-Spindle
Y1888	SP11	Spindle override code 1 1st-Spindle
Y1889	SP21	Spindle override code 2 1st-Spindle
Y188A	SP41	Spindle override code 4 1st-Spindle
Y188F	SPS1	Spindle override method selection 1st-Spindle
Y1890	GI11	Spindle gear selection code 1 1st-Spindle
Y1891	GI21	Spindle gear selection code 2 1st-Spindle
Y1893	EXOBS	Spindle holding force up 1st-spindle
Y1894	SSTP1	Spindle stop 1st-Spindle
Y1895	SSFT1	Spindle gear shift 1st-Spindle
Y1896	SORC1	Spindle orientation 1st-Spindle
Y1897		Spindle command invalid 1st-Spindle
Y1898	SRN1	Spindle forward run start 1st-Spindle
Y1899	SRI1	Spindle reverse run start 1st-Spindle
Y189A	TL11	Spindle torque limit 1 1st-Spindle
Y189B	TL21	Torque limit 2 1st-Spindle
Y189C	WRN1	Spindle forward run index 1st-Spindle
Y189D	WRI1	Spindle reverse run index 1st-Spindle
Y189E	ORC1	Spindle orientation command 1st-Spindle
Y189F	LRSL1	L coil selection 1st-Spindle
Y18A2		Spindle position control (C axis)cutting gain L 1st-Spindle
Y18A3		Spindle position control (C axis)cutting gain H 1st-Spindle
Y18A6	LRSM1	In M coil selection 1st-Spindle
Y18A8	SWS1	Spindle selection 1st-Spindle
X18AC	SPCMP1	Chuck close confirmation 1st-spindle
Y18AF	MPCSL1	PLC coil changeover 1st-Spindle
Y18AF	SPSYC1	Spindle synchronization/superimposition cancel 1st-Spindle
Y18B0	SPSY1	Spindle synchronization 1st-Spindle
Y18B1	SPPHS1	Spindle phase synchronization 1st-Spindle
Y18B2	SPSDR1	Spindle synchronous rotation direction 1st-Spindle
Y18B3	SSPHM1	Phase shift calculation request 1st-Spindle
Y18B4	SSPHF1	Phase offset request 1st-Spindle
Y18B5	SPDRPO1	Error temporary cancel 1st-Spindle
Y18B8	SPSYC1	Spindle synchronization/superimposition cancel 1st-Spindle
Y18B9	SPCMPC1	Chuck close 1st-Spindle
Y18E5	GFIN2	Gear shift completion 2nd-Spindle
Y18E8	SP12	Spindle override code 1 2nd-Spindle
Y18E9	SP22	Spindle override code 2 2nd-Spindle
Y18EA	SP42	Spindle override code 4 2nd-Spindle
Y18EF	SPS2	Spindle override method selection 2nd-Spindle
Y18F0	GI12	Spindle gear selection code 1 2nd-Spindle
Y18F1	GI22	Spindle gear selection code 2 2nd-Spindle
Y18F3	EXOBS	Spindle holding force up 2nd-spindle
Y18F4	SSTP2	Spindle stop 2nd-Spindle
Y18F5	SSFT2	Spindle gear shift 2nd-Spindle
Y18F6	SORC2	Spindle orientation 2nd-Spindle
Y18F7		Spindle command invalid 2nd-Spindle
Y18F8	SRN2	Spindle forward run start 2nd-Spindle

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y18F9	SRI2	Spindle reverse run start 2nd-Spindle
Y18FA	TL12	Spindle torque limit 1 2nd-Spindle
Y18FB	TL22	Torque limit 2 2nd-Spindle
Y18FC	WRN2	Spindle forward run index 2nd-Spindle
Y18FD	WRI2	Spindle reverse run index 2nd-Spindle
Y18FE	ORC2	Spindle orientation command 2nd-Spindle
Y18FF	LRLS2	L coil selection 2nd-Spindle
Y1902		Spindle position control (C axis)cutting gain L 2nd-Spindle
Y1903		Spindle position control (C axis)cutting gain H 2nd-Spindle
Y1906	LRSM2	In M coil selection 2nd-Spindle
Y1908	SWS2	Spindle selection 2nd-Spindle
X190C	SPCMP2	Chuck close confirmation 2nd-spindle
Y190F	MPCSL2	PLC coil changeover 2nd-Spindle
Y190F	SPSYC2	Spindle synchronization/superimposition cancel 2nd-Spindle
Y1910	SPSY2	Spindle synchronization 2nd-Spindle
Y1911	SPPHS2	Spindle phase synchronization 2nd-Spindle
Y1912	SPSDR2	Spindle synchronous rotation direction 2nd-Spindle
Y1913	SSPHM2	Phase shift calculation request 2nd-Spindle
Y1914	SSPHF2	Phase offset request 2nd-Spindle
Y1915	SPDRPO2	Error temporary cancel 2nd-Spindle
Y1918	SPSYC2	Spindle synchronization/superimposition cancel 2nd-Spindle
Y1919	SPCMP2	Chuck close 2nd-Spindle
Y1945	GFIN3	Gear shift completion 3rd-Spindle
Y1948	SP13	Spindle override code 1 3rd-Spindle
Y1949	SP23	Spindle override code 2 3rd-Spindle
Y194A	SP43	Spindle override code 4 3rd-Spindle
Y194F	SPS3	Spindle override method selection 3rd-Spindle
Y1950	GI13	Spindle gear selection code 1 3rd-Spindle
Y1951	GI23	Spindle gear selection code 2 3rd-Spindle
Y1953	EXOBS	Spindle holding force up 3rd-spindle
Y1954	SSTP3	Spindle stop 3rd-Spindle
Y1955	SSFT3	Spindle gear shift 3rd-Spindle
Y1956	SORC3	Spindle orientation 3rd-Spindle
Y1957		Spindle command invalid 3rd-Spindle
Y1958	SRN3	Spindle forward run start 3rd-Spindle
Y1959	SRI3	Spindle reverse run start 3rd-Spindle
Y195A	TL13	Spindle torque limit 1 3rd-Spindle
Y195B	TL23	Torque limit 2 3rd-Spindle
Y195C	WRN3	Spindle forward run index 3rd-Spindle
Y195D	WRI3	Spindle reverse run index 3rd-Spindle
Y195E	ORC3	Spindle orientation command 3rd-Spindle
Y195F	LRLS3	L coil selection 3rd-Spindle
Y1962		Spindle position control (C axis)cutting gain L 3rd-spindle
Y1963		Spindle position control (C axis)cutting gain H 3rd-spindle
Y1966	LRSM3	In M coil selection 3rd-spindle
Y1968	SWS3	Spindle selection 3rd-spindle
X196C	SPCMP3	Chuck close confirmation 3rd-spindle
Y196F	MPCSL3	PLC coil changeover 3rd-spindle
Y196F	SPSYC3	Spindle synchronization/superimposition cancel 3rd-spindle
Y1970	SPSY3	Spindle synchronization 3rd-Spindle
Y1971	SPPHS3	Spindle phase synchronization 3rd-Spindle
Y1972	SPSDR3	Spindle synchronous rotation direction 3rd-Spindle
Y1973	SSPHM3	Phase shift calculation request 3rd-Spindle
Y1974	SSPHF3	Phase offset request 3rd-Spindle
Y1975	SPDRPO3	Error temporary cancel 3rd-Spindle
Y1978	SPSYC3	Spindle synchronization/superimposition cancel 3rd-Spindle
Y1979	SPCMP3	Chuck close 3rd-Spindle
Y19A5	GFIN4	Gear shift completion 4th-Spindle
Y19A8	SP14	Spindle override code 1 4th-Spindle
Y19A9	SP24	Spindle override code 2 4th-Spindle
Y19AA	SP44	Spindle override code 4 4th-Spindle
Y19AF	SPS4	Spindle override method selection 4th-Spindle
Y19B0	GI14	Spindle gear selection code 1 4th-Spindle
Y19B1	GI24	Spindle gear selection code 2 4th-Spindle
Y19B3	EXOBS	Spindle holding force up 4th-spindle
Y19B4	SSTP4	Spindle stop 4th-Spindle
Y19B5	SSFT4	Spindle gear shift 4th-Spindle
Y19B6	SORC4	Spindle orientation 4th-Spindle
Y19B7		Spindle command invalid 4th-Spindle
Y19B8	SRN4	Spindle forward run start 4th-Spindle
Y19B9	SRI4	Spindle reverse run start 4th-Spindle
Y19BA	TL14	Spindle torque limit 1 4th-Spindle
Y19BB	TL24	Torque limit 2 4th-Spindle
Y19BC	WRN4	Spindle forward run index 4th-Spindle
Y19BD	WRI4	Spindle reverse run index 4th-Spindle
Y19BE	ORC4	Spindle orientation command 4th-Spindle
Y19BF	LRLS4	L coil selection 4th-Spindle
Y19C2		Spindle position control (C axis)cutting gain L 4th-Spindle
Y19C3		Spindle position control (C axis)cutting gain H 4th-Spindle
Y19C6	LRSM4	In M coil selection 4th-Spindle

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y19C8	SWS4	Spindle selection 4th-Spindle
X19CC	SPCMP4	Chuck close confirmation 4th-spindle
Y19CF	MPCSL4	PLC coil changeover 4th-Spindle
Y19CF	SPSYC4	Spindle synchronization/superimposition cancel 4th-Spindle
Y19D0	SPSY4	Spindle synchronization 4th-Spindle
Y19D1	SPPHS4	Spindle phase synchronization 4th-Spindle
Y19D2	SPSDR3	Spindle synchronous rotation direction 4th-Spindle
Y19D3	SSPHM4	Phase shift calculation request 4th-Spindle
Y19D4	SSPHF4	Phase offset request 4th-Spindle
Y19D5	SPDRPO4	Error temporary cancel 4th-Spindle
Y19D8	SPSYC4	Spindle synchronization/superimposition cancel 4th-Spindle
Y19D9	SPCMPC4	Chuck close 4th-Spindle
Y1A05	GFIN1	Gear shift completion 5th-Spindle
Y1A08	SP15	Spindle override code 1 5th-Spindle
Y1A09	SP25	Spindle override code 2 5th-Spindle
Y1A0A	SP45	Spindle override code 4 5th-Spindle
Y1A10	GI15	Spindle gear selection code 1 5th-Spindle
Y1A11	GI25	Spindle gear selection code 2 5th-Spindle
Y1A13	EXOBS	Spindle holding force up 5th-spindle
Y1A14	SSTP5	Spindle stop 5th-Spindle
Y1A15	SSFT5	Spindle gear shift 5th-Spindle
Y1A17		Spindle command invalid 5th-Spindle
Y1A18	SRN5	Spindle forward run start 5th-Spindle
Y1A19	SRI5	Spindle reverse run start 5th-Spindle
Y1A1A	TL15	Spindle torque limit 1 5th-Spindle
Y1A1B	TL25	Torque limit 2 5th-Spindle
Y1A1C	WRN5	Spindle forward run index 5th-Spindle
Y1A1D	WRI5	Spindle reverse run index 5th-Spindle
Y1A1E	ORC5	Spindle orientation command 5th-Spindle
Y1A1F		L coil selection 5th-Spindle
Y1A22		Spindle position control (C axis)cutting gain L 5th-Spindle
Y1A23		Spindle position control (C axis)cutting gain H 5th-Spindle
Y1A26		In M coil selection 5th-Spindle
Y1A28		Spindle selection 5th-Spindle
Y1A2F		PLC coil changeover 5th-Spindle
Y1A30		Spindle synchronization 5th-Spindle
Y1A31		Spindle phase synchronization 5th-Spindle
Y1A32		Spindle synchronous rotation direction 5th-Spindle
Y1A33		Phase shift calculation request 5th-Spindle
Y1A34		Phase offset request 5th-Spindle
Y1A35		Error temporary cancel 5th-Spindle
Y1A38		Spindle synchronization/superimposition cancel 5th-Spindle
Y1A39		Chuck close 5th-Spindle
Y1A65	GFIN1	Gear shift completion 6th-Spindle
Y1A68	SP16	Spindle override code 1 6th-Spindle
Y1A69	SP26	Spindle override code 2 6th-Spindle
Y1A6A	SP46	Spindle override code 4 6th-Spindle
Y1A70	GI16	Spindle gear selection code 1 6th-Spindle
Y1A71	GI26	Spindle gear selection code 2 6th-Spindle
Y1A73	EXOBS	Spindle holding force up 6th-spindle
Y1A74	SSTP6	Spindle stop 6th-Spindle
Y1A75	SSFT6	Spindle gear shift 6th-Spindle
Y1A77		Spindle command invalid 6th-Spindle
Y1A78	SRN6	Spindle forward run start 6th-Spindle
Y1A79	SRI6	Spindle reverse run start 6th-Spindle
Y1A7A	TL16	Spindle torque limit 1 6th-Spindle
Y1A7B	TL26	Torque limit 2 6th-Spindle
Y1A7C	WRN6	Spindle forward run index 6th-Spindle
Y1A7D	WRI6	Spindle reverse run index 6th-Spindle
Y1A7E	ORC6	Spindle orientation command 6th-Spindle
Y1A7F		L coil selection 6th-Spindle
Y1A82		Spindle position control (C axis)cutting gain L 6th-Spindle
Y1A83		Spindle position control (C axis)cutting gain H 6th-Spindle
Y1A86		In M coil selection 6th-Spindle
Y1A88		Spindle selection 6th-Spindle
Y1A8F		PLC coil changeover 6th-Spindle
Y1A90		Spindle synchronization 6th-Spindle
Y1A91		Spindle phase synchronization 6th-Spindle
Y1A92		Spindle synchronous rotation direction 6th-Spindle
Y1A93		Phase shift calculation request 6th-Spindle
Y1A94		Phase offset request 6th-Spindle
Y1A95		Error temporary cancel 6th-Spindle
Y1A98		Spindle synchronization/superimposition cancel 6th-Spindle
Y1A99		Chuck close 6th-Spindle
Y1D00		Position switch 1 interlock 1st-phase
Y1D01		Position switch 2 interlock 1st-phase
Y1D02		Position switch 3 interlock 1st-phase
Y1D03		Position switch 4 interlock 1st-phase
Y1D04		Position switch 5 interlock 1st-phase
Y1D05		Position switch 6 interlock 1st-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y1D06		Position switch 7 interlock 1st-phase
Y1D07		Position switch 8 interlock 1st-phase
Y1D08		Position switch 9 interlock 1st-phase
Y1D09		Position switch 10 interlock 1st-phase
Y1D0A		Position switch 11 interlock 1st-phase
Y1D0B		Position switch 12 interlock 1st-phase
Y1D0C		Position switch 13 interlock 1st-phase
Y1D0D		Position switch 14 interlock 1st-phase
Y1D0E		Position switch 15 interlock 1st-phase
Y1D0F		Position switch 16 interlock 1st-phase
Y1D10		Position switch 17 interlock 1st-phase
Y1D11		Position switch 18 interlock 1st-phase
Y1D12		Position switch 19 interlock 1st-phase
Y1D13		Position switch 20 interlock 1st-phase
Y1D14		Position switch 21 interlock 1st-phase
Y1D15		Position switch 22 interlock 1st-phase
Y1D16		Position switch 23 interlock 1st-phase
Y1D17		Position switch 24 interlock 1st-phase
Y1D20		Position switch 1 interlock 2nd-phase
Y1D21		Position switch 2 interlock 2nd-phase
Y1D22		Position switch 3 interlock 2nd-phase
Y1D23		Position switch 4 interlock 2nd-phase
Y1D24		Position switch 5 interlock 2nd-phase
Y1D25		Position switch 6 interlock 2nd-phase
Y1D26		Position switch 7 interlock 2nd-phase
Y1D27		Position switch 8 interlock 2nd-phase
Y1D28		Position switch 9 interlock 2nd-phase
Y1D29		Position switch 10 interlock 2nd-phase
Y1D2A		Position switch 11 interlock 2nd-phase
Y1D2B		Position switch 12 interlock 2nd-phase
Y1D2C		Position switch 13 interlock 2nd-phase
Y1D2D		Position switch 14 interlock 2nd-phase
Y1D2E		Position switch 15 interlock 2nd-phase
Y1D2F		Position switch 16 interlock 2nd-phase
Y1D30		Position switch 17 interlock 2nd-phase
Y1D31		Position switch 18 interlock 2nd-phase
Y1D32		Position switch 19 interlock 2nd-phase
Y1D33		Position switch 20 interlock 2nd-phase
Y1D34		Position switch 21 interlock 2nd-phase
Y1D35		Position switch 22 interlock 2nd-phase
Y1D36		Position switch 23 interlock 2nd-phase
Y1D37		Position switch 24 interlock 2nd-phase
Y1D40		Position switch 1 interlock 3rd-phase
Y1D41		Position switch 2 interlock 3rd-phase
Y1D42		Position switch 3 interlock 3rd-phase
Y1D43		Position switch 4 interlock 3rd-phase
Y1D44		Position switch 5 interlock 3rd-phase
Y1D45		Position switch 6 interlock 3rd-phase
Y1D46		Position switch 7 interlock 3rd-phase
Y1D47		Position switch 8 interlock 3rd-phase
Y1D48		Position switch 9 interlock 3rd-phase
Y1D49		Position switch 10 interlock 3rd-phase
Y1D4A		Position switch 11 interlock 3rd-phase
Y1D4B		Position switch 12 interlock 3rd-phase
Y1D4C		Position switch 13 interlock 3rd-phase
Y1D4D		Position switch 14 interlock 3rd-phase
Y1D4E		Position switch 15 interlock 3rd-phase
Y1D4F		Position switch 16 interlock 3rd-phase
Y1D50		Position switch 17 interlock 3rd-phase
Y1D51		Position switch 18 interlock 3rd-phase
Y1D52		Position switch 19 interlock 3rd-phase
Y1D53		Position switch 20 interlock 3rd-phase
Y1D54		Position switch 21 interlock 3rd-phase
Y1D55		Position switch 22 interlock 3rd-phase
Y1D56		Position switch 23 interlock 3rd-phase
Y1D57		Position switch 24 interlock 3rd-phase
Y1D60		Position switch 1 interlock 4th-phase
Y1D61		Position switch 2 interlock 4th-phase
Y1D62		Position switch 3 interlock 4th-phase
Y1D63		Position switch 4 interlock 4th-phase
Y1D64		Position switch 5 interlock 4th-phase
Y1D65		Position switch 6 interlock 4th-phase
Y1D66		Position switch 7 interlock 4th-phase
Y1D67		Position switch 8 interlock 4th-phase
Y1D68		Position switch 9 interlock 4th-phase
Y1D69		Position switch 10 interlock 4th-phase
Y1D6A		Position switch 11 interlock 4th-phase
Y1D6B		Position switch 12 interlock 4th-phase
Y1D6C		Position switch 13 interlock 4th-phase
Y1D6D		Position switch 14 interlock 4th-phase

III PLC Devices
3. Bit Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
Y1D6E		Position switch 15 interlock 4th-phase
Y1D6F		Position switch 16 interlock 4th-phase
Y1D70		Position switch 17 interlock 4th-phase
Y1D71		Position switch 18 interlock 4th-phase
Y1D72		Position switch 19 interlock 4th-phase
Y1D73		Position switch 20 interlock 4th-phase
Y1D74		Position switch 21 interlock 4th-phase
Y1D75		Position switch 22 interlock 4th-phase
Y1D76		Position switch 23 interlock 4th-phase
Y1D77		Position switch 24 interlock 4th-phase

III PLC Devices
4. Data Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
R200	AO1	Analog output 1
R201	AO2	Analog output 2
R202	AO3	Analog output 3
R203	AO4	Analog output 4
R204	AO5	Analog output 5
R205	AO6	Analog output 6
R206	AO7	Analog output 7
R207	AO8	Analog output 8
R212		KEY OUT 1
R215		Power OFF indication device No.
R224		User sequence program version code A
R225		User sequence program version code B
R226		User sequence program version code C
R227		User sequence program version code D
R232		User sequence program version code 2 A
R233		User sequence program version code 2 B
R234		User sequence program version code 2 C
R235		User sequence program version code 2 D
R236		User sequence program version code 2 E
R237		User sequence program version code 2 F
R238		User sequence program version code 2 G
R239		User sequence program version code 2 H
R240		APLC version D
R241		APLC version C
R242		APLC version B
R243		APLC version A
R248		OT ignored (Axis 1 to 16 or axis 1 to 8 for part system 1,2)
R249		OT ignored (Axis 17 to 32 or axis 1 to 8 for part system 3,4)
R272		Near-point dog ignored(Axis 1 to 16 or axis 1 to 8 for part system 1,2)
R273		Near-point dog ignored(Axis 17 to 32 or axis 1 to 8 for part system 3,4)
R296	SMOD	Speed monitor mode
R297		Handy terminal Data area top address
R298		Handy terminal Data valid number of registers
R299		Handy terminal Cause of communication error
R336		Tool I/D R/W pot No. designation
R337		Large diameter tool information
R338		Tool weight (spindle tool)
R339		Tool weight (standby tool)
R340		Unset tool information
R342		Specified shape interference Shape No. designation
R343		Specified shape interference Shape No. designation (Spare)
R347		Skip retract valid
R348		Skip retract amount
R349		Skip retract amount
R350		Skip retract speed
R351		Skip retract speed
R352		Remote program input No.
R353		Remote program input No.
R354		Machine manufacturer macro password No.
R355		Machine manufacturer macro password No.
R356		Direct screen selection
R357		Direct screen selection
R358		Direct screen selection
R359		Direct screen selection
R364		Machine parameter lock I/F
R365		Measures against tool setter chattering movement amount
R396		User PLC program format info
R400		Ball screw thermal displacement compensation Offset amount 1st axis
R401		Ball screw thermal displacement compensation Max. compensation amount 1st axis
R402		Ball screw thermal displacement compensation Part-system, axis No. 1st axis
R403		Ball screw thermal displacement compensation Offset amount 2nd axis
R404		Ball screw thermal displacement compensation Max. compensation amount 2nd axis
R405		Ball screw thermal displacement compensation Part-system, axis No. 2nd axis
R406		Ball screw thermal displacement compensation Offset amount 3rd axis
R407		Ball screw thermal displacement compensation Max. compensation amount 3rd axis
R408		Ball screw thermal displacement compensation Part-system, axis No. 3rd axis
R409		Ball screw thermal displacement compensation Offset amount 4th axis
R410		Ball screw thermal displacement compensation Max. compensation amount 4th axis

III PLC Devices
4. Data Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
R411		Ball screw thermal displacement compensation Part-system, axis No. 4th axis
R424		PLC window Reading start R register 1
R425		PLC window Number of read windows 1
R426		PLC window Writing start R register 1
R427		PLC window Number of write windows 1
R428		PLC window Reading start R register 2
R429		PLC window Number of read windows 2
R430		PLC window Writing start R register 2
R431		PLC window Number of write windows 2
R432		PLC window Reading start R register 3
R433		PLC window Number of read windows 3
R434		PLC window Writing start R register 3
R435		PLC window Number of write windows 3
R440		PLC axis control information address 1st axis
R441		PLC axis control information address 2nd axis
R442		PLC axis control information address 3rd axis
R443		PLC axis control information address 4th axis
R444		PLC axis control information address 5th axis
R445		PLC axis control information address 6th axis
R446		PLC axis control information address 7th axis
R447		PLC axis control information address 8th axis
R448		PLC axis control buffering mode information address
R456		Encoder 1 arbitrary pulse 1
R457		Encoder 1 arbitrary pulse 2
R458		Encoder 2 arbitrary pulse 1
R459		Encoder 2 arbitrary pulse 2
R608		No. of work machining (maximum value) 1st-phase
R609		No. of work machining (maximum value) 1st-phase
R808		No. of work machining (maximum value) 2nd-phase
R809		No. of work machining (maximum value) 2nd-phase
R1008		No. of work machining (maximum value) 3rd-phase
R1009		No. of work machining (maximum value) 3rd-phase
R1208		No. of work machining (maximum value) 4th-phase
R1209		No. of work machining (maximum value) 4th-phase
R2500		1st cutting feedrate override 1st-phase
R2501		2nd cutting feedrate override 1st-phase
R2502		Rapid traverse override 1st-phase
R2503	CHPOV1	Chopping override 1st-phase
R2504		Manual feedrate 1st-phase
R2505		Manual feedrate 1st-phase
R2506		Manual feedrate B 1st-phase
R2507		Manual feedrate B (H) 1st-phase
R2508		1st Handle/incremental feed magnification 1st-phase
R2509		1st Handle/incremental feed magnification 1st-phase
R2510		2nd handle feed magnification 1st-phase
R2511		2nd handle feed magnification 1st-phase
R2512		3rd handle feed magnification 1st-phase
R2513		3rd handle feed magnification 1st-phase
R2517		Machine status animated warning display type 1st-phase
R2518		PLC interrupt program number 1st-phase (L)
R2519		PLC interrupt program number 1st-phase (H)
R2520		Load meter display interface 1 1st-phase (L)
R2521		Load meter display interface 1 1st-phase (H)
R2522		Load meter display interface 2 1st-phase (L)
R2523		Load meter display interface 2 1st-phase (H)
R2524		Manual feedrate B override 1st-phase
R2525		External search device No. 1st-phase
R2526		External search program No. 1st-phase
R2527		External search program No. 1st-phase
R2528		External search sequence No. 1st-phase
R2529		External search sequence No. 1st-phase
R2530		External search block No. 1st-phase
R2531		External search block No. 1st-phase
R2544		Manual arbitrary feed 1st axis travel amount 1st-phase
R2545		Manual arbitrary feed 1st axis travel amount 1st-phase
R2546		Manual arbitrary feed 1st axis travel amount 1st-phase
R2547		Manual arbitrary feed 1st axis travel amount 1st-phase
R2548		Manual arbitrary feed 2st axis travel amount 1st-phase
R2549		Manual arbitrary feed 2st axis travel amount 1st-phase
R2550		Manual arbitrary feed 2st axis travel amount 1st-phase
R2551		Manual arbitrary feed 2st axis travel amount 1st-phase
R2552		Manual arbitrary feed 3st axis travel amount 1st-phase
R2553		Manual arbitrary feed 3st axis travel amount 1st-phase
R2554		Manual arbitrary feed 3st axis travel amount 1st-phase
R2555		Manual arbitrary feed 3st axis travel amount 1st-phase
R2556		Alarm message I/F 1 1st-phase
R2557		Alarm message I/F 2 1st-phase
R2558		Alarm message I/F 3 1st-phase
R2559		Alarm message I/F 4 1st-phase

III PLC Devices
4. Data Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
R2560		Operator message I/F 1st-phase
R2562		Search & start program No. 1st-phase
R2563		Search & start program No. 1st-phase
R2564		Manual skip I/F 1 (manual skip control) 1st-phase
R2565		Manual skip I/F 2 (manual skip axis stop/read request) 1st-phase
R2566		Manual skip I/F 3 (Manual skip axis stop mode) 1st-phase
R2567		Encoder selection 1st-phase
R2568		C axis selection 1st-phase
R2580		Load monitor teaching axis selection 1st-phase
R2581		Load monitor load change rate detection axis 1st-phase
R2582		Load monitor teaching data sub-no. 1st-phase
R2583		Adaptive control basic axis selection 1st-phase
R2584		Each axis reference position selection
R2587		Chopping control data address 1st-phase
R2588		Tool life management data sort 1st-phase
R2589		Synchronization control operation method 1st-phase
R2590		Tool group No. designation 1st-phase
R2591		Tool group No. designation 1st-phase
R2593		Current limit changeover 1st-phase
R2594		Wear compensation no. (tool presetter) 1st-phase
R2595		(Spare) 1st-phase
R2596		Turret interference object tool no. designation 1st-phase
R2597		Turret interference object tool no. designation (spare) 1st-phase
R2600		Workpiece coordinate offset measurement compensation No. 1st-phase
R2601		Workpiece coordinate offset measurement compensation No. 1st-phase
R2602		Selected tool No. 1st-phase
R2603		Selected tool No. 1st-phase
R2604		Selected tool compensation No.(sub) 1st-phase (L)
R2605		Selected tool compensation No.(sub) 1st-phase (H)
R2606		Selected tool wear No. (sub) 1st-phase (L)
R2607		Selected tool wear No. (sub) 1st-phase (H)
R2608		Tool mounting information 1-16 1st-phase
R2609		Tool mounting information 17-32 1st-phase
R2610		Tool mounting information 33-48 1st-phase
R2611		Tool mounting information 49-64 1st-phase
R2612		Tool mounting information 65-80 1st-phase
R2628		Mechanical axis specifications 1st rotary axis angle 1st-phase (L)
R2629		Mechanical axis specifications 1st rotary axis angle 1st-phase (H)
R2630		Mechanical axis specifications 2nd rotary axis angle 1st-phase (L)
R2631		Mechanical axis specifications 2nd rotary axis angle 1st-phase (H)
R2700		1st cutting feedrate override 2nd-phase
R2701		2nd cutting feedrate override 2nd-phase
R2702		Rapid traverse override 2nd-phase
R2703	CHPOV2	Chopping override 2nd-phase
R2704		Manual feedrate 2nd-phase
R2705		Manual feedrate 2nd-phase
R2706		Manual feedrate B 2nd-phase
R2707		Manual feedrate B (H) 2nd-phase
R2708		1st handle/incremental feed magnification 2nd-phase
R2709		1st handle/incremental feed magnification 2nd-phase
R2710		2nd handle feed magnification 2nd-phase
R2711		2nd handle feed magnification 2nd-phase
R2712		3rd handle feed magnification 2nd-phase
R2713		3rd handle feed magnification 2nd-phase
R2717		Machine status animated warning display type 2nd-phase
R2718		PLC interrupt program number 2nd-phase (L)
R2719		PLC interrupt program number 2nd-phase (H)
R2720		Load meter display interface 1 2nd-phase (L)
R2721		Load meter display interface 1 2nd-phase (H)
R2722		Load meter display interface 2 2nd-phase (L)
R2723		Load meter display interface 2 2nd-phase (H)
R2724		Manual feedrate B override 2nd-phase
R2725		External search device No. 2nd-phase
R2726		External search program No. 2nd-phase
R2727		External search program No. 2nd-phase
R2728		External search sequence No. 2nd-phase
R2729		External search sequence No. 2nd-phase
R2730		External search block No. 2nd-phase
R2731		External search block No. 2nd-phase
R2744		Manual arbitrary feed 1st axis travel amount 2nd-phase
R2745		Manual arbitrary feed 1st axis travel amount 2nd-phase
R2746		Manual arbitrary feed 1st axis travel amount 2nd-phase
R2747		Manual arbitrary feed 1st axis travel amount 2nd-phase
R2748		Manual arbitrary feed 2st axis travel amount 2nd-phase
R2749		Manual arbitrary feed 2st axis travel amount 2nd-phase
R2750		Manual arbitrary feed 2st axis travel amount 2nd-phase
R2751		Manual arbitrary feed 2st axis travel amount 2nd-phase
R2752		Manual arbitrary feed 3st axis travel amount 2nd-phase
R2753		Manual arbitrary feed 3st axis travel amount 2nd-phase
R2754		Manual arbitrary feed 3st axis travel amount 2nd-phase

III PLC Devices
4. Data Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
R2755		Manual arbitrary feed 3st axis travel amount 2nd-phase
R2756		Alarm message I/F 1 2nd-phase
R2757		Alarm message I/F 2 2nd-phase
R2758		Alarm message I/F 3 2nd-phase
R2759		Alarm message I/F 4 2nd-phase
R2760		Operator message I/F 2nd-phase
R2762		Search & start program No. 2nd-phase
R2763		Search & start program No. 2nd-phase
R2764		Manual skip I/F 1 (manual skip control) 2nd-phase
R2765		Manual skip I/F 2 (manual skip axis stop/read request) 2nd-phase
R2766		Manual skip I/F 3 (Manual skip axis stop mode) 2nd-phase
R2767		Encoder selection 2nd-phase
R2768		C axis selection 2nd-phase
R2780		Load monitor teaching axis selection 2nd-phase
R2781		Load monitor load change rate detection axis 2nd-phase
R2782		Load monitor teaching data sub-no. 2nd-phase
R2783		Adaptive control basic axis selection 2nd-phase
R2784		Each axis reference position selection 1st-phase
R2784		Each axis reference position selection 2nd-phase
R2787		Chopping control data address 2nd-phase
R2788		Tool life management data sort 2nd-phase
R2789		Synchronization control operation method 2nd-phase
R2790		Tool group No. designation 2nd-phase
R2791		Tool group No. designation 2nd-phase
R2793		Current limit changeover 2nd-phase
R2794		Wear compensation no. (tool presetter) 2nd-phase
R2795		(Spare) 2nd-phase
R2796		Turret interference object tool no. designation 2nd-phase
R2797		Turret interference object tool no. designation (spare) 2nd-phase
R2800		Workpiece coordinate offset measurement compensation No. 2nd-phase
R2801		Workpiece coordinate offset measurement compensation No. 2nd-phase
R2802		Selected tool No. 2nd-phase
R2803		Selected tool No. 2nd-phase
R2804		Selected tool compensation No.(sub) 2nd-phase (L)
R2805		Selected tool compensation No.(sub) 2nd-phase (H)
R2806		Selected tool wear No. (sub) 2nd-phase (L)
R2807		Selected tool wear No. (sub) 2nd-phase (H)
R2808		Tool mounting information 1-16 2nd-phase
R2809		Tool mounting information 17-32 2nd-phase
R2810		Tool mounting information 33-48 2nd-phase
R2811		Tool mounting information 49-64 2nd-phase
R2812		Tool mounting information 65-80 2nd-phase
R2828		Mechanical axis specifications 1st rotary axis angle 2nd-phase (L)
R2829		Mechanical axis specifications 1st rotary axis angle 2nd-phase (H)
R2830		Mechanical axis specifications 2nd rotary axis angle 2nd-phase (L)
R2831		Mechanical axis specifications 2nd rotary axis angle 2nd-phase (H)
R2900		1st cutting feedrate override 3rd-phase
R2901		2nd cutting feedrate override 3rd-phase
R2902		Rapid traverse override 3rd-phase
R2903	CHPOV3	Chopping override 3rd-phase
R2904		Manual feedrate 3rd-phase
R2905		Manual feedrate 3rd-phase
R2906		Manual feedrate B 3rd-phase
R2907		Manual feedrate B (H) 3rd-phase
R2908		1st handle/incremental feed magnification 3rd-phase
R2909		1st handle/incremental feed magnification 3rd-phase
R2910		2nd handle feed magnification 3rd-phase
R2911		2nd handle feed magnification 3rd-phase
R2912		3rd handle feed magnification 3rd-phase
R2913		3rd handle feed magnification 3rd-phase
R2917		Machine status animated warning display type 3rd-phase
R2918		PLC interrupt program number 3rd-phase (L)
R2919		PLC interrupt program number 3rd-phase (H)
R2920		Load meter display interface 1 3rd-phase (L)
R2921		Load meter display interface 1 3rd-phase (H)
R2922		Load meter display interface 2 3rd-phase (L)
R2923		Load meter display interface 2 3rd-phase (H)
R2924		Manual feedrate B override 3rd-phase
R2925		External search device No. 3rd-phase
R2926		External search program No. 3rd-phase
R2927		External search program No. 3rd-phase
R2928		External search sequence No. 3rd-phase
R2929		External search sequence No. 3rd-phase
R2930		External search block No. 3rd-phase
R2931		External search block No. 3rd-phase
R2944		Manual arbitrary feed 1st axis travel amount 3rd-phase
R2945		Manual arbitrary feed 1st axis travel amount 3rd-phase
R2946		Manual arbitrary feed 1st axis travel amount 3rd-phase
R2947		Manual arbitrary feed 1st axis travel amount 3rd-phase
R2948		Manual arbitrary feed 2st axis travel amount 3rd-phase

III PLC Devices
4. Data Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
R2949		Manual arbitrary feed 2st axis travel amount 3rd-phase
R2950		Manual arbitrary feed 2st axis travel amount 3rd-phase
R2951		Manual arbitrary feed 2st axis travel amount 3rd-phase
R2952		Manual arbitrary feed 3st axis travel amount 3rd-phase
R2953		Manual arbitrary feed 3st axis travel amount 3rd-phase
R2954		Manual arbitrary feed 3st axis travel amount 3rd-phase
R2955		Manual arbitrary feed 3st axis travel amount 3rd-phase
R2956		Alarm message I/F 1 3rd-phase
R2957		Alarm message I/F 2 3rd-phase
R2958		Alarm message I/F 3 3rd-phase
R2959		Alarm message I/F 4 3rd-phase
R2960		Operator message I/F 3rd-phase
R2962		Search & start program No. 3rd-phase
R2963		Search & start program No. 3rd-phase
R2964		Manual skip I/F 1 (manual skip control) 3rd-phase
R2965		Manual skip I/F 2 (manual skip axis stop/read request) 3rd-phase
R2966		Manual skip I/F 3 (Manual skip axis stop mode) 3rd-phase
R2967		Encoder selection 3rd-phase
R2968		C axis selection 3rd-phase
R2980		Load monitor teaching axis selection 3rd-phase
R2981		Load monitor load change rate detection axis 3rd-phase
R2982		Load monitor teaching data sub-no. 3rd-phase
R2983		Adaptive control basic axis selection 3rd-phase
R2984		Each axis reference position selection 3rd-phase
R2987		Chopping control data address 3rd-phase
R2988		Tool life management data sort 3rd-phase
R2989		Synchronization control operation method 3rd-phase
R2990		Tool group No. designation 3rd-phase
R2991		Tool group No. designation 3rd-phase
R2993		Current limit changeover 3rd-phase
R2994		Wear compensation no. (tool presetter) 3rd-phase
R2995		(Spare) 3rd-phase
R2996		Turret interference object tool no. designation 3rd-phase
R2997		Turret interference object tool no. designation (spare) 3rd-phase
R3000		Workpiece coordinate offset measurement compensation No. 3rd-phase
R3001		Workpiece coordinate offset measurement compensation No. 3rd-phase
R3002		Selected tool No. 3rd-phase
R3003		Selected tool No. 3rd-phase
R3004		Selected tool compensation No.(sub) 3rd-phase (L)
R3005		Selected tool compensation No.(sub) 3rd-phase (H)
R3006		Selected tool wear No. (sub) 3rd-phase (L)
R3007		Selected tool wear No. (sub) 3rd-phase (H)
R3008		Tool mounting information 1-16 3rd-phase
R3009		Tool mounting information 17-32 3rd-phase
R3010		Tool mounting information 33-48 3rd-phase
R3011		Tool mounting information 49-64 3rd-phase
R3012		Tool mounting information 65-80 3rd-phase
R3028		Mechanical axis specifications 1st rotary axis angle 3rd-phase (L)
R3029		Mechanical axis specifications 1st rotary axis angle 3rd-phase (H)
R3030		Mechanical axis specifications 2nd rotary axis angle 3rd-phase (L)
R3031		Mechanical axis specifications 2nd rotary axis angle 3rd-phase (H)
R3100		1st cutting feedrate override 4th-phase
R3101		2nd cutting feedrate override 4th-phase
R3102		Rapid traverse override 4th-phase
R3103	CHPOV4	Chopping override 4th-phase
R3104		Manual feedrate 4th-phase
R3105		Manual feedrate 4th-phase
R3106		Manual feedrate B 4th-phase
R3107		Manual feedrate B (H) 4th-phase
R3108		1st handle/incremental feed magnification 4th-phase
R3109		1st handle/incremental feed magnification 4th-phase
R3110		2nd handle feed magnification 4th-phase
R3111		2nd handle feed magnification 4th-phase
R3112		3rd handle feed magnification 4th-phase
R3113		3rd handle feed magnification 4th-phase
R3117		Machine status animated warning display type 4th-phase
R3118		PLC interrupt program number 4th-phase (L)
R3119		PLC interrupt program number 4th-phase (H)
R3120		Load meter display interface 1 4th-phase (L)
R3121		Load meter display interface 1 4th-phase (H)
R3122		Load meter display interface 2 4th-phase (L)
R3123		Load meter display interface 2 4th-phase (H)
R3124		Manual feedrate B override 4th-phase
R3125		External search device No. 4th-phase
R3126		External search program No. 4th-phase
R3127		External search program No. 4th-phase
R3128		External search sequence No. 4th-phase
R3129		External search sequence No. 4th-phase
R3130		External search block No. 4th-phase
R3131		External search block No. 4th-phase

III PLC Devices
4. Data Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
R3144		Manual arbitrary feed 1st axis travel amount 4th-phase
R3145		Manual arbitrary feed 1st axis travel amount 4th-phase
R3146		Manual arbitrary feed 1st axis travel amount 4th-phase
R3147		Manual arbitrary feed 1st axis travel amount 4th-phase
R3148		Manual arbitrary feed 2st axis travel amount 4th-phase
R3149		Manual arbitrary feed 2st axis travel amount 4th-phase
R3150		Manual arbitrary feed 2st axis travel amount 4th-phase
R3151		Manual arbitrary feed 2st axis travel amount 4th-phase
R3152		Manual arbitrary feed 3st axis travel amount 4th-phase
R3153		Manual arbitrary feed 3st axis travel amount 4th-phase
R3154		Manual arbitrary feed 3st axis travel amount 4th-phase
R3155		Manual arbitrary feed 3st axis travel amount 4th-phase
R3156		Alarm message I/F 1 4th-phase
R3157		Alarm message I/F 2 4th-phase
R3158		Alarm message I/F 3 4th-phase
R3159		Alarm message I/F 4 4th-phase
R3160		Operator message I/F 4th-phase
R3162		Search & start program No. 4th-phase
R3163		Search & start program No. 4th-phase
R3164		Manual skip I/F 1 (manual skip control) 4th-phase
R3165		Manual skip I/F 2 (manual skip axis stop/read request) 4th-phase
R3166		Manual skip I/F 3 (Manual skip axis stop mode) 4th-phase
R3167		Encoder selection 4th-phase
R3168		C axis selection 4th-phase
R3180		Load monitor teaching axis selection 4th-phase
R3181		Load monitor load change rate detection axis 4th-phase
R3182		Load monitor teaching data sub-no. 4th-phase
R3183		Adaptive control basic axis selection 4th-phase
R3184		Each axis reference position selection 4th-phase
R3187		Chopping control data address 4th-phase
R3188		Tool life management data sort 4th-phase
R3189		Synchronization control operation method 4th-phase
R3190		Tool group No. designation 4th-phase
R3191		Tool group No. designation 4th-phase
R3193		Current limit changeover 4th-phase
R3194		Wear compensation no. (tool presetter) 4th-phase
R3195		(Spare) 4th-phase
R3196		Turret interference object tool no. designation 4th-phase
R3197		Turret interference object tool no. designation (spare) 4th-phase
R3200		Workpiece coordinate offset measurement compensation No. 4th-phase
R3201		Workpiece coordinate offset measurement compensation No. 4th-phase
R3202		Selected tool No. 4th-phase
R3203		Selected tool No. 4th-phase
R3204		Selected tool compensation No.(sub) 4th-phase (L)
R3205		Selected tool compensation No.(sub) 4th-phase (H)
R3206		Selected tool wear No. (sub) 4th-phase (L)
R3207		Selected tool wear No. (sub) 4th-phase (H)
R3208		Tool mounting information 1-16 4th-phase
R3209		Tool mounting information 17-32 4th-phase
R3210		Tool mounting information 33-48 4th-phase
R3211		Tool mounting information 49-64 4th-phase
R3212		Tool mounting information 65-80 4th-phase
R3228		Mechanical axis specifications 1st rotary axis angle 4th-phase (L)
R3229		Mechanical axis specifications 1st rotary axis angle 4th-phase (H)
R3230		Mechanical axis specifications 2nd rotary axis angle 4th-phase (L)
R3231		Mechanical axis specifications 2nd rotary axis angle 4th-phase (H)
R4100		Pallet program registration Pallet information in machine
R4101		Pallet program registration Miscellaneous function presence
R4102		Pallet program registration Pallet index plane in machine
R4103		Pallet program registration Machining ON/OFF screen setting
R5700		External machine coordinate system offset data 1st-axis 1st-phase
R5701		External machine coordinate system offset data 1st-axis 1st-phase
R5702		External machine coordinate system offset data 2nd-axis 1st-phase
R5703		External machine coordinate system offset data 2nd-axis 1st-phase
R5704		External machine coordinate system offset data 3rd-axis 1st-phase
R5705		External machine coordinate system offset data 3rd-axis 1st-phase
R5706		External machine coordinate system offset data 4th-axis 1st-phase
R5707		External machine coordinate system offset data 4th-axis 1st-phase
R5708		External machine coordinate system offset data 5th-axis 1st-phase
R5709		External machine coordinate system offset data 5th-axis 1st-phase
R5710		External machine coordinate system offset data 6th-axis 1st-phase
R5711		External machine coordinate system offset data 6th-axis 1st-phase
R5712		External machine coordinate system offset data 7th-axis 1st-phase
R5713		External machine coordinate system offset data 7th-axis 1st-phase
R5714		External machine coordinate system offset data 8th-axis 1st-phase
R5715		External machine coordinate system offset data 8th-axis 1st-phase
R5716		External machine coordinate system offset data 1st-axis 2nd-phase
R5717		External machine coordinate system offset data 1st-axis 2nd-phase
R5718		External machine coordinate system offset data 2nd-axis 2nd-phase
R5719		External machine coordinate system offset data 2nd-axis 2nd-phase

III PLC Devices
4. Data Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
R5800		Each axis manual feedrate B 3rd axis 3rd-phase (L)
R5801		Each axis manual feedrate B 3rd axis 3rd-phase (H)
R5802		Each axis manual feedrate B 4th axis 3rd-phase (L)
R5803		Each axis manual feedrate B 4th axis 3rd-phase (H)
R5804		Each axis manual feedrate B 5th axis 3rd-phase (L)
R5805		Each axis manual feedrate B 5th axis 3rd-phase (H)
R5806		Each axis manual feedrate B 6th axis 3rd-phase (L)
R5807		Each axis manual feedrate B 6th axis 3rd-phase (H)
R5808		Each axis manual feedrate B 7th axis 3rd-phase (L)
R5809		Each axis manual feedrate B 7th axis 3rd-phase (H)
R5810		Each axis manual feedrate B 8th axis 3rd-phase (L)
R5811		Each axis manual feedrate B 8th axis 3rd-phase (H)
R5812		Each axis manual feedrate B 1st axis 4th-phase (L)
R5813		Each axis manual feedrate B 1st axis 4th-phase (H)
R5814		Each axis manual feedrate B 2nd axis 4th-phase (L)
R5815		Each axis manual feedrate B 2nd axis 4th-phase (H)
R5816		Each axis manual feedrate B 3rd axis 4th-phase (L)
R5817		Each axis manual feedrate B 3rd axis 4th-phase (H)
R5818		Each axis manual feedrate B 4th axis 4th-phase (L)
R5819		Each axis manual feedrate B 4th axis 4th-phase (H)
R5820		Each axis manual feedrate B 5th axis 4th-phase (L)
R5821		Each axis manual feedrate B 5th axis 4th-phase (H)
R5822		Each axis manual feedrate B 6th axis 4th-phase (L)
R5823		Each axis manual feedrate B 6th axis 4th-phase (H)
R5824		Each axis manual feedrate B 7th axis 4th-phase (L)
R5825		Each axis manual feedrate B 7th axis 4th-phase (H)
R5826		Each axis manual feedrate B 8th axis 4th-phase (L)
R5827		Each axis manual feedrate B 8th axis 4th-phase (H)
R6436		User macro input #1032(PLC -> Controller) 1st-phase
R6437		User macro input #1032(PLC -> Controller) 1st-phase
R6438		User macro input #1033(PLC -> Controller) 1st-phase
R6439		User macro input #1033(PLC -> Controller) 1st-phase
R6440		User macro input #1034(PLC -> Controller) 1st-phase
R6441		User macro input #1034(PLC -> Controller) 1st-phase
R6442		User macro input #1035(PLC -> Controller) 1st-phase
R6443		User macro input #1035(PLC -> Controller) 1st-phase
R6444		User macro input #1032(PLC -> Controller) 2nd-phase
R6445		User macro input #1032(PLC -> Controller) 2nd-phase
R6446		User macro input #1033(PLC -> Controller) 2nd-phase
R6447		User macro input #1033(PLC -> Controller) 2nd-phase
R6448		User macro input #1034(PLC -> Controller) 2nd-phase
R6449		User macro input #1034(PLC -> Controller) 2nd-phase
R6450		User macro input #1035(PLC -> Controller) 2nd-phase
R6451		User macro input #1035(PLC -> Controller) 2nd-phase
R6452		User macro input #1032(PLC -> Controller) 3rd-phase
R6453		User macro input #1032(PLC -> Controller) 3rd-phase
R6454		User macro input #1033(PLC -> Controller) 3rd-phase
R6455		User macro input #1033(PLC -> Controller) 3rd-phase
R6456		User macro input #1034(PLC -> Controller) 3rd-phase
R6457		User macro input #1034(PLC -> Controller) 3rd-phase
R6458		User macro input #1035(PLC -> Controller) 3rd-phase
R6459		User macro input #1035(PLC -> Controller) 3rd-phase
R6460		User macro input #1032(PLC -> Controller) 4th-phase
R6461		User macro input #1032(PLC -> Controller) 4th-phase
R6462		User macro input #1033(PLC -> Controller) 4th-phase
R6463		User macro input #1033(PLC -> Controller) 4th-phase
R6464		User macro input #1034(PLC -> Controller) 4th-phase
R6465		User macro input #1034(PLC -> Controller) 4th-phase
R6466		User macro input #1035(PLC -> Controller) 4th-phase
R6467		User macro input #1035(PLC -> Controller) 4th-phase
R7000		Spindle command rotation speed output 1st-Spindle
R7001		Spindle command rotation speed output 1st-Spindle
R7002	SLSP1	Spindle command selection 1st-Spindle
R7008		S command override 1st-Spindle
R7009		Multi-point orientation position data 1st-Spindle
R7016		Spindle synchronization Basic spindle selection 1st-Spindle
R7017		Spindle synchronization Synchronous spindle selection 1st-Spindle
R7018		Spindle synchronization Phase shift amount 1st-Spindle
R7050		Spindle command rotation speed output 2nd-Spindle
R7051		Spindle command rotation speed output 2nd-Spindle
R7052	SLSP2	Spindle command selection 2nd-Spindle
R7058		S command override 2nd-Spindle
R7059		Multi-point orientation position data 2nd-Spindle
R7066		Spindle synchronization Basic spindle selection 2nd-Spindle
R7067		Spindle synchronization Synchronous spindle selection 2nd-Spindle
R7068		Spindle synchronization Phase shift amount 2nd-Spindle
R7100		Spindle command rotation speed output 3rd-Spindle
R7101		Spindle command rotation speed output 3rd-Spindle
R7102	SLSP3	Spindle command selection 3rd-Spindle
R7108		S command override 3rd-Spindle

III PLC Devices
4. Data Type Output Signals (PLC->CNC)

Device	Abbrev.	Signal name
R7109		Multi-point orientation position data 3rd-Spindle
R7116		Spindle synchronization Basic spindle selection 3rd-Spindle
R7117		Spindle synchronization Synchronous spindle selection 3rd-Spindle
R7118		Spindle synchronization Phase shift amount 3rd-Spindle
R7150		Spindle command rotation speed output 4th-Spindle
R7151		Spindle command rotation speed output 4th-Spindle
R7152	SLSP4	Spindle command selection 4th-Spindle
R7158		S command override 4th-Spindle
R7159		Multi-point orientation position data 4th-Spindle
R7166		Spindle synchronization Basic spindle selection 4th-Spindle
R7167		Spindle synchronization Synchronous spindle selection 4th-Spindle
R7168		Spindle synchronization Phase shift amount 4th-Spindle
R7200		Spindle command rotation speed output 5th-Spindle
R7201		Spindle command rotation speed output 5th-Spindle
R7202		Spindle command selection 5th-Spindle
R7208		S command override 5th-Spindle
R7209		Multi-point orientation position data 5th-Spindle
R7216		Spindle synchronization Basic spindle selection 5th-Spindle
R7217		Spindle synchronization Synchronous spindle selection 5th-Spindle
R7218		Spindle synchronization Phase shift amount 5th-Spindle
R7250		Spindle command rotation speed output 6th-Spindle
R7251		Spindle command rotation speed output 6th-Spindle
R7252		Spindle command selection 6th-Spindle
R7258		S command override 6th-Spindle
R7259		Multi-point orientation position data 6th-Spindle
R7266		Spindle synchronization Basic spindle selection 6th-Spindle
R7267		Spindle synchronization Synchronous spindle selection 6th-Spindle
R7268		Spindle synchronization Phase shift amount 6th-Spindle
R9950		J2CT control command 4 1st-phase
R9951		J2CT control command 3 1st-phase
R9952		J2CT control command 2 1st-phase
R9953		J2CT control command 1 1st-phase
R9954		J2CT control command position (L) 1st axis
R9955		J2CT control command position (H) 1st axis
R9956		J2CT control command 4 2nd-phase
R9957		J2CT control command 3 2nd-phase
R9958		J2CT control command 2 2nd-phase
R9959		J2CT control command 1 2nd-phase
R9960		J2CT control command position (L) 2nd axis
R9961		J2CT control command position (H) 2nd axis
R9962		J2CT control command 4 3rd-phase
R9963		J2CT control command 3 3rd-phase
R9964		J2CT control command 2 3rd-phase
R9965		J2CT control command 1 3rd-phase
R9966		J2CT control command position (L) 3rd axis
R9967		J2CT control command position (H) 3rd axis
R9968		J2CT control command 4 4th-phase
R9969		J2CT control command 3 4th-phase
R9970		J2CT control command 2 4th-phase
R9971		J2CT control command 1 4th-phase
R9972		J2CT control command position (L) 4th axis
R9973		J2CT control command position (H) 4th axis
R9974		J2CT control command 4 5th-phase
R9975		J2CT control command 3 5th-phase
R9976		J2CT control command 2 5th-phase
R9977		J2CT control command 1 5th-phase
R9978		J2CT control command position (L) 5th axis
R9979		J2CT control command position (H) 5th axis
R9980		J2CT control command 4 6th-phase
R9981		J2CT control command 3 6th-phase
R9982		J2CT control command 2 6th-phase
R9983		J2CT control command 1 6th-phase
R9984		J2CT control command position (L) 6th axis
R9985		J2CT control command position (H) 6th axis
R9998		J2CT operation adjustment mode valid
R10603		Display tool selection parameter
R12200		Spindle tool No. 1st-phase (L)
R12201		Spindle tool No. 1st-phase (H)
R12210		Spindle tool No. 2nd-phase (L)
R12211		Spindle tool No. 2nd-phase (H)
R12220		Spindle tool No. 3rd-phase (L)
R12221		Spindle tool No. 3rd-phase (H)
R12230		Spindle tool No. 4th-phase (L)
R12231		Spindle tool No. 4th-phase (H)

III PLC Devices

5. Each Application : Pallet Program Registration

Device	Abbrev.	Signal name
R2100		Pallet program registration Search valid/invalid state
R2101		Pallet program registration continuous start valid/invalid state
R2102		Pallet program registration Pallet registration specification
R2103		Pallet program registration Number of valid pallets
R2110		Pallet 1 0° Machining program device No.
R2111		Pallet 1 0° Machining valid/invalid state
R2112		Pallet 1 0° Machining program No. (L)
R2113		Pallet 1 0° Machining program No. (H)
R2114		Pallet 1 0° Auxiliary data
R2116		Pallet 1 90° Machining program device No.
R2117		Pallet 1 90° Machining valid/invalid state
R2118		Pallet 1 90° Machining program No. (L)
R2119		Pallet 1 90° Machining program No. (H)
R2120		Pallet 1 90° Auxiliary data
R2122		Pallet 1 180° Machining program device No.
R2123		Pallet 1 180° Machining valid/invalid state
R2124		Pallet 1 180° Machining program No. (L)
R2125		Pallet 1 180° Machining program No. (H)
R2126		Pallet 1 180° Auxiliary data
R2128		Pallet 1 270° Machining program device No.
R2129		Pallet 1 270° Machining valid/invalid state
R2130		Pallet 1 270° Machining program No. (L)
R2131		Pallet 1 270° Machining program No. (H)
R2132		Pallet 1 270° Auxiliary data
R2135		Pallet 2 0° Machining valid/invalid state
R2136		Pallet 2 0° Machining program No. (L)
R2137		Pallet 2 0° Machining program No. (H)
R2138		Pallet 2 0° Auxiliary data
R2140		Pallet 2 90° Machining program device No.
R2141		Pallet 2 90° Machining valid/invalid state
R2142		Pallet 2 90° Machining program No. (L)
R2143		Pallet 2 90° Machining program No. (H)
R2144		Pallet 2 90° Auxiliary data
R2146		Pallet 2 180° Machining program device No.
R2147		Pallet 2 180° Machining valid/invalid state
R2148		Pallet 2 180° Machining program No. (L)
R2149		Pallet 2 180° Machining program No. (H)
R2150		Pallet 2 180° Auxiliary data
R2152		Pallet 2 270° Machining program device No.
R2153		Pallet 2 270° Machining valid/invalid state
R2154		Pallet 2 270° Machining program No. (L)
R2155		Pallet 2 270° Machining program No. (H)
R2156		Pallet 2 270° Auxiliary data
R2134		Pallet 2 0° Machining program device No.

III PLC Devices
6. Each Application : PLC Axis Indexing

Device	Abbrev.	Signal name
R8000		PLC axis indexing control status 4 1st axis
R8001		PLC axis indexing control status 3 1st axis
R8002		PLC axis indexing control status 2 1st axis
R8003		PLC axis indexing control status 1 1st axis
R8004		PLC axis indexing control machine position (L) 1st axis
R8005		PLC axis indexing control machine position (H) 1st axis
R8006		PLC axis indexing control status 4 2nd axis
R8007		PLC axis indexing control status 3 2nd axis
R8008		PLC axis indexing control status 2 2nd axis
R8009		PLC axis indexing control status 1 2nd axis
R8010		PLC axis indexing control machine position (L) 2nd axis
R8011		PLC axis indexing control machine position (H) 2nd axis
R8012		PLC axis indexing control status 4 3rd axis
R8013		PLC axis indexing control status 3 3rd axis
R8014		PLC axis indexing control status 2 3rd axis
R8015		PLC axis indexing control status 1 3rd axis
R8016		PLC axis indexing control machine position (L) 3rd axis
R8017		PLC axis indexing control machine position (H) 3rd axis
R8018		PLC axis indexing control status 4 4th axis
R8019		PLC axis indexing control status 3 4th axis
R8020		PLC axis indexing control status 2 4th axis
R8021		PLC axis indexing control status 1 4th axis
R8022		PLC axis indexing control machine position (L) 4th axis
R8023		PLC axis indexing control machine position (H) 4th axis
R8024		PLC axis indexing control status 4 5th axis
R8025		PLC axis indexing control status 3 5th axis
R8026		PLC axis indexing control status 2 5th axis
R8027		PLC axis indexing control status 1 5th axis
R8028		PLC axis indexing control machine position (L) 5th axis
R8029		PLC axis indexing control machine position (H) 5th axis
R8030		PLC axis indexing control status 4 6th axis
R8031		PLC axis indexing control status 3 6th axis
R8032		PLC axis indexing control status 2 6th axis
R8033		PLC axis indexing control status 1 6th axis
R8034		PLC axis indexing control machine position (L) 6th axis
R8035		PLC axis indexing control machine position (H) 6th axis
R8048		PLC indexing axis in operation adjustment mode
R8050		PLC axis indexing control command 4 1st axis
R8051		PLC axis indexing control command 3 1st axis
R8052		PLC axis indexing control command 2 1st axis
R8053		PLC axis indexing control command 1 1st axis
R8054		PLC axis indexing control command position (L) 1st axis
R8055		PLC axis indexing control command position (H) 1st axis
R8056		PLC axis indexing control command 4 2nd axis
R8057		PLC axis indexing control command 3 2nd axis
R8058		PLC axis indexing control command 2 2nd axis
R8059		PLC axis indexing control command 1 2nd axis
R8060		PLC axis indexing control command position (L) 2nd axis
R8061		PLC axis indexing control command position (H) 2nd axis
R8062		PLC axis indexing control command 4 3rd axis
R8063		PLC axis indexing control command 3 3rd axis
R8064		PLC axis indexing control command 2 3rd axis
R8065		PLC axis indexing control command 1 3rd axis
R8066		PLC axis indexing control command position (L) 3rd axis
R8067		PLC axis indexing control command position (H) 3rd axis
R8068		PLC axis indexing control command 4 4th axis
R8069		PLC axis indexing control command 3 4th axis
R8070		PLC axis indexing control command 2 4th axis
R8071		PLC axis indexing control command 1 4th axis
R8072		PLC axis indexing control command position (L) 4th axis
R8073		PLC axis indexing control command position (H) 4th axis
R8074		PLC axis indexing control command 4 5th axis
R8075		PLC axis indexing control command 3 5th axis
R8076		PLC axis indexing control command 2 5th axis
R8077		PLC axis indexing control command 1 5th axis
R8078		PLC axis indexing control command position (L) 5th axis
R8079		PLC axis indexing control command position (H) 5th axis
R8080		PLC axis indexing control command 4 6th axis
R8081		PLC axis indexing control command 3 6th axis
R8082		PLC axis indexing control command 2 6th axis
R8083		PLC axis indexing control command 1 6th axis
R8084		PLC axis indexing control command position (L) 6th axis
R8085		PLC axis indexing control command position (H) 6th axis
R8098		PLC indexing axis operation adjustment mode valid

III PLC Devices

7. Each Application : Tool Life Management Interface

Device	Abbrev.	Signal name
R10604		AUX data
R10605		No.1 magazine No.
R10606		No.2 magazine No.
R10607		No.3 magazine No.
R10608		No.4 magazine No.
R10609		No.5 magazine No.
R10610		Number of tools for No.1 magazine
R10611		Number of tools for No.2 magazine
R10612		Number of tools for No.3 magazine
R10613		Number of tools for No.4 magazine
R10614		Number of tools for No.5 magazine
R10615		No.1 magazine pointer
R10616		No.2 magazine pointer
R10617		No.3 magazine pointer
R10618		No.4 magazine pointer
R10619		No.5 magazine pointer
R10620		No.1 magazine T8-digit Spindle tool (L)
R10621		No.1 magazine T8-digit Spindle tool (H)
R10622		No.1 magazine T8-digit Standby 1 tool (L)
R10623		No.1 magazine T8-digit Standby 1 tool (H)
R10624		No.1 magazine T8-digit Standby 2 tool (L)
R10625		No.1 magazine T8-digit Standby 2 tool (H)
R10626		No.1 magazine T8-digit Standby 3 tool (L)
R10627		No.1 magazine T8-digit Standby 3 tool (H)
R10628		No.1 magazine T8-digit Standby 4 tool (L)
R10629		No.1 magazine T8-digit Standby 4 tool (H)
R10630		No.2 magazine T8-digit Spindle tool (L)
R10631		No.2 magazine T8-digit Spindle tool (H)
R10632		No.2 magazine T8-digit Standby 1 tool (L)
R10633		No.2 magazine T8-digit Standby 1 tool (H)
R10634		No.2 magazine T8-digit Standby 2 tool (L)
R10635		No.2 magazine T8-digit Standby 2 tool (H)
R10636		No.2 magazine T8-digit Standby 3 tool (L)
R10637		No.2 magazine T8-digit Standby 3 tool (H)
R10638		No.2 magazine T8-digit Standby 4 tool (L)
R10639		No.2 magazine T8-digit Standby 4 tool (H)
R10640		No.3 magazine T8-digit Spindle tool (L)
R10641		No.3 magazine T8-digit Spindle tool (H)
R10642		No.3 magazine T8-digit Standby 1 tool (L)
R10643		No.3 magazine T8-digit Standby 1 tool (H)
R10644		No.3 magazine T8-digit Standby 2 tool (L)
R10645		No.3 magazine T8-digit Standby 2 tool (H)
R10646		No.3 magazine T8-digit Standby 3 tool (L)
R10647		No.3 magazine T8-digit Standby 3 tool (H)
R10648		No.3 magazine T8-digit Standby 4 tool (L)
R10649		No.3 magazine T8-digit Standby 4 tool (H)
R10650		No.4 magazine T8-digit Spindle tool (L)
R10651		No.4 magazine T8-digit Spindle tool (H)
R10652		No.4 magazine T8-digit Standby 1 tool (L)
R10653		No.4 magazine T8-digit Standby 1 tool (H)
R10654		No.4 magazine T8-digit Standby 2 tool (L)
R10655		No.4 magazine T8-digit Standby 2 tool (H)
R10656		No.4 magazine T8-digit Standby 3 tool (L)
R10657		No.4 magazine T8-digit Standby 3 tool (H)
R10658		No.4 magazine T8-digit Standby 4 tool (L)
R10659		No.4 magazine T8-digit Standby 4 tool (H)
R10660		No.5 magazine T8-digit Spindle tool (L)
R10661		No.5 magazine T8-digit Spindle tool (H)
R10662		No.5 magazine T8-digit Standby 1 tool (L)
R10663		No.5 magazine T8-digit Standby 1 tool (H)
R10664		No.5 magazine T8-digit Standby 2 tool (L)
R10665		No.5 magazine T8-digit Standby 2 tool (H)
R10666		No.5 magazine T8-digit Standby 3 tool (L)
R10667		No.5 magazine T8-digit Standby 3 tool (H)
R10668		No.5 magazine T8-digit Standby 4 tool (L)
R10669		No.5 magazine T8-digit Standby 4 tool (H)
R10670		No.1 magazine Spindle tool D
R10671		No.1 magazine Standby 1 tool D
R10672		No.1 magazine Standby 2 tool D
R10673		No.1 magazine Standby 3 tool D
R10674		No.1 magazine Standby 4 tool D
R10675		No.2 magazine Spindle tool D
R10676		No.2 magazine Standby 1 tool D
R10677		No.2 magazine Standby 2 tool D
R10678		No.2 magazine Standby 3 tool D
R10679		No.2 magazine Standby 4 tool D
R10680		No.3 magazine Spindle tool D
R10681		No.3 magazine Standby 1 tool D
R10682		No.3 magazine Standby 2 tool D
R10683		No.3 magazine Standby 3 tool D

III PLC Devices
7. Each Application : Tool Life Management Interface

Device	Abbrev.	Signal name
R10684		No.3 magazine Standby 4 tool D
R10685		No.4 magazine Spindle tool D
R10686		No.4 magazine Standby 1 tool D
R10687		No.4 magazine Standby 2 tool D
R10688		No.4 magazine Standby 3 tool D
R10689		No.4 magazine Standby 4 tool D
R10690		No.5 magazine Spindle tool D
R10691		No.5 magazine Standby 1 tool D
R10692		No.5 magazine Standby 2 tool D
R10693		No.5 magazine Standby 3 tool D
R10694		No.5 magazine Standby 4 tool D
R10695		Head No. of No.1 magazine
R10696		Head No. of No.2 magazine
R10697		Head No. of No.3 magazine
R10698		Head No. of No.4 magazine
R10699		Head No. of No.5 magazine
R10700		No.1 magazine tool data
R11060		No.2 magazine tool data
R11420		No.3 magazine tool data
R11800		Standby tool: Group No. 1st-phase
R11801		Standby tool: Group No. 1st-phase
R11802		Standby tool: Tool No. 1st-phase
R11803		Standby tool: Tool No. 1st-phase
R11804		Standby tool: Tool data flag/status 1st-phase
R11805		Standby tool: Auxiliary data 1st-phase
R11816		Standby tool: Length compensation amount 1st-phase
R11817		Standby tool: Length compensation amount 1st-phase
R11818		Standby tool: Radius compensation amount 1st-phase
R11819		Standby tool: Radius compensation amount 1st-phase
R11824		Active tool: Group No. 1st-phase
R11825		Active tool: Group No. 1st-phase
R11826		Active tool: Tool No. 1st-phase
R11826		Spindle tool No. 1st-phase
R11827		Active tool: Tool No. 1st-phase
R11827		Spindle tool No. 1st-phase
R11828		Active tool: Tool data flag/status 1st-phase
R11829		Active tool: Auxiliary data 1st-phase
R11840		Active tool: Length compensation amount 1st-phase
R11841		Active tool: Length compensation amount 1st-phase
R11842		Active tool: Radius compensation amount 1st-phase
R11843		Active tool: Radius compensation amount 1st-phase
R11850		Standby tool: Group No. 2nd-phase
R11851		Standby tool: Group No. 2nd-phase
R11852		Standby tool: Tool No. 2nd-phase
R11853		Standby tool: Tool No. 2nd-phase
R11854		Standby tool: Tool data flag/status 2nd-phase
R11855		Standby tool: Auxiliary data 2nd-phase
R11866		Standby tool: Length compensation amount 2nd-phase
R11867		Standby tool: Length compensation amount 2nd-phase
R11868		Standby tool: Radius compensation amount 2nd-phase
R11869		Standby tool: Radius compensation amount 2nd-phase
R11874		Active tool: Group No. 2nd-phase
R11875		Active tool: Group No. 2nd-phase
R11876		Active tool: Tool No. 2nd-phase
R11876		Spindle tool No. 2nd-phase
R11877		Active tool: Tool No. 2nd-phase
R11877		Spindle tool No. 2nd-phase
R11878		Active tool: Tool data flag/status 2nd-phase
R11879		Active tool: Auxiliary data 2nd-phase
R11890		Active tool: Length compensation amount 2nd-phase
R11891		Active tool: Length compensation amount 2nd-phase
R11892		Active tool: Radius compensation amount 2nd-phase
R11893		Active tool: Radius compensation amount 2nd-phase
R11900		Standby tool: Group No. 3rd-phase
R11901		Standby tool: Group No. 3rd-phase
R11902		Standby tool: Tool No. 3rd-phase
R11903		Standby tool: Tool No. 3rd-phase
R11904		Standby tool: Tool data flag/status 3rd-phase
R11905		Standby tool: Auxiliary data 3rd-phase
R11916		Standby tool: Length compensation amount 3rd-phase
R11917		Standby tool: Length compensation amount 3rd-phase
R11918		Standby tool: Radius compensation amount 3rd-phase
R11919		Standby tool: Radius compensation amount 3rd-phase
R11924		Active tool: Group No. 3rd-phase
R11925		Active tool: Group No. 3rd-phase
R11926		Active tool: Tool No. 3rd-phase
R11926		Spindle tool No. 3rd-phase
R11927		Active tool: Tool No. 3rd-phase
R11927		Spindle tool No. 3rd-phase
R11928		Active tool: Tool data flag/status 3rd-phase

III PLC Devices

7. Each Application : Tool Life Management Interface

Device	Abbrev.	Signal name
R11929		Active tool: Auxiliary data 3rd-phase
R11940		Active tool: Length compensation amount 3rd-phase
R11941		Active tool: Length compensation amount 3rd-phase
R11942		Active tool: Radius compensation amount 3rd-phase
R11943		Active tool: Radius compensation amount 3rd-phase
R11950		Standby tool: Group No. 4th-phase
R11951		Standby tool: Group No. 4th-phase
R11952		Standby tool: Tool No. 4th-phase
R11953		Standby tool: Tool No. 4th-phase
R11954		Standby tool: Tool data flag/status 4th-phase
R11955		Standby tool: Auxiliary data 4th-phase
R11966		Standby tool: Length compensation amount 4th-phase
R11967		Standby tool: Length compensation amount 4th-phase
R11968		Standby tool: Radius compensation amount 4th-phase
R11969		Standby tool: Radius compensation amount 4th-phase
R11974		Active tool: Group No. 4th-phase
R11975		Active tool: Group No. 4th-phase
R11976		Active tool: Tool No. 4th-phase
R11976		Spindle tool No. 4th-phase
R11977		Active tool: Tool No. 4th-phase
R11977		Spindle tool No. 4th-phase
R11978		Active tool: Tool data flag/status 4th-phase
R11979		Active tool: Auxiliary data 4th-phase
R11990		Active tool: Length compensation amount 4th-phase
R11991		Active tool: Length compensation amount 4th-phase
R11992		Active tool: Radius compensation amount 4th-phase
R11993		Active tool: Radius compensation amount 4th-phase
R12202		Standby tool No. 1st-phase
R12203		Standby tool No. 1st-phase
R12212		Standby tool No. 2nd-phase
R12213		Standby tool No. 2nd-phase
R12222		Standby tool No. 3rd-phase
R12223		Standby tool No. 3rd-phase
R12232		Standby tool No. 4th-phase
R12233		Standby tool No. 4th-phase

III PLC Devices
8. Special Relays

Device	Abbrev.	Signal name
SM16	THER	Temperature rise

MITSUBISHI CNC



MODEL	700/70 Series
MODEL CODE	100—175
Manual No.	IB-1500087 (ENG)