



Side A JAPANESE  
Side B ENGLISH

Programmable Controller  
MELSEC-F

FX3U-64DP-M

INSTALLATION MANUAL



Manual Number	JY997D19901
Revision	E
Date	March 2018

This manual describes the part names, dimensions, installation, and specifications of the product. Before use, read this manual and manuals of relevant products fully to acquire proficiency in handling and operating the product. Make sure to learn all the product information, safety information, and precautions.

Store this manual in a safe place so that it can be taken out and read whenever necessary. Always forward it to the end user.

Registration

The company name and the product name to be described in this manual are the registered trademarks or trademarks of each company.

Effective March 2018

Specifications are subject to change without notice.

© 2005 Mitsubishi Electric Corporation

Safety Precautions (Read these precautions before use.)

This manual classifies the safety precautions into two categories:

⚠️ WARNING and ⚠️ CAUTION

<b>⚠️ WARNING</b>	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
<b>⚠️ CAUTION</b>	Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Depending on circumstances, procedures indicated by ⚠️ CAUTION may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Associated Manuals

Manual name	Manual No.	Description
FX3U Series User's Manual - Hardware Edition	JY997D16501 MODEL CODE: 09R516	Explains FX3U Series PLC specification details for I/O, wiring, installation, and maintenance.
FX3UC Series User's Manual - Hardware Edition	JY997D28701 MODEL CODE: 09R519	Explains FX3UC Series PLC specification details for I/O, wiring, installation, and maintenance.
FX3S/FX3G/FX3GC/FX3U/FX3UC Series Programming Manual - Basic & Applied Instruction Edition	JY997D16601 MODEL CODE: 09R517	Describes PLC programming for basic/applied instructions and devices.
FX3U-64DP-M User's Manual	JY997D19201	Contents explanations for wiring, installation, specification and allocation of BFM's, etc. for FX3U-64DP-M PROFIBUS-DP Master Block.
GX Configurator-DP Configuration System for Open Networks Software Manual	-	Contents explanations for operation of GX Configurator-DP Configuration System for Open Networks Software.

How to obtain manuals

For the necessary product manuals or documents, consult with the Mitsubishi Electric dealer from where you purchased your product.

Certification of UL, cUL standards

The following product has UL and cUL certification.

UL, cUL File Number: E95239

Regarding the standards that comply with the main unit, please refer to either the FX series product catalog or consult with your nearest Mitsubishi product provider.

Compliance with EC directive (CE Marking)

This note does not guarantee that an entire mechanical module produced in accordance with the contents of this note will comply with the following standards. Compliance to EMC directive and LVD directive for the entire mechanical module should be checked by the user / manufacturer. For more details please contact the local Mitsubishi Electric sales site.

Requirement for Compliance with EMC directive

The following products have shown compliance through direct testing (of the identified standards below) and design analysis (through the creation of a technical construction file) to the European Directive for Electromagnetic Compatibility (2014/30/EU) when used as directed by the appropriate documentation.

Attention

This product is designed for use in industrial applications.

Type: Programmable Controller (Open Type Equipment)


Models: MELSEC FX3U series manufactured

from August 1st, 2005 FX3U-64DP-M

Standard	Remark
EN61131-2:2007 Programmable controllers - Equipment requirements and tests	Compliance with all relevant aspects of the standard. <b>EMI</b> • Radiated Emission • Conducted Emission <b>EMS</b> • Radiated electromagnetic field • Fast transient burst • Electrostatic discharge • High-energy surge • Voltage drops and interruptions • Conducted RF • Power frequency magnetic field

Caution for Compliance with EC Directive

- Installation in Enclosure  
Programmable controllers are open-type devices that must be installed and used within conductive control cabinets. Please use the programmable controller while installed within a conductive shielded control cabinet. Please secure the cabinet door to the control cabinet (for conduction). Installation within a control cabinet greatly affects the safety of the system and aids in shielding noise from the programmable controller.
- Control cabinet
  - The control cabinet must be conductive.
  - Ground the control cabinet with the thickest possible grounding cable.
  - To ensure that there is electric contact between the control cabinet and its door, connect the cabinet and its doors with thick wires.
  - In order to suppress the leakage of radio waves, the control cabinet structure must have minimal openings. Also, wrap the cable holes with a shielding cover or other shielding devices.
  - The gap between the control cabinet and its door must be as small as possible by attaching EMI gaskets between them.



\*1 These wires are used to improve the conductivity between the door and control cabinet.

- Caution for wiring  
For noise prevention please attach at least 50 mm (1.97") of the twisted-pair cable along the grounding plate to which the ground terminal is connected.

→ For details of wiring, refer to Section 3.2

1. Introduction

The FX3U-64DP-M PROFIBUS-DP Master Block (hereafter called "64DP-M") is a Master (Class 1) for the PROFIBUS-DP network. The FX3U/FX3UC<sup>1</sup> Series PLC, when connected to the 64DP-M, can read input data from the DP-Slave, and write output data to the DP-Slave. Only one 64DP-M can be connected directly to the FX3U/FX3UC<sup>1</sup> series PLC's extension port, or to any other extension unit / block's right side extension port.


→ For details, refer to FX3U-64DP-M User's Manual

\*1 An FX2NC-CNV-IF or FX3UC-1PS-5V is necessary to connect to the 64DP-M with the FX3UC Series PLC. However, the 64DP-M cannot be connected to the FX3UC-32MT-LT(-2).

1.1 Incorporated Items

Included Item	
FX3U-64DP-M	1 unit
Special Unit/Block No. label	1 sheet
Dust proof sheet	1 sheet
Manuals (Japanese version, English version)	1 manual each

1.2 External Dimensions and Part Names<sup>1</sup>



- [1] PROFIBUS-DP port (9-pin D-SUB Connector: #4-40unc inch screw thread)
- [2] Extension cable
- [3] Direct mounting hole: 2 holes of φ4.5 (0.18") (mounting screw: M4 screw)
- [4] Status LED

LED Name	Color	Description
RUN	Green	Lit: During normal operation → For other status, refer to FX3U-64DP-M User's Manual
TOKEN	Green	Lit when token is maintained.
FROM/TO	Green	Lit when accessing from PLC by FROM/TO instruction.
ERROR	Red	Unlit: During normal operation Otherwise: An error occurs. → For error details, refer to FX3U-64DP-M User's Manual
POWER	Green	Lit while 24V DC power is properly supplied from FX3U PLC.

- [5] Extension port under the top cover
- [6] Name plate
- [7] DIN rail mounting groove (DIN rail: DIN46277)
- [8] DIN rail mounting hook

1.3 Pin configuration of PROFIBUS-DP Connector

The connector is a 9-pin D-SUB (#4-40unc inch screw thread) type, with the pin configuration shown below.

Pin No.	Signal Name	Meaning
3	RXD/TXD-P	Receive/transmit-Data-P
5	DGND	Data Ground
6	VP	Voltage-Plus (5V, 90mA)
8	RXD/TXD-N	Receive/transmit-Data-N
1, 2, 4, 7, 9	NC	Pin not assigned

- Assigned
- Not assigned

2. Installation

**INSTALLATION PRECAUTIONS** ⚠️ **WARNING**

- Cut off all phases of the power source externally before starting the installation or wiring work, thus avoiding electric shock or damages to the product.

**INSTALLATION PRECAUTIONS** ⚠️ **CAUTION**

- Use the product in the environment within the general specifications described in the PLC main unit manual (Hardware Edition). Never use the product in areas with dust, oily smoke, conductive dusts, corrosive gas (salt air, Cl<sub>2</sub>, H<sub>2</sub>S, SO<sub>2</sub> or NO<sub>2</sub>), flammable gas, vibrations or impacts, or expose it to high temperature, condensation, or wind and rain. If the product is used in such a place described above, electrical shock, fire, malfunction, damage, or deterioration may be caused.
- Install the product securely using the DIN rail or screws.
- Install the product on a flat surface. If the mounting surface is rough, undue force will be applied to the PC board, thereby causing nonconformity.
- When drilling screw holes or wiring, make sure or cutting or wire debris does not enter ventilation slits. This may cause fire, failures, or malfunctions.
- Be sure to remove the dust proof sheet from the PLC's ventilation slits when the installation work is completed. Failure to do so could cause fires, equipment failures, and malfunctions.
- Fit the extension cables and communication cables securely to the designated connectors. Contact failures may cause malfunctions.
- Do not touch the conductive parts of the product directly, in order to avoid failure or malfunction.

2.1 Connection with PLC

Only one FX3U-64DP-M can be connected to the right side of a PLC main unit or extension unit/block (including special function units/blocks). An FX2NC-CNV-IF or FX3UC-1PS-5V is necessary to connect to the 64DP-M with the FX3UC Series PLC. However, the 64DP-M cannot be connected to the FX3UC-32MT-LT(-2).

For details, refer to the respective PLC manual.  
→ FX3U Series User's Manual - Hardware Edition  
→ FX3UC Series User's Manual - Hardware Edition

2.2 Mounting

The 64DP-M can be mounted on a DIN rail (DIN46227) or mounted directly using screws. For the details of installation, refer to the following manual.  
→ FX3U Series User's Manual - Hardware Edition  
→ FX3UC Series User's Manual - Hardware Edition


2.2.1 Direct Mounting

The 64DP-M can be mounted with M4 screws by using the direct mounting holes. An interval space between each unit of 1 to 2 mm (0.04" to 0.08") is necessary.  
→ For the mounting hole pitch information, refer to Section 1.2

2.2.2 DIN Rail Mounting


The 64DP-M can be mounted on a DIN rail (DIN46227, 35mm width).

- Fit the upper edge of the DIN rail mounting groove (right fig. A) onto the DIN rail.
- Push the product onto the DIN rail.



- Connect extension cable to the main unit, I/O extension unit/block, or special function unit/block of the left side.

→ FX3U Series User's Manual - Hardware Edition  
→ FX3UC Series User's Manual - Hardware Edition



### 3. Wiring

**DESIGN PRECAUTIONS** **CAUTION**

- Make sure to observe the precautions below in order to prevent any damage to a machine or any accident which might be caused by abnormal data written in the PLC due to the influence of noise:
  - Do not lay wires close or bundle with the main circuit, high-voltage power line, or load line.  
Otherwise effects of noise or surge induction are likely to take place. Keep a safe distance of more than 100 mm (3.94") from the above when wiring.
  - Ground the shield wire or shield of a shielded cable at one point on the PLC. However, do not ground at the same point as high voltage lines.
- Install in a manner which prevents excessive force from being applied to the connectors for peripheral device connections.  
Failure to do so may result in wire breakage or failure of the PLC.

**WIRING PRECAUTIONS** **WARNING**

- Cut off all phases of power source externally, before installation or wiring work in order to avoid electric shock or damage of product.

**WIRING PRECAUTIONS** **CAUTION**

- Never let cutting chips and wire chips enter the ventilation slits of this product or PLC when performing wiring.  
Otherwise, fire, failure, or malfunction may occur.
- When drilling screw holes or wiring, cutting chips or wire chips should not enter ventilation slits. This may cause fire, failures, or malfunctions.


#### 3.1 Applicable Cable and Connector

The following table shows the applicable cable and connector for PROFIBUS-DP network.

Item	Description
PROFIBUS-DP network cable	Shielded twisted-pair PROFIBUS cable complying with EN50170
Connector	Applicable only to PROFIBUS connector (9-pin D-SUB Connector: #4-40unc inch screw thread) → For PROFIBUS connectors see the PROFIBUS connector manual

#### 3.2 Wiring


To connect the 64DP-M to a PROFIBUS-DP network, use only the PROFIBUS connector and shielded twisted-pair PROFIBUS cable complying with EN50170.



### 3.3 Grounding

Grounding should be performed as stated below.

- The grounding resistance should be 100Ω or less.
- Independent grounding should be performed for best results.  
When independent grounding is not performed, perform "shared grounding" of the following figure.



- The grounding wire size should be as follows.

PLC Type	Grounding Wire Size
FX3U Series PLC	AWG 14 (2 mm <sup>2</sup> ) or larger
FX3UC Series PLC	AWG 22-20 (0.3 to 0.5 mm <sup>2</sup> )

- The grounding point should be close to the PLC, and all grounding wire should be as short as possible.

#### 3.4 Bus Terminator

The units at each end of the PROFIBUS-DP network must have a bus terminator. This will either be in the DP-Master or DP-Slave unit or in the PROFIBUS connector. However, the 64DP-M does not have a terminating resistance built-in.

### 4. Specifications

**DESIGN PRECAUTIONS** **WARNING**

- Provide a safety circuit on the outside of the PLC so that the whole system operates to ensure the safety even when external power supply trouble or PLC failure occurs.  
Otherwise, malfunctions or output failures may result in an accident.
  - An emergency stop circuit, a protection circuit, an interlock circuit for opposite movements, such as normal and reverse rotations, and an interlock circuit for preventing damage to the machine at the upper and lower positioning limits should be configured on the outside of the PLC.
  - When the PLC CPU detects an error, such as a watch dog timer error, during self-diagnosis, all outputs are turned off. When an error that cannot be detected by the PLC CPU occurs in an input/output control block, output control may be disabled.  
Design external circuits and mechanisms to ensure safe operations of the machine in such a case.
  - When some sort of error occurs in a relay, triac or transistor of the output unit/block, output may be kept on or off.  
For output signals that may lead to serious accidents, design external circuits and mechanisms to ensure safe operations of the machine.

**DESIGN PRECAUTIONS** **CAUTION**

- Make sure to observe the precautions below in order to prevent any damage to a machine or any wires accident which might be caused by abnormal data written in the PLC due to the influence of noise:
  - Do not lay close or bundle with the main circuit, high-voltage power line, or load line.  
Otherwise effects of noise or surge induction are likely to take place. Keep a safe distance of more than 100 mm (3.94") from the above when wiring.
  - Ground the shield wire or shield of a shielded cable at one point on the PLC. However, do not ground at the same point as high voltage lines.
- Install in a manner which prevents excessive force from being applied to the connectors for peripheral device connections.  
Failure to do so may result in wire breakage or failure of the PLC.

**STARTUP AND MAINTENANCE PRECAUTIONS** **WARNING**

- Do not touch any terminal while the PLC's power is on.  
Doing so may cause electrical shock or malfunctions.
- Before cleaning or retightening terminals, externally cut off all phases of the power supply. Failure to do so may expose you to shock hazard.
- Before modifying the program under operation or performing operation for forcible output, running or stopping, carefully read the manual, and sufficiently ensure the safety. An operation error may damage the machine or cause accidents.

**STARTUP AND MAINTENANCE PRECAUTIONS** **CAUTION**

- Do not disassemble or modify the unit.  
Doing so may cause failure, malfunction or fire.  
\* For repair, contact your local Mitsubishi Electric representative.
- Do not drop the product or do not exert strong impact, as doing so may cause damage.
- Before connecting or disconnecting any extension cable, turn off power.  
Failure to do so may cause unit failure or malfunctions.

**DISPOSAL PRECAUTIONS** **CAUTION**

- Please contact a company certified in the disposal of electronic waste for environmentally safe recycling and disposal of the product.

**TRANSPORTATION AND STORAGE PRECAUTIONS** **CAUTION**

- The product is a precision instrument. During transportation, avoid impacts larger than those specified in the general specifications by using dedicated packaging boxes and shock-absorbing pallets. Failure to do so may cause failures in the product. After transportation, verify operation of the product and check for damage of the mounting part, etc.

#### 4.1 Applicable PLC

Model name	Applicability
FX3U Series PLC	Ver. 2.21 or later
FX3UC Series PLC <sup>1</sup>	Ver. 2.21 or later

<sup>1</sup> An FX2NC-CNV-IF or FX3UC-1PS-5V is necessary to connect to the 64DP-M with the FX3UC Series PLC.  
However, the 64DP-M cannot be connected to the FX3UC-32MT-LT(-2).

#### 4.2 General Specifications

For the general specification, refer to the manual of the PLC main unit. The items other than the following are equivalent to those of the PLC main unit. However, please don't perform any dielectric withstand voltage tests and insulation resistance tests to this product.

- Refer to FX3U Series User's Manual - Hardware Edition
- Refer to FX3UC Series User's Manual - Hardware Edition

Item	Specifications	
Withstand voltage	500 V AC for 1 min	Between communication connector frame and ground terminal of PLC main unit
Insulation resistance	5 MΩ or higher by 500 V DC insulation resistance tester	

#### 4.3 Power Supply Specifications

24V DC, 155 mA is supplied from the internal power supply (service power supply) in main unit.

#### 4.4 Performance Specifications

Item	Specifications	
Transmission Type	Bus network	
Unit Type	PROFIBUS-DP master Class 1	
Transmission Data (Maximum Exchanged Data Length)	<ul style="list-style-type: none"> <li>Normal service mode: 32 bytes / slave</li> <li>Extended service mode (default): 244 bytes/slave</li> </ul>	
Maximum Number of FX3U-64DP-M at one PLC	1 unit	
Maximum Number of FX3U-64DP-M at one PROFIBUS-DP Network	3 units In case of multi master configuration, all master stations must be FX3U-64DP-M.	
Maximum Number of Repeaters / Communication Path	3 units	
Maximum Number of Stations / Segment	32 stations	
Maximum Number of Slaves / Master	64 slaves	
No. of Connectable Nodes	31, 61 (1), 91 (2), 121 (3)	
Supported Transmission speed (bps) and Bus Length	9.6k, 19.2k, 93.75k	1,200 m (3,937') / segment
	187.5k	1,000 m (3,281') / segment
	500k	400 m (1,312') / segment
	1.5 M	200 m (656') / segment
	3M, 6M, 12M	100 m (328') / segment
PNO ID	"F364" hex	
Connector	Port for PROFIBUS-DP network (9 pin D-SUB Connector)	
Global Control	Synchronization, unsynchronization, freeze and unfreeze modes are supported.	
Terminal Resistor	Not built in.	

### 4.5 Maximum Bus Length and Baud Rate

Length that the bus can be expanded by using repeaters.  
Maximum Bus Length = (No. of repeaters + 1) \* (Bus Length / segment)

Baud Rate (bps)	Maximum Bus Length			
	No repeater	1 repeater	2 repeaters	3 repeaters
9.6k, 19.2k, 93.75k	1,200 m (3,937')	2,400 m (7,874')	3,600 m (11,811')	4,800 m (15,748')
187.5k	1,000 m (3,281')	2,000 m (6,562')	3,000 (9,843')	4,000 m (13,123')
500k	400 m (1,312')	800 m (2,625')	1,200 m (3,937')	1,600 m (5,249')
1.5 M	200 m (656')	400 m (1,312')	600 m (1,969')	800 m (2,625')
3M, 6M, 12M	100 m (328')	200 m (656')	300 m (984')	400 m (1,312')

「电器电子产品有害物质限制使用标识要求」的表示方式

**15** Note: This symbol mark is for China only.

含有有害6物质的名称, 含有量, 含有部品  
本产品中所含有的有害6物质的名称, 含有量, 含有部品如下表所示。

部件名称	产品中有害物质的名称及含量					
	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
可编程控制器	○	○	○	○	○	○
外壳	○	○	○	○	○	○
印刷基板	×	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。

○: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。  
×: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

基于中国标准法的参考规格: GB/T15969.2

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

**Warranty**  
Exclusion of loss in opportunity and secondary loss from warranty liability  
Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:  
(1) Damages caused by any cause found not to be the responsibility of Mitsubishi.  
(2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.  
(3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.  
(4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

**For safe use**

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi Electric.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

**MITSUBISHI ELECTRIC CORPORATION**

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN





Side A JAPANESE  
Side B ENGLISH

FX3U-64DP-M

INSTALLATION MANUAL



Manual Number	JY997D19901
Revision	E
Date	March 2018

This manual describes the part names, dimensions, installation, and specifications of the product. Before use, read this manual and manuals of relevant products fully to acquire proficiency in handling and operating the product. Make sure to learn all the product information, safety information, and precautions.

Store this manual in a safe place so that it can be taken out and read whenever necessary. Always forward it to the end user.

Registration  
The company name and the product name to be described in this manual are the registered trademarks or trademarks of each company.

Effective March 2018  
Specifications are subject to change without notice.

© 2005 Mitsubishi Electric Corporation

Safety Precautions (Read these precautions before use.)

This manual classifies the safety precautions into two categories:

WARNING and CAUTION

<b>WARNING</b>	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
<b>CAUTION</b>	Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Depending on circumstances, procedures indicated by CAUTION may also be linked to serious results.  
In any case, it is important to follow the directions for usage.

Associated Manuals

Manual name	Manual No.	Description
FX3U Series User's Manual - Hardware Edition	JY997D16501 MODEL CODE: 09R516	Explains FX3U Series PLC specification details for I/O, wiring, installation, and maintenance.
FX3UC Series User's Manual - Hardware Edition	JY997D28701 MODEL CODE: 09R519	Explains FX3UC Series PLC specification details for I/O, wiring, installation, and maintenance.
FX3S/FX3G/FX3GC/FX3U/FX3UC Series Programming Manual - Basic & Applied Instruction Edition	JY997D16601 MODEL CODE: 09R517	Describes PLC programming for basic/applied instructions and devices.
FX3U-64DP-M User's Manual	JY997D19201	Contents explanations for wiring, installation, specification and allocation of BFM's, etc. for FX3U-64DP-M PROFIBUS-DP Master Block.
GX Configurator-DP Configuration System for Open Networks Software Manual	-	Contents explanations for operation of GX Configurator-DP Configuration System for Open Networks Software.

How to obtain manuals  
For the necessary product manuals or documents, consult with the Mitsubishi Electric dealer from where you purchased your product.

Certification of UL, cUL standards

The following product has UL and cUL certification.  
UL cUL File Number: E95239  
Regarding the standards that comply with the main unit, please refer to either the FX series product catalog or consult with your nearest Mitsubishi product provider.

Compliance with EC directive (CE Marking)

This note does not guarantee that an entire mechanical module produced in accordance with the contents of this note will comply with the following standards. Compliance to EMC directive and LVD directive for the entire mechanical module should be checked by the user / manufacturer. For more details please contact the local Mitsubishi Electric sales site.

Requirement for Compliance with EMC directive

The following products have shown compliance through direct testing (of the identified standards below) and design analysis (through the creation of a technical construction file) to the European Directive for Electromagnetic Compatibility (2014/30/EU) when used as directed by the appropriate documentation.

Attention  
This product is designed for use in industrial applications.


Type: Programmable Controller (Open Type Equipment)

Models: MELSEC FX3U series manufactured from August 1st, 2005 FX3U-64DP-M

Standard	Remark
EN61131-2:2007 Programmable controllers - Equipment requirements and tests	Compliance with all relevant aspects of the standard. <b>EMI</b> • Radiated Emission • Conducted Emission <b>EMS</b> • Radiated electromagnetic field • Fast transient burst • Electrostatic discharge • High-energy surge • Voltage drops and interruptions • Conducted RF • Power frequency magnetic field

Caution for Compliance with EC Directive

- Installation in Enclosure  
Programmable controllers are open-type devices that must be installed and used within conductive control cabinets. Please use the programmable controller while installed within a conductive shielded control cabinet. Please secure the cabinet door to the control cabinet (for conduction). Installation within a control cabinet greatly affects the safety of the system and aids in shielding noise from the programmable controller.
- Control cabinet  
- The control cabinet must be conductive.  
- Ground the control cabinet with the thickest possible grounding cable.  
- To ensure that there is electric contact between the control cabinet and its door, connect the cabinet and its doors with thick wires.  
- In order to suppress the leakage of radio waves, the control cabinet structure must have minimal openings. Also, wrap the cable holes with a shielding cover or other shielding devices.  
- The gap between the control cabinet and its door must be as small as possible by attaching EMI gaskets between them.



- These wires are used to improve the conductivity between the door and control cabinet.
- Caution for wiring  
For noise prevention please attach at least 50 mm (1.97") of the twisted-pair cable along the grounding plate to which the ground terminal is connected.  
→ For details of wiring, refer to Section 3.2

1. Introduction


The FX3U-64DP-M PROFIBUS-DP Master Block (hereafter called "64DP-M") is a Master (Class 1) for the PROFIBUS-DP network. The FX3U/FX3UC<sup>1</sup> Series PLC, when connected to the 64DP-M, can read input data from the DP-Slave, and write output data to the DP-Slave. Only one 64DP-M can be connected directly to the FX3U/FX3UC<sup>1</sup> series PLC's extension port, or to any other extension unit / block's right side extension port.  
→ For details, refer to FX3U-64DP-M User's Manual

<sup>1</sup> An FX2NC-CNV-IF or FX3UC-1PS-5V is necessary to connect to the 64DP-M with the FX3UC Series PLC.  
However, the 64DP-M cannot be connected to the FX3UC-32MT-LT(-2).

1.1 Incorporated Items

Included Item	Quantity
FX3U-64DP-M	1 unit
Special Unit/Block No. label	1 sheet
Dust proof sheet	1 sheet
Manuals (Japanese version, English version)	1 manual each

1.2 External Dimensions and Part Names



- PROFIBUS-DP port (9-pin D-SUB Connector: #4-40unc inch screw thread)
- Extension cable
- Direct mounting hole: 2 holes of  $\phi 4.5$  (0.18") (mounting screw: M4 screw)
- Status LED

LED Name	Color	Description
RUN	Green	Lit: During normal operation → For other status, refer to FX3U-64DP-M User's Manual
TOKEN	Green	Lit when token is maintained.
FROM/TO	Green	Lit when accessing from PLC by FROM/TO instruction.
ERROR	Red	Unlit: During normal operation Otherwise: An error occurs. → For error details, refer to FX3U-64DP-M User's Manual
POWER	Green	Lit while 24V DC power is properly supplied from FX3U PLC.

- Extension port under the top cover
- Name plate
- DIN rail mounting groove (DIN rail: DIN46277)
- DIN rail mounting hook

1.3 Pin configuration of PROFIBUS-DP Connector

The connector is a 9-pin D-SUB (#4-40unc inch screw thread) type, with the pin configuration shown below.

Pin No.	Signal Name	Meaning
3	RXD/TXD-P	Receive/transmit-Data-P
5	DGND	Data Ground
6	VP	Voltage-Plus (5V, 90mA)
8	RXD/TXD-N	Receive/transmit-Data-N
1, 2, 4, 7, 9	NC	Pin not assigned

● Assigned  
○ Not assigned

2. Installation

**INSTALLATION PRECAUTIONS** **WARNING**

- Cut off all phases of the power source externally before starting the installation or wiring work, thus avoiding electric shock or damages to the product.

**INSTALLATION PRECAUTIONS** **CAUTION**

- Use the product in the environment within the general specifications described in the PLC main unit manual (Hardware Edition).  
Never use the product in areas with dust, oily smoke, conductive dusts, corrosive gas (salt air, Cl<sub>2</sub>, H<sub>2</sub>S, SO<sub>2</sub> or NO<sub>2</sub>), flammable gas, vibrations or impacts, or expose it to high temperature, condensation, or wind and rain. If the product is used in such a place described above, electrical shock, fire, malfunction, damage, or deterioration may be caused.
- Install the product securely using the DIN rail or screws.
- Install the product on a flat surface.  
If the mounting surface is rough, undue force will be applied to the PC board, thereby causing nonconformity.
- When drilling screw holes or wiring, make sure or cutting or wire debris does not enter ventilation slits.  
This may cause fire, failures, or malfunctions.
- Be sure to remove the dust proof sheet from the PLC's ventilation slits when the installation work is completed.  
Failure to do so could cause fires, equipment failures, and malfunctions.
- Fit the extension cables and communication cables securely to the designated connectors.  
Contact failures may cause malfunctions.
- Do not touch the conductive parts of the product directly, in order to avoid failure or malfunction.

2.1 Connection with PLC

Only one FX3U-64DP-M can be connected to the right side of a PLC main unit or extension unit/block (including special function units/blocks).  
An FX2NC-CNV-IF or FX3UC-1PS-5V is necessary to connect to the 64DP-M with the FX3UC Series PLC. However, the 64DP-M cannot be connected to the FX3UC-32MT-LT(-2).  
For details, refer to the respective PLC manual.  
→ FX3U Series User's Manual - Hardware Edition  
→ FX3UC Series User's Manual - Hardware Edition

2.2 Mounting

The 64DP-M can be mounted on a DIN rail (DIN46227) or mounted directly using screws. For the details of installation, refer to the following manual.  
→ FX3U Series User's Manual - Hardware Edition  
→ FX3UC Series User's Manual - Hardware Edition

2.2.1 Direct Mounting

The 64DP-M can be mounted with M4 screws by using the direct mounting holes. An interval space between each unit of 1 to 2 mm (0.04" to 0.08") is necessary.  
→ For the mounting hole pitch information, refer to Section 1.2

2.2.2 DIN Rail Mounting

The 64DP-M can be mounted on a DIN rail (DIN46227, 35mm width).  
1) Fit the upper edge of the DIN rail mounting groove (right fig. A) onto the DIN rail.  
2) Push the product onto the DIN rail.

3) Connect extension cable to the main unit, I/O extension unit/block, or special function unit/block of the left side.  
→ FX3U Series User's Manual - Hardware Edition  
→ FX3UC Series User's Manual - Hardware Edition

3. Wiring

**DESIGN PRECAUTIONS** **CAUTION**

- Make sure to observe the precautions below in order to prevent any damage to a machine or any accident which might be caused by abnormal data written in the PLC due to the influence of noise:  
1) Do not lay wires close or bundle with the main circuit, high-voltage power line, or load line.  
Otherwise effects of noise or surge induction are likely to take place. Keep a safe distance of more than 100 mm (3.94") from the above when wiring.
- Ground the shield wire or shield of a shielded cable at one point on the PLC. However, do not ground at the same point as high voltage lines.
- Install in a manner which prevents excessive force from being applied to the connectors for peripheral device connections.  
Failure to do so may result in wire breakage or failure of the PLC.

**WIRING PRECAUTIONS** **WARNING**

- Cut off all phases of power source externally, before installation or wiring work in order to avoid electric shock or damage of product.

**WIRING PRECAUTIONS** **CAUTION**

- Never let cutting chips and wire chips enter the ventilation slits of this product or PLC when performing wiring.  
Otherwise, fire, failure, or malfunction may occur.
- When drilling screw holes or wiring, cutting chips or wire chips should not enter ventilation slits. This may cause fire, failures, or malfunctions.


3.1 Applicable Cable and Connector

The following table shows the applicable cable and connector for PROFIBUS-DP network.

Item	Description
PROFIBUS-DP network cable	Shielded twisted-pair PROFIBUS cable complying with EN50170
Connector	Applicable only to PROFIBUS connector (9-pin D-SUB Connector: #4-40unc inch screw thread) → For PROFIBUS connectors see the PROFIBUS connector manual

3.2 Wiring

To connect the 64DP-M to a PROFIBUS-DP network, use only the PROFIBUS connector and shielded twisted-pair PROFIBUS cable complying with EN50170.




For noise prevention please attach at least 50 mm (1.97") of the twisted-pair PROFIBUS cable along the grounding plate to which the ground terminal is connected.

Shielded twisted-pair PROFIBUS cable complying with EN50170 to Profibus-DP network

Grounding resistance of 100 Ω or less (Class D)

3.3 Grounding

Grounding should be performed as stated below.  
• The grounding resistance should be 100Ω or less.  
• Independent grounding should be performed for best results.  
When independent grounding is not performed, perform "shared grounding" of the following figure.  
→ For details, refer to the FX3U Series User's Manual - Hardware Edition.  
→ For details, refer to the FX3UC Series User's Manual - Hardware Edition.



• The grounding wire size should be as follows.

PLC Type	Grounding Wire Size
FX3U Series PLC	AWG 14 (2 mm <sup>2</sup> ) or larger
FX3UC Series PLC	AWG 22-20 (0.3 to 0.5 mm <sup>2</sup> )

• The grounding point should be close to the PLC, and all grounding wire should be as short as possible.

3.4 Bus Terminator

The units at each end of the PROFIBUS-DP network must have a bus terminator. This will either be in the DP-Master or DP-Slave unit or in the PROFIBUS connector. However, the 64DP-M does not have a terminating resistance built-in.

4. Specifications

**DESIGN PRECAUTIONS** **WARNING**

- Provide a safety circuit on the outside of the PLC so that the whole system operates to ensure the safety even when external power supply trouble or PLC failure occurs.  
Otherwise, malfunctions or output failures may result in an accident.
- 1) An emergency stop circuit, a protection circuit, an interlock circuit for opposite movements, such as normal and reverse rotations, and an interlock circuit for preventing damage to the machine at the upper and lower positioning limits should be configured on the outside of the PLC.
- 2) When the PLC CPU detects an error, such as a watch dog timer error, during self-diagnosis, all outputs are turned off. When an error that cannot be detected by the PLC CPU occurs in an input/output control block, output control may be disabled.  
Design external circuits and mechanisms to ensure safe operations of the machine in such a case.
- 3) When some sort of error occurs in a relay, triac or transistor of the output unit/block, output may be kept on or off.  
For output signals that may lead to serious accidents, design external circuits and mechanisms to ensure safe operations of the machine.

**DESIGN PRECAUTIONS** **CAUTION**

- Make sure to observe the precautions below in order to prevent any damage to a machine or any wires accident which might be caused by abnormal data written in the PLC due to the influence of noise:  
1) Do not lay close or bundle with the main circuit, high-voltage power line, or load line.  
Otherwise effects of noise or surge induction are likely to take place. Keep a safe distance of more than 100 mm (3.94") from the above when wiring.
- 2) Ground the shield wire or shield of a shielded cable at one point on the PLC. However, do not ground at the same point as high voltage lines.
- Install in a manner which prevents excessive force from being applied to the connectors for peripheral device connections.  
Failure to do so may result in wire breakage or failure of the PLC.

**STARTUP AND MAINTENANCE PRECAUTIONS** **WARNING**

- Do not touch any terminal while the PLC's power is on.  
Doing so may cause electrical shock or malfunctions.
- Before cleaning or retightening terminals, externally cut off all phases of the power supply. Failure to do so may expose you to shock hazard.
- Before modifying the program under operation or performing operation for forcible output, running or stopping, carefully read the manual, and sufficiently ensure the safety. An operation error may damage the machine or cause accidents.

**STARTUP AND MAINTENANCE PRECAUTIONS** **CAUTION**

- Do not disassemble or modify the unit.  
Doing so may cause failure, malfunction or fire.  
\* For repair, contact your local Mitsubishi Electric representative.
- Do not drop the product or do not exert strong impact, as doing so may cause damage.
- Before connecting or disconnecting any extension cable, turn off power.  
Failure to do so may cause unit failure or malfunctions.

**DISPOSAL PRECAUTIONS** **CAUTION**

- Please contact a company certified in the disposal of electronic waste for environmentally safe recycling and disposal of the product.

**TRANSPORTATION AND STORAGE PRECAUTIONS** **CAUTION**

- The product is a precision instrument. During transportation, avoid impacts larger than those specified in the general specifications by using dedicated packaging boxes and shock-absorbing pallets. Failure to do so may cause failures in the product. After transportation, verify operation of the product and check for damage of the mounting part, etc.

4.1 Applicable PLC

Model name	Applicability
FX3U Series PLC	Ver. 2.21 or later
FX3UC Series PLC <sup>1</sup>	Ver. 2.21 or later

<sup>1</sup> An FX2NC-CNV-IF or FX3UC-1PS-5V is necessary to connect to the 64DP-M with the FX3UC Series PLC.  
However, the 64DP-M cannot be connected to the FX3UC-32MT-LT(-2).

4.2 General Specifications

For the general specification, refer to the manual of the PLC main unit.  
The items other than the following are equivalent to those of the PLC main unit.  
However, please don't perform any dielectric withstand voltage tests and insulation resistance tests to this product.  
→ Refer to FX3U Series User's Manual - Hardware Edition  
→ Refer to FX3UC Series User's Manual - Hardware Edition

Item	Specifications
Withstand voltage	500 V AC for 1 min
Insulation resistance	5 MΩ or higher by 500 V DC insulation resistance tester

4.3 Power Supply Specifications

24V DC, 155 mA is supplied from the internal power supply (service power supply) in main unit.

4.4 Performance Specifications

Item	Specifications										
Transmission Type	Bus network										
Unit Type	PROFIBUS-DP master Class 1										
Transmission Data (Maximum Exchanged Data Length)	• Normal service mode: 32 bytes / slave • Extended service mode (default): 244 bytes/slave										
Maximum Number of FX3U-64DP-M at one PLC	1 unit										
Maximum Number of FX3U-64DP-M at one PROFIBUS-DP Network	3 units In case of multi master configuration, all master stations must be FX3U-64DP-M.										
Maximum Number of Repeaters / Communication Path	3 units										
Maximum Number of Stations / Segment	32 stations										
Maximum Number of Slaves / Master	64 slaves										
No. of Connectable Nodes	31, 61 (1), 91 (2), 121 (3)										
Supported Transmission speed (bps) and Bus Length	<table border="1"> <tr> <td>9.6k, 19.2k, 93.75k</td> <td>1,200 m (3,937') / segment</td> </tr> <tr> <td>187.5k</td> <td>1,000 m (3,281') / segment</td> </tr> <tr> <td>500k</td> <td>400 m (1,312') / segment</td> </tr> <tr> <td>1.5 M</td> <td>200 m (656') / segment</td> </tr> <tr> <td>3M, 6M, 12M</td> <td>100 m (328') / segment</td> </tr> </table>	9.6k, 19.2k, 93.75k	1,200 m (3,937') / segment	187.5k	1,000 m (3,281') / segment	500k	400 m (1,312') / segment	1.5 M	200 m (656') / segment	3M, 6M, 12M	100 m (328') / segment
9.6k, 19.2k, 93.75k	1,200 m (3,937') / segment										
187.5k	1,000 m (3,281') / segment										
500k	400 m (1,312') / segment										
1.5 M	200 m (656') / segment										
3M, 6M, 12M	100 m (328') / segment										
PNO ID	"F364" hex										
Connector	PROFIBUS-DP Network Port for PROFIBUS-DP network (9 pin D-SUB Connector)										
Global Control	Synchronization, unsynchronization, freeze and unfreeze modes are supported.										
Terminal Resistor	Not built in.										

4.5 Maximum Bus Length and Baud Rate

Length that the bus can be expanded by using Repeaters.  
Maximum Bus Length = (No. of repeaters + 1) \* (Bus Length / segment)

Baud Rate (bps)	Maximum Bus Length			
	No repeater	1 repeater	2 repeaters	3 repeaters
9.6k, 19.2k, 93.75k	1,200 m (3,937')	2,400 m (7,874')	3,600 m (11,811')	4,800 m (15,748')
187.5k	1,000 m (3,281')	2,000 m (6,562')	3,000 m (9,843')	4,000 m (13,123')
500k	400 m (1,312')	800 m (2,625')	1,200 m (3,937')	1,600 m (5,249')
1.5 M	200 m (656')	400 m (1,312')	600 m (1,969')	800 m (2,625')
3M, 6M, 12M	100 m (328')	200 m (656')	300 m (984')	400 m (1,312')

「电器电子产品有害物质限制使用标识要求」的表示方式

Note: This symbol mark is for China only.

含有害物质的名称, 含有量, 含有部品  
本产品中所含有的有害6物质的名称, 含有量, 含有部品如下表所示。

部件名称	产品中有害物质的名称及含量					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
可编程控制器	○	○	○	○	○	○
印刷基板	×	○	○	○	○	○

本表格依据J/T 11364的规定编制。

○: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。  
×: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

基于中国标准法的参考规格: GB/T15969.2

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

**Warranty**  
Exclusion of loss in opportunity and secondary loss from warranty liability  
Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:  
(1) Damages caused by any cause found not to be the responsibility of Mitsubishi.  
(2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.  
(3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for products to others than Mitsubishi products.  
(4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

**For safe use**

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi Electric.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.