



## 2. 安装步骤

### 2.1 安装前请确认

- 安装至个人计算机时，请以“管理员”或“Administrator”权限的用户进行登录。
- 安装前，请结束所有运行的应用程序。如果在其他应用程序运行的状态下进行安装，有可能导致产品无法正常运行。
- 请禁用统一写入筛选器。
- 若存在正在使用CC-Link IE TSN通信库的用户程序，应在安装前停止该程序。

### 安装CC-Link IE TSN数据采集器

- 若要安装CC-Link IE TSN数据采集器，则应确认以下事项。
- 执行安装前，请先安装Edgecross基本软件及CC-Link IE TSN通信软件Windows版(SWIND-CCIETCT-M)。
  - 安装前，应将实时流程管理器与Management Shell的运行状态切换为STOP状态。
  - 使用CC-Link IE TSN数据采集器时，请勿启动将增加以太网驱动程序负载的应用程序。
  - 应在系统驱动器中确保360MB及以上的可用容量。
  - 必须启用.NET Framework 3.5。

### 2.2 步骤

1. 将CC-Link IE TSN通信软件Windows版DVD放入DVD驱动器中，并双击DVD内的“setup.exe”。
2. 请按画面指示选择或输入必要事项。

## 3. 产品构成

型号	产品名	数量
SWIND-CCIETCT-M	CC-Link IE TSN通信软件Windows版DVD	1
	安装步骤说明书(本说明书)	1
	最终用户软件授权协议	1
	License Application Instructions	1

### 3.1 申明

- 三菱电机株式会社不负责对所介绍的支持Microsoft Windows Operating System的市面销售软件产品提供保证，敬请谅解。
- 本产品软件著作权属于三菱电机株式会社所有。
- 本产品（包含手册）只能基于软件使用协议使用。
- 对于使用本产品（包含手册）后产生的一切影响，三菱电机株式会社不予负责，敬请谅解。

## 4. 卸载步骤

应通过Windows的控制面板进行卸载。

### 4.1 卸载前请确认

- 若存在正在使用CC-Link IE TSN通信库的用户程序，应在卸载前停止该程序。
- 卸载前，应将实时流程管理器与Management Shell的运行状态切换为STOP状态。

Microsoft and Windows are trademarks of the Microsoft group of companies. Intel is either registered trademarks or trademarks of Intel Corporation in the United States and/or other countries. The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies. In some cases, trademark symbols such as “™” or “®” are not specified in this manual.
---