



## FX3U Input Wiring Caution


This notice is wholly designed to explain the FX3U (DC input type) sink/source input wiring variation to users of the exclusive sink input type model.

FX3U external input wiring can be either sink method or source method. (Please refer to the following diagram.)


**It is absolutely necessary to wire the S/S terminal.**

For more details, Please refer to the "FX3U SERIES PROGRAMMABLE CONTROLLERS HARDWARE MANUAL" included with the FX3U.

- Input wiring example for AC power type (Except FX3U-□MR/UA1)



- Input wiring example for DC power type



**\* Do not connect the (0V) and (24V) terminals with others.**